deltaacdrives.com

11111

sales@deltaacdrives.com







**Power Range :** 

3-phase 230V series: 5.5kW~22kW 3-phase 460V series: 5.5kW~22kW

(7.5~30HP) (7.5~30HP)

Call 1(800)985-6929 for Sales

deltaacdrives.com

sales@deltaacdrives.com



# www.delta.com.tw/industrialautomation

# ASIA

# Delta Electronics, Inc.

Taoyuan1 31-1, Xingbang Road, Guishan Industrial Zone, Taoyuan County 33370, Taiwan, R.O.C. TEL: 886-3-362-6301 / FAX: 886-3-362-7267

# Delta Electronics (Jiang Su) Ltd.

Wujiang Plant3 1688 Jiangxing East Road, Wujiang Economy Development Zone, Wujiang City, Jiang Su Province, People's Republic of China (Post code: 215200) TEL: 86-512-6340-3008 / FAX: 86-512-6340-7290

## **Delta Electronics (Japan), Inc.** Tokyo Office

Delta Shibadaimon Building, 2-1-14 Shibadaimon, Minato-Ku, Tokyo, 105-0012, Japan TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

# Delta Electronics (Korea), Inc.

234-9, Duck Soo BD 7F, Nonhyun-dong, Kangnam-ku, Seoul, Korea Post code : 135-010 TEL: 82-2-515-5303/5 / FAX: 82-2-515-5302



Delta Electronics (Singapore) Pte. Ltd. 8 Kaki Bukit Road 2, #04-18 Ruby Warehouse Complex, Singapore 417841 TEL: 65-6747-5155 / FAX: 65-6744-9228

# Delta Energy Systems (India) Pvt. Ltd.

Plot No. 27 & 31, Sector-34, EHTP, Gurgaon-122001 Haryana, India TEL: 91-124-4169040 / FAX: 91-124-4036045

# AMERICA

# Delta Products Corporation (USA)

Raleigh Office P.O. Box 12173,5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A. TEL: 1-919-767-3813 / FAX: 1-919-767-3969

# EUROPE

Deltronics (Netherlands) B.V. Eindhoven Office De Witbogt 15, 5652 AG Eindhoven, The Netherlands TEL: 31-40-259-28-50/ FAX: 31-40-259-28-51



\*We reserve the right to change the information in this manual without prior notice

A NELTA **User Manual Elevator Drive** 

# Preface

Firmware Version 1.09

Thank you for choosing DELTA's high-performance VFD-VL Series. The VFD-VL Series is manufactured with high-quality components and materials and incorporates the latest microprocessor technology available.

This manual is to be used for the installation, parameter setting, troubleshooting, and daily maintenance of the AC motor drive. To guarantee safe operation of the equipment, read the following safety guidelines before connecting power to the AC motor drive. Keep this operating manual at hand and distribute to all users for reference.

To ensure the safety of operators and equipment, only qualified personnel familiar with AC motor drive are to do installation, start-up and maintenance. Always read this manual thoroughly before using VFD-VL series AC Motor Drive, especially the WARNING, DANGER and CAUTION notes. Failure to comply may result in personal injury and equipment damage. If you have any question, please contact your dealer.

#### PLEASE READ PRIOR TO INSTALLATION FOR SAFETY.



- 1. AC input power must be disconnected before any wiring to the AC motor drive is made.
- A charge may still remain in the DC-link capacitors with hazardous voltages, even if the power has been turned off. To prevent personal injury, please ensure that power has turned off before opening the AC motor drive and wait ten minutes for the capacitors to discharge to safe voltage levels.
- 3. Never reassemble internal components or wiring.
- 4. The AC motor drive may be destroyed beyond repair if incorrect cables are connected to the input/output terminals. Never connect the AC motor drive output terminals U/T1, V/T2, and W/T3 directly to the AC mains circuit power supply.
- Ground the VFD-VL using the ground terminal. The grounding method must comply with the laws of the country where the AC motor drive is to be installed. Refer to the Basic Wiring Diagram.
- VFD-VL series is used only to control variable speed of 3-phase induction motors, NOT for 1phase motors or other purpose.
- 7. VFD-VL series shall NOT be used for life support equipment or any life safety situation.

## Call 1(800)985-6929 the taaledrives.com

# Call 1(800)985-6929 footsaledrives.scalers@deltaacdrives.com



- DO NOT use Hi-pot test for internal components. The semi-conductor used in AC motor drive easily damage by high-voltage.
- There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. To prevent damage to these components, do not touch these components or the circuit boards with metal objects or your bare hands.
- 3. Only qualified persons are allowed to install, wire and maintain AC motor drives.



- 1. Some parameters settings can cause the motor to run immediately after applying power.
- DO NOT install the AC motor drive in a place subjected to high temperature, direct sunlight, high humidity, excessive vibration, corrosive gases or liquids, or airborne dust or metallic particles.
- Only use AC motor drives within specification. Failure to comply may result in fire, explosion or electric shock.
- 4. To prevent personal injury, please keep children and unqualified people away from the equipment.
- 5. When the motor cable between AC motor drive and motor is too long, the layer insulation of the motor may be damaged. Please use a frequency inverter duty motor or add an AC output reactor to prevent damage to the motor. Refer to appendix B Reactor for details.
- The rated voltage for AC motor drive must be ≤ 240V (≤ 480V for 460V models) and the mains supply current capacity must be ≤ 5000A RMS (≤10000A RMS for the ≥ 40hp (30kW) models)

# Table of Contents

Preface	i
Table of Contents	iii
Chapter 1 Introduction	1-1
1.1 Receiving and Inspection	
1.1.1 Nameplate Information	1-2
1.1.2 Model Explanation	
1.1.3 Series Number Explanation	1-3
1.1.4 Drive Frames and Appearances	1-3
1.1.5 Drive Features	1-5
1.2 Preparation for Installation and Wiring	
1.2.1 Ambient Conditions	1-6
1.2.2 Remove Front Cover	1-7
1.2.3 Lifting	1-8
1.2.4 Flange Mounting	1-9
1.2.5 Cutout Dimensions	
1.3 Dimensions	1-13
Chapter 2 Installation and Wiring	2-1
2.1 Wiring	2-2
2.2 External Wiring	2-7
2.3 Main Circuit	2-8

# Call 1(800)985-6929 footsalestrives.scalers@deltaacdrives.com

2.3.1 Main Circuit Connection	2-8
2.3.2 Main Circuit Terminals	2-10
2.4 Control Terminals	2-11
Chapter 3 Operation and Start Up	3-1
3.1 Operation Method	3-2
3.2 Trial Run	3-3
3.3 Auto-tuning Operations	3-4
3.3.1 Flow Chart	3-4
3.3.2 Explanations for the Auto-tuning Steps	3-5
3.3.2.1 Step 1	3-5
3.3.2.2 Step 2	3-7
3.3.2.3 Step 3	3-8
3.3.2.4 Step 4	3-12
3.3.2.5 Step 5	3-13
3.3.2.6 Step 6	3-14
3.3.2.7 Step 7	3-14
Chapter 4 Parameters	4-1
4.1 Summary of Parameter Settings	4-2
4.1.1 Group 0 System Parameters	4-2
4.1.2 Group 1 Basic Parameters	4-4
4.1.3 Group 2 Digital Input/Output Parameters	4-5
4.1.4 Group 3 Analog Input/Output Parameters	4-7
4.1.5 Group 4 Multi-Step Speed Parameters	4-9
4.1.6 Group 5 IM Parameters	4-10
4.1.7 Group 6 Protection Parameters	4-11

4.1.8 Group 7 Special Parameters	4-14
4.1.9 Group 8 PM Parameters	4-15
4.1.10 Group 9 Communication Parameters	4-16
4.1.11 Group 10 Speed Feedback Control Parameters	4-17
4.1.12 Group 11 Advanced Parameters	4-19
4.1.13 Group 12 User-defined Parameters	4-20
4.1.14 Group 13 View User-defined Parameters	4-21
4.2 Description of Parameter Settings	4-22
4.2.1 Group 0 User Parameters	4-22
4.2.2 Group 1 Basic Parameters	4-32
4.2.3 Group 2 Digital Input/Output Parameters	4-39
4.2.4 Group 3 Analog Input/Output Parameters	4-55
4.2.5 Group 4 Multi-Step Speed Parameters	4-61
4.2.6 Group 5 IM Parameters	4-62
4.2.7 Group 6 Protection Parameters	4-67
4.2.8 Group 7 Special Parameters	4-84
4.2.9 Group 8 PM Parameters	4-91
4.2.10 Group 9: Communication Parameters	4-95
4.2.11 Group 10 Speed Feedback Control Parameters	4-106
4.2.12 Group 11 Advanced Parameters	4-114
4.2.13 Group 12 User-defined Parameters	4-119
4.2.14 Group 13 View User-defined Parameters	4-127
Chapter 5 Troubleshooting	5-1
5.1 Over Current (OC)	5-1

# Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

5.2 Ground Fault		5-2
5.3 Over Voltage (OV)		5-2
5.4 Low Voltage (Lv)		5-3
5.5 Over Heat (OH)		5-4
5.6 Overload		5-4
5.7 Display of KPVL-CC	01 is Abnormal	5-5
5.8 Phase Loss (PHL)		5-5
5.9 Motor cannot Run		5-6
5.10 Motor Speed canno	t be Changed	5-7
5.11 Motor Stalls during	Acceleration	5-8
5.12 The Motor does not	Run as Expected	5-8
5.13 Electromagnetic/Inc	luction Noise	5-9
5.14 Environmental Con	dition	5-9
5.15 Affecting Other Mac	chines	5-10
Chapter 6 Fault Code Info	rmation	6-1
6.1 Fault Code Information	on	6-1
6.1.1 Common Proble	ems and Solutions	6-2
6.1.2 Reset		6-9
Appendix A Specification	S	A-1
Appendix B Accessories.		B-1
B.1 All Brake Resistors &	Brake Units Used in AC Motor Drives.	B-2
B.1.1 Dimensions and	Weights for Brake Resistors	B-5
B.1.1 Dimensions and	Weights for Brake Resistors	B-5
B.1.2 Specifications for	or Brake Unit	B-7
B.1.3 Dimensions for	Brake Unit	B-8

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

B.2 Non-fuse Circuit Breaker Chart	В-9
B.3 Fuse Specification Chart	В-9
B.4 AC Reactor	B-11
B.4.1 AC Input Reactor Recommended Value	B-11
B.4.2 AC Output Reactor Recommended Value	B-11
B.4.3 Applications for AC Reactor	B-12
B.5 Zero Phase Reactor (RF220X00A)	B-14
B.6 DC Choke Recommended Values	B-15
B.7 Digital Keypad KPVL-CC01	B-16
B.7.1 Description of the Digital Keypad KPVL-CC01	B-16
B.7.2 How to Operate the Digital Keypad KPVL-CC01	B-18
B.7.3 Dimension of the Digital Keypad	B-20
B.7.4 Recommended Position the Rubber Magnet of the Digi	
B.8 PG Card (for Encoder)	B-21
B.8.1 EMVL-PGABL	B-21
B.8.2 EMVL-PGABO	B-24
B.8.3 EMVL-PGH01 (only for Heidenhain ERN1387)	B-31
B.8.4 EMVL-PGS01	B-35
B.9 AMD-EMI Filter Cross Reference	B-38
B.10 EMVL-IOA01	B-41
B.11 Safety Relay EMVL-SAF01	B-42
B.11.1 Functions of the Terminals	B-42
B.11.2 Wiring of the Safety Relay	B-42

Appendix C How to Select the Right AC Motor Drive	C-1
C.1 Capacity Formulas	C-2
C.2 General Precaution	C-4
C.3 How to Choose a Suitable Motor	C-5
Appendix D Suggestions and Error Corrections for Standard AC I Drives	
D.1 Maintenance and Inspections	D-2
D.2 Greasy Dirt Problem	D-7
D.3 Fiber Dust Problem	D-8
D.4 Erosion Problem	D-9
D.5 Industrial Dust Problem	D-10
D.6 Wiring and Installation Problem	D-11
D.7 Multi-function Input/Output Terminals Problem	D-12

# **Chapter 1 Introduction**

The AC motor drive should be kept in the shipping carton or crate before installation. In order to retain the warranty coverage, the AC motor drive should be stored properly when it is not to be used for an extended period of time. Storage conditions are:



- 1. Store in a clean and dry location free from direct sunlight or corrosive fumes.
- 2. Store within an ambient temperature range of -20 °C to +60 °C.
- 3. Store within a relative humidity range of 0% to 90% and non-condensing environment.
- 4. Store within an air pressure range of 86 kPA to 106kPA.
- DO NOT place on the ground directly. It should be stored properly. Moreover, if the surrounding environment is humid, you should put exsiccator in the package.
- DO NOT store in an area with rapid changes in temperature. It may cause condensation and frost.
- If the AC motor drive is stored for more than 3 months, the temperature should not be higher than 30 °C. Storage longer than one year is not recommended, it could result in the degradation of the electrolytic capacitors.
- When the AC motor drive is not used for longer time after installation on building sites or places with humidity and dust, it's best to move the AC motor drive to an environment as stated above.

The VFD-VL is able to control Induction Motors (IM) and Permanent Magnet Motors (PM). In the manual throughout the abbreviations IM and PM are used.

Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

Chapter 1 Introduction | VFD-VL


# 1.1 Receiving and Inspection

This VFD-VLAC motor drive has gone through rigorous quality control tests at the factory before shipment. After receiving the AC motor drive, please check for the following:


- Check to make sure that the package includes an AC motor drive, the User Manual/Quick Start and CD.
- Inspect the unit to assure it was not damaged during shipment.
- Make sure that the part number indicated on the nameplate corresponds with the part number of your order.

#### 1.1.1 Nameplate Information

Example for 15HP/11kW 230V 3-Phase AC motor drive




## 1.1.2 Model Explanation



Call 1(800)985-6929 the talestrives.com

Chapter 1 Introduction | VFD-VL



If the nameplate information does not correspond to your purchase order or if there are any problems, please contact your distributor.

## 1.1.4 Drive Frames and Appearances



Call 1(800)985-6929 the talestrives.com

Chapter 1 Introduction | VFD-VL

#### 40-100HP/30-75kW(Frame E)



Frame	Power range	Models			
С	7.5-15HP (5.5-11kW)	VFD055VL23A/43A, VFD075VL23A/43A, VFD110VL23A/43A			
D	20-30HP (15-22kW)	20-30HP (15-22kW) VFD150VL23A/43A, VFD185VL23A/43A, VFD220VL23A/43A			
E (E1)	40-60hp (30-45kW)	VFD300VL43A, VFD370VL43A, VFD450V43A			
E (E2)	40-100hp (30-75kW)	VFD300VL23A, VFD370VL23A, VFD550VL43A, VFD750VL43A			

Please refer to Chapter 1.3 for exact dimensions.

Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

#### Chapter 1 Introduction | VFD-VL

# 1.1.5 Drive Features

#### **Communication Port**



Call 1(800)985-6929 food latestrives.sales@deltaacdrives.com

Chapter 1 Introduction | VFD-VL


# 1.2 Preparation for Installation and Wiring

## **1.2.1 Ambient Conditions**

Install the AC motor drive in an environment with the following conditions:

	Air Temperature:	-10 ~ +45°C (14 ~ 113°F)				
	Relative Humidity:	<90%, no condensation allowed				
Operation	Atmosphere pressure:	86 ~ 106 kPa				
	Installation Site Altitude:	<1000m				
	Vibration:	<20Hz: 9.80 m/s <sup>2</sup> (1G) max 20 ~ 50Hz: 5.88 m/s <sup>2</sup> (0.6G) max				
	Temperature:	-20°C ~ +60°C (-4°F ~ 140°F)				
Storage	Relative Humidity:	<90%, no condensation allowed				
Transportation		86 ~ 106 kPa				
Iransportation	Atmosphere pressure:	86 ~ 106 kPa				
Iransportation		86 ~ 106 kPa <20Hz: 9.80 m/s <sup>2</sup> (1G) max 20 ~ 50Hz: 5.88 m/s <sup>2</sup> (0.6G) max				

#### Minimum Mounting Clearances



HP	W mm (inch)	H mm (inch)
7.5-20HP	75 (3)	175 (7)
25-75HP	75 (3)	200 (8)
100HP	75 (3)	250 (10)

Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

# 

- Operating, storing or transporting the AC motor drive outside these conditions may cause damage to the AC motor drive.
- 2. Failure to observe these precautions may void the warranty!
- Mount the AC motor drive vertically on a flat vertical surface object by screws. Other directions are not allowed.
- The AC motor drive will generate heat during operation. Allow sufficient space around the unit for heat dissipation.
- 5. The heat sink temperature may rise to 90°C when running. The material on which the AC motor drive is mounted must be noncombustible and be able to withstand this high temperature.
- 6. When AC motor drive is installed in a confined space (e.g. cabinet), the surrounding temperature must be within 10 ~ 40°C with good ventilation. DO NOT install the AC motor drive in a space with bad ventilation.
- Prevent fiber particles, scraps of paper, saw dust, metal particles, etc. from adhering to the heatsink.
- 8. When installing multiple AC more drives in the same cabinet, they should be adjacent in a row with enough space in-between. When installing one AC motor drive below another one, use a metal separation between the AC motor drives to prevent mutual heating.

# 1.2.2 Remove Front Cover

#### 7.5-15HP/5.5-11kW(frame C) & 20-30HP/15-22kW(frame D)

After removing the screws, please push the front cover to open it. For the open cover direction, please refer to the following picture.



Call 1(800)985-6929 the tales rives.com

Chapter 1 Introduction | VFD-VL


#### 40-100HP/30-75kW (frame E)

After removing the screws, please push the front cover to open it. For the open cover direction, please refer to the following picture.




#### 1.2.3 Lifting

Please carry only fully assembled AC motor drives as shown in the following.




Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

Chapter 1 Introduction | VFD-VL



## 1.2.4 Flange Mounting

Step 1: Please take out the 16 screws (8 screws for each top and bottom side of the drive) and remove the fixed plate 1 and fixed plate 2) as shown in the following figures.



#### Chapter 1 Introduction | VFD-VL


Step 2: place the 8 screws back in to secure the fixed plate 1 and fixed plate 2 (as shown in the following figures) with the following torque.

Frame C: 14-17kgf-cm [12.2-14.8in-lbf]

Frame D: 20-25kgf-cm [17.4-21.7in-lbf] Frame E: 20-25kgf-cm [17.4-21.7in-lbf]

fixed plate 1 4 fixed plate 2 4

Step 3: Please notice that it doesn't need to put those 8 screws shown in the following figures back to the drive. Moreover, please make sure that these 2 different fixed plates are put in the correct side as shown in the figures.




Chapter 1 Introduction | VFD-VL

# 7.5-15HP/5.5-11kW (frame C) 238.0 [9.37] M6\*P1.0(4X) 204.0 [8.03] DR Ø6.5[Ø0.26](4X) 175.0 [6.89] 5.0 [0.20] 325.0 [12.80] 337.0 [13.27] $\odot$ 6.0 [0.23]

# **1.2.5 Cutout Dimensions**

Call 1(800)985-6929 food the tales trives sealers @deltaacdrives.com

Chapter 1 Introduction | VFD-VL



Call 1(800)985-6929 the tales rives.com

Chapter 1 Introduction | VFD-VL

Ø3


22

[0.87]

[1.34]

# **1.3 Dimensions**







С

[9.25]

[8.03]

Frame C: VFD055VL23A/43A, VFD075VL23A/43A, VFD110VL23A/43A

[13.78] [13.27] [12.60]

-


[5.35]

[0.26]

Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

Chapter 1 Introduction | VFD-VL

Frame D




Frame	w	W1	н	H1	H2	H3	D	ø	Ø1	Ø2	Ø3
D	255.0 [10.04]	226.0 [8.90]	403.8 [15.90]	384.0 [15.12]	360.0 [14.17]	21.9 [0.86]	168.0 [6.61]	8.5 [0.33]	44 [1.73]	34 [1.34]	22 [0.87]



Frame D: VFD150VL23A/43A, VFD185VL23A/43A, VFD220VL23A/43A

Call 1(800)985-6929 fbertaaleetrives.salers@deltaacdrives.com

Chapter 1 Introduction | VFD-VL



Unit: mm [inch]

Frame	w	W1	н	H1	H2	D	D1	D2	S1	S2	S3
E1	370.0 [14.57]	335.0 [13.19]	-	589.0 [23.19]	560.0 [22.05]	260.0 [10.24]			13.0 [0.51]		18.0 [0.71]
E2	370.0 [14.57]	335.0 [13.19]		589.0 [23.19]	560.0 [22.05]	260.0 [10.24]			13.0 [0.51]		18.0 [0.71]

# 

Frame E1: VFD300VL43A, VFD370VL43A, VFD450VL43A Frame E2: VFD300VL23A, VFD370VL23A, VFD550VL43A, VFD750VL43A

Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

# Call 1(800)985-6929 for the tales rives.com

Chapter 1 Introduction | VFD-VL

This page intentionally left blank

Call 1(800)985-6929 fbertaaleetrives.salers@deltaacdrives.com

# Chapter 2 Installation and Wiring

After removing the front cover (see chapter 1.2.2 for details), check if the power and control terminals are clear. Be sure to observe the following precautions when wiring.



- Make sure that power is only applied to the R/L1, S/L2, T/L3 terminals. Failure to comply may
  result in damage to the equipment. The voltage and current should lie within the range as
  indicated on the nameplate.
- 2. Check the following items after finishing the wiring:
  - A. Are all connections correct?
  - B. No loose wires?
  - C. No short-circuits between terminals or to ground?



- A charge may still remain in the DC bus capacitors with hazardous voltages even if the power has been turned off. To prevent personal injury, please ensure that the power is turned off and wait ten minutes for the capacitors to discharge to safe voltage levels before opening the AC motor drive.
- All the units must be grounded directly to a common ground terminal to prevent lightning strike or electric shock.
- Only qualified personnel familiar with AC motor drives is allowed to perform installation, wiring and commissioning.
- 4. Make sure that the power is off before doing any wiring to prevent electric shock.


Call 1(800)985-6929 food the tales rives.set model tale of the set of the set

## Call 1(800)985-6929 the taaledrives.com

Chapter 2 Installation and Wiring | VFD-VL


## 2.1 Wiring

Users must connect wires according to the circuit diagrams on the following pages. Do not plug a modem or telephone line to the RS-485 communication port, permanent damage may result. Pins 1 & 2 are the power supply for the optional copy keypad only and should not be used for RS-485 communication.




Call 1(800)985-6929 the tales rives. sales @deltaacdrives.com

#### Chapter 2 Installation and Wiring | VFD-VL




#### Figure 3 Apply to 1-phase UPS power supply system



Call 1(800)985-6929 ther taaledrives.scalers@deltaacdrives.com

#### Chapter 2 Installation and Wiring | VFD-VL

#### Figure 4 Apply to two batteries with main battery voltage is lower than 280Vdc



Notes for the emergency power supply. Please be aware of the following condition when emergency power is ON:

- 1. Fan doesn't run
- 2. Parameter setting will not be saved, when the power is turned off and applies again, the parameter setting will be gone.
- 3. Operate by the speed set in Pr.06-48.
- 4. No protections for low voltage and phase loss
- 5. Display DC-BUS voltage by Pr.06-29


Call 1(800)985-6929 the tale drives. sales @deltaacdrives.com

# Call 1(800)985-6929 for the tales rives.com

Chapter 2 Installation and Wiring | VFD-VL




- 1. The wiring of main circuit and control circuit should be separated to prevent erroneous actions.
- Please use shield wire for the control wiring and not to expose the peeled-off net in front of the terminal.
- Please use the shield wire or tube for the power wiring and ground the two ends of the shield wire or tube.
- 4. Damaged insulation of wiring may cause personal injury or damage to circuits/equipment if it comes in contact with high voltage.
- The AC motor drive, motor and wiring may cause interference. To prevent the equipment damage, please take care of the erroneous actions of the surrounding sensors and the equipment.
- When the AC drive output terminals U/T1, V/T2, and W/T3 are connected to the motor terminals U/T1, V/T2, and W/T3, respectively. To permanently reverse the direction of motor rotation, switch over any of the two motor leads.
- With long motor cables, high capacitive switching current peaks can cause over-current, high leakage current or lower current readout accuracy. For longer motor cables use an AC output reactor.
- The AC motor drive, electric welding machine and the greater horsepower motor should be grounded separately.
- 9. Use ground leads that comply with local regulations and keep them as short as possible.
- 10. No brake resistor is built in the VFD-VL series, it can install brake resistor for those occasions that use higher load inertia or frequent start/stop. Refer to Appendix B for details.
- Multiple VFD-VL units can be installed in one location. All the units should be grounded directly to a common ground terminal, as shown in the figure below. Ensure there are no ground loops.



Call 1(800)985-6929 the tales rives.com

Call 1(800)985-6929 fbertaaledrives.salers@deltaacdrives.com

Chapter 2 Installation and Wiring | VFD-VL



Call 1(800)985-6929 (the tales rives.sales@deltaacdrives.com

#### Chapter 2 Installation and Wiring | VFD-VL

# 2.2 External Wiring


Power Sup	oply	Items	Explanations
		Power supply	Please follow the specific power supply requirements shown in Appendix A.
	O FUSE/NFB	Fuse/NFB (Optional)	There may be an inrush current during power up. Please check the chart of Appendix B and select the correct fuse with rated current. Use of an NFB is optional.
$\pm$ $\pm$	Magnetic contactor	Magnetic contactor (Optional)	Please do not use a Magnetic contactor as the I/O switch of the AC motor drive, as it will reduce the operating life cycle of the AC drive.
EMIFilte	Input AC Line Reactor Zero-phase Reactor	Input AC Line Reactor (Optional)	Used to improve the input power factor, to reduce harmonics and provide protection from AC line disturbances <sub>₹</sub> (surges, switching spikes, short interruptions, etc.). AC line reactor should be installed when the power supply capacity is 500kVA or more and exceeds 6 times the inverter capacity, or the mains wiring distance ≤ 10m.
R/L1 S/L2		Zero-phase Reactor (Ferrite Core Common Choke) (Optional)	Zero phase reactors are used to reduce radio noise especially when audio equipment is installed near the inverter. Effective for noise reduction on both the input and output sides. Attenuation quality is good for a wide range from AM band to 10MHz. Appendix B specifies the zero phase reactor. (RF220X00A)
	Zero-phase Reactor	EMI filter (Optional)	To reduce electromagnetic interference, please refer to Appendix B for more details.
	Output AC Line Reactor	Brake Resistor (Optional)	Used to reduce the deceleration time of the motor. Please refer to the chart in Appendix B for specific Brake Resistors.
Motor	$\sum$	Output AC Line Reactor (Optional)	Motor surge voltage amplitude depends on motor cable length. For applications with long motor cable (>20m), it is necessary to install a reactor at the inverter output side.

Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

Chapter 2 Installation and Wiring | VFD-VL

## 2.3 Main Circuit

## 2.3.1 Main Circuit Connection



Terminal Symbol	Explanation of Terminal Function
EPS (+, -)	For emergency power or backup power supply
R/L1, S/L2, T/L3	AC line input terminals
U/T1, V/T2, W/T3	AC drive output terminals for connecting 3-phase induction motor
+1, +2/B1	Connections for DC Choke (optional). Please remove jumper when installation. (It is built in DC choke for models 22kW and above)
+2/B1, B2	Connections for Brake Resistor (optional)
(±	Earth connection, please comply with local regulations.

#### Mains power terminals (R/L1, S/L2, T/L3)

- Connect these terminals (R/L1, S/L2, T/L3) via a non-fuse breaker or earth leakage breaker to 3-phase AC power (some models to 1-phase AC power) for circuit protection. It is unnecessary to consider phase-sequence.
- It is recommended to add a magnetic contactor (MC) in the power input wiring to cut off power quickly and reduce malfunction when activating the protection function of AC motor drives. Both ends of the MC should have an R-C surge absorber.
- Please make sure to fasten the screw of the main circuit terminals to prevent sparks which is made by the loose screws due to vibration.
- Please use voltage and current within the regulation shown in Appendix A.
- When using a general GFCI (Ground Fault Circuit Interrupter), select a current sensor with sensitivity of 200mA or above, and not less than 0.1-second operation

Call 1(800)985-6929 thertSalectrives.scales@deltaacdrives.com

# Call 1(800)985-6929 the talestrives.com

#### Chapter 2 Installation and Wiring | VFD-VL


time to avoid nuisance tripping. For the specific GFCI of the AC motor drive, please select a current sensor with sensitivity of 30mA or above.

- Do NOT run/stop AC motor drives by turning the power ON/OFF. Run/stop AC motor drives by RUN/STOP command via control terminals or keypad. If you still need to run/stop AC drives by turning power ON/OFF, it is recommended to do so only ONCE per hour.
- Do NOT connect 3-phase models to a 1-phase power source.

#### Output terminals for main circuit (U, V, W)

- When it needs to install the filter at the output side of terminals U/T1, V/T2, W/T3 on the AC motor drive. Please use inductance filter. Do not use phase-compensation capacitors or L-C (Inductance-Capacitance) or R-C (Resistance-Capacitance), unless approved by Delta.
- DO NOT connect phase-compensation capacitors or surge absorbers at the output terminals of AC motor drives.
- Use well-insulated motor, suitable for inverter operation.

Terminals [+1, +2] for connecting DC reactor, terminals [+1, +2/B1] for connecting brake resistor



- To improve power factor and reduce harmonics connect a DC reactor between terminals [+1, +2/B1]. Please remove the jumper before connecting the DC reactor.
- Models above 22kW don't have a built-in brake chopper. Please connect an external optional brake resistor.
- When not used, please leave the terminals [+2/B1, -] open.
- Short-circuiting [B2] or [-] to [+2/B1] can damage the AC motor drive.


Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

Call 1(800)985-6929 the tales rives.com

Chapter 2 Installation and Wiring | VFD-VL

### 2.3.2 Main Circuit Terminals

Main circuit term	ninals	0	
R/L1, S/L2, T/L3	, U/T1, V/T2, W/T	3, 🗐, +1, +	2/B1, -, B2
Models	Wire	Torque	Wire Type
VFD055VL23A	10-6 AWG. (5.3-		
VFD110VL43A	13.3mm2)	30kgf-cm (26in-lbf)	Stranded copper only, 75°C
VFD055VL43A	12-6 AWG.		
VFD075VL43A	(3.3-13.3mm <sup>2</sup> )		
	8-6 AWG.		
VFD075VL23A	(8.4-13.3mm <sup>2</sup> )		
VFD110VL23A	6 AWG. (13.3mm <sup>2</sup> )		
	R/L1, S/L2, T/L3 Models VFD055VL23A VFD110VL43A VFD055VL43A VFD075VL43A VFD075VL23A	Models         Wire           VFD055VL23A         10-6 AWG. (5.3- 13.3mm2)           VFD110VL43A         12-6 AWG. (3.3-13.3mm²)           VFD075VL43A         12-6 AWG. (3.3-13.3mm²)           VFD075VL23A         8-6 AWG. (8.4-13.3mm²)           VFD075VL23A         6 AWG.	Models     Wire     Torque       VFD055VL23A     10-6 AWG. (5.3- 13.3mm2)     30kgf-cm (26in-lbf)       VFD075VL43A     12-6 AWG. (3.3-13.3mm²)     30kgf-cm (26in-lbf)       VFD075VL23A     8-6 AWG. (8.4-13.3mm²)     30kgf-cm



Main circuit terminals

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, 🕒, +1, +2, -

Models	Wire	Torque	Wire Type
VFD150VL43A	8-2 AWG.		
VFD185VL43A	(8.4-33.6mm <sup>2</sup> )		
VFD150VL23A	4-2 AWG. (21.1-33.6mm <sup>2</sup> )		01
VFD185VL23A	3-2 AWG. (26.7-33.6mm <sup>2</sup> )	50Kgf-cm (43.4 lbf-in)	Stranded copper only, 75 °C
VFD220VL43A	6-2 AWG (13.3-33.6mm <sup>2</sup> )		
VFD220VL23A	3-2 AWG (26.7-33.6mm <sup>2</sup> )		


Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

# Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

0 " 0 T " 0 L T


#### Chapter 2 Installation and Wiring | VFD-VL

(<u>1</u>)



Models	Wire	Torque	Wire Type
VFD300VL43A			
VFD370VL43A		57kgf-cm (49in-lbf)	
VFD450VL43A	4-2 AWG. (21.2-33.6mm2)	(101)	Stranded
VFD300VL23A			copper only, 75 °C
VFD370VL23A		200kgf-cm	75 0
VFD550VL43A		(173in-lbf)	
VFD750VL43A			

# 2.4 Control Terminals



Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

# Call 1(800)985-6929 foot Sales ives.com

### Chapter 2 Installation and Wiring | VFD-VL

Terminal symbols and functions

Terminal Symbol	Terminal Function	Factory Settings (SINK) ON: Connect to DCM	
- Cymbol			
FWD	Forward-Stop Command	ON: RUN in FWD direction	
		OFF: Stop acc. to Stop Method	
REV	Reverse-Stop Command	ON: RUN in REV direction	
		OFF: Stop acc. to Stop Method	
MI1	Multi-function Input 1		
MI2	Multi-function Input 2		
MI3	Multi-function Input 3	Refer to Pr.02-01 to Pr.02-08 for programming the Multi-function Inputs.	
MI4	Multi-function Input 4	ON: input voltage is 24Vdc (Max. 30Vdc), input impedance is $3.75 k\Omega$	
MI5	Multi-function Input 5	OFF: leakage current tolerance is 10µA.	
MI6	Multi-function Input 6	MI8: when JP1 is inserted, this function is disabled.	
MI7	Multi-function Input 7		
MI8	Multi-function Input 8		
СОМ	Digital Signal Common	Common for digital inputs and used for SINK mode	
+E24V	Digital Signal Common (Source)	+24V 80mA	
DCM	Digital Signal Common (Sink)	Common for digital inputs and used for SINK mode	
RA	Multi-function Relay Output 1 (N.O.) a	Resistive Load:	
RB	Multi-function Relay Output 1 (N.C.) b	5A(N.O.)/3A(N.C.) 240VAC 5A(N.O.)/3A(N.C.) 24VDC	
RC	Multi-function Relay Common	Inductive Load: 1.5A(N.O.)/0.5A(N.C.) 240VAC	
MRA	Multi-function Relay Output 2 (N.O.) a	1.5A(N.O.)/0.5A(N.C.) 24VDC To output monitor signal, including in operation, frequency arrival, overload and etc.	
MRC	Multi-function Relay Common	Refer to Pr.02-11~02-12 for programming	
+10V			
-10V	Potentiometer Power Supply	-10~+10VDC 20mA (variable resistor 3-5kohm)	
МСМ	Multi-function Output Common (Photocoupler)	Max. 48VDC 50mA	

Call 1(800)985-6929 food the tales by sealing a construction of the sealing and the sealing a construction of the sealing a construction of the sealing and the sealing a construction of the sealing a construction of

### Call 1(800)985-6929 food latestrives.sales@deltaacdrives.com

#### Chapter 2 Installation and Wiring | VFD-VL

Terminal Symbol	Terminal Function	Factory Settings (SINK) ON: Connect to DCM	
MO1	Multi-function Output 1 (Photocoupler)	The AC motor drive output every monitor signal, such as operational, frequency attained, overload, etc. by open collector transistor. Refer to Pr.03.01 multi-function output terminals for	
MO2	Multi-function Output 2 (Photocoupler)	details.	
ACI	Analog current Input	Impedance: $250\Omega$ Resolution:12 bitsRange:4 ~ $20mA/0~10V =$ 0 ~ Max. Output Frequency (Pr.01-00)Set-up:Pr.03-00 ~ Pr.03-02	
AUI1/ AUI2	Auxiliary analog voltage input	Impedance: $2m\Omega$ Resolution:12 bitsRange: $-10 \sim +10VDC =$ $0 \sim Max.$ Output Frequency (Pr.01-00)Set-up:Pr.03-00 ~ Pr.03-02	
ACM	Analog control signal (common)	Common for ACI, AUI1, AUI2	

\*Control signal wiring size: 18 AWG (0.75 mm<sup>2</sup>) with shielded wire.

### Analog input terminals (ACI, AUI1, AUI2, ACM)


Analog input signals are easily affected by external noise. Use shielded wiring and keep it as short as possible (<20m) with proper grounding. If the noise is inductive, connecting the shield to terminal ACM can bring improvement.</p>

### Call 1(800)985-6929 ther tales by seven we have a seven we hav

### Call 1(800)985-6929 food the tales by sealing a construction of the sealing and the sealing a construction of the sealing a construction of the sealing and the sealing a construction of the sealing a construction of

#### Chapter 2 Installation and Wiring | VFD-VL

If the analog input signals are affected by noise from the AC motor drive, please connect a capacitor and ferrite core as indicated in the following diagrams:




wind each wires 3 times or more around the core

#### Digital inputs (FWD, REV, MI1~MI8, COM)

When using contacts or switches to control the digital inputs, please use high quality components to avoid contact bounce.

#### Digital outputs (MO1, MO2, MCM)

- Make sure to connect the digital outputs to the right polarity, see wiring diagrams.
- When connecting a relay to the digital outputs, connect a surge absorber or fly-back diode across the coil and check the polarity.



Frame	Torque		Wire
C, D, E	8 kgf-cm (6.9 in-lbf)		22-14 AWG (0.3-2.1mm <sup>2</sup> )
C, D, E	Terminal: 0V/24V	1.6 kgf-com(1.4 in-lbf)	30-16 AWG (0.051-1.3mm <sup>2</sup> )

# 

Frame C: VFD055VL23A/43A, VFD075VL23A/43A, VFD110VL23A/43A

Frame D: VFD150VL23A/43A, VFD185VL23A/43A, VFD220VL23A/43A

Frame E: VFD300VL23A/43A, VFD370VL23A/43A, VFD450VL43A, VFD550VL43A, VFD750VL43A

Call 1(800)985-6929 ther tales by seven we have a seven we hav

# Chapter 3 Operation and Start Up

CAUTION	<ul> <li>Make sure that the wiring is correct. In particular, check that the output terminals U/T1, V/T2, W/T3 are NOT connected to power and that the drive is well grounded.</li> <li>Verify that no other equipment is connected to the AC motor</li> <li>Do NOT operate the AC motor drive with humid hands.</li> <li>Verify that there are no short-circuits between terminals and from terminals to ground or mains power.</li> <li>Check for loose terminals, connectors or screws.</li> </ul>
	<ul> <li>Make sure that the front cover is well installed before applying power.</li> </ul>
WARNING	Please do NOT touch output terminals U, V, W when power is still applied to L1/R, L2/S, L3/T even when the AC motor drive has stopped. The DC-link capacitors may still be charged to hazardous voltage levels, even if the power has been turned off.

#### Chapter 3 Operation and Start Up | VFD-VL

### 3.1 Operation Method

The factory setting for operation method is set to control terminal. But it is just one of the operation methods. The operation method can be via communication, control terminals settings or optional digital keypad KPVL-CC01. Please choose a suitable method depending on application and operation rule. The operation is usually used as shown in the following table.

Operation Method	Frequency Source	Operation Command Source
Operate from communication	Please refer to the communication addres in the communication address definition.	ss 2000H and 2119H settings
Control Terminals- Operate from external signal	Factory setting: SINK Mode * Factory Factory Factory Factory Factory Factory Factory Setting * Don't apply the mains voltage directly to above terminals. (*1) When JP1 ICO on the control board is inserted, M	COM CE (=) +10V AU11/AU12 Master Frequency +10 to 10V Powersupply-10V 20mA CE (=) ACI ACM
KPVL-CC01 keypad (Optional)		
	UP/DOWN key	RUN, STOP/RESET key

Call 1(800)985-6929 foortSalestrives.salers@deltaacdrives.com

# Call 1(800)985-6929 for the tales rives.com

#### Chapter 3 Operation and Start Up | VFD-VL

### 3.2 Trial Run

The factory setting of operation source is from external terminals.

- Please connect a switch for both external terminals FWD-COM and REV-COM. When Pr02-08=40 (default) enable the drive by activating MI8
- Please connect a potentiometer among AUI1/AUI2, +10V, -10V and ACM or apply power –10 ~+10Vdc to AUI1/AUI2-ACM.
- 3. Setting the potentiometer or -10~+10Vdc power to less than 1V.
- Make sure that all external terminal wirings are finished before applying power. After applying power, verify that LED "READY" is ON.
- Setting FWD-COM=ON for forward running. And if you want to change to reverse running direction, you should set REV-COM=ON. And if you want to decelerate to stop, please set FWD/REV-COM=OFF.
- 6. Check following items:
  - Check if the motor direction of rotation is correct.
  - Check if the motor runs steadily without abnormal noise and vibration.
  - Check if acceleration and deceleration are smooth.

If the results of trial run are normal, please start the formal run.


Call 1(800)985-6929 for talestrives.com

Call 1(800)985-6929 the taaledrives.com

Chapter 3 Operation and Start Up | VFD-VL

### 3.3 Auto-tuning Operations

### 3.3.1 Flow Chart



3-4

Call 1(800)985-6929 the tales rives. sales @deltaacdrives.com

### 3.3.2 Explanations for the Auto-tuning Steps

### 3.3.2.1 Step 1

Basic parameters settings

- Make sure that Pr.00-00 (identity code of the AC motor drive) corresponds with the nameplate indicated on the AC motor drive.
- Make sure that all parameters are reset to factory setting (Pr.00-02 is set to 9 or 10).

Pr.00-02	0: No function	
Parameter Reset	1: Read only	
	8: Keypad lock	
	9: All parameters are reset to factory settings (50Hz, 220V/380V)	
	10: All parameters are reset to factory settings (60Hz, 220V/440V)	
Source of the Master Frequency Command: users can set by themselves (Pr.00-14)		

	Pr.00-14 Source of the Master Frequency Command	1: RS-485 serial communication or digital keypad (KPVL-CC01) 2: External analog input (Pr. 03-00) 3: Digital terminals input
1	Source of the Operation	on Command: users can set by themselves (Pr.00-15)

Pr.00-15	1: External terminals
Source of the Operation Command	2: RS-485 serial communication or digital keypad (KPVL-CC01)

MI/MO external terminals settings:

Refer to Pr.02-01~02-08 for setting the external input terminals MI1~MI8.

NOTE: The factory setting of Pr.02-08 is 40 (Enable drive function). Please disable this function if you don't need to use this function.

Settings of Pr.02- 01~02-08	0: no function
01~02-08	1: multi-step speed command 1
	2: multi-step speed command 2
	3: multi-step speed command 3
	4: multi-step speed command 4
	5: Reset
	6: JOG command
	7: acceleration/deceleration speed inhibit
	8: the 1st, 2nd acceleration/deceleration time selection
	9: the 3rd, 4th acceleration/deceleration time selection
	10: EF input (07-28)
	11: Reserved
	12: Stop output
	13: Reserved

Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

### Call 1(800)985-6929 the tales rives scales @deltaacdrives.com

#### Chapter 3 Operation and Start Up | VFD-VL

	ration speed command form AUI1
15: ope	•
16: ope	ration speed command form ACI
17: ope	ration speed command form AUI2
18: Eme	ergency Stop (07-28)
19-23: F	Reserved
24: FW	D JOG command
25: RE\	/ JOG command
26: Res	erved
27: ASF	R1/ASR2 selection
28: Eme	ergency stop (EF1) (Motor coasts to stop)
29-30: F	Reserved
31: High	n torque bias (by Pr.07-21)
32: Mid	dle torque bias (by Pr.07-22)
33: Low	torque bias (by Pr.07-23)
34-37: F	Reserved
38: Disa	able write EEPROM function
39: Torc	ue command direction
40: Ena	ble drive function
41: Det	ection for magnetic contactor
42: Mec	chanical brake
43: EPS	S function

Refer to Pr.02-13~02-22 for setting external output terminals MO1~MO10.

Settings of Pr.02- 13~02-22	0: No function 1: Operation indication 2: Operation speed attained 3: Desired frequency attained 1 (Pr.02-25) 4: Desired frequency attained 2 (Pr.02-27) 5: Zero speed (frequency command) 6: Zero speed with stop (frequency command) 7: Over torque (OT1) (Pr.06-05~06-07) 8: Over torque (OT2) (Pr.06-08~06-10) 9: Drive ready
	10: User-defined Low-voltage Detection (LV) 11: Malfunction indication
	12: Mechanical brake release (Pr.02-29, Pr.02-30)
	13: Overheat (Pr.06-14)
	14: Brake chopper signal
	15: Motor-controlled magnetic contactor output
	16: Slip error (oSL)
	17: Malfunction indication 1

Call 1(800)985-6929 fberltaaleetrives.scalers@deltaacdrives.com

### Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

#### Chapter 3 Operation and Start Up | VFD-VL

Settings of Pr.02-	18: Reserved
13~02-22	19: Brake chopper output error
	20: Warning output
	21: Over voltage warning
	22: Over-current stall prevention warning
	23: Over-voltage stall prevention warning
	24: Operation mode indication (Pr.00-15 $\neq$ 0)
	25: Forward command
	26: Reverse command
	27: Output when current >= Pr.02-33
	28: Output when current < Pr.02-33
	29: Output when frequency >= Pr.02-34
	30: Output when frequency < Pr.02-34
	31-32: Reserved
	33: Zero speed (actual output frequency)
	34: Zero speed with Stop (actual output frequency)
	35: Error output selection 1 (Pr.06-22)
	36: Error output selection 2 (Pr.06-23)
	37: Error output selection 3 (Pr.06-24)
	38: Error output selection 4 (Pr.06-25)
	39: Reserved
	40: Speed attained (including zero speed)
	41: Reserved

### 3.3.2.2 Step 2

Encoder settings

Selection of speed feedback cards

Please refer to appendix B.8 for details. Delta provides 4 PG cards for user to select by their application, including EMVL-PGABL, EMVL-PGABO, EMVL-PGH01 and EMVL-PGS01.

Pr.10-00 PG signal type	0: No function 1: ABZ 2: ABZ+Hall 3: SIN/COS+Sinusoidal 4: SIN/COS+Endat 5: SIN/COS 6: SIN/COS + Hiperface
----------------------------	--

Encoder settings: Pr.10-01~Pr.10-02

Detection for the magnetic pole position of motor

The detection method will be different by the setting of Pr.10-00 PG Signal Type.

The detection methods: (refer to Pr.10-00)

### Call 1(800)985-6929 for the tales rives.com

### Call 1(800)985-6929 the tales rives scales @deltaacdrives.com

#### Chapter 3 Operation and Start Up | VFD-VL

- Setting 1 or 5: The AC motor drive will output short circuit to detect the position of the magnetic pole. At this moment, the motor will generate a little noise.
- Setting 2: The AC motor drive will detect the position of the magnetic pole by the UVW signal of PG.
- Setting 3: The AC motor drive will detect the position of the magnetic pole by the sine signal of PG.
- Setting 4: The AC motor drive will detect the position of the magnetic pole by the communication signal of PG.

Reference table for tuning

Setting of PG signal type	PG signal type	Applicable PG card	Pr.08-00=1	Pr.08-00=3
10-00=1	A, B, Z	EMVL-PGABO/ABL	Motor will run	Motor will run
10-00=2	A, B, Z+U, V, W	EMVL-PGABL	Motor will run	Motor will run
10-00=3	SIN/COS+ Sinusoidal	EMVL-PGH01/02	Motor will run	Motor will run
10-00=4	SIN/COS+Endat	EMVL-PGS01	Motor will run	Motor won't run
10-00=5	SIN/COS	EMVL-PGH01/02	Motor will run	Motor will run
10-00=6	SIN/COS + Hiperface	EMVL-PGS01	Motor will run	Motor won't run

Pr.10-01 Encoder Pulse	1~25000

Pr.10-02 Encoder Input Type Setting	0: Disable 1: Phase A leads in a forward run command and phase B leads in a reverse run command 2: Phase B leads in a forward run command and phase A leads in a reverse run command 3: Phase A is a pulse input and phase B is a direction input. (low input=reverse direction, high input=forward direction) 4: Phase A is a pulse input and phase B is a direction input. (low input=forward direction, high
	input=reverse direction) 5: Single-phase input

### 3.3.2.3 Step 3

Motor tuning

Call 1(800)985-6929 fbertaaleetrives.salers@deltaacdrives.com

# Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

#### Chapter 3 Operation and Start Up | VFD-VL

- Setting the parameters according to the motor type (PM or IM)
- Motor Auto-tuning: When the Source of the Operation Command is set to digital keypad (Pr.00-15=2, refer to step 1)
- Control method: Please set Pr.00-09 to 8.

Pr.00-09	0: V/f Control
Control Method	1: V/f Control + Encoder (VFPG)
	2: Sensorless vector control (SVC)
	3: FOC vector control + Encoder (FOCPG)
	4: Torque control + Encoder (TQCPG)
	8: FOC PM control (FOCPM)

- NOTE: Setting parameter by the motor type (PM or IM).
- Inputting the nameplate information on the motor into Pr.01-00~01-02

Pr.01-00	10.00~120.00Hz
Maximum Output Frequency	

Pr.01-01 1st Output Frequency Setting 1	0.00~120.00Hz
(base frequency/motor rated frequency)	

Pr.01-02 1st Output Voltage Setting 1 (base voltage/motor rated voltage)	230V: 0.1V~255.0V 460V: 0.1V~510.0V
---	--

IM

Motor Auto-tuning: When the Source of the Operation Command is set to digital

keypad (Pr.00-15=2, refer to step 1) and setting Pr.05-00=2

Pr.05-00	0: No function
Motor Auto tuning	1: Rolling test (Rs, Rr, Lm, Lx, no-load current)
	2: Static Test

NOTE 1: It doesn't need to release the brake in this auto tuning operation. Please make sure that the electromagnetic valve is ON when it is used between the AC motor drive and motor. When Pr.05-00 is set to 2, no-load current of motor must be entered into Pr.05-05. The warning message "Auto tuning" will be displayed on the digital keypad during tuning until it is finished. Then, the measure result will be saved into Pr.05-06-Pr.05-09.

NOTE 2: It needs to finish motor auto tuning before measuring the angle between magnetic pole and PG origin.

Pr.05-01 Full-load Current of Motor	(40~120%)*00-01 Amps
--	----------------------

Call 1(800)985-6929 the tales trives scales @deltaacdrives.com

### Call 1(800)985-6929 foortaaleetrives.scalers@deltaacdrives.com

#### Chapter 3 Operation and Start Up | VFD-VL

Pr.05-02 Rated power of Motor	0.00~655.35kW

535

Pr.05-04 Number of Motor Poles	2~48

ΡM

Motor Auto-tuning: When the Source of the Operation Command is set to digital keypad (Pr.00-15=2, refer to step 1) and setting Pr.08-00=2

Pr.08-00 Motor Auto tuning	0: No function
	1: Only for the unloaded motor, auto measure the Angle between magnetic pole and PG origin (08-09)
	2: For PM parameters
	3: Auto measure the Angle between magnetic pole and PG origin (08-09)

NOTE 1: It doesn't need to release the brake in this auto tuning operation. Please make sure that the electromagnetic valve is ON when it is used between the AC motor drive and motor. The warning message "Auto tuning" will be displayed on the digital keypad during tuning until it is finished. Then, the measure result will be saved into Pr.08-05 and Pr.08-07. (Pr.08-05 is Rs of Motor and Pr.08-07 is Lq of Motor)

NOTE 2: It is recommended to set Pr.08-00 to 1 (unloaded motor) for the most accurate calculation. If it needs to execute this function with loaded motor, please balance the carriage before execution. When Pr.08-00=1, please note:

- When executing the function of auto measure the Angle between magnetic pole and PG origin, it is recommended to stop the carriage car at the middle level.
- Make sure that the electromagnetic valve and mechanical brake are OFF before executing this function.
- When Pr.08-00=1, please execute this function with unloaded motor to get the most accurate result. If it needs to execute this function with loaded motor, please balance the carriage before execution. Make sure the balance by releasing the brake manually before running. This balance will affect the accuracy and the accuracy will influence the power efficiency in driving the motor.

NOTE 3: If it doesn't allow balancing carriage in the measured environment, it can set Pr.08-00 to 3 for executing this function. It will have a difference of  $15 \sim 30^\circ$  by the different encoder type.

When Pr.08-00 is set to 3, the driver will execute the function by the setting of Pr.10-00. The difference between Pr.08-00=3 and Pr.08-00=1 is it doesn't need to put the

### Call 1(800)985-6929 the tales trives scales @deltaacdrives.com

# Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

#### Chapter 3 Operation and Start Up | VFD-VL

balanced carriage when Pr.08-00=3. Besides, the operation status of the motor will be as shown in the above table (Pr.10-00=1, 2, 3 and 5, the motor will run. Pr.10-00=4 and 6, the motor won't run)

When Pr.08-00=3, please make sure if the setting of Pr.10-02 is correct. The incorrect setting will result in the wrong position of the magnetic pole and make the wrong angle between magnetic pole and PG origin.

NOTE 4: The warning message "Auto tuning" will be displayed on the digital keypad during tuning until it is finished. Then, the measure result will be saved into Pr.08-09.

NOTE 5: If the warning message "Auto Tuning Err" displayed on the digital keypad during tuning due to abnormal drive or human factor, please check if the wiring is correct. When the warning message "PG Fbk Error" displayed on the digital keypad, please change the setting of Pr.10-02 (for example: if it was set to 1, please change it to 2). When the warning message "PG Fbk Loss" is displayed on the digital keypad, please check the feedback of Z-phase pulse.

Pr.08-01 Full-load Current of Motor	(40~120%)*00-01 Amps
--	----------------------

Pr.08-02 Rated power of Motor	0.00~655.35 kW

Pr.08-03 Rated speed of Motor	0~65535
(rpm)	

Pr.08-04 Number of Motor Poles	2~96
-----------------------------------	------

Measure the angle between magnetic pole and PG origin

It can execute "RUN" by keypad or digital terminals:

1. Using digital keypad: setting Pr.08-00 to 1 and press "RUN" to execute "auto measure the angle between magnetic pole and PG origin". Please note that if the electromagnetic valve and brake are not controlled by the AC motor drive, please release it by manual.

2. Using external terminals: setting Pr.00-14=3 (frequency source) and Pr.00-15=1 (operation source). Please use "inspection" function to execute "auto measure the angle between magnetic pole and PG origin".

For the IM, it doesn't need to detect the position of the magnetic pole, this function (auto measure the Angle between magnetic pole and PG origin) doesn't have to be executed.

Measure the angle between magnetic pole and PG origin: Pr.08-00=1 or 3

Pr.08-00 Motor Auto tuning	0: No function
	1: Only for the unloaded motor, auto measure the Angle between magnetic pole and PG origin

Call 1(800)985-6929 therital alcohrives.com

### Call 1(800)985-6929 foortaaleetrives.scalers@deltaacdrives.com

#### Chapter 3 Operation and Start Up | VFD-VL

(08-09)
2: For PM parameters
3: Auto measure the Angle between magnetic pole and PG origin (08-09)

NOTE: The function of "auto measure the angle between magnetic pole and Pg origin" only can be enabled after finishing motor auto-tuning.

### 3.3.2.4 Step 4

Multi-step speed settings

- Please confirm the total speed steps (high speed, middle speed, low speed, creep, inspection and level auto-learning)
- Please make sure that the setting of step speeds and the action of the corresponding terminals of multi-function input commands are correct.
- Setting multi-step speeds in Pr.04-00 to Pr.04-15

	Zero Step Speed Frequency	0.00~400.00Hz
	1st Step Speed Frequency	0.00~400.00Hz
	2nd Step Speed Frequency	0.00~400.00Hz
	3rd Step Speed Frequency	0.00~400.00Hz
	4th Step Speed Frequency	0.00~400.00Hz
	5th Step Speed Frequency	0.00~400.00Hz
	6th Step Speed Frequency	0.00~400.00Hz
	7th Step Speed Frequency	0.00~400.00Hz
Settings of Pr.04-00 to Pr.04-15	8th Step Speed Frequency	0.00~400.00Hz
	9th Step Speed Frequency	0.00~400.00Hz
	10th Step Speed Frequency	0.00~400.00Hz
	11th Step Speed Frequency	0.00~400.00Hz
	12th Step Speed Frequency	0.00~400.00Hz
	13th Step Speed Frequency	0.00~400.00Hz
	14th Step Speed Frequency	0.00~400.00Hz
	15th Step Speed Frequency	0.00~400.00Hz

NOTE: It is recommended to set the max. operating frequency to the half of max. operating frequency before confirming the setting of each step speed and the action of the corresponding terminals of multi-function input commands.

Call 1(800)985-6929 ther tales by seven we have a seven we hav

### Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

#### Chapter 3 Operation and Start Up | VFD-VL

- Setting the acceleration/deceleration with Pr.01-23 and the setting 08 (the 1st, 2nd acceleration/deceleration time selection) and 09 (the 3rd, 4th acceleration/deceleration time selection) of multi-function input command Pr.02-01~02-08.
- Settings of acceleration/deceleration time: Pr.01-12~Pr.01-19

Settings of Pr.01-12 to Pr.01-19	Accel Time 1	0.00~600.00 sec
	Decel Time 1	0.00~600.00 sec
	Accel Time 2	0.00~600.00 sec
	Decel Time 2	0.00~600.00 sec
	Accel Time 3	0.00~600.00 sec
	Decel Time 3	0.00~600.00 sec
	Accel Time 4	0.00~600.00 sec
	Decel Time 4	0.00~600.00 sec

NOTE: it is recommended to set the Pr.01-31 (deceleration time) to the small value in the trial run and execute smooth test after all the actions are correct.

Settings of S curve: Pr.01-24~Pr.01-30

Settings of Pr.01-24 to Pr.01-30	S-curve for Acceleration Departure Time S1	0.00~25.00 sec
	S-curve for Acceleration Arrival Time S2	0.00~25.00 sec
	S-curve for Deceleration Departure Time S3	0.00~25.00 sec
	S-curve for Deceleration Arrival Time S4	0.00~25.00 sec
	Mode Selection when Frequency < Fmin	0: Output waiting
		1: Zero-speed operation
		2: Fmin (4th output frequency setting)
	Switch Frequency for S3/S4 Changes to S5	0.00~400.00Hz
	S-curve for Deceleration Arrival Time S5	0.00~25.00 sec

NOTE: it is recommended to set the S curve time to 0 in trial run and execute smooth test after all the actions are correct.

### 3.3.2.5 Step 5

Inertia Elevator speed

### Call 1(800)985-6929 the taaledrives.com

### Call 1(800)985-6929 foortSalestrives.sales@deltaacdrives.com

#### Chapter 3 Operation and Start Up | VFD-VL

Pr.11-01 Elevator Speed	0.10~4.00 m/s
Pr.11-02 Sheave Diameter	100~2000 mm
Pr.11-03 Mechanical Gear Ratio	1~100
Pr.11-04 Suspension Ratio	0: 1:1 1: 2:1
Pr.11-05 Inertial Ratio	1~300%
Pr.11-14 Motor Current at Accel.	50~200%
Pr.11-15 Elevator Acceleration	0.20~2.00m/s <sup>2</sup>

### 3.3.2.6 Step 6

#### Trial run

This step is used to trial run after finishing the settings of Step 1 to Step 5 to check if it runs normally after executing the inspection with the loaded motor. At the same time, please also check if the operations of multi-function output terminals is normal, such as the action of the brake release and electromagnetic valve correspond to the host controller.

It needs to check the switch between each step speed, current value, the noise in the carriage and noise source during operation.

### 3.3.2.7 Step 7

Elevator tuning

1. Setting Pr. 11-00 to bit 0=1

Call 1(800)985-6929 thertaaleetrives.scalers@deltaacdrives.com

### Call 1(800)985-6929 food factorives.com

#### Chapter 3 Operation and Start Up | VFD-VL

Pr.11-00	Bit 0=0: disable
System control	Bit 0=1: ASR Auto tuning, PDFF enable
	Bit 7=1: When position control is enabled, it doesn't need to set Pr.07-02 (DC Brake Current Level)
	Bit 15=0: when power is applied, it will detect the position of magnetic pole again
	Bit 15=1: when power is applied, it will start from the magnetic pole position of previous power failure

NOTE: bit 15=0, it will detect the position of magnetic pole when the power is applied. (it will detect every time when the power is applied.)

Bit 15=1: when power is applied, it will start from the magnetic pole position of previous power failure. Please make sure that the motor is not manually rotated during power off. If the motor has been rotated during power off, please set Pr.08-10=1 for magnetic pole re-orientation.

- 2. Smooth test for general operation
  - Adjust the setting of Pr.11-05

Pr.11-05	1~300%
Inertial Ratio	
Adjust the settings of Pr.11-06 to Pr.11-08	

Settings of Pr.11-	Zero-speed Bandwidth	0~40Hz
06 to Pr.11-08	Low-speed Bandwidth	0~40Hz
	High-speed Bandwidth	0~40Hz

- 3. Start-up adjustment (only for PM)
  - Control by the zero-speed position

Setting Pr.11-00, 10-19, 10-22, 10-23, 02-29 and 10-24

Pr.11-00	Bit 0=0: disable
System control	Bit 0=1: ASR Auto tuning, PDFF enable
	Bit 7=1: When position control is enabled, it doesn't need to set Pr.07-02 (DC Brake Current Level)
	Bit 15=0: when power is applied, it will detect the position of magnetic pole again
	Bit 15=1: when power is applied, it will start from the magnetic pole position of previous power failure
Pr.10-19	0~655.00%
Zero Speed Gain (P)	

NOTE: refer to the explanations in Pr.02-32

Call 1(800)985-6929 foot Sales @deltaacdrives.com

### Call 1(800)985-6929 foortSalestrives.sales@deltaacdrives.com

#### Chapter 3 Operation and Start Up | VFD-VL

Pr.10-22 Operation Time of Zero Speed	0.000~65.535sec
Pr.10-23 Filter Time of Zero Speed	0.000~65.535sec
Pr.10-24 Time for Zero Speed Execution	0: after the brake release set in Pr.02-29 1: after the brake signal input (Pr.02-01~02-08 is set to 42)

Pr.02-29	0.000~65.000 Sec
Brake Release Delay Time when Elevator Starts	

NOTE: When Pr.10-24=0, the zero speed control needs to be used with Pr.02-29. (refer to the explanations in Pr.02-32)

#### Function of the preload input

Please connect the signal of the preload signal to the external terminal of the AC motor drive (AUI1) and setting Pr.03-00=11, 07-19=1, 03-03, 03-06 and 03-09.

Pr.03-00	0: No function
Analog Input 1 (AUI1)	1: Frequency command (torque limit under TQR control mode)
	2: Torque command (torque limit under speed mode)
	3: Torque compensation command
	4-5: Reserved
	6: P.T.C. thermistor input value
	7: Positive torque limit
	8: Negative torque limit
	9: Regenerative torque limit
	10: Positive/negative torque limit

Pr.07-19	0: Disable
Source of Torque Offset	1: Analog input (Pr.03-00)
	2: Torque offset setting (Pr.07-20)
	3: Control by external terminal (by Pr.07-21 to Pr.07-23)

Call 1(800)985-6929 fberltaaleetrives.scalers@deltaacdrives.com

### Call 1(800)985-6929 food factorives.com


#### Chapter 3 Operation and Start Up | VFD-VL

Pr.03-03 Analog Input Bias 1 (AUI1)	-100.0~100.0%
---	---------------

Pr.03-06	0: Zero bias
Positive/negative Bias	1: Lower than bias=bias
Mode (AUI1)	2: Greater than bias=bias
	3: The absolute value of the bias voltage while serving as the center
	4: Serve bias as the center

Pr.03-09	-500.0~500.0%
Analog Input Gain 1 (AUI1)	

NOTE: Pr.03-03, 03-06 and 03-09 are used to adjust the analog input signal.



4. Setting of drive stop

Adjusting Pr.01-29, Pr.01-30, Pr.01-31 and Pr.11-06

Pr.01-29	0.00~400.00Hz
Switch Frequency for S3/S4 Changes to S5	

Pr.01-30	0.00~25.00 sec
S-curve for Deceleration Arrival Time S5	

Call 1(800)985-6929 ther tales by seven we have a seven we hav

# Call 1(800)985-6929 the tales rives.com

### Chapter 3 Operation and Start Up | VFD-VL

Pr.11-06 Zero-speed Bandwidth	0~40Hz
Pr.01-31	0.00~600.00 sec
Deceleration Time	

Call 1(800)985-6929 the tales rives.com

# **Chapter 4 Parameters**

The VFD-VL parameters are divided into 14 groups by property for easy setting. In most applications, the user can finish all parameter settings before start-up without the need for re-adjustment during operation.

The 14 groups are as follows:

- Group 0: System Parameters
- Group 1: Basic Parameters
- Group 2: Digital Input/Output Parameters
- Group 3: Analog Input/Output Parameters
- Group 4: Multi-Step Speed Parameters
- Group 5: IM Parameters
- Group 6: Protection Parameters
- Group 7: Special Parameters
- Group 8: PM Parameters
- Group 9: Communication Parameters
- Group 10: Speed Feedback Control Parameters
- Group 11: Advanced Parameters
- Group 12: User-defined Parameters
- Group 13: View User-defined Parameters

Chapter 4 Parameters | VFD-VL

### 4.1 Summary of Parameter Settings

 $\mathcal{M}$ : The parameter can be set during operation.

### 4.1.1 Group 0 System Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
00-00	Identity Code of the AC motor drive	Read-only	#	0	0	0	0	0	0
00-01		Read-only	#	0	0	0	0	0	0
00-02	Parameter Reset	0: No function 1: Read only 8: Keypad lock 9: All parameters are reset to factory settings (50Hz, 220V/380V) 10: All parameters are reset to factory settings (60Hz, 220V/480V)	0	0	0	0	0	0	0
₩00-03	Start-up Display Selection	0: Display the frequency command value (LED F) 1: Display the actual output frequency (LED H) 2: DC BUS voltage 3: Display the output current (A) 4: Output voltage 5: Multifunction display, see Pr.00-04	0	0	0	0	0	0	0
₩00-04	Content of Multi Function Display	Display output current (A)     1: Reserved     1: Reserved     2: Display output frequency (H)     3: Display OC-BUS voltage (U)     4: Display output voltage (E)     5: Output power factor angle (n)     6: Display output power kW(P)     7: Display actual motor speed in rpm(r)     8: Display actual motor speed in rpm(r)     8: Display actual motor speed in rpm(r)     10: Display actual motor speed in rpm(r)     11: Display ACI % (2.)     13: Display ACI % (2.)     13: Display ACI % (2.)     15: Display ACI % (2.)     15: Display ACI % (2.)     16: The status of digital input ON/OFF (I)     17: The status of digital input ON/OFF (I)     18: Multi-step speed (S)     19: Or the corresponding CPU pin status of digital input (i.)     20: The corresponding CPU pin status of digital input (a)     21: Output Covlage when malfunction (8)     26: Output DC voltage when malfunction (A)     28: Output DC voltage when malfunction (A)     29: Frequency when malfunction     31: Output corrent when malfunction     32: Input terminal status when malfunction     33: Output terminal status when malfunction     34: Dive status when malfunction	0	0	0	0	0	0	0
<b>≠</b> 00-05	User-Defined Coefficient K	Digit 4: decimal point number (0 to 3) Digit 0-3: 40 to 9999	0	0	0	0	0	0	0
00-06	Software Version	Read-only	#.#	0	0	0	0	0	0
<b>≠</b> 00-07	Password Input	1 to 9998 and 10000 to 65535 0 to 2: times of wrong password	0	0	0	0	0	0	0
<b>₩</b> 00-08	Password Set	1 to 9998 and 10000 to 65535 0: No password set or successful input in Pr.00-07 1: Password has been set	0	0	0	0	0	0	0
00-09	Control Method	0: V/f Control 1: V/f Control + Encoder (VFPG) 2: Sensories vector control (SVC) 3: FOC vector control + Encoder (FOCPG)	0	0	0	0	0	0	0

Call 1(800)985-6929 ftertSalestrives.sales@deltaacdrives.com

# Call 1(800)985-6929 the tales rives.com

### Chapter 4 Parameters | VFD-VL

Pr.	Explanation		Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
		4: Torque control + Encoder (TQCPG) 8: FOC PM control (FOCPM)							
₩00-10	Speed Unit	0: Hz 1: m/s 2: ft/s	0	0	0	0	0	0	0
00-11	Output Direction Selection	0: FWD: counterclockwise, REV: clockwise 1: FWD: clockwise, REV: counterclockwise	0	0	0	0	0	0	0
<b>⊮</b> 00-12	Carrier Frequency	2~15KHz	12	0	0	0	0	0	0
<b>⊮</b> 00-13	Auto Voltage Regulation (AVR) Function	0: Enable AVR 1: Disable AVR 2: Disable AVR when deceleration stop	0	0	0	0	0	0	0
<b>⊮</b> 00-14	Source of the Master Frequency Command	1: RS-485 serial communication or digital keypad (KPVL-CC01) 2: External analog input (Pr. 03-00) 3: Digital terminals input (Pr. 04-00~04-15)	1	0	0	0	0		0
<b>⊮</b> 00-15	Source of the Operation Command	1: External terminals 2: RS-485 serial communication or digital keypad (KPVL-CC01)	1	0	0	0	0	0	0

Chapter 4 Parameters | VFD-VL

### 4.1.2 Group 1 Basic Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
01-00	Maximum Output Frequency	10.00~400.00Hz	60.00/ 50.00	0	0	0	0	0	0
01-01	1st Output Frequency Setting 1	0.00~400.00Hz	60.00/ 50.00	0	0	0	0	0	0
01-02	1st Output Voltage Setting 1	230V: 0.1V~255.0V 460V: 0.1V~510.0V	220.0 440.0	0	0	0	0	0	$^{\circ}$
01-03	2nd Output Frequency Setting 1	0.00~400.00Hz	0.50	0	0				<u> </u>
<b>⊮</b> 01-04	2nd Output Voltage Setting	230V: 0.1V~255.0V 460V: 0.1V~510.0V	5.0 10.0	0	0				
01-05	3rd Output Frequency Setting 1	0.00~400.00Hz	0.50	0	0				<u> </u>
<b>⊮</b> 01-06	3rd Output Voltage Setting 1	230V: 0.1V~255.0V 460V: 0.1V~510.0V	5.0 10.0	0	0				<u> </u>
01-07	4th Output Frequency Setting 1	0.00~400.00Hz	0.00	0	0	0	0	0	<u> </u>
<b>⊮</b> 01-08	4th Output Voltage Setting 1	230V: 0.1V~255.0V 460V: 0.1V~510.0V	0.0 0.0	0	0				
01-09	Start Frequency	0.00~400.00Hz	0.50	$\bigcirc$	$\bigcirc$	$^{\circ}$	$\bigcirc$		
<b>⊮</b> 01-10	Output Frequency Upper Limit	0.00~400.00Hz	120.00	0	0	0	0		0
<b>⊮</b> 01-11	Output Frequency Lower Limit	0.00~400.00Hz	0.00	0	0	0	0		0
<b>⊮</b> 01-12	Accel Time 1	0.00~600.00 sec	3.00	$\bigcirc$	$^{\circ}$	$^{\circ}$	0		0
<b>⊮</b> 01-13	Decel Time 1	0.00~600.00 sec	2.00	$\bigcirc$	$^{\circ}$	$^{\circ}$	$\bigcirc$		0
×01-14	Accel Time 2	0.00~600.00 sec	3.00	$^{\circ}$	$^{\circ}$	0	0		0
<b>⊮</b> 01-15	Decel Time 2	0.00~600.00 sec	2.00	$^{\circ}$	$^{\circ}$	0	0		0
<b>№</b> 01-16	Accel Time 3	0.00~600.00 sec	3.00	$^{\circ}$	$^{\circ}$	0	0		0
<b>№</b> 01-17	Decel Time 3	0.00~600.00 sec	2.00	0	0	0	0		0
<b>⊮</b> 01-18	Accel Time 4	0.00~600.00 sec	3.00	0	0	0	0		0
<b>⊮</b> 01-19	Decel Time 4	0.00~600.00 sec	2.00	0	0	0	0		0
<b>№</b> 01-20	JOG Acceleration Time	0.00~600.00 sec	1.00	$^{\circ}$	$^{\circ}$	0	0		0
<b>⊮</b> 01-21	JOG Deceleration Time	0.00~600.00 sec	1.00	0	0	0	0		0
<b>⊮</b> 01-22	JOG Frequency	0.00~400.00Hz	6.00	0	0	0	0	0	0
<b>≠</b> 01-23	Switch Frequency between 1st/4th Accel/decel	0.00~400.00Hz	0.00	0	0	0	0		0
₩01-24	S-curve for Acceleration Departure Time S1	0.00~25.00 sec	1.00	0	0	0	0		0
₩01-25	S-curve for Acceleration Arrival Time S2	0.00~25.00 sec	1.00	0	0	0	0		0
<b>⊮</b> 01-26	S-curve for Deceleration Departure Time S3	0.00~25.00 sec	1.00	0	0	0	0		0
₩01-27	S-curve for Deceleration Arrival Time S4	0.00~25.00 sec	1.00	0	0	0	0		0
01-28	Mode Selection when Frequency < Fmin	0: Output waiting 1: Zero-speed operation 2: Fmin (4th output frequency setting)	0	0	0	0			
<b>⊮</b> 01-29	Switch Frequency for S3/S4 Changes to S5	0.00~400.00Hz	0.00	0	0	0	0		0
<b>⊮</b> 01-30	S-curve for Deceleration Arrival Time S5	0.00~25.00 sec	1.00	0	0	0	0		0
₩01-31	Deceleration Time when Operating without RUN Command	0.00~60.00 sec	2.00	0	0	0	0		0

Call 1(800)985-6929 fberlfaaledrives.szalers@deltaacdrives.com

# 4.1.3 Group 2 Digital Input/Output Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
02-00	2-wire/3-wire Operation Control	0: FWD/STOP, REV/STOP 1: FWD/STOP, REV/STOP (Line Start Lockout) 2: RUN/STOP, REV/FWD 3: RUN/STOP, REV/FWD (Line Start Lockout) 4: 3-wire 5: 3-wire (Line Start Lockout)	0	0	0	0	0	0	0
02-01	Multi-Function Input	0: no function	1	0	0	0	0	0	0
	Command 1 (MI1)	1: multi-step speed command 1		0	$\bigcirc$	0	$\bigcirc$		$\bigcirc$
	(it is Stop terminal for 3-wire operation)	2: multi-step speed command 2		0	$\bigcirc$	0	$\bigcirc$		$\bigcirc$
02-02	Multi-Function Input	3: multi-step speed command 3	2	$\cap$	$\cap$	$\cap$	$\cap$		$\circ$
	Command 2 (MI2)	4: multi-step speed command 4		õ	Õ	Õ	$\overline{\circ}$		õ
02-03	Multi-Function Input	5: Reset	3	Õ	$\overline{\circ}$	0	$\overline{\circ}$	0	Õ
02 00	Command 3 (MI3)	6: JOG command	- °	$\overline{\circ}$	$\overline{\circ}$	$\overline{\circ}$		0	0
02-04	Multi-Function Input	7: acceleration/deceleration speed inhibit	4	ŏ	0	ŏ	0		0
02 0 .	Command 4 (MI4)	8: the 1st, 2nd acceleration/deceleration time selection		ŏ	ŏ	$\overline{\circ}$	$\overline{\circ}$		Õ
02-05	· · ·	9: the 3rd, 4th acceleration/deceleration time selection	0	$\overline{\circ}$	0				0
52 00	Multi-Function Input	10: EF input (07-28)		0	0	0		0	0
	Command 5 (MI5)	11: Reserved		$\cup$	0	0	$\cup$	0	$\cup$
		12: Stop output	0	$\cap$		0	$\cap$	0	
02-06		13: Reserved		0	0	0	$\cup$	U	$\cup$
	Multi-Function Input	14: Reserved							-
	Command 6 (MI6)	15: operation speed command form AUI1		$\bigcirc$	$\bigcirc$	$\cap$	$\bigcirc$		$\cap$
		16: operation speed command form ACI		Õ	$\overline{O}$	$\overline{\circ}$	$\overline{\circ}$		Õ
02-07	Multi-Function Input	17: operation speed command form AUI2	0	Õ	0	Õ	0		Õ
	Command 7 (MI7)			~		_	0	0	_
02-08	Multi-Function Input	18: Emergency Stop (07-28)	40	0	$\odot$	0	$\odot$	0	O
	Command 8 (MI8)	19-23: Reserved		~	~	_	~		_
		24: FWD JOG command		0	0	0	0		0
	(When JP1 on the control	25: REV JOG command		0	0	$\odot$	$\odot$		0
	board is inserted, MI8	26: Reserved		_		-	~		0
	functions acc. to Pr02-08.)	27: ASR1/ASR2 selection		0	0	$\odot$	$\odot$	0	$\odot$
	(When JP1 on the control	28: Emergency stop (EF1) (Motor coasts to stop)		0	$\bigcirc$	0	$\odot$	0	0
	board is removed, MI8 is	29-30: Reserved		_	_	-	~	~	0
	always "enable",	31: High torque bias (by Pr.07-21)		Ő	O	0	O	0	$\bigcirc$
	independent of Pr02-08.)	32: Middle torque bias (by Pr.07-22)		0	0	0	0	0	C
		33: Low torque bias (by Pr.07-23)		0	0	$\odot$	$\odot$	0	С
		34-37: Reserved		~	~	_	~	~	_
		38: Disable write EEPROM function		0	0	0	$\odot$	0	0
		39: Torque command direction					_	0	_
		40: Enable drive function		0	$\odot$	0	$\odot$	0	$\odot$
		41: Detection of magnetic contactor		0	0	0	$\odot$	0	0
		42: Mechanical brake		0	$\odot$	0	$\odot$	0	O
		43: EPS function		$\circ$	$\bigcirc$	$\circ$	$\bigcirc$	0	$\circ$
<b>x</b> 02-09		0.001~ 30.000 sec	0.005	0	$^{\circ}$	0	0	0	0
<b>⊮</b> 02-10	Direction	0 ~ 65535	0	0	0	0	0	0	0
<b>⊮</b> 02-11	Multi-function Output 1 RA,	0: No function	11	$^{\circ}$	$\bigcirc$	$\bigcirc$	$\bigcirc$	0	0
<b>#</b> 02-11		1: Operation indication		$\bigcirc$	$\bigcirc$	$\bigcirc$	$\bigcirc$	$^{\circ}$	$\bigcirc$
	Multi-function Output 2	2: Operation speed attained	1	$^{\circ}$	$\bigcirc$	$\bigcirc$	$\bigcirc$	0	$\bigcirc$
₩02-12	MRA, MRC (Relay2)	<ol><li>Desired frequency attained 1 (Pr.02-25)</li></ol>		$\bigcirc$	$\bigcirc$	$\bigcirc$	$\bigcirc$		$\bigcirc$
	Multi-function Output 3	4: Desired frequency attained 2 (Pr.02-27)	0	0	$\bigcirc$	0	$\bigcirc$		0
<b>★</b> 02-13	(MO1)	5: Zero speed (frequency command)		$\bigcirc$	$\bigcirc$	0	$\bigcirc$		0
	1	6: Zero speed with stop (frequency command)		$\bigcirc$	$\bigcirc$	$\bigcirc$	$\bigcirc$		0
		7: Over torque (OT1) (Pr.06-05~06-07)		Ō	Ō	Ō	$\bigcirc$	0	Ō
		8: Over torque (OT2) (Pr.06-08~06-10)		Ō	Õ	Ō	Ō	Õ	Õ
				<u> </u>	$\sim$		~	)	-
	Multi-function Output 4	9: Drive ready	0	$\bigcirc$	$\bigcirc$	$\bigcirc$	$\bigcirc$	$\bigcirc$	$\cap$
<b>x</b> 02-14	Multi-function Output 4 (MO2)	9: Drive ready 10: User-defined Low-voltage Detection (LV)	0	0	0	0	00	0	0
<b>⊮</b> 02-14		9: Drive ready 10: User-defined Low-voltage Detection (LV) 11: Malfunction indication	0	000	000	000	000	000	0

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

Pr.	Explanation	Settings	Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
	(MO3)	13: Overheat (Pr.06-14)		0	0	0	0	0	0
		14: Brake chopper signal	0	Õ	Õ	Õ	Õ	Õ	Õ
(00.40	Multi-function Output 6	15: Motor-controlled magnetic contactor output	0	Õ	Õ	Õ	Õ	Õ	Õ
<b>№</b> 02-16	(MO4)	16: Slip error (oSL)	-	$\overline{\circ}$	Õ	$\overline{\circ}$	Õ		Õ
		17: Malfunction indication 1		Õ	ŏ	Õ	õ	0	õ
		18: Reserved	-			<u> </u>	<u> </u>	~	<u> </u>
		19: Brake chopper output error		$\bigcirc$	$\bigcirc$	$\bigcirc$	$\bigcirc$	$\bigcirc$	$\cap$
(00.47	Multi-function Output 7	20: Warning output	0	Õ	Õ	$\overline{\bigcirc}$	Õ	Õ	$\overline{\bigcirc}$
₩02-17	(MO5)	21: Over voltage warning	-	Õ	Õ	Õ	Õ	Õ	Õ
<b>№</b> 02-18	Multi-function Output 8	22: Over-current stall prevention warning	0	Õ	Õ	Õ	Ŭ		
# UZ-16	(MO6)	23: Over-voltage stall prevention warning	_	0		0	$\sim$	0	$\sim$
	Multi-function Output 9	24: Operation mode indication (Pr.00-15≠0 and PU LED on	0	0	0	$\sim$	0	~	$\overline{\bigcirc}$
<b>⊮</b> 02-19	(MO7)	KPVL-CC01 is off)	0	0	0	0	0	0	0
	. ,	25: Forward command		0	$\bigcirc$	$\bigcirc$	$\bigcirc$	0	$\bigcirc$
₩02-20	Multi-function Output 10	26: Reverse command	0	Õ	Õ	Õ	Õ	Õ	$\overline{\circ}$
#02-20	(MO8)	27: Output when current >= Pr.02-33	-	Õ	Õ	Õ	Õ	Õ	Õ
	Multi-function Output 11	28: Output when current < Pr.02-33	0	Õ	Õ	Õ	Õ	Õ	$\overline{\circ}$
<b>⊮</b> 02-21	(MO9)	29: Output when frequency >= Pr.02-34		Õ	$\overline{\circ}$	$\overline{\circ}$	$\overline{\circ}$	0	$\overline{\circ}$
	Multi-function Output 12	30: Output when frequency < Pr.02-34	0	ŏ	$\overline{\circ}$	$\overline{\circ}$	$\overline{\circ}$	0	$\overline{\circ}$
<b>₩</b> 02-22	(MO10)	31: Power generation direction and status verify		Õ	$\overline{\circ}$	$\overline{\circ}$	$\overline{\circ}$	0	$\overline{\circ}$
		32: Power generation direction	-	Ő	$\overline{\circ}$	$\overline{\circ}$	$\overline{\circ}$	0	
		33: Zero speed (actual output frequency)	_	$\overline{\bigcirc}$	$\overline{\circ}$	Õ	Ő	U	$\sim$
		34: Zero speed with Stop (actual output frequency)	_	0			$\overline{\circ}$		
		35: Fault output option 1 (Pr.06-22)	_		0	0	0	0	
			_	0	0	0	0	0	0
		36: Fault output option 2 (Pr.06-23)		0	0	0	0	0	0
		37: Fault output option 3 (Pr.06-24)	_	0	0	0	Ő	0	$\odot$
		38: Fault output option 4 (Pr.06-25)		$\odot$	0	0	0	0	$\odot$
		39: Reserved 40: Speed attained (including zero speed)	_	$\sim$	~	$\sim$	$\sim$		$\sim$
		40. Speed attained (including zero speed) 41: Reserved	_	0	0	0	0		0
	Multi autout Direction	0 ~ 65535	0	0	0	0	0	0	0
<b>⊮</b> 02-23	Multi-output Direction		-	-	_		-	<u> </u>	-
02-24	Serial Start Signal Selection	0: by FWD/REV 1: by Enable	0	0	0	0	0		0
<b>⊮</b> 02-25	Desired Frequency Attained 1	0.00 ~ 400.00Hz	60.00/ 50.00	0	0	0	0		0
<b>№</b> 02-26	The Width of the Desired Frequency Attained 1	0.00 ~ 400.00Hz	2.00	0	0	0	0		0
₩02-27	Desired Frequency Attained	0.00 ~ 400.00Hz	60.00/	$\bigcirc$	$\bigcirc$	$\bigcirc$	0		0
	2 The Mildle of the Decised		50.00	~	0	0	~		~
<b>⊮</b> 02-28	The Width of the Desired Frequency Attained 2	0.00 ~ 400.00Hz	2.00	0	0	0	0	0	0
02-29	Brake Release Delay Time when Elevator Starts	0.000~65.000 Sec	0.250	0	0	0	0	0	0
02-30	Brake Engage Delay Time when Elevator Stops	0.000~65.000 Sec	0.250	0	0	0	0	0	0
<b>⊮</b> 02-31	Turn On Delay of Magnetic Contactor between Drive and Motor	0.000~65.000 Sec	0.200	0	0	0	0	0	0
<b>⊮</b> 02-32	Turn Off Delay of Magnetic Contactor between Drive and Motor	0.000~65.000 Sec	0.200	0	0	0	0	0	0
<b>₩</b> 02-33	Output Current Level Setting for External Terminals	0~100%	0	0	0	0	0	0	0
<b>№</b> 02-34	Output Boundary for External Terminals	0.00~+-400.00Hz (it is motor speed when using with PG)	0.00	0	0	0	0	0	0
<b>⊮</b> 02-35	Detection Time of Mechanical Brake	0.00~10.00 Sec	0.00	0	0	0	0	0	0
<b>⊮</b> 02-36	Detection Time of Contactor	0.00~10.00 Sec	0.00	0	0	0	0	0	0
02-37	Check Torque Output	0: Enable	0	$\bigcirc$	$\bigcirc$	$\bigcirc$	$\bigcirc$	0	$\bigcirc$
02-37	Function	1: Disable	1	1	1	1	1		1

Call 1(800)985-6929 fter tales rives.sales@deltaacdrives.com

# 4.1.4 Group 3 Analog Input/Output Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
<b>₩</b> 03-00	Analog Input 1 (AUI1)	0: No function	1	0	0	0	0	0	0
<b>№</b> 03-01	Analog Input 2 (ACI)	1: Frequency command (torque limit under TQR control mode)	0	$^{\circ}$	$\bigcirc$	0	$^{\circ}$	Ο	0
₩03-02	Analog Input 3 (AUI2)	2: Torque command (torque limit under speed mode)	0					0	
		3: Preload Input	1	$\bigcirc$	$\bigcirc$	$\bigcirc$	$\bigcirc$	$\bigcirc$	$^{\circ}$
		4-5: Reserved							
		6: P.T.C. thermistor input value		0	$\odot$	0	$^{\circ}$	0	0
		7: Positive torque limit					0		0
		8: Negative torque limit			-		0		0
		9: Regenerative torque limit					0		0
		10: Positive/negative torque limit					0		0
	Analog Input Bias 1 (AUI1)	, , , , , , , , , , , , , , , , , , ,	0.0	0	0	0	0		0
<b>₩</b> 03-03	Analog Input Bias 2 (ACI)	-100.0~100.0%	0.0	0		0	0	0	0
<b>№</b> 03-04		-100.0~100.0%		$\sim$	0	-	0	0	0
<b>⊮</b> 03-05	Analog Input Bias 3 (AUI2)	-100.0~100.0%	0.0	0	0	0	0	0	0
<b>⊮</b> 03-06	Positive/negative Bias Mode (AUI1)	0: Zero bias	0	0	0	0	0	0	0
<b>≠</b> 03-07	Positive/negative Bias Mode (ACI) (can be set to 0 or 1 only)	<ol> <li>Serve bias as the center, lower than bias=bias</li> <li>Serve bias as the center, greater than bias=bias</li> <li>The absolute value of the bias voltage while serving as the center (single polar)</li> </ol>	0	0	0	0	0	0	0
<b>⊮</b> 03-08	Positive/negative Bias Mode (AUI2)	4: Serve bias as the center (single polar)	0	0	0	0	0	0	0
<b>№</b> 03-09	Analog Input Gain 1 (AUI1)	-500.0~500.0%	100.0	0	0	0	0	0	0
<b>₩</b> 03-10	Analog Input Gain 2 (ACI)	-500.0~500.0%	100.0	$\bigcirc$	$\bigcirc$	0	$\bigcirc$	0	0
×03-11	Analog Input Gain 3 (AUI2)	-500.0~500.0%	100.0	$\bigcirc$	$\bigcirc$	$\bigcirc$	$\odot$	$\bigcirc$	0
<b>⊮</b> 03-12	Analog Input Delay Time (AUI1)	0.00~2.00 sec	0.01	0	0	0	0	0	0
<b>≠</b> 03-13	Analog Input Delay Time (ACI)	0.00~2.00 sec	0.01	0	0	0	0	0	0
<b>⊮</b> 03-14	Analog Input Delay Time (AUI2)	0.00~2.00 sec	0.01	0	0	0	0	0	0
<b>★</b> 03-15	Loss of the ACI Signal	0: Disable 1: Continue operation at the last frequency 2: Decelerate to 0Hz 3: Stop immediately and display E.F.	0	0	0	0	0	0	0
03-16	Reserved								
<b>⊮</b> 03-17	Analog Output Selection 1	0: Output frequency (Hz)	0	$\bigcirc$	$\bigcirc$	0	$\bigcirc$	0	0
		1: Frequency command (Hz)		0	0	0	0	0	0
		2: Motor speed (RPM) 3: Output current (rms)		0	0	00	0	0	0
		4: Output voltage		Õ	Õ	0	Õ	0	0
		5: DC Bus Voltage		Õ	Õ	Õ	Õ	Õ	Õ
		6: Power factor		0	0	0	0	0	0
		7: Power		0	0	0	0	0	0
		8: Output torque 9: AUI1		0	0	0	0	0	0
		10: ACI		0	0	0	0	0	$\overline{\circ}$
		11: AUI2		Õ	Õ	Õ	Õ	Õ	Õ
		12: q-axis current	]	$\bigcirc$	0	0	0	0	0
		13: q-axis feedback value	ł	0	0	0	0	Ó	0
		14: d-axis current 15: d-axis feedback value	-	0	0	0	0	0	0
		16: q-axis voltage	1	0	0	0	0	0	0
		17: d-axis voltage	1	Õ	0	Õ	Õ	Õ	TO
		18: Torque command	1	Ō	Õ	Ō	Ō	Õ	Ō
	Apples Output Cais 1	19-20: Reserved	100.0		0	0	0	0	
<b>⊮</b> 03-18	Analog Output Gain 1	0~200.0%	100.0	$\left  \right\rangle$	0	$\cup$	$\cup$	$\circ$	0

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

# Call 1(800)985-6929 the tales rives.com

#### Chapter 4 Parameters | VFD-VL

Pr.	Explanation	Settings	Factory Setting		VFPG	SVC	FOCPG	TOCPG	FOCPM
<b>⊮</b> 03-19	Analog Output Value in REV Direction 1	0: Absolute value in REV direction 1: Output 0V in REV direction 2: Enable output voltage in REV direction	0	0	0	0	0	0	0
¥03-20	Analog Output Selection 2	0: Output frequency (Hz) 1: Frequency command (Hz) 2: Motor speed (RPM) 3: Output current (ms) 4: Output voltage 5: DC Bus Voltage 6: Power factor 7: Power 8: Output torque 9: AVI 10: ACI 11: AUI 12: q-axis feedback value 13: q-axis feedback value 14: d-axis current 15: d-axis feedback value 16: q-axis voltage 18: Torsis voltage 18: Torsis voltage	0	0 0000000000000000000000000000000000000	0 0000000000000000000000000000000000000	0 0000000000000000000000000000000000000	0 0000000000000000000000000000000000000	0 0000000000000000000000000000000000000	0 0000000000000000000000000000000000000
₩03-21	Analog Output Gain 2	19-20: Reserved 0~200.0%	100.0	0	0	0	0	0	0
¥03-22	Analog Output Value in REV Direction 2	0: Absolute value in REV direction 1: Output 0V in REV direction 2: Enable output voltage in REV direction	0	0	0	0	0	0	0
03-23	Analog Input Type (AUI1)	0: Bipolar (±10V) 1: Unipolar (0-10V)	0	0	0	0	0	0	0
03-24	Analog Input Type (AUI2)	0: Bipolar (±10V) 1: Unipolar (0-10V)	0	0	0	0	0	0	0

### Chapter 4 Parameters | VFD-VL

Pr.	Explanation	Settings	Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
<b>₩</b> 04-00	Zero Step Speed Frequency	0.00~400.00Hz	0.00	0	0	0	0		0
<b>⊮</b> 04-01	1st Step Speed Frequency	0.00~400.00Hz	0.00	0	0	0	$^{\circ}$		0
<b>₩</b> 04-02	2nd Step Speed Frequency	0.00~400.00Hz	0.00	0	0	0	0		0
<b>₩</b> 04-03	3rd Step Speed Frequency	0.00~400.00Hz	0.00	$^{\circ}$	$^{\circ}$	$^{\circ}$	$^{\circ}$		0
<b>₩</b> 04-04	4th Step Speed Frequency	0.00~400.00Hz	0.00	$^{\circ}$	$^{\circ}$	$^{\circ}$	$^{\circ}$		0
<b>⊮</b> 04-05	5th Step Speed Frequency	0.00~400.00Hz	0.00	0	0	0	0		0
<b>₩</b> 04-06	6th Step Speed Frequency	0.00~400.00Hz	0.00	0	0	0	0		0
<b>⊮</b> 04-07	7th Step Speed Frequency	0.00~400.00Hz	0.00	$^{\circ}$	$^{\circ}$	$^{\circ}$	$^{\circ}$		0
₩04-08	8th Step Speed Frequency	0.00~400.00Hz	0.00	$^{\circ}$	$^{\circ}$	$^{\circ}$	$^{\circ}$		0
<b>₩</b> 04-09	9th Step Speed Frequency	0.00~400.00Hz	0.00	0	$\bigcirc$	$\bigcirc$	0	_	0
<b>⊮</b> 04-10	AOIL OLAR OLAR I FRANK	0.00~400.00Hz	0.00	$^{\circ}$	$^{\circ}$	$^{\circ}$	$^{\circ}$		0
<b>⊮</b> 04-11	11th Step Speed Frequency	0.00~400.00Hz	0.00	$^{\circ}$	$^{\circ}$	$^{\circ}$	$^{\circ}$		0
<b>⊮</b> 04-12	12th Step Speed Frequency	0.00~400.00Hz	0.00	0	0	0	0		0
<b>№</b> 04-13	12th Ctop Coosed Economic	0.00~400.00Hz	0.00	0	0	0	0		0
<b>№</b> 04-14	14th Step Speed Frequency	0.00~400.00Hz	0.00	$^{\circ}$	0	0	0		0
<b>№</b> 04-15	15th Step Speed Frequency	0.00~400.00Hz	0.00	0	0	0	0		0

### 4.1.5 Group 4 Multi-Step Speed Parameters

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

### 4.1.6 Group 5 IM Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
05-00	Motor Auto Tuning	0: No function 1: Rolling test (Rs, Rr, Lm, Lx, no-load current) 2: Static test	0	0					
05-01	Full-load Current of Motor	(40-120%)* Pr.00-01 Amps	#.##	Ο	0	0	$\bigcirc$	$\bigcirc$	
05-02	Rated power of Motor	0.00~655.35kW	#.##			0	0	0	
05-03	Rated speed of Motor (rpm)	0~65535	1710		0	0	$\bigcirc$	$\bigcirc$	
05-03	Number of Motor Poles	2~48	4	$\bigcirc$	$\bigcirc$	$\bigcirc$	$\bigcirc$	$\bigcirc$	
05-05	No-load Current of Motor	0-100%	#.##		ŏ	ŏ	ŏ	Õ	<u> </u>
05-06	Rs of Motor	0.000~65.535Ω	0.000			Ō	Ō	Ō	
05-07	Rr of Motor	0.000~65.535Ω	0.000			Ō	Ō	Ō	
05-08	Lm of Motor	0.0~6553.5mH	0.0			0	$\bigcirc$	0	
05-09	Lx of Motor	0.0~6553.5mH	0.0			0	$\bigcirc$	0	
<b>⊮</b> 05-10	Torque Compensation Time Constant	0.001~10.000sec	0.020			0			
₩05-11	Slip Compensation Time Constant	0.001~10.000sec	0.100			0			
<b>⊮</b> 05-12	Torque Compensation Gain	0~10	0	0	0				
<b>⊮</b> 05-13	Slip Compensation Gain	0.00~10.00	0.00	0	0	0			
<b>⊮</b> 05-14	Slip Deviation Level	0~1000% (0: disable)	0		0	0	0		
<b>⊮</b> 05-15	Detection Time of Slip Deviation	0.0~10.0 sec	1.0		0	0	0		
<b>₩</b> 05-16	Over Slip Treatment	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop	0		0	0	0		
₩05-17	Hunting Gain	0~10000 (0: disable)	2000	0	0	0			
05-18	Accumulative Motor Operation Time (Min.)	00~1439	00	0	0	0	0	0	0
05-19	Accumulative Motor Operation Time (day)	00~65535	00	0	0	0	0	0	0
₩05-20	Core Loss Compensation	0~250%	10			0			
05-21	Accumulative Drive Power- on Time (Min.)	00~1439	00	0	0	0	0	0	0
05-22	Accumulative Drive Power- on Time (day)	00~65535	00	0	0	0	0	0	0

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

### 4.1.7 Group 6 Protection Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
₩06-00	Low Voltage Level	160.0~220.0Vdc	180.0	0	0	0	0	0	0
/		320.0~440.0Vdc	360.0	0	Ο	0	$\bigcirc$	0	0
<b>⊮</b> 06-01	Phase-loss Protection	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop	2	0	0	0	0	0	0
<b>★</b> 06-02	Over-current Stall Prevention during Acceleration	00: disable 00~250%	00	0	0	0			
<b>№</b> 06-03	Over-current Stall Prevention during Operation	00: disable 00~250%	00	0	0	0			
<b>₩</b> 06-04	Accel./Decel. Time Selection of Stall Prevention at constant speed	0: by current accel/decel time 1: by the 1st accel/decel time 2: by the 2nd accel/decel time 3: by the 3rd accel/decel time 4: by the 4th accel/decel time 5: by auto accel/decel time	0	0	0	0			
<b>₩</b> 06-05	Over-torque Detection Selection (OT1)	Or disable 1: over-torque detection during constant speed operation, continue to operate after detection 2: over-torque detection during constant speed operation, stop operation after detection 3: over-torque detection during operation, continue to operate after detection 4: over-torque detection during operation, stop operation after detection	0	0	0	0	0	0	0
₩06-06	Over-torque Detection Level (OT1)	10~250%	150	0	0	0	0	0	0
<b>≠</b> 06-07	Over-torque Detection Time (OT1)	0.0~60.0 sec	0.1	0	0	0	0	0	0
₩06-08	Over-torque Detection Selection (OT2)	0: disable 1: over-forque detection during constant speed operation, continue to operate after detection 2: over-forque detection during constant speed operation, stop operation after detection 3: over-forque detection during operation, continue to operate after detection 4: over-forque detection during operation, stop operation after detection	0	0	0	0	0	0	0
<b>≠</b> 06-09	Over-torque Detection Level (OT2)	10~250%	150	0	0	0	0	0	0
<b>№</b> 06-10	Over-torque Detection Time (OT2)	0.0~60.0 sec	0.1	0	0	0	0	0	0
₩06-11	Current Limit	0~250%	200				0	0	0
06-12	Electronic Thermal Relay Selection	0: Inverter motor 1: Standard motor 2: Disable	2	0	0	0	0	0	0
<b>⊮</b> 06-13	Electronic Thermal Characteristic	30.0~600.0 sec	60.0	0	0	0	0	0	0
<b>⊮</b> 06-14	Heat Sink Over-heat (OH) Warning	0.0~110.0℃	85.0	0	0	0	0	0	0
₩06-15	Stall Prevention Limit Level	0~100% (refer to Pr.06-02, Pr.06-03)	50	$\bigcirc$	$^{\circ}$	0			
06-16	Present Fault Record	0: No fault	0	$\bigcirc$	0	$\odot$	$\bigcirc$	$\bigcirc$	$\bigcirc$
06-17	Second Most Recent Fault Record	1: Over-current during acceleration (ocA) 2: Over-current during deceleration (ocd)	0	0	0	0	0	0	0
06-18	Third Most Recent Fault Record	3: Over-current during constant speed (ocn) 4: Ground fault (GFF)	0	0	0	0	0	0	0
06-19	Fourth Most Recent Fault Record	5: IGBT short-circuit (occ) 6: Over-current at stop (ocS) 7: Over-cutrage dragedearting (ovA)	0	0	0	0	0	0	0
06-20	Fifth Most Recent Fault Record	7: Over-voltage during acceleration (ovA) 8: Over-voltage during deceleration (ovd) 9: Over-voltage during constant speed (ovn)	0	0	0	0	0	0	0
06-21	Sixth Most Recent Fault Record	10: Over-voltage at stop (ovS)	0	0	0	0	0	0	0

# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

Chapter 4 Parameters | VFD-VL

Pr.	Explanation	Settings	Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
		11: Low-voltage during acceleration (LvA) 12: Low-voltage during deceleration (Lvd) 13: Low-voltage during constant speed (Lvn) 14: Low-voltage during constant speed (Lvn) 14: Low-voltage during constant speed (Lvn) 15: Phase loss (PHL) 16: IGBT heat sink over-heat (oH1) 17: Heat sink over-heat (OH2) 18: TH1 open loop error (H120) 20: Fan error signal output 21: over-load (oL) (150% 1Min) 22: Motor over-load (EoL1) 23: Reserved 24: Motor PTC overheat (OH3) 25: Reserved 28: Reserved 28: Reserved 29: Reserved 29: Reserved 20: Memory write-in error (GF1) 31: Memory write-in error (GF1) 31: Memory write-in error (GC1) 33: U-phase current detection error (cd1) 34: V-phase current detection error (cd2) 35: Coure-torque 1 (ol1) 29: Over-voltage detection error (rd1) 34: V-phase current detection error (rd2) 35: Courne durent detection error (rd1) 36: Ouer-voltage detection error (rd2) 37: Over-current detection error (rd2) 39: Ground current detection error (rd2) 30: Actor tuning error (AuE) 41: PID feedback loss (PGF2) 42: PG feedback ross (PGF1) 43: PG feedback stall (PGF3) 45: PG feit loss (PGF2) 44: PG feedback stall (PGF3) 45: PG feedback stall (PGF3)							
₩06-22	Fault Output Option 1	67: Phase loss of drive output (MPHL) 0~65535 (refer to bit table for fault code)	0	0	0	0	0	0	0
<b>⊮</b> 06-23	Fault Output Option 2	0~65535 (refer to bit table for fault code)	0	0	0	0	0	0	0
₩06-24	Fault Output Option 3	0~65535 (refer to bit table for fault code)	0	0	0	0	0	0	0
₩06-25	Fault Output Option 4	0~65535 (refer to bit table for fault code)	0	0	0	0	0	0	0
₩06-26	PTC (Positive Temperature Coefficient) Detection Selection	0: Warn and keep operation 1: Warn and ramp to stop	0	0	0	0	0	0	0
₩06-27	PTC Level	0.0~100.0%	50.0	0	0	0	0	0	0
₩06-28	Filter Time for PTC Detection Voltage of Emergency	0.00~10.00sec 48.0~375.0Vdc	0.20 48.0	0	0	0	0	0	0
06-29	Power	96.0~750.0Vdc	96.0				0	0	0
<b>№</b> 06-30	Setting Method of Fault Output	0: By settings of Pr.06-22~06-25 1: By the binary setting	0	0	0	U	Ο	Ο	0

Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

### Chapter 4 Parameters | VFD-VL

Pr.	Explanation	Settings	Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
06-31	Phase Loss Detection of Drive Output at Start up(MPHL)	0: Disable 1: Enable	0	0	0	0	0	0	0
06-32	Accumulative Drive Power- on Time at the First Fault (min.)	00~1439	00	0	0	0	0	0	0
06-33	Accumulative Drive Power- on Time at the First Fault (day)	00~65535	00	0	0	0	0	0	0
06-34	Accumulative Drive Power- on Time at the Second Fault (min.)	00~1439	00	0	0	0	0	0	0
06-35	Accumulative Drive Power- on Time at the Second Fault (day)	00~65535	00	0	0	0	0	0	0
06-36	Accumulative Drive Power- on Time at the Third Fault (min.)	00~1439	00	0	0	0	0	0	0
06-37	Accumulative Drive Power- on Time at the Third Fault (day)	00~65535	00	0	0	0	0	0	0
06-38	Accumulative Drive Power- on Time at the Fourth Fault (min.)	00~1439	00	0	0	0	0	0	0
06-39	Accumulative Drive Power- on Time at the Fourth Fault (day)	00~65535	00	0	0	0	0	0	0
06-40	Accumulative Drive Power- on Time at the Fifth Fault (min.)	00~1439	00	0	0	0	0	0	0
06-41	Accumulative Drive Power- on Time at the Fifth Fault (day)	00~65535	00	0	0	0	0	0	0
06-42	Accumulative Drive Power- on Time at the Sixth Fault (min.)	00~1439	00	0	0	0	0	0	0
06-43	Accumulative Drive Power- on Time at the Sixth Fault (day)	00~65535	00	0	0	0	0	0	0
≠06-44	Operation Speed of Emergency Power Mode	0.00~400.00Hz	Read Only	0	0	0	0	0	0
₩06-45	Low-voltage Protection	0: Display Lv fault and coast to stop 1: Display Lv warn and coast to stop 2: Fan lock, fault and coast to stop 3: Fan lock, warn and coast to stop	0	0	0	0	0	0	0
≠06-46	Operation Direction for Emergency Power ON	0: Operate by current command 1: Operate by the direction of power generating mode	0	0	0	0	0	0	0
≠06-47	Power Generation Direction Searching Time	0.0~5.0 sec	1.0	0	0	0	0	0	0
₩06-48	Power Capacity of Emergency Power	0.0~100.0 kVA	0.0	0	0	0	0	0	0

### 4.1.8 Group 7 Special Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
<b>≠</b> 07-00	Brake Chopper Level	230V: 350.0~450.0Vdc 460V: 700.0~900.0Vdc	380.0 760.0	0	0	0	0	0	0
07-01	Reserved								
<b>₩</b> 07-02	DC Brake Current Level	0~100%	0	$^{\circ}$	0	0			
<b>₩</b> 07-03	DC Brake Activation Time	0.0~60.0 sec	0.0	$\bigcirc$	$\bigcirc$	$\bigcirc$	0		0
<b>₩</b> 07-04	DC Brake Stopping Time	0.0~60.0 sec	0.0	0	0	0	0		0
<b>⊮</b> 07-05	Start-point for DC Brake	0.00~400.00Hz	0.00	0	0	0	0		
<b>⊮</b> 07-06	DC Brake Proportional Gain	1~500Hz	50	0	0	0			
<b>⊮</b> 07-07	Dwell Time at Accel.	0.00~600.00sec	0.00	0	0	0	0		0
<b>≠</b> 07-08	Dwell Frequency at Accel.	0.00~400.00Hz	0.00	0	0	0	0		0
<b>⊮</b> 07-09	Dwell Time at Decel.	0.00~600.00sec	0.00	0	0	0	0		0
<b>⊮</b> 07-10	Dwell Frequency at Decel.	0.00~400.00Hz	0.00	0	0	0	0		0
<b>₩</b> 07-11	Fan Control	C: Fan always ON 1: 1 minute after AC motor drive stops, fan will be OFF 2: AC motor drive runs and fan ON, AC motor drive stops and fan OFF 3: Fan ON to run when preliminary heat sink temperature attained 4: Fan always OFF	2	0	0	0	0	0	0
₩07-12	Torque Command	-100.0~100.0% (Pr. 07-14 setting=100%)	0.0					0	
<b>₩</b> 07-13	Torque Command Source	0: Digital keypad (KPVL-CC01) 1: RS485 serial communication (RJ-11) 2: Analog signal (Pr.03-00)	2					0	
₩07-14	Maximum Torque Command	0~300%	100	0	0	$\bigcirc$	0	0	0
<b>⊮</b> 07-15	Filter Time of Torque Command	0.000~1.000 sec	0.000					0	
07-16	Speed Limit Selection	0: By Pr.07-17 and Pr.07-18 1: Frequency command source (Pr.00-14)	0					0	
<b>#</b> 07-17	Torque Mode +Speed Limit	0~120%	10					0	
<b>⊮</b> 07-18	Torque Mode-Speed Limit	0~120%	10					0	
<b>₩</b> 07-19	Source of Torque Offset	0: Disable 1: Analog input (Pr.03-00) 2: Torque offset setting (Pr.07-20) 3: Control by external terminal (by Pr.07-21 to Pr.07-23)	0			0	0	0	0
<b>★</b> 07-20	Torque Offset Setting	0.0~100.0%	0.0			$\bigcirc$	0	0	0
×07-21	High Torque Offset	0.0~100.0%	30.0			0	0	0	0
×07-22	Middle Torque Offset	0.0~100.0%	20.0			0	0	0	0
×07-23	Low Torque Offset	0.0~100.0%	10.0			0	0	0	0
×07-24	Forward Motor Torque Limit	0~300%	200				0	0	0
×07-24	Forward Regenerative	0~300%	200			╞	0	0	0
	Torque Limit Reverse Motor Torque Limit	0~300%	200	_	_	-	0	0	0
×07-26 ×07-27	Reverse Regenerative Torque Limit	0~300%	200				0	0	0
<b>₩</b> 07-28	Emergency Stop (EF) & Forced Stop Selection	0: Coast to stop 1: By deceleration Time 1 2: By deceleration Time 2 3: By deceleration Time 3 4: By deceleration Time 4 5: By Pr.01-31	0	0	0	0	0	0	0
<b>⊮</b> 07-29	Time for Decreasing Torque at Stop	0.000~1.000 sec	0.000				0	0	0

Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

### 4.1.9 Group 8 PM Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
08-00	Motor Auto Tuning	0: No function 1: Only for the unloaded motor, auto measure the angle between magnetic pole and PG origin (08-09) 2: For PM parameters 3: Auto measure the angle between magnetic pole and PG origin (08-09)	0						0
08-01	Full-load Current of Motor	(40-120%)*00-01 Amps	#.##						0
08-02	Rated power of Motor	0.00~655.35 kW	#.##						0
08-03	Rated speed of Motor (rpm)	0~65535	1710						0
08-04	Number of Motor Poles	2~96	4						0
08-05	Rs of Motor	0.000~65.535Ω	0.000						0
08-06	Ld of Motor	0.0~6553.5mH	0.0						0
08-07	Lq of Motor	0.0~6553.5mH	0.0						0
08-08	Back Electromotive Force	0.0~6553.5Vrms	0.0						$\bigcirc$
08-09	Angle between Magnetic Pole and PG Origin	0.0-360.0°	360.0						0
08-10	Magnetic Pole Re- orientation	0: Disable 1: Enable	0						0

## 4.1.10 Group 9 Communication Parameters

Pr.	Explanation		Factory Setting		VFPG	SVC	FOCPG	TOCPG	FOCPM
×09-00	Communication Address	1~254	1	$^{\circ}$	0	0	0	0	$^{\circ}$
<b>⊮</b> 09-01	Transmission Speed	4.8~115.2Kbps	9.6	$\bigcirc$	0	0	0	0	$^{\circ}$
<b>⊮</b> 09-02	Transmission Fault Treatment	0: Warn and keep operation 1: Warn and ramp to stop 2: Reserved 3: No action and no display	3	0	0	0	0	0	0
<b>₩</b> 09-03	Time-out Detection	0.0~100.0 sec	0.0	$\bigcirc$	0	0	0	0	$^{\circ}$
¥09-04	Communication Protocol	0: TN1 (ASCII) 1: TN2 (ASCII) 2: TE1 (ASCII) 2: TE1 (ASCII) 4: TE2 (ASCII) 5: 702 (ASCII) 5: 702 (ASCII) 6: 8N1 (ASCII) 7: 8N2 (ASCII) 8: 8E1 (ASCII) 10: 8E2 (ASCII) 11: 802 (ASCII) 11: 802 (ASCII) 11: 802 (ASCII) 12: 8N1 (RTU) 13: 8N2 (RTU) 14: 8E1 (RTU) 15: 801 (RTU) 15: 801 (RTU) 16: 8E2 (RTU) 17: 802 (RTU)	13	0	0	0	0	0	0
₩09-05	Response Delay Time	0.0~200.0ms	2.0	$\odot$	$^{\circ}$	$^{\circ}$	$\bigcirc$	$\odot$	0

### 4.1.11 Group 10 Speed Feedback Control Parameters

Pr.	Explanation	Settings	Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
10-00	PG Signal Type	0: No function 1: ABZ 2: ABZ+Hall 3: SIN/COS+Sinusoidal 4: SIN/COS+Endat	0		0		0	0	0
10-01	Encoder Pulse	5: SIN/COS 6: SIN/COS + Hiperface 1~20000	600		0		0	0	0
10-02	Encoder Input Type Setting	0: Disable 1: Phase A leads in a forward run command and phase B leads in a reverse run command 2: Phase B leads in a forward run command and phase A leads in a reverse run command 3: Phase A is a pulse input and phase B is a direction input. (low input=reverse direction, high input=forward direction) 4: Phase A is a pulse input and phase B is a direction input. (low input=forward direction, high input=reverse direction) 5: Single-phase input 4: Phase A is a pulse input and phase B is a direction input.	0		0		0	0	0
<b>№</b> 10-03	Encoder Feedback Fault Treatment (PGF1, PGF2)	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and stop operation			0		0	0	
<b>⊮</b> 10-04	Detection Time for Encoder Feedback Fault	0.00~10.0 sec	1.0		0		0	0	0
<b>⊮</b> 10-05	Encoder Stall Level (PGF3)	0~120% (0: disable)	115		0	0	0		0
<b>⊮</b> 10-06	Encoder Stall Detection Time	0.0~2.0 sec	0.1		0	0	0		0
<b>⊮</b> 10-07	Encoder Slip Range (PGF4)	0~50% (0: disable)	50		0	0	0		0
≠10-08	Encoder Slip Detection Time		0.5		0	0	0		0
<b>⊮</b> 10-09	Encoder Stall and Slip Error Treatment	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop	2		0	0	0		0
10-10	Mode Selection for UVW	0: Z signal is at the falling edge of U-phase 1: Z signal is at the rising edge of U-phase	0	_	0	_	0	0	0
₩10-11	ASR (Auto Speed Regulation) Control (P) of Zero Speed	0.0~500.0%	100.0	0	0	0	0		0
<b>⊮</b> 10-12	ASR (Auto Speed Regulation) Control (I) of Zero Speed	0.000~10.000 sec	0.100	0	0	0	0		0
<b>⊮</b> 10-13	ASR (Auto Speed Regulation) Control (P) 1 ASR (Auto Speed	0.0~500.0% 0.000~10.000 sec	100.0 0.100	0	0	0	0		0
×10-14	Regulation) Control (I) 1 ASR (Auto Speed	0.000 500.0%	100.0	0	0	0	0		0
x 10-15 x 10-16	Regulation) Control (P) 2 ASR (Auto Speed	0.000~10.000 sec	0.100	0	0	0	0		0
× 10-10	Regulation) Control (I) 2 ASR 1/ASR2 Switch	0.00~400.00Hz (0: disable)	7.00	0	0	0	0		0
≠10-18	Frequency ASR Primary Low Pass Filter Gain	0.000~0.350 sec	0.008	0	0	0	0		0
₩10-19	Zero Speed Gain (P)	0~655.00%e	80.00						0
×10-20	Zero Speed/ASR1 Width Adjustment	0.0~400.00Hz	5.00		0		0		0
<b>∦</b> 10-21	ASR1/ASR2 Width Adjustment	0.0~400.00Hz	5.00		0		0		0
<b>x</b> 10-22	Zero speed Position Holding Time	0.000~65.535 sec	0.250						0
<b>∦</b> 10-23	Filter Time at Zero Speed	0.000~65.535 sec	0.004						0
<b>⊮</b> 10-24	Time for Executing Zero Speed	0: after the brake release set in Pr.02-29 1: after the brake signal input (Pr.02-01~02-08 is set to 42)	0			~			0
<b>⊮</b> 10-25	Elevator Leveling (Zero	0~1000.0%	100.0	0	Ο	Ο	Ο		$\cup$

Call 1(800)985-6929 foortSalestrives.salers@deltaacdrives.com

# Call 1(800)985-6929 the tales rives.com

#### Chapter 4 Parameters | VFD-VL

Pr.	Explanation		Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
	Speed Gain P)								
# 10-20	Speed Integral I)	0~10.000 sec	0.100	0	0	0	0		0
# 10-27	Elevator Starts (Zero Speed Gain P)		100.0	0	0	0	0		0
<b>⊮</b> 10-28	Elevator Starts (Zero Speed Integral I)	0~10.000 sec	0.100	0	0	0	0		0

## 4.1.12 Group 11 Advanced Parameters

Pr.	Explanation		Factory Setting	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
<b>≠</b> 11-00	System Control	Bit 0=0: no function Bit 0=1: ASR Auto tuning, PDFF enable Bit 7=0: no function Bit 7=1: When position control is enabled, it doesn't need to set Pr.07-02 (DC Brake Current Level) Bit 15=0: when power is applied, it will detect the position of magnetic pole again Bit 15=1: when power is applied, it will start from the magnetic pole position of previous power failure	0				0		0
<b>⊮</b> 11-01		0.10~4.00 m/s	1.00				$\bigcirc$		$\bigcirc$
<b>⊮</b> 11-02	Sheave Diameter	100~2000 mm	400				0		0
<b>⊮</b> 11-03	Mechanical Gear Ratio	1~100	1				0		0
<b>⊮</b> 11-04	Suspension Ratio	0: 1:1 1: 2:1	1				0		0
<b>∦</b> 11-05	Inertial Ratio	1~300%	40				$^{\circ}$		0
<b>⊮</b> 11-06	Zero-speed Bandwidth	0~40Hz	10				$\bigcirc$		0
<b>⊮</b> 11-07	Low-speed Bandwidth	0~40Hz	10				0		0
<b>⊮</b> 11-08	High-speed Bandwidth	0~40Hz	10				$\bigcirc$		0
<b>⊮</b> 11-09	PDFF Gain Value	0~200%	30				$\bigcirc$		0
<b>⊮</b> 11-10	Gain for Speed Feed Forward	0~500	0				0		0
₩11-11	Notch Filter Depth	0~20db	0				0		0
₩11-12	Notch Filter Frequency	0.00~200.00Hz	0.00				0		0
₩11-13	Low-pass Filter Time of Keypad Display	0.001~65.535s	0.500	0	0	0	0	0	0
₩11-14	Motor Current at Accel.	50~200%	150						0
₩11-15	Elevator Acceleration	0.20~2.00m/s <sup>2</sup>	0.75						0
11-16	Reserved								
11-17	Reserved								
11-18	Reserved								

Call 1(800)985-6929 footsalestrives.scalers@deltaacdrives.com

### 4.1.13 Group 12 User-defined Parameters

### User-defined Parameters with range from group 00 to 11

✓: The parameter can be set during operation.

Pr.	Explanation (Default Function)	Settings	VF	VFPG	SVC	FOCPG	TOCPG	FOCPM
<b>⊮</b> 12-00	Present Fault Record	0610	0	0	0	0	0	0
<b>⊮</b> 12-01	Present Fault Time of Motor Operation (min.)	0620	0	0	0	0	0	0
<b>⊮</b> 12-02	Present Fault Time of Motor Operation (day)	0621	0	0	0	0	0	0
<b>⊮</b> 12-03	Frequency Command at Present Fault	2120	0	0	0	0	0	0
<b>⊮</b> 12-04	Output Frequency at Preset Fault	2121	0	0	0	0	0	0
<b>⊮</b> 12-05	Output Current at Present Fault	2122	0	0	0	0	0	0
<b>⊮</b> 12-06	Motor Frequency at Present Fault	2123	0	0	0	0	0	0
<b>⊮</b> 12-07	Output Voltage at Present Fault	2124	0	0	0	0	0	0
<b>⊮</b> 12-08	DC-Bus Voltage at Present Fault	2125	0	0	0	0	0	0
<b>⊮</b> 12-09	Output Power at Present Fault	2126	0	0	0	0	0	0
<b>⊮</b> 12-10	Output Torque at Present Fault	2127	0	0	0	0	0	0
<b>⊮</b> 12-11	IGBT Temperature of Power Module at Present Fault	2128	0	0	0	0	0	0
<b>⊮</b> 12-12	Multi-function Terminal Input Status at Present Fault	2129	0	0	0	0	0	0
<b>⊮</b> 12-13	Multi-function Terminal Output Status at Present Fault	212A	0	0	0	0	0	0
<b>⊮</b> 12-14	Drive Status at Present Fault	212B	0	0	0	0	0	0
<b>⊮</b> 12-15	Second Most Recent Fault Record	0611	0	0	0	0	0	0
<b>⊮</b> 12-16	Second Most Recent Fault Time of Motor Operation (min.)	0622	0	0	0	0	0	0
<b>⊮</b> 12-17	Second Most Recent Fault Time of Motor Operation (day)	0623	0	0	0	0	0	0
<b>⊮</b> 12-18	Third Most Recent Fault Record	0612	0	0	0	0	0	0
<b>⊮</b> 12-19	Third Most Recent Fault Time of Motor Operation (min.)	0624	0	0	0	0	0	0
<b>⊮</b> 12-20	Third Most Recent Fault Time of Motor Operation (day)	0625	0	0	0	0	0	0
<b>⊮</b> 12-21	Fourth Most Recent Fault Record	0613	$^{\circ}$	0	0	0	0	0
<b>⊮</b> 12-22	Fourth Most Recent Fault Time of Motor Operation (min.)	0626	0	0	0	0	0	0
<b>⊮</b> 12-23	Fourth Most Recent Fault Time of Motor Operation (day)	0627	0	0	0	0	0	0
<b>⊮</b> 12-24	Fifth Most Recent Fault Record	0614	0	0	0	0	0	0
<b>⊮</b> 12-25	Fifth Most Recent Fault Time of Motor Operation (min.)	0628	0	0	0	0	0	0
<b>⊮</b> 12-26	Fifth Most Recent Fault Time of Motor Operation (day)	0629	0	0	0	0	0	0
<b>⊮</b> 12-27	Sixth Most Recent Fault Record	0615	0	0	0	0	0	0
<b>⊮</b> 12-28	Sixth Most Recent Fault Time of Motor Operation (min.)	062A	0	0	0	0	0	0
<b>⊮</b> 12-29	Sixth Most Recent Fault Time of Motor Operation (day)	062B	0	0	0	0	0	0
<b>⊮</b> 12-30	No Factory Setting							
	No Factory Setting							

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

# 4.1.14 Group 13 View User-defined Parameters

Pr.	Explanation		Factory Setting	٨F	VFPG	SVC	FOCPG	TOCPG	FOCPM
13-00   13-31	View User-defined Parameters	Pr.00-00 to Pr.11-18	-	0	0	0	0	0	0

Call 1(800)985-6929 the tales rives.com

Call 1(800)985-6929 foortaaleestrives.scalers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

### 4.2 Description of Parameter Settings

### 4.2.1 Group 0 User Parameters

	•		
✓: This par	ameter can b	e set during of	operation.

00-00	Identity	Code of t	the AC	Motor Drive	
Control mode	VF	VFPG	svc	FOCPG TQCPG FOCPM	Factory setting: ##
	Settings	Read	d Only		
00-01	Rated C	urrent Di	isplay o	of the AC Motor Drive	
00-01 Control mode	Rated C	urrent Di VFPG	isplay o <b>svc</b>	of the AC Motor Drive FOCPG TQCPG FOCPM	Factory setting: ##

- Pr. 00-00 displays the identity code of the AC motor drive. The capacity, rated current, rated voltage and the max. carrier frequency relate to the identity code. Users can use the following table to check how the rated current, rated voltage and max. carrier frequency of the AC motor drive correspond to the identity code.
- Pr.00-01 displays the rated current of the AC motor drive. By reading this parameter the user can check if the AC motor drive is correct.

		230V Series										
kW	5.5 7.5 11 15 18.5 22 30											
HP	7.5	10	15	20	25	30	40	50				
Pr.00-00	12	14	16	18	20	22	24	26				
Rated Output Current for General Purposes (A)	21.9	27.1	41	53	70	79	120	146				
Rated Output Current for Elevators (A)	25	31	47	60	80	90	150	183				
Max. Carrier Frequency	15kHz 9kł							Ηz				

		460V Series										
kW	5.5	5.5 7.5 11 15 18.5 22 30 37 45 55										
HP	7.5	10	15	20	25	30	40	50	60	75	100	
Pr.00-00	13	15	17	19	21	23	25	27	29	31	33	
Rated Output Current for General Purposes (A)	12.3	15.8	21	27	34	41	60	73	91	110	150	
Rated Output Current for Elevators (A)	14	18	24	31	39	47	75	91	113	138	188	
Max. Carrier Frequency	15kHz 9kHz							6k	Ηz			

## Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

00-0	2 Param	eter Re	eset		
Contro mode	VE	VFPG	SVC	FOCPG TQCPG FOCPM	Factory setting: 0
	Settings	s 0	No Fun	ction	
		1	Read O	nly	
		8	Keypad	Lock	
		9	All para	meters are reset to factory settings (50	Hz, 220V/380V)
		10	All para	meters are reset to factory settings (60	Hz, 220V/440V)
Ш	When it is	set to ?	I, all para	ameters are read only except Pr.00-00~	-00-07 and it can be used
	with passw	vord se	tting for p	bassword protection.	
ш	This paran	neter a	llows the	user to reset all parameters to the factor	ory settings except the fault
	records (P	r.06-16	~ Pr.06-	21).	
	50Hz: Pr.0	1-01 is	set to 50	0Hz and Pr.01-02 is set to 230V or 400\	V.
	60Hz: Pr.0	1-01 is	set to 60	Hz and Pr.01-02 is set to 230Vor 460V	<i>'</i> .
ш	When Pr.0	0-02=0	8, the Kl	PVL-CC01 keypad is locked and only P	r.00-02 can be set. To unlock
	the keypad	l, set P	r.00-02=	00.	
ш	When Pr.0	0-02 is	set to 1,	Pr.00-02 setting should be set to 0 bef	fore setting to other setting.
00-03	S ∕ Start-	up Dis	play Sele	ection	
Contro mode		VFPG	SVC	FOCPG TQCPG FOCPM	Factory setting: 0
	Settings	s 0	Display	the frequency command value. (LED F	)
		1	Display	the actual output frequency (LED H)	
		2	DC BUS	S voltage	
		3	Display	the output current (A)	
		4	Output	voltage	
		5	Multifun	ction display, see Pr.00-04	
	This paran	neter d	etermine	s the start-up display page after power	is applied to the drive.
00-04	Conte	ent of N	/lulti-Fun	ction Display	
Contro mode	VE	VFPG	SVC	FOCPG TQCPG FOCPM	Factory setting: 0

Settings 0 Display the output current in A supplied to the motor

U:Output Current So 0.0Amps

1 Reserved

Call 1(800)985-6929 the tales rives scales @deltaacdrives.com

# Call 1(800)985-6929 footsalestrives.scalers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

00-04 / Content of	Multi-Function Display	
2	Display actual output frequency (H)	U: Actual Freq. So 0.00Hz
3	Display the actual DC BUS voltage in VDC of the AC motor drive	U: DC BUS S@ 255.3Vol t
4	Display the output voltage in VAC of terminals U, V, W to the motor.	U: Output Voltage Sª 0.0Volt
5	Display the power factor angle in $^{\rm o}$ of terminals U, V, W to the motor.	U: Power Angle S <sup>on</sup> 0.0deg
6	Display the output power in kW of terminals U, V and W to the motor.	U: Output Power S® 0.000KW
7	Display the actual motor speed in rpm (enabled when using with PG card).	U:MotorSpeed So•0RPM
8	Display the estimated value of torque in % as it relates to current.	U: Tor que S <b>e</b> 0.0%
9	Display PG position	U: PG Feedback S° 1567
10	Display the electrical angle of drive output	U:Electric Angle Se XXX.Xdeg
11	Display the signal of AUI1 analog input terminal in %. Range 0~10V corresponds to 0~100%. (1.)	U: AUI 1 S@ 0.3%
12	Display the signal of ACI analog input terminal in %.	U: ACI S@ 0.0%
13	Display the signal of AUI2 analog input terminal in 5 %. Range -10V~10V corresponds to 0~100%. (3.)	U: AUI 2 S° 0.3%
14	Display the temperature of heat sink (°C)	U: Heat Sink S° 0.0 C
15	5 Display the temperature of IGBT in °C.	U:IGBT Temp S° 41.3 C
16	Display digital input status ON/OFF (i)	U: DI ON/ OFF Stat Se 0000
17	Display digital output status ON/OFF (o)	U: DO ON/ OFF Stat Se 0000
18	Display multi-step speed	U: Multi-Speed Sa O


Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

## Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

<b>00-04</b> <i>★</i> Content of	Multi-Function Display	
19	The corresponding CPU pin status of digital input (i.)	U: DI Pin Status So FFFF
20	The corresponding CPU pin status of digital output (o.)	U: DO Pin Status So FFFF
21   23	Reserved	
24	Output AC voltage when malfunction (8)	U: Error Vout Se 0. OVac
25	Output DC voltage when malfunction (8.)	U: Error Vbus S@ 256.4Vdc
26	Motor frequency when malfunction (h)	U: Error Ffbk S <b>e</b> 0.00Hz
27	Output current when malfunction (4)	U:Error Current So:00Amps
28	Output frequency when malfunction (h.)	U: Error Fout S@ 0.00Hz
29	Frequency command when malfunction	U:Error Fcmd Son 0.00Amps
30	Output power when malfunction	U:Error Power Sª 0.00KW
31	Output torque when malfunction	U: Error Torque Sª 0.00%
32	Input terminal status when malfunction	U: Error DI State Sª 0000Hex
33	Output terminal status when malfunction	U: Error DO State Sª 0000Hex
34	Drive status when malfunction	U:Error Drive Sa 0000Hex

Ш It is used to display the content when LED U is ON. It is helpful for getting the AC motor drive's status by this parameter.



Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

Terminal	MI8	MI7	MI6	MI5	MI4	MI3	MI2	MI1	REV	FWD
Status	0	0	1	0	0	0	0	1	1	0

0: OFF, 1: ON

MI1: Pr.02-01 is set to 1 (multi-step speed command 1)

MI8: Pr.02-08 is set to 8 (the 1st, 2nd acceleration/deceleration time selection)

If REV, MI1 and MI8 are ON, the value is 0000 0000 1000 0110<sub>2</sub> in binary and 0086H in HEX. At the meanwhile, if Pr.00-04 is set to "14" or "17", it will display "0086" with LED U is ON on the keypad KPVL-CC01. The setting 14 is the status of digital input and the setting 17 is the corresponding CPU pin status of digital input. User can set to 14 to monitor digital input status and then set to 17 to check if the wire is normal.

U: DO	ON/	OFF	St	at
Sa		0001		

Terminal	MO10	MO9	MO8	MO7	MO6	MO5	MO4	MO3	MO2	MO1	MRA	RA	MO10
Status	0	0	0	0	1	0	0	0	0	1	1	0	0

RA: Pr.02-11 is set to 9 (Drive ready).


After applying the power to the AC motor drive, if there is no other abnormal status, the contact will be ON. At the meanwhile, if Pr.00-04 is set to 15 or 18, it will display 0001 with LED U is ON on the keypad. The setting 15 is the status of digital output and the setting 18 is the corresponding CPU pin status of digital output. User can set 15 to monitor the digital output status and then set to 18 to check if the wire if normal.

00-05	✓ User Define	User Defined Coefficient K										
Control mode	VF VFPG	SVC FOCPG TQCPG FOCPM	Factory setting: 0									
	Settings	Digit 4: decimal point number (0 to 3)										
		Digit 0-3: 40 to 9999										

It is used digital setting method

Digital 4: decimal point number (0: no decimal point, 1: 1 decimal point and so on.)

Digit 0-3: 40 to 9999 (the corresponding value for the max. frequency).



Call 1(800)985-6929 the taaledrives.com

### Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

- For example, if use uses rpm to display the motor speed and the corresponding value to the 4pole motor 60Hz is 1800. This parameter can be set to 01800 to indicate that the corresponding value for 60Hz is 1800rpm. If the unit is rps, it can be set 10300 to indicate the corresponding value for 60Hz is 30.0 (a decimal point).
- Only frequency setting can be displayed by the corresponding value.
- After setting Pr.00-05, it won't display the unit of frequency "Hz" after returning to the main menu.

00-06	Softwar	Software Version											
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory setting: Read Only					
	Settings	5	Read Or	ıly									
	Display		#.##										

00-07		Password Input										
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory setting: 0				
	Settings	; 1 <sup>-</sup>	to 9998	and 100	000 to 65	535						
	Display	0~	~2 (time	es of wror	ng passv	vord)						

The function of this parameter is to input the password that is set in Pr.00-08. Input the correct password here to enable changing parameters. You are limited to a maximum of 3 attempts. After 3 consecutive failed attempts, a fault code "Password Error" will show up to force the user to restart the AC motor drive in order to try again to input the correct password.

- When forgetting password, you can decode by setting 9999 and press button twice.
  Please note that all the settings will be set to factory setting.
- Ш

00-08	<b>∦</b> Pass\	word Set						
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory setting: 0
	Settings	; 1 t	o 9998	and 100	00 to 65	535		
	Display	0		No pase	sword se	t or succes	sful input in Pr. 00-	07
		1		Passwo	ord has b	een set		

To set a password to protect your parameter settings.

If the display shows 0, no password is set or password has been correctly entered in Pr.00-07. All parameters can then be changed, including Pr.00-08.

## Call 1(800)985-6929 fbertaaledrives.salers@deltaacdrives.com

### Call 1(800)985-6929 foortaaleestrives.scalers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

The first time you can set a password directly. After successful setting of password the display will show 1.

Be sure to record the password for later use.

To cancel the parameter lock, set the parameter to 0 after inputting correct password into Pr.

00-07.


The password consists of min. 2 digits and max. 5 digits.

How to make the password valid again after decoding by Pr.00-07:

Method 1: Re-input original password into Pr.00-08 (Or you can enter a new password if you

want to use a changed or new one).

Method 2: After rebooting, password function will be recovered.



Call 1(800)985-6929 the tales trives scales @deltaacdrives.com

00-09	Control	Method		
Control mode	VF	VFPG	SVC	FOCPG TQCPG FOCPM
				Factory Setting: 0
	Settings	s 0	V/f o	control
		1	V/f -	Encoder (VFPG)
		2	Sen	sorless vector control (SVC)
		3	FOO	Cvector control + Encoder (FOCPG)
		4	Tore	ue control + Encoder (TQCPG)
		8	FOO	CPM control (FOCPM)
II II	nis param	eter dete	ermines	the control method of the AC motor drive:
Se	etting 0: u	iser can o	design	V/f ratio by requirement and control multiple motors simultaneously
Se	etting 1: L	Jser can	use PC	G card with Encoder to do close-loop speed control.
Se	etting 2: T	o have o	ptimal	control characteristic by auto-tuning.
Se	etting 3: T	o increa	se torq	ue and control speed precisely. (1:1000)
Se	etting 4: T	o increa	se acci	racy for torque control.
Se	etting 8: T	o increa	se torq	ue and control speed precisely. (1:1000). This setting is only for
us	ing with <sub>l</sub>	permane	nt mag	net motor and others are for induction motor.
00-10	<b>∦</b> Spee	d Unit		
Control mode	VF	VFPG	SVC	FOCPG TQCPG FOCPM
				Factory Setting: 0

Settings 0 Hz 1 m/s 2 ft/s

00-11	Output I	Output Direction Selection									
Control mode	VF	VFPG	SVC	<b>FOCPG TQCPG FOCPM</b>							
				Factory	/ Setting: 0						
	Settings	0	FWD:	counterclockwise, REV: clockwise							
		1	FWD:	clockwise, REV: counterclockwise							

## Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

00-1		✓Carri			-					-	16
Cont mod		VF	VFPC	G SV	/C	FOCPG	TQCPG FOCPM			Factory setting:	12
		Settings	; 2	2~15K⊦	Ηz						
Ш	Th	is param	eter d	etermi	nate	es the PV	VM carrier freque	ency of the	AC moto	r drive.	_
							230V/46	<b>60V Series</b>			
		Models	5			5HP 1kW	20-30HP 15-22kW	40-60 30-45		40-100HP 30-75kW	
	Se	etting Ra	nge		~15		2~15kHz	02-09		02~15kHz	
	Fa	ctory Se	tting		12kł	Hz	9kHz	6k⊦	łz	6kHz	
-				rrier uency		coustic Noise	Electromagnetic Noise or Leakage Current	Heat Dissipation	Current Wave		-
				Hz	Sig	nificant	Minimal	Minimal 🛉		<u>†</u>	
				:Hz kHz	- N	linimal	Significant	Significant	-	Ţ	
ш	Fro	om the ta	ıble. w	/e see	that	the PW	M carrier frequen		anificant	influence on the	
							ive heat dissipati		•		
00-′							R) Function				
Cont mod		VF	VFPC	-			TQCPG FOCPM			Factory setting	j: C
		Settings	; 0	Er	nabl	e AVR					
			1	Di	sab	le AVR					
			2	Di	sab	le AVR v	vhen deceleration	n stop			
Ш	lt is	s used to	selec	t the A	VR	mode. A	AVR is used to re	gulate the c	output vol	Itage to the motor	. Fo
	exa	ample, if	V/f cu	Irve is	set	to AC200	0V/50Hz and the	input voltag	ge is from	1 200 to 264VAC,	the
	out	put volta	age wo	on't exe	cess	s AC200	V/50Hz. If the inp	out voltage i	is from 18	30 to 200V, the ou	utpu
	vol	tage to t	he mo	otor and	d the	e input v	oltage will be in c	lirect propo	rtion.		
ш	Wł	nen settir	ng Pr.	00-13 1	to 1	during ra	amp to stop and	used with a	uto accel	./decel. function,	the
	aco	celeratio	n will l	oe smo	ooth	er and fa	aster.				
00-1	14	✓Sour	ce of t	he Ma	ster	Frequer	ncy Command				
Cont mod		VF	VFPC			•	FOCPM			Factory setting	j: 1
		Settings	;	<sup>1</sup> R	S-4	85 serial	communication	or digital ke	ypad (KF	PVL-CC01)	
				<sup>2</sup> E	xter	nal analo	og input (Pr. 03-0	00)			
				3			als input (Pr.04-0				
m	Th	io norom	otor d		-		e's master freque	,			

This parameter determines the drive's master frequency source.

## Call 1(800)985-6929 fbertaaleetrives.salers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

00-	15 <b>,</b> ∕∖S	ource of	the Oper	ation Com	mand			
Cont mo		VFP	G SVC	FOCPG	TQCPG	FOCPM	I	Factory setting: 1
	Sett	ngs	<sup>1</sup> Ext	ernal term	inals			
			<sup>2</sup> RS	-485 serial	commu	nication or	digital keypad (KPVL	-CC01)
Ш	VFD-VL	series is	shipped	without d	gital key	pad and u	sers can use external	terminals or RS-
	485 to c	ontrol the	e operati	on comma	nd.			
Ш	When th	ne LED P	U is light	, the opera	ation con	nmand car	be controlled by the	optional digital

When the LED PU is light, the operation command can be controlled by the optional digita keypad (KPVL-CC01). Refer to appendix B for details.

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

### Call 1(800)985-6929 fberltaaledrives.seelers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

### 4.2.2 Group 1 Basic Parameters

01-00	Maximum Output Frequency								
Control mode	VF	VFPG	SVC	FOCPG T	QCPG	FOCPM		Factory se	etting: 60.00/50.00
	Settings		10.00 t	o 400.00H	z				
~ <b>-</b>									

This parameter determines the AC motor drive's Maximum Output Frequency. All the AC motor drive frequency command sources (analog inputs 0 to +10V, 4 to 20mA and -10V to +10V) are scaled to correspond to the output frequency range.

01-01	1st Out	st Output Frequency Setting								
Control mode	VF	VFPG	SVC	FOCPG TQCPG FOCPM	Factory setting: 60.00/50.00					
	Setting	S	0.00	)~400.00Hz						

It is for the base frequency and motor rated frequency.

This value should be set according to the rated frequency of the motor as indicated on the motor nameplate. If the motor is 60Hz, the setting should be 60Hz. If the motor is 50Hz, it should be set to 50Hz.

01-02	-02 1st Output Voltage Setting							
Control mode	VF	VFPG	SVC	FOCPG TQCPG	FOCPM	Factory Setting: 220.0/440.0		
	Settings	230V	series	0.1 to 255.0V				
		460V	series	0.1 to 510.0V		Factory Setting: 440.0		

It is for the base frequency and motor rated frequency.

This value should be set according to the rated voltage of the motor as indicated on the motor nameplate. If the motor is 220V, the setting should be 220.0. If the motor is 200V, it should be set to 200.0.

There are many motor types in the market and the power system for each country is also difference. The economic and convenience method to solve this problem is to install the AC motor drive. There is no problem to use with the different voltage and frequency and also can amplify the original characteristic and life of the motor.

01-03	2nd Output Frequency Setting							
Control mode	VF VFP	G	Factory setting: 0.50					
	Settings	0.00~400.00Hz						

Call 1(800)985-6929 ther taaleet rives.sellers@deltaacdrives.com

## Call 1(800)985-6929 foortSalestrives.salers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL


01-04	<b>∦</b> 2nd 0	Dutput Voltage Setting		
Control mode	VF	VFPG		Factory Setting: 5.0/10.0
	Setting	s 230V series	0.1 to 255.0V	
		460V series	0.1 to 510.0V	Factory Setting: 10.0
01-05	3rd Out	put Frequency Setting		
Control mode	VF	VFPG		Factory setting: 0.50
	Setting	s 0.00~400.00Hz		
01-06	≠ 3rd C	Output Voltage Setting		
Control mode	VF	VFPG		Factory Setting: 5.0/10.0
	Setting	s 230V series	0.1 to 255.0V	
		460V series	0.1 to 510.0V	
01-07	4th Out	put Frequency Setting		
Control mode	VF	VFPG SVC FOCP	G TQCPG	
	Setting	s 0.00~400.00Hz		Factory Setting: 0.00
01-08	i ∕⁄ 4th C	Output Voltage Setting		
Control mode	VF	VFPG		Factory Setting: 5.0/10.0
	Setting	s 230V series	0.1 to 255.0V	
		460V series	0.1 to 510.0V	

V/f curve setting is usually set by the motor's allowable loading characteristics. Pay special attention to the motor's heat dissipation, dynamic balance, and bearing lubricity, if the loading characteristics exceed the loading limit of the motor.

□ For the V/f curve setting, it should be Pr.01-01≥ Pr.01-03≥ Pr.01-05≥ Pr.01-07. There is no limit for the voltage setting, but a high voltage at the low frequency may cause motor damage, overheat, stall prevention or over-current protection. Therefore, please use the low voltage at the low frequency to prevent motor damage.

Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL



### Call 1(800)985-6929 the tales rives. sales @deltaacdrives.com

### Call 1(800)985-6929 foortSalestrives.scollers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

01-12	✓ Accel. Time 1					
01-14	✓ Accel. Time 2					
01-16	Accel. Time 3					
01-18	Accel. Time 4					
Control mode	VF VFPG SVC FOCPG FOCPM	Factory setting: 3.00				
	Settings 0.00~600.00 sec					

01-13	⊮ Dece	el. Time 1						
01-15	✓ Dece	el. Time 2						
01-17	⊮ Dece	✓ Decel. Time 3						
01-19	⊮ Dece	el. Time 4						
Control mode	VF	VFPG	SVC	FOCPG	FOCPM	Factory setting: 2.00		
	Setting	s 0.0	00~600	.00 sec				


01-20	✓ JOG Acceleration Tim	✓ JOG Acceleration Time						
01-21	✓ JOG Deceleration Tim	/JOG Deceleration Time						
Control		VF VFPG SVC FOCPG FOCPM Factory setting: 1.00						
mode	VF VFPG SVC	FOCPG FOCPM	Factory setting: 1.00					

- The Acceleration Time is used to determine the time required for the AC motor drive to ramp from 0Hz to Maximum Output Frequency (Pr.01-00).
- The Deceleration Time is used to determine the time require for the AC motor drive to decelerate from the Maximum Output Frequency (Pr.01-00) down to 0Hz.
- The Acceleration/Deceleration Time 1, 2, 3, 4 are selected according to the Multi-function Input Terminals settings. The factory settings are acceleration time 1 and deceleration time 1.
- The larger against torque and inertia torque of the load and the accel./decel. time setting is less than the necessary value, it will enable torque limit and stall prevention function. When it happens, actual accel./decel. time will be longer than the action above.

Call 1(800)985-6929 the tales rives sales @deltaacdrives.com


### Call 1(800)985-6929 the tales rives.com

#### Chapter 4 Parameters | VFD-VL



01-2	<b>22</b> <i>★</i> JOG	Frequen	су		
Cont		VFPG	SVC	FOCPG TQCPG FOCPM	Factory setting: 6.00
	Setting	s 0.00	0~400.0	0Hz	
	Both extern	nal termii	nal JOG	and key "JOG" on the keypa	ad can be used. When the jog
	command	is ON, th	e AC m	otor drive will accelerate from	n 0Hz to jog frequency (Pr.01-22).
	When the j	og comn	nand is (	OFF, the AC motor drive will	decelerate from Jog Frequency to zero.
	The used A	Accel./De	cel. tim	e is set by the Jog Accel./De	cel. time (Pr.01-20, Pr.01-21).
	The JOG o	ommand	l can't b	e executed when the AC mo	tor drive is running. In the same way,
	when the J	OG com	mand is	executing, other operation of	commands are invalid except
	forward/rev		nmands quenc	and STOP key on the digita	al keypad.
	01-22 JOG fr	equenc	y		






01-23	🖌 Swit	ch Frequ	ency be	etween 1st/4th Accel/decel	
Control mode	VF	VFPG	SVC	FOCPG FOCPM	Factory setting: 0.00
	Setting	s 0.00	~400.0	0Hz	

Call 1(800)985-6929 foortSalestrives.scollers@deltaacdrives.com

### Call 1(800)985-6929 fbertSaledrives.sellers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

- This parameter selects the frequency point for transition from acceleration/deceleration time 1 to acceleration/deceleration time 4.
- The transition from acceleration/deceleration time 1 to acceleration/deceleration time 4, may also be enabled by the external terminals (Pr. 02-01 to 02-08). The external terminal has priority over Pr. 01-23.



#### 1st/4th Acceleration/Deceleration Switching


01-24	✓ S-curve for Acceleration Departure Time S1							
01-25	✓ S-curve for Acceleration Arrival Time S2							
01-26	✓S-curve for Deceleration Departure Time S3							
01-27	✓ S-curve for Deceleration Arrival Time S4							
01-30	✓ S-curve for Deceleration Arrival Time S5							
Control mode	VF VFPG SVC FOCPG FOCPM	Factory setting: 1.00						
	Settings 0.00~25.00 sec							
01-29	✓ Switch Frequency for S3/S4 Changes to S5							
Control mode	VF VFPG SVC FOCPG M	Factory setting: 0.00						
	Settings 0.00~400.00Hz							

- It is used to give the smoothest transition between speed changes. The accel./decel. curve can adjust the S-curve of the accel./decel. When it is enabled, the drive will have different accel./decel. curve by the accel./decel. time.
- The Actual Accel. Time = selected accel. Time + (Pr.01-24 + Pr.01-25)/2
   The Actual Decel. Time = selected decel. Time + (Pr.01-26 + Pr.01-27 + Pr.01-30\*2)/2
- Pr.01-29 is used to set the switch frequency between S4 and S5 for smooth stop.
- It is recommended to set this parameter to the leveling speed of elevator.

### Call 1(800)985-6929 ther taaleer ives.seelers@deltaacdrives.com

## Call 1(800)985-6929 foortaaleetrives.scalers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL



01-28	Mode S	Selection	when Frequency< Fmin						
Contro mode		VFPG	SVC	Factory setting: 1					
	Settings	0	Output Waiting						
		1	Zero-speed operation						
_		2	Fmin (4th output frequency setting)						
	When the A	C motor	drive is at 0Hz, it will operate by this parameter.						
	When it is s	set to 1 c	r 2, voltage will be output by Fmin corresponding out	out voltage(Pr.01-08).					
01-31	01_31 ✓ Deceleration Time when Operating without RUN								

01.01	Comma	nd				
Control mode	VF	VFPG	SVC	FOCPG	FOCPM	Factory setting: 2.0
	Settings	0.00	~600.0	0 Sec		


The AC motor drive will stop by the setting of this parameter when canceling RUN command. Refer to the figure in Pr.01-29 for details.

Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

02-00	2-wire/3-wire Operation Control										
Control mode	VF	VFPG	SVC	FOCPG	TQCPG FOCPM	Factory setting: 0					
	Settings	0	F	WD/STO	P, REV/STOP						
		1	F	WD/STO	P, REV/STOP (Line Start Lockout)						
		2	R	UN/STO	P, REV/FWD						
		3	R	UN/STO	P, REV/FWD (Line Start Lockout)						
		4	3	-wire							
		5	3	-wire (Lin	e Start Lockout)						

### 4.2.3 Group 2 Digital Input/Output Parameters

- Three of the six methods include a "Line Start Lockout" feature. When line start lockout is enabled, the drive will not run once applying the power. The Line Start Lockout feature doesn't guarantee the motor will never start under this condition. It is possible the motor may be set in motion by a malfunctioning switch.
- This parameter is used to control operation from external terminals. There are three different control modes.



02-01	Multi-Function Input Command 1 (MI1)
02-01	(it is Stop terminal for 3-wire operation)

Factory Setting: 1

Call 1(800)985-6929 foortaalestrives.salers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

02-02	Multi-Function Input Command 2 (MI2)	
		Factory Setting: 2
02-03	Multi-Function Input Command 3 (MI3)	
-		Factory Setting: 3
02-04	Multi-Function Input Command 4 (MI4)	
		Factory Setting: 4
02-05	Multi-Function Input Command 5 (MI5)	
		Factory Setting: 0
02-06	Multi-Function Input Command 6 (MI6)	
		Factory Setting: 0
02-07	Multi-Function Input Command 7 (MI7)	
-		Factory Setting: 0
	Multi-Function Input Command 8 (MI8)	
02-08	When JP1 on the control board is inserted, MI8 functions acc. to Pr02-08.	
	When JP1 on the control board is removed, MI8 is always "enable", independent of Pr02-08.	
		Factory Setting: 40

Settings 0-43

Settings	Control Mode							
Settings	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		
0: no function	0	0	0	0	0	0		
1: multi-step speed command 1	0	0	0	0		0		
2: multi-step speed command 2	0	0	0	0		0		
3: multi-step speed command 3	0	0	0	0		0		
4: multi-step speed command 4	0	0	0	0		0		
5: Reset	0	0	0	0	0	0		
6: JOG command	0	0	0	0		0		
7: acceleration/deceleration speed inhibit	0	0	0	0		0		
8: the 1st, 2nd acceleration/deceleration time selection	0	0	0	0		0		
9: the 3rd, 4th acceleration/deceleration time selection	0	0	0	0		0		
10: EF input (07-28)	0	0	0	0	0	0		
11: Reserved								
12: Stop output	0	0	0	0	0	0		
13: Reserved								
14: Reserved								
15: operation speed command form AUI1	0	0	0	0		0		
16: operation speed command form ACI	0	0	0	0		0		
17: operation speed command form AUI2	0	0	0	0		0		
18: Emergency Stop (07-28)	0	0	0	0	0	0		
19-23: Reserved								
24: FWD JOG command	0	0	0	0		0		
25: REV JOG command	0	0	0	0		0		
26: Reserved								
27: ASR1/ASR2 selection	0	0	0	0		0		
28: Emergency stop (EF1) (Motor coasts to stop)	0	0	0	0	0	0		
29-30: Reserved								

4-40

# Call 1(800)985-6929 food the tales of the second se

#### Chapter 4 Parameters | VFD-VL

Settings	Control Mode							
Settings	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		
31: High torque bias (by Pr.07-21)	0	0	0	0	0	0		
32: Middle torque bias (by Pr.07-22)	0	0	0	0	0	0		
33: Low torque bias (by Pr.07-23)	0	0	0	0	0	0		
34-37: Reserved								
38: Disable write EEPROM function	0	0	0	0	0	0		
39: Torque command direction					0			
40: Enable drive function	0	0	0	0	0	0		
41: Detection of magnetic contactor	0	0	0	0	0	0		
42: Mechanical brake	0	0	0	0	0	0		
43: EPS function	0	0	0	0	0	0		

This parameter selects the functions for each multi-function terminal.

If Pr.02-00 is set to 3-wire operation control. Terminal MI1 is for STOP terminal. Therefore, MI1

is not allowed for any other operation.

Settings	Functions	Descriptions						
0	No Function							
1	Multi-step speed command 1							
2	Multi-step speed command 2	15 step speeds could be conducted through the digital statuses of the 4 terminals, and 17 in total if the master speed and JOG are included. (Refer to Pr. 04-00~04-14)						
3	Multi-step speed command 3	When using communication to control the multi-step speed, setting 1 to 4 will be invalid.						
4	Multi-step speed command 4							
5	Reset	After the error of the drive is eliminated, use this terminal to reset the drive.						
6	JOG Command	JOG operation						
7	Acceleration/deceleration Speed Inhibit	When this function is enabled, acceleration and deceleration is stopped and the AC motor drive starts to accel./decel. from the inhibit point.						
8	The 1 <sup>st</sup> , 2 <sup>nd</sup> acceleration or deceleration time selection	The acceleration/deceleration time of the drive could be selected from this function or the digital statuses of the terminals; there are 4 acceleration/deceleration speeds in total for selection. Bit Bit Descriptions 0 1 0 0 First acceleration/deceleration time When output frequency is less than Pr.01-23 (Switch Frequency between 1st/4th						

Call 1(800)985-6929 fbertaaleetrives.salers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

Settings	Functions	Descriptions					
9	The 3 <sup>rd</sup> , 4 <sup>th</sup> acceleration or deceleration time selection	between 1st/4th Accel/decel), it will output 4 <sup>th</sup> accel/decel time. 0 1 2 <sup>nd</sup> accel./decel. time 1 0 3 <sup>rd</sup> accel./decel. time 1 1 4 <sup>th</sup> accel./decel. time If the drive receives STOP command, it will decelerate to stop by Pr.01-31.					
10	EF Input	External fault input terminal and decelerates by Pr.07-28. (EF fault will be recorded)					
11	Reserved						
12	Stop output	When this function is enabled, the drive output will stop immediately and the motor is free run. When this function is disabled, the drive will accelerate to the frequency setting.					
13-14	Reserved						
15	Operation speed command form AUI1	When the source of operation speed command is set to AUI1, ACI and AUI2 at the same time and two or above terminals are ON, the priority is AUI1>ACI>AUI2. When this function is enabled, the source of the frequency will force to be AUI1.					
16	Operation speed command form ACI	When this function is enabled, the source of the frequency will force to be ACI.					
17	Operation speed command form AUI2	When this function is enabled, the source of the frequency will force to be AUI2.					
18	Emergency Stop	When this function is enabled, the drive will ramp to stop by Pr.07-28 setting.					
19-23	Reserved						
24	FWD JOG command	When this function is enabled, the drive will execute forward Jog command.					
25	REV JOG command	When this function is enabled, the drive will execute reverse Jog command.					
26	Reserved						
27	ASR1/ASR2 selection	ON: speed will be adjusted by ASR 2 setting. OFF: speed will be adjusted by ASR 1 setting.					
28	Emergency stop (EF1) (Motor coasts to stop)	When it is ON, the drive will execute emergency stop. (it will have fault code record)					
29-30	Reserved						
31	High torgue bias	When Pr.07-19 is set to 3:					

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

### Chapter 4 Parameters | VFD-VL


Settings	Functions	Descriptions							
32	Middle torque bias	The high torque bias is according to the Pr.07-21 setting.							
		The middle torque bi	as is according to	the Pr.07-22 setti	ng.				
		The low torque bias	is according to the	e Pr.07-23 setting.					
		31	32	33	Torque Bias				
		OFF	OFF	OFF	No				
		OFF	OFF	ON	07-23				
		OFF	ON	OFF	07-22				
33	Low torque bias	OFF	ON	ON	07- 23+07- 22				
		ON	OFF	OFF	07-21				
		ON	OFF	ON	07- 21+07- 23				
		ON	ON	OFF	07- 21+07- 22				
		ON	ON	ON	07- 21+07- 22+07- 23				
34-37	Reserved	•							
38	Disable write EEPROM function	When this function is	enabled, you car	i't write into EEPR	OM.				
39	Torque command direction	When Pr.07-13=2 ar command direction is			JI, torque				
40	Enable drive function	When this function is enabled, the drive function can be executed. This function can be used with multi-function output (setting Pr.02-11~Pr.02-114 to 15) and (Pr.02-31 and Pr.02-32).							
		This terminal is used ON/OFF.	I for the feedback	signal of magnetic	contactor				
41	Detection of magnetic contactor	When drive receives (setting 15) will be en function is enabled v of mechanical brake	nabled after Pr.02 vithin the detection	-31 time. It will che n time (Pr.02-36).	eck if this If NOT, the fault				
42	Mechanical brake	When drive receives (setting 12) will be en function is enabled v of mechanical brake	nabled after Pr.02 vithin the detection	-29 time. It will che n time (Pr.02-35).	eck if this If NOT, the fault				
43	EPS function	If power is cut during less than low voltage frequency depend or	e level. After powe	r is cut, drive will ı	un by the				

Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

Chapter 4 Parameters | VFD-VL

02-09 Control

mode



This parameter is used for digital input terminal signal delay and confirmation. The delay time is confirmation time to prevent some uncertain interferences that would result in error (except for the counter input) in the input of the digital terminals (FWD, REV and MI1~8). Under this condition, confirmation for this parameter could be improved effectively, but the response time will be somewhat delayed.

### Call 1(800)985-6929 the tales rives. sales @deltaacdrives.com

Chapter 4 Parameters | VFD-VL

Conti mod		VF	VFP	G S	SVC	FOCPO	з тос	PG FO	OCPM			Factory setting: 0
	S	Setting	S	0~	65535							
Ш	This	paran	neter i	is use	d to se	et the i	nput s	ignal l	evel a	nd it w	vor	n't be affected by the
	SIN	K/SOL	JRCE	status	s.							
ш	Bit0	is for	FWD	termir	al, bit	1 is for	REV	termin	al and	l bit2 t	o k	bit9 is for MI1 to MI8.
ш	Use	r can d	change	e term	ninal st	tatus b	y com	munic	ating.			
	For	examp	ole, Ml	l1 is s	et to 1	(multi-	-step s	speed	comm	and 1	), I	MI2 is set to 2 (multi-step speed
	com	mand	2). Th	en th	e forw	ard + 2	nd ste	o spee	ed com	nmanc	1=1	1001(binary)=9 (Decimal). Only
	need	d to se	t Pr.0	2-10=	9 by c	ommu	nicatio	n and	it can	forwa	ard	with 2 <sup>nd</sup> step speed. It doesn't
_	need	d to wi	re any	/ multi	i-funct	ion terr	ninal.					
	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
	MI8	MI7	MI6	MI5	MI4	MI3	MI2	MI1	REV	FWD		
L												
02-1	1	Multi-f	unctio	on Out	put 1	RA, RE	8, RC	(Relay	/1)			
												Factory Setting: 11
02-1	2	/lulti-fi	unctio	n Out	out 2 M	/IRA, N	IRC (I	Relay2	2)			Faster Ostian 1
02-1	3 1	/ulti_fi	Inctio	n Outr	out 3 (	MO1)						Factory Setting: 1
02-1					out 4 (							
02-1							need	to use	with I	EMVL	-IC	DDA01)
02-1					`	, ,						DDA01)
02-1	7	/lulti-fu	unctio	n Out	out 7 (	MO5) (	need	to use	with E	EMVL	-IC	DDA01)
02-1	8	/lulti-fu	unctio	n Out	out 8 (	MO6) (	need	to use	with I	EMVL	-IC	DDA01)
02-1	9	∕lulti-fı	unctio	n Out <sub>l</sub>	out 9 (	MO7) (	need	to use	with E	EMVL	-IC	DDA01)
02-2	20	/lulti-fu	unctio	n Out	out 10	(MO8)	(need	d to us	e with	EMV	L-I	ODA01)
02-2						· · ·	`					ODA01)
02-2	22	/lulti-fu	unctio	n Out	out 12	(MO10	)) (nee	ed to u	ise wit	th EM	VL	-IODA01)
		S-111-		0.1								Factory Setting: 0
	5	Setting	js	0-4	1							

#### Chapter 4 Parameters | VFD-VL

<b>0</b> ///	Control Mode						
Settings	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	
0: No function	0	0	0	0	0	0	
1: Operation indication	0	0	0	0	0	0	
2: Operation speed attained	0	0	0	0	0	0	
3: Desired frequency attained 1 (Pr.02-25, 02-26)	0	0	0	0		0	
4: Desired frequency attained 2 (Pr.02-27, 02-28)	0	0	0	0		0	
5: Zero speed (frequency command)	0	0	0	0		0	
6: Zero speed with stop (frequency command)	0	0	0	0		0	
7: Over torque (OT1) (Pr.06-05~06-07)	0	0	0	0	0	0	
8: Over torque (OT2) (Pr.06-08~06-10)	0	0	0	0	0	0	
9: Drive ready	0	0	0	0	0	0	
10: User-defined Low-voltage Detection (LV)	0	0	0	0	0	0	
11: Malfunction indication	0	0	0	0	0	0	
12: Mechanical brake release (Pr.02-29, Pr.02-30)	Õ	Õ	Õ	Õ	Õ	Õ	
13: Overheat (Pr.06-14)	Ō	Õ	Õ	Ō	Õ	Õ	
14: Brake chopper signal	Ō	Õ	Õ	Ō	Ō	Õ	
15: Motor-controlled magnetic contactor output	Ō	Õ	Õ	Ō	Ō	Õ	
16: Slip error (oSL)	Ō	Õ	Õ	Ō	-	Õ	
17: Malfunction indication 1	Õ	Õ	Õ	Õ	0	Õ	
18: Reserved	0	0	0	0	0	0	
19: Brake chopper output error	0	0	0	0	0	0	
20: Warning output	0	0	0	0	0	0	
21: Over voltage warning	0	0	0	0	0	0	
22: Over-current stall prevention warning	0	0	0				
23: Over-voltage stall prevention warning	0	0	0	0	0	0	
24: Operation mode indication (Pr.00-15≠0)	Ō	Õ	Õ	Ō	Õ	Õ	
25: Forward command	Õ	Õ	Õ	Õ	Õ	Õ	
26: Reverse command	Õ	Õ	Õ	Õ	Õ	Õ	
27: Output when current >= Pr.02-33	Ō	Õ	Õ	Ō	Õ	Õ	
28: Output when current < Pr.02-33	Ō	Õ	Õ	Ō	Ō	Õ	
29: Output when frequency >= Pr.02-34	Ō	Õ	Õ	Ō	Ō	Õ	
30: Output when frequency < Pr.02-34	Ō	Õ	Õ	Ō	Ō	Õ	
31: Power generation direction and status verify	Õ	0	Õ	Õ	Õ	Õ	
32: Power generation direction	Õ	0	Õ	0	Õ	Õ	
33: Zero speed (actual output frequency)	0	0	0	0	0	0	
34: Zero speed with Stop (actual output frequency)	0	0	0	0		0	
35: Fault output option 1 (Pr.06-22)	0	0	0	0	0	0	
36: Fault output option 2 (Pr.06-23)	Ő	0	Ŏ	0	Ő	0	
37: Fault output option 3 (Pr.06-24)	Ő	0	Ŏ	Ő	Ő	0	
38: Fault output option 4 (Pr.06-25)	0	0	0	0	0	0	
39: Reserved							
40: Speed attained (including zero speed)	0	$\cap$	0	0		0	
41: Reserved							

Settings	Functions	Descriptions
0	No Function	
1		Active when there is an output from the drive or RUN command is ON.

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

# Call 1(800)985-6929 the tales rives.com

### Chapter 4 Parameters | VFD-VL

Settings	Functions	Descriptions
2	Operation speed attained	Active when the AC motor drive reaches the output frequency setting.
3	Desired Frequency Attained 1 (Pr.02-25, 02- 26)	Active when the desired frequency (Pr.02-25, 02-26) is attained.
4	Desired Frequency Attained 2 (Pr.02-27, 02- 28)	Active when the desired frequency (Pr.02-27, 02-28) is attained.
5	Zero Speed (frequency command)	Active when frequency command =0. (the drive should be at RUN mode)
6	Zero Speed with Stop (frequency command)	Active when frequency command =0 or stop.
7	Over Torque (OT1) (Pr.06-05~06-07)	Active when detecting over-torque. Refer to Pr.06-05 (over- torque detection selection-OT1), Pr.06-06 (over-torque detection level-OT1) and Pr.06-07 (over-torque detection time-OT1).
8	Over Torque (OT2) (Pr.06-08~06-10)	Active when detecting over-torque. Refer to Pr.06-08 (over- torque detection selection-OT2), Pr.06-09 (over-torque detection level-OT2) and Pr.06-10 (over-torque detection time-OT2).
9	Drive Ready	Active when the drive is ON and no abnormality detected.
10	User-defined Low- voltage Detection	Active when the DC Bus voltage is too low. (refer to Pr.06-00 low voltage level)
11	Malfunction Indication	Active when fault occurs (except Lv stop).
12	Mechanical Brake Release (Pr.02-29, Pr.02-30)	When drive runs after Pr.02-29, it will be ON. This function should be used with DC brake and it is recommended to use contact "b"(N.C).
13	Overheat (Pr.06-14)	Active when IGBT or heat sink overheats to prevent OH turn off the drive. (refer to Pr.06-14)
14	Brake Chopper Signal	The output will be activated when the drive needs help braking the load. A smooth deceleration is achieved by using this function. (refer to Pr.07-00)
15	Motor-controlled Magnetic Contactor Output	Active when the setting is set to 15.
16	Slip Error (oSL)	Active when the slip error is detected (by Pr.05-14).
17	Malfunction indication 1	Activate after 10ms when fault occurs (except Lv stop).

Call 1(800)985-6929 food the tales of the second se

# Call 1(800)985-6929 footsalestrives.scalers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

Settings	Functions	Descriptions						
18	Reserved							
19	Brake Chopper Output Error	Active when the brake chopper error is detected.						
20	Warning Output	Active when the warning is detected.						
21	Over-voltage Warning	Active when the over-voltage is detected.						
22	Over-current Stall Prevention Warning	Active when the over-current stall prevention is detected.						
23	Over-voltage Stall prevention Warning	Active when the over-voltage stall prevention is detected.						
24	Operation Mode Indication	Active when the operation command is controlled by external terminal. (Pr.00-15=1) and PU LED on keypad KPVL-CC01 is OFF.						
25	Forward Command	Active when the operation direction is forward.						
26	Reverse Command	Active when the operation direction is reverse.						
27	Output when Current >= Pr.02-33	Active when current is >= Pr.02-33.						
28	Output when Current < Pr.02-33	Active when current is < Pr.02-33.						
29	Output when frequency >= Pr.02-34	Active when frequency is >= Pr.02-34.						
30	Output when Frequency < Pr.02-34	Active when frequency is < Pr.02-34.						
31	Power Generation Direction and Status Verify	Activate when power generation direction is verified.						
32	Power Generation Direction	Activate when power generation direction is forward run.						
33	Zero Speed (actual output frequency)	Active when the actual output frequency is 0. (the drive should be at RUN mode)						
34	Zero Speed with Stop (actual output frequency)	Active when the actual output frequency is 0 or Stop. (the drive should be at RUN mode)						
35	Fault output option 1	Active when Pr.06-22 is ON.						
36	Fault output option 2	Active when Pr.06-23 is ON.						

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

## Call 1(800)985-6929 the tales rives.com

Chapter 4 Parameters | VFD-VL

Settings	Functions	Descriptions
37	Fault output option 3	Active when Pr.06-24 is ON.
38	Fault output option 4	Active when Pr.06-25 is ON.
39	Reserved	
40	Speed Attained (including zero speed)	Active when the output frequency reaches frequency setting.
41	Reserved	

02-23	🖌 Multi	-outpu	it Directio	n				
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	F	actory setting: 0
	Settings	6	0 ~ 6553	5				
·							 	

This parameter is bit setting. If the bit is 1, the multi-function output terminal will be act with opposite direction. For example, if Pr.02-11 is set to 1 and forward bit is 0, Relay 1 will be ON when the drive is running and OFF when the drive is stop.

The multi-function output terminals MO3~MO10 need to use with EMVL-IODA01.


Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
MO10	MO9	MO8	MO7	MO6	MO5	MO4	MO3	MO2	MO1	MRA	RA

02-24	✓ Serial	Start S	gnal Selection	
Control mode	VF	VFPG	SVC FOCPG FOCPM	Factory setting: 0
	Settings	0	by FWD/REV	
		1	by Enable	

Description: This parameter is used to select serial start method of electromagnetic valve.

## Call 1(800)985-6929 for tales rives.com

#### Chapter 4 Parameters | VFD-VL



02-29	29 Brake Release Delay Time when Elevator Starts									
Control mode	VF	VFPG	SVC	FOCPG TQCPG FOCPM	Factory setting: 0.250					

Call 1(800)985-6929 foortaalestrives.salers@deltaacdrives.com


## Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

Control VF VFPG SVC FOCPG TQCPG FOCPM mode Settings 0.000~65.000 Sec	Factory setting: 0.250									
Settings 0.000, 65,000 See										
Settings 0.000~65.000 Sec										
When the AC motor drive runs after Pr.02-29 delay	time, the corresponding multi-function									
output terminal (12: mechanical brake release) will be ON. This function should be used with										
DC brake.	DC brake.									
When the AC motor drive stops 12 after Pr.02-30 delay time, the corresponding multi-function										
output terminal (12: mechanical brake release) will t	De OFF.									
07-03 DCbrake time during start-up Motor speed/ Output frequency	07-04 DCbrake time during stopping DCbrake									
RUN/STOP	STOP									
Multi-function output (mechanical braker elease)	02-30 Brake engage delay time when elevator stops									
bounce time of mecha	nicalbrake									
Mechanicalbrake engage Mechan	ical brake release brake engage									
I										
02-31 X Turn On Delay of Magnetic Contact between	Drive and Motor									
02-32 X Turn Off Delay of Magnetic Contact between	Drive and Motor									
Control VF VFPG SVC FOCPG TQCPG FOCPM mode	Factory setting: 0.200									
Settings 0.000~65.000 Sec										

After running, it is used with setting 40 of multifunction input terminal and settings 15 of multifunction output terminals. When multifunction output terminals is ON, the drive starts output after Pr.02-31 delay time. When drive stops output, multifunction output terminals will release after Pr.02-32 delay time.

# Call 1(800)985-6929 fberltaalederives.scallers@deltaacdrives.com



Call 1(800)985-6929 thertSaledrives.sealers@deltaacdrives.com

## Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

02-33	🖌 Outpu	✓ Output Current Level Setting for External Terminals										
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	Factory setting: 0					
	Settings	0	~100%									
m w	hon outru	it curror	t = 1	Dr 02 33	it will a	stivato multi fun	tion output terminal (Pr 02 11 to					

When output current is >= Pr.02-33, it will activate multi-function output terminal (Pr.02-11 to Pr.02-22 is set to 27).

When output current is < Pr.02-33, it will activate multi-function output terminal (Pr.02-11 to Pr.02-22 is set to 28).

02-34	🖌 Outp	<ul> <li>Output Boundary for External Terminals</li> </ul>									
Control mode	VF	VFPG	SVC	FOCPG	TQCPG FOCPM		Factory setting: 0.00				
	Setting	s 0	.00~±40	0.00Hz							

When output frequency is >=02-34, it will activate the multi-function terminal (Pr.02-11 to Pr.02-22 is set to 29).

When output frequency is <02-34, it will activate the multi-function terminal (Pr.02-11 to Pr.02-22 is set to 30).

02-35	🖌 Dete	✓ Detection Time of Mechanical Brake									
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory setting: 0.00			
	Settings	s 0	.00 ~ 10	).00 sec							

When mechanical brake function (setting 42 of Pr.02-01~02-08) is not enabled within this

setting time, it will display fault code 64 (MBF) mechanical brake error.


02-36	🖌 Deteo	Detection Time of Magnetic Contactor									
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory setting: 0.00			
	Settings	0	.00 ~ 10	).00 sec							

When mechanical brake function (setting 41 of Pr.02-01~02-08) is not enabled within this setting time, it will display fault code 66 (MCF) mechanical brake error.

Call 1(800)985-6929 the tales rives. sales @deltaacdrives.com

#### Call 1(800)985-6929 foortSalestrives.scales@deltaacdrives.com

Chapter 4 Parameters | VFD-VL



Call 1(800)985-6929 the talestrives.com

## Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

## 4.2.4 Group 3 Analog Input/Output Parameters

03-00	✓Analog Input 1 (AUI1)	
		Factory Setting: 1
03-01	✓Analog Input 2 (ACI)	
		Factory Setting: 0

03-02 Analog Input 3 (AUI2)

m

Factory Setting: 0

Settings	Control Mode							
Setungs	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		
0: No function	0	0	0	0	0	0		
1: Frequency command (torque limit under TQR control mode)	0	0	0	0	0	0		
2: Torque command (torque limit under speed mode)					0			
3: Preload input	0	0	0	0	0	0		
4-5: Reserved								
6: P.T.C. thermistor input value	0	0	0	0	0	0		
7: Positive torque limit				0		0		
8: Negative torque limit				0		0		
9: Regenerative torque limit				0		0		
10: Positive/negative torque limit				0		0		
11: Preload Input						0		

When it is frequency command or TQR speed limit, the corresponding value for 0~± 10V/4~20mA is 0 – max. output frequency(Pr.01-00)

When it is torque command or torque limit, the corresponding value for 0~±10V/4~20mA is 0 – max. output torque (Pr.07-14).

When it is torque compensation, the corresponding value for 0~±10V/4~20mA is 0 – rated torque.

Call 1(800)985-6929 the taaledrives.sales@deltaacdrives.com

## Call 1(800)985-6929 for talestrives.sales@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

#### Positive to rque 03-00~02=7 03-00~02=9 Positive to raue limit Regenerative torque limit 03-00~02=10 Positive/negative torque limit Reverse Forward 03-00~02=10 \_\_ 03-00~02=9 Positive/negative torque limit Regenerative torque limit 03-00~02=8 -Neg ative to rque limit Neg ative Torgue 07-19: Source of torgue offset 03-00~02: Analog input selections (AUI1/ACI/AUI2) 03-03~05: Analog input bias (AUI1/ACI/AUI2) 03-06~08: AUI1/ACI/AUI2 bias mode Torque Analog input Analog input gain 07 - 19 = 1for preload 03-00~02=3 03-09~11 +/. Bias mode 03-06~08 Bias 03-03~05 03-03 Analog Input Bias 1 (AUI1) Control Factory setting: 0.0 VF VFPG SVC FOCPG TQCPG FOCPM mode Settings -100.0~100.0% m It is used to set the corresponding AUI1 voltage of the external analog input 0.

03-04	<b>∦</b> Anal	Analog Input Bias 1 (ACI)								
Control mode	VF	VFPG	SVC	FOCPG TQCPG FOCPM	Factory setting: 0.0					
	Setting	s -1	00.0~1	00.0%						

## Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

It is used to set the corresponding ACI voltage of the external analog input 0.


03-05		g Input I	Bias 1 (	AUI2)					—
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	I	Factory setting: 0	0.0
	Settings	; -1	00.0~1	00.0%					
🕮 lti	s used to	set the	corresp	onding A	UI2 volt	age of the ex	kternal analog inp	ut 0.	
🕮 Th	e relatior	n betwee	n exter	nal input	voltage/	current and	setting frequency	is equal to -10~+	10V
(4-	-20mA) c	orrespor	ids to 0	-60Hz.					
03-06	🖌 Posit	ive/nega	ative Biz	as Mode	(AUI1)				
Control mode	VF	VFPG	SVC		TQCPG	FOCPM		Factory setting:	0
03-07	N Posit	ive/nega	ative Bia	as Mode	(ACI) (c	an be set to	0 or 1 only)		
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory setting:	0
03-08	🖋 Posit	tive/nega	ative Bia	as Mode	(AUI2)				
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory setting:	0
	Settings	0	Zer	o bias					
		1	Ser	ve bias a	is the ce	nter, lower t	han bias=bias		
		2	Ser	ve bias a	is the ce	nter, greater	than bias=bias		
		3		e absolute ipolar)	e value o	of the bias vo	oltage while servin	ig as the center	
		4	Ser	ve bias a	is the ce	nter (unipola	ar)		

In a noisy environment, it is advantageous to use negative bias to provide a noise margin. It is recommended NOT to use less than 1V to set the operating frequency.

Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

#### Call 1(800)985-6929 the tales rives.seles@deltaacdrives.com

# Chapter 4 Parameters | VFD-VL



03-09~03-11 gain is positive

0 Zerobias

1 Serve bias as the center, lower than bias = bias

- 2 Serve bias as the center, greater than bias=bias
- The absolute value of the bias voltage
- <sup>3</sup> while serving as the center (unipolar)
- 4 Serve bias as the center (unipolar)

03-09	✓ Analog Input Gain 1 (AUI1)									
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	Factory setting:	100.0		
03-10	✓ Analog Input Gain 1 (ACI)									
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	Factory setting:	100.0		
03-11	🖌 Ana	log Input	Gain 1	(AUI2)						
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	Factory setting: 2	100.0		
	Settings 0.0~500.0%									

# Parameters 03-03 to 03-11 are used when the source of frequency command is the analog voltage/current signal.

03-12	🖌 Ana	✓ Analog Input Delay Time (AUI1)							
Control mode	VF	VFPG	SVC	FOCPG TQCPG	FOCPM	Factory setting: 0.01			
03-13	03-13 / Analog Input Delay Time (ACI)								
Control mode	VF	VFPG	SVC	FOCPG TQCPG	FOCPM	Factory setting: 0.01			

03-14	🖌 Ana	✓ Analog Input Delay Time (AUI2)										
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory setting: 0.01				
	Setting	s 0.	00 to 2	00 sec								

# Interferences commonly exist with analog signals, such as those entering AUI, ACI and AUI2. These interferences constantly affect the stability of analog control and using the Input Noise Filter will create a more stable system.

#### Call 1(800)985-6929 foortSalestrives.scollers@deltaacdrives.com

## Call 1(800)985-6929 foortSalestrives.salers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

If Pr. 03-14 is large, the control will be stable, yet the response to the input will be slow. If Pr.

03-14 is small, the control may be unstable, yet the response to the input will fast.

03-15	🖌 Loss	of the A	CI Sigr	nal							
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPN	l		F	actory se	etting: 0
	Settings	0	Dis	able							
		1	Co	ntinue op	peration	at the la	st freque	ncy			
		2	De	aalarata	to oton						
		2	De	celerate	to stop						
		3	Sto	p immed	diately ar	nd displa	ay E.F.				
🕮 Th	nis parame	eter dete	rmines	the beh	avior wh	en ACI	(4-20mA)	) is lost.			
03-16	Reserve	d									
03-17	🖌 Analo	og Outpu	t Selec	ction 1							
03-20		og Outpu									
	<i>// /</i>	-g o aipo							6	actory S	otting: 0
	O attine are	0	00						1	actory 3	eung. u
	Settings	0-	20								
Д											
		Setting	js		-	VE	VERC		I Mode	TOCRG	FOCPM
0: Output f	requency (		gs			VF	VFPG	Contro SVC	I Mode FOCPG		FOCPM
0: Output f 1: Frequen		Hz)	<u>js</u>				_	SVC	FOCPG		
	icy commai	Hz) nd (Hz)	js			0	0	SVC	FOCPG	0	0
1: Frequen	icy comman beed (RPM	Hz) nd (Hz) )	js			0	0	SVC () ()	FOCPG	0	0
1: Frequen 2: Motor sp 3: Output o 4: Output v	beed (RPM current (rms voltage	Hz) nd (Hz) )	js			0 0 0 0		SVC 0 0 0 0 0 0	<b>FOCPG</b>		
1: Frequen 2: Motor sp 3: Output of 4: Output v 5: DC Bus	ocy comman peed (RPM current (rms voltage Voltage	Hz) nd (Hz) )	js			0 0 0 0 0		SVC 0 0 0 0 0 0	FOCPG 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		
1: Frequent 2: Motor sp 3: Output of 4: Output of 5: DC Bus 6: Power fa	ocy comman peed (RPM current (rms voltage Voltage	Hz) nd (Hz) )	js			0 0 0 0 0		SVC 0 0 0 0 0 0 0 0	FOCPG 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		
1: Frequent 2: Motor sp 3: Output of 4: Output of 5: DC Bus 6: Power fa 7: Power	ocy comman beed (RPM current (rms voltage Voltage actor	Hz) nd (Hz) )	js					SVC 0 0 0 0 0 0 0 0 0	FOCPG 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		
1: Frequen 2: Motor sp 3: Output of 4: Output of 5: DC Bus 6: Power fa 7: Power 8: Output t	ocy comman beed (RPM current (rms voltage Voltage actor	Hz) nd (Hz) )	gs 					SVC 0 0 0 0 0 0 0 0 0 0 0 0 0	FOCPG 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		
1: Frequen 2: Motor sp 3: Output of 4: Output of 5: DC Bus 6: Power fa 7: Power 8: Output t 9: AUI1	ocy comman beed (RPM current (rms voltage Voltage actor	Hz) nd (Hz) )	gs 					SVC 0 0 0 0 0 0 0 0 0 0 0 0 0	FOCPG 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		
1: Frequen 2: Motor sp 3: Output of 4: Output of 5: DC Bus 6: Power fa 7: Power 8: Output t 9: AUI1 10: ACI	ocy comman beed (RPM current (rms voltage Voltage actor	Hz) nd (Hz) )	gs					<b>SVC</b> 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	FOCPG 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		
1: Frequen 2: Motor sp 3: Output of 4: Output of 5: DC Bus 6: Power fa 7: Power 8: Output t 9: AUI1 10: ACI 11: AUI2	cy commai peed (RPM current (rms voltage Voltage actor orque	Hz) nd (Hz) )	gs					SVC           0	FOCPG 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		
1: Frequen 2: Motor sp 3: Output of 4: Output of 5: DC Bus 6: Power fa 7: Power 8: Output t 9: AUI1 10: ACI 11: AUI2 12: q-axis	cy commai peed (RPM current (rms voltage Voltage actor orque	Hz) Hz) ) ) )	gs					SVC           0	FOCPG 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		
1: Frequen 2: Motor sp 3: Output of 4: Output of 5: DC Bus 6: Power fa 7: Power 8: Output t 9: AUI1 10: ACI 11: AUI2 12: q-axis 13: q-axis	cy commai peed (RPM current (rms voltage Voltage actor orque current feedback vo	Hz) Hz) ) ) )	gs					SVC           0	FOCPG 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		
1: Frequen 2: Motor sp 3: Output of 4: Output of 5: DC Buss 6: Power fa 7: Power 8: Output t 9: AUI1 10: ACI 11: AUI2 12: q-axis 14: d-axis	icy comman beed (RPM current (rms /oltage Voltage actor orque current feedback v. current	Hz) hd (Hz) ) ) alue	js					SVC           0	FOCPG           O		
1: Frequen 2: Motor sp 3: Output of 5: DC Bus 6: Power fa 7: Power 8: Output t 9: AUI1 10: ACI 11: AUI2 12: q-axis 13: q-axis 14: d-axis	act command beed (RPM surrent (rms roltage Voltage actor orque current feedback v. current feedback v.	Hz) hd (Hz) ) ) alue	JS					SVC           0	FOCPG           O		
1: Frequen 2: Motor sp 3: Output of 4: Output of 5: DC Bus 6: Power fa 7: Power 8: Output t 9: AUI1 10: ACI 11: AUI2 12: q-axis 14: d-axis 15: d-axis 16: q-axis	icy commainable (RPM) surrent (rms voltage voltage actor orque current feedback v. current feedback v. voltage	Hz) hd (Hz) ) ) alue	js					SVC           0	FOCPG           O		
1: Frequen 2: Motor sp 3: Output of 4: Output of 5: DC Bus 6: Power fa 7: Power 8: Output t 9: AUI1 10: ACI 11: AUI2 12: q-axis 13: q-axis 15: d-axis 17: d-axis	icy commainable (RPM) surrent (rms voltage voltage actor orque current feedback v. current feedback v. voltage	Hz) hd (Hz) ) ) alue	js					SVC           0	FOCPG           O		

## Call 1(800)985-6929 fbertaaledrives.salers@deltaacdrives.com

## Call 1(800)985-6929 fbertSalestrives.szelers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

03-18	🖌 Analo	✓ Analog Output Gain 1									
03-21	🖌 Analo	og Outpu	t Gain	2							
Control mode	VF	VFPG	SVC	FOCPG TQCPG FO	СРМ	Factory setting: 100.0					
	Settings	0 1	to 200.	)%							

This parameter is set the corresponding voltage of the analog output 0.

03-19	🖌 Analo	oa Outpu	t Value	e in REV [	Directior	ו 1			—
03-22	-	• ·		e in REV [					
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory setting:	0
	Settings	0	Abs	solute valu	ue in RE	V directior	า		_
		1	Out	tput 0V in	REV di	rection			
		2	Ena	able outpu	ıt voltag	e in REV c	lirection		
		ov	10V free 03-19=	quency	ov	03-19=1		10V frequency 03-19=2	
				Selectio	on for the a	analog outpu	t direction		
03-23	Analog	Input Typ	e (AU	1)					
03-24	Analog	Input Typ	e (AU	12)					
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory setting:	0
	Settings	0	Bip	olar (±10\	/)				_
		1	Uni	polar (0-1	0V)				

When setting to 0 and Pr.03-00=1 or 2, AUI can decide the operation direction.

When setting to 1 and Pr.03-00=1, the operation direction can be set by FWD/REV terminal.

When setting to 1 and Pr.03-00=2, the operation direction can be set by setting 39 of Pr.02-01 to Pr.02-08.

#### Call 1(800)985-6929 the taaled rives.com

#### Chapter 4 Parameters | VFD-VL

04-00	✓Zero Step Speed Frequency									
04-01	✓ 1st Step Speed Frequency									
04-02	✓ 2nd Step Speed Frequency									
04-03	✓ 3rd Step Speed Frequency									
04-04	✓4th Step Speed Frequency									
04-05	✓ 5th Step Speed Frequency									
04-06	✓ 6th Step Speed Frequency									
04-07	✓7th Step Speed Frequency									
04-08	✓ 8th Step Speed Frequency									
04-09	✓ 9th Step Speed Frequency									
04-10	✓ 10th Step Speed Frequency									
04-11	✓11th Step Speed Frequency									
04-12	✓ 12th Step Speed Frequency									
04-13	✓ 13th Step Speed Frequency									
04-14	✓ 14th Step Speed Frequency									
04-15	✓ 15th Step Speed Frequency									
Control mode	VF VFPG SVC FOCPG FOCPM Factory setting: 0.00									
	Settings 0.00 to 400.00 Hz									

#### 4.2.5 Group 4 Multi-Step Speed Parameters

The Multi-Function Input Terminals (refer to Pr.02-01 to 02-08) are used to select one of the AC motor drive Multi-step speeds. The speeds (frequencies) are determined by Pr.04-00 to 04-15 as shown above.

Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

## Call 1(800)985-6929 the tales rives.com

Chapter 4 Parameters | VFD-VL

05	-00	Motor Auto	Tuning	
	ntrol ode	VF		Factory setting: 0
		Settings	0	No function
			1	Rolling test (Rs, Rr, Lm, Lx, no-load current)
			2	Static Test
	Sta	arting auto tu	uning by	pressing RUN key and it will write the measure value into Pr.05-05 to
	Pr.	.05-09 (Rs, F	Rr, Lm, L	.x, no-load current).
Ш	Th	e steps to A	UTO-Tu	ning are: (when setting to 1)
	1.	Make sure	e that all	the parameters are set to factory settings and the motor wiring is
		correct.		
	2.	Make sure	e the mo	tor has no-load before executing auto-tuning and the shaft is not
		connected	to any l	belt or gear motor. It is recommended to set to 2 if the motor can't
		separate f	rom the	load.
	3.	Fill in Pr.0	1-02, Pr	.01-01, Pr.05-01, Pr.05-02, Pr.05-03 and Pr.05-04 with correct values.
		Refer to m	notor cap	pacity to set accel./decel. time.
	4.	When Pr.0	05-00 is	set to 1, the AC motor drive will execute auto-tuning immediately after
		receiving	a "RUN'	' command. (NOTE: the motor will run!)
	5.	After exec	uting, pl	ease check if all values are filled in Pr.05-05 to Pr.05-09.
	6.	Equivalen		
			/	Rs Lx 005-06 Pr.05-09
		Vs		
				Pr.05-08 Pr.05-07
		•	Fauiv	alent circuit for VFD-VL series
Ĥ	If E	Pr 05-00 ie e		t needs to input Pr.05-05.
10101		1.00-00 18 8	οι ιυ <b>2</b> , Π	110003 to input 11.00-00.
	€	ΝΟΤΕ		

## 4.2.6 Group 5 IM Parameters

- 1. In torque/vector control mode, it is not recommended to have motors run in parallel.
- It is not recommended to use torque/vector control mode if motor rated power exceeds the rated power of the AC motor drive.
- 3. The no-load current is usually 20~50% X rated current.

Call 1(800)985-6929 foor tales states @deltaacdrives.com

## Call 1(800)985-6929 fbertSaledrives.sellers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

- The rated speed can't be larger or equal to 120f/p. (f: output frequency Pr.01-01, p: Number of Motor Poles Pr.05-04)
- After the tuning, user needs to activate the drive again to make it operate if the source command of Auto-tuning comes from external terminal,

05-01	Full-load											
Control mode	VF	VFPG	SVC	FOCPG TQCPG	Factory setting: #.##							
	Settings	s (4	0 to 12	0%)*Pr.00-01 Amps								

This value should be set according to the rated frequency of the motor as indicated on the motor nameplate. The factory setting is 90% X rated current.

Example: if the rated current for 7.5hp (5.5kW) models is 25A and the factory setting is 22.5A. In this way, the current range will be from 10A (25\*40%) to 30A (25\*120%).

05-02	Rated Power of Motor								
Control mode	SVC FOCF	PG TQCPG	Factory setting: #.##						
	Settings	0.00 to 655.35 kW	Factory Setting: #.##						

It is used to set rated power of the motor. The factory setting is the power of the drive.

05-03	Rated Sp	Rated Speed of Motor (rpm)							
Control mode	VFPG	SVC FOCPG TQCPG	Factory setting: 1710						
	Settings	0 to 65535 rpm							

It is used to set the rated speed of the motor and need to set according to the value indicated on the motor nameplate.

05-04	Number	of Moto	r Poles			
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	Factory setting: 4
	Settings	2	to 48			

It is used to set the number of motor poles (must be an even number).

05-05	No-load Current of Motor								
Control mode	VFPG	SVC FOCPG TQCPG	Factory setting: #.##						
	Settings	0 to 100%							

The factory setting is 40% X rated current.

#### Call 1(800)985-6929 fbertSalestrives.szellers@deltaacdrives.com

## Call 1(800)985-6929 fberltaaledrives.seelers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

-								
05-06	Rs of M	Notor						
Control mode	SVC	FOCPG	TQCPG				Factory setting:	0.000
05-07	Rr of I	Motor						
Control mode	SVC	FOCPG	TQCPG				Factory setting:	0.000
	Setting	js O	.000~65.53	5Ω				
05-08	Lm of	Motor						
Control mode	SVC	FOCPG	TQCPG				Factory setting	ng: 0.0
05-09	Lx of N	/lotor						
Control mode	SVC	FOCPG	TQCPG				Factory settin	ng: 0.0
	Setting	js O	.0~6553.5r	ιH				
05-10	✓ Tore	que Com	pensation 1	ime Constant				
Control mode	SVC						Factory setting:	0.020
	Setting	js 0	.001 to 10.	000 sec				
05-11	🖌 Slip	Compen	sation Time	Constant				
Control mode	SVC						Factory setting:	0.100
	Setting	js 0	.001 to 10.	000 sec				
S S	etting Pr	.05-10 ar	ld Pr.05-11	change the resp	onse time for	the com	pensation.	
🕮 W	hen Pr.	05-10 and	l Pr.05-11 a	re set to 10 seco	nds, its resp	onse time	e for the compens	ation
w	ill be the	longest.	But if the s	ettings are too sh	ort, unstable	system n	nay occur.	
05-12	✔ Tor	aue Com	pensation (	ain				

Control mode	VF	VFPG	Factory setting: 0
	Settings	0 to10	

This parameter may be set so that the AC motor drive will increase its voltage output to obtain a higher torque.

05-13	✓ Slip Compensation Gain					
Control mode	SVC	VFPG	SVC	Factory setting: 0.00		
	Settings	0.0	00 to10.00			

Call 1(800)985-6929 foortSalestrives.salers@deltaacdrives.com

#### Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

- When the asynchronous motor is driven by the drive, the load and slip will be increased. This parameter can be used to correct frequency and lower the slip to make the motor can run near the synchronous speed under rated current. When the output current is larger than the motor no-load current, the drive will compensate the frequency by Pr.05-13 setting. If the actual speed is slower than expectation, please increase the setting and vice versa.
- It is only valid in SVC mode.

05-14	🖌 Slip D	eviatio	on Level		
Control mode	VFPG	SVC	FOCPG		Factory setting: 0
	Settings	(	0 to 1000%	6 (0: disable)	
05-15	🖌 Detec	tion tir	ne of Slip	Deviation	
Control mode	VFPG	SVC	FOCPG		Factory setting: 1.0
	Settings	(	0.0 to 10.0	sec	
05-16	r Over S	Slip Tre	eatment		
Control mode	VFPG	svc	FOCPG		Factory setting: 0
	Settings	(	0 War	n and keep operation	
			1 War	n and ramp to stop	
		:	2 War	n and coast to stop	

Pr.05-14 to Pr.05-16 are used to set allowable slip level/time and over slip treatment when the

drive is running.

05-17	🖌 Huntii	ng Gain		
Control mode	VF	VFPG	SVC	Factory setting: 2000
	Settings	0 t	o 10000 (0: disable)	

The motor will have current wave motion in some specific area. It can improve this situation by setting this parameter. (When it is high frequency or run with PG, Pr.05-17 can be set to 0. when the current wave motion happens in the low frequency, please increase Pr.05-17.)

05-18	Accum	Accumulative Motor Operation Time (Min.)					
Control mode	VF	VFPG	SVC	FOCPG	TQCPG FOCPM	Factory setting: 00	
	Setting	s 00	) to143	9 min			

Call 1(800)985-6929 ther taaleet rives.sellers@deltaacdrives.com

## Call 1(800)985-6929 fbertaaledrives.salers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

05-19	Accur	Accumulative Motor Operation Time (Day)						
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory setting: 00
	Setting	s 00	) to 655	535 day				

Pr. 05-18 and Pr.05-19 are used to record the motor operation time. They can be cleared by

setting to 00 and time which is less than 60 seconds will not be recorded.

05-20	✓ Core Loss Compensation						
Control mode	SVC		Factory setting: 10				
	Settings	0 to 250%					

05-21	Accu	Accumulative Drive Power-on Time (Min.)					
Control mode	VF	VFPG	SVC	FOCPG TQCPG FOCPM	Factory setting: 00		
	Setting	ls 00	) to 143	39 min			
		Accumulative Drive Power-on Time (day)					
05-22	Accu	mulative [	Drive P	ower-on Time (day)			
05-22 Control mode	Accu VF	mulative [ VFPG		ower-on Time (day) FOCPG TQCPG FOCPM	Factory setting: 00		

## Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

06-00	Low Vol	tage Lev	/el			
Control mode	VF	VFPG	svc	FOCPG TQCPG	FOCPM	Factory Setting: 180.0/360.0
	Settings	230V	series	160.0~220.0Vdd	:	
		460V	series	320.0~440.0Vdd	:	
🕮 lti	s used to	set the	Lv leve	el.		,
			<b>\ ←</b> i	nput voltage		
			$\backslash$			
				<u>\</u>	/	30V(60V)
			Pr. 06-0	° 📉		
06-01	✓ Phase	e-loss P	rotectio	on		
Control mode	VF	VFPG	SVC	FOCPG TQCPG	FOCPM	Factory setting: 2
	Settings	0	Wa	arn and keep oper	ation	
		1	Wa	arn and ramp to s	ор	
		2	Wa	arn and coast to s	top	
🕮 Iti	s used to	set the	nhase-	loss treatment. T	he nhase-lo	ss will effect driver's control
	aracterist					
CI	aracterist	ic and ii	ie.			
00.00	✔ Over-	Current	Stall Pr	evention during A		
06-02	,	ounon		oronaon damig,		
Control mode	VF	VFPG	SVC			Factory setting: 00
	Settings	0	)~250%	6 (00: disable)		
Du Du	uring acce	eleration	, the A	C drive output cur	rent may inc	crease abruptly and exceed the value
	-				-	sive load on the motor. When this
24	concu by	1.00-0				solve load on the motor. When this


#### - - -

function is enabled, the AC drive will stop accelerating and keep the output frequency constant until the current drops below the maximum value.

## Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

#### Call 1(800)985-6929 foortaaleestrives.scalers@deltaacdrives.com


#### Chapter 4 Parameters | VFD-VL



06-03	✔Over-curre	✓ Over-current Stall Prevention during Operation					
Control mode	VF VFPC	SVC	Factory setting: 00				
	Settings	00 to 250% (00: disable)					

If the output current exceeds the setting specified in Pr.06-03 when the drive is operating, the drive will decrease its output frequency by Pr.06-04 setting to prevent the motor stall. If the output current is lower than the setting specified in Pr.06-03, the drive will accelerate (by

Pr.06-04) again to catch up with the set frequency command value.





06-04	✓Accel	./Decel.	Time Selection of Stall Prevention at constant speed	
Control mode	VF	VFPG	SVC	Factory setting: 0
	Settings	0	by current accel/decel time	
		1	by the 1st accel/decel time	
		2	by the 2nd accel/decel time	
		3	by the 3rd accel/decel time	
		4	by the 4th accel/decel time	
		5	by auto accel/decel time	

#### Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

## Call 1(800)985-6929 the tales rives.com

#### Chapter 4 Parameters | VFD-VL

It is used to set the accel./decel. time selection when stall prevention occurs at constant speed.

06-05	r Over-	✓ Over-torque Detection Selection (OT1)							
Control mode	VF	VFPG	SVC	FOCPG TQCPG FOCPM	Factory setting: 0				
	Settings	0	С	ver-Torque detection disabl	ed.				
		1		Over-torque detection during constant speed operation, continue to operate after detection					
		2		ver-torque detection during peration after detection	constant speed operation, stop				
	3			ver-torque detection during etection	operation, continue to operate after				
		4		ver-torque detection during	operation, stop operation after				

06-06	r∕Over-t	VOver-torque Detection Level (OT1)					
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	Factory setting: 150
	Settings	Settings 10 to 250%					
06-07	r Over-t	orque D	etectior	n Time (C	DT1)		
Control mode	VF	VF VFPG SVC FOCPG TQCPG FOCPM Factory setting: 0.1					
	Settings	0.	0 to 60.	0 sec			

06-08 Control mode	VF	VFPG	SVC	n Selection (OT2) FOCPG TQCPG FOCPM	Factory setting: 0
	Settings	0	С	ver-Torque detection disabled.	
		1		ver-torque detection during constant perate after detection	speed operation, continue to
		2		ver-torque detection during constant peration after detection	speed operation, stop
		3		ver-torque detection during operation etection	n, continue to operate after
		4		ver-torque detection during operation	n, stop operation after

06-09	✓Over-	VOver-torque Detection Level (OT2)								
Control mode	VF	VFPG	SVC	FOCPG TQCP	G FOCPM	Factory setting: 150				
	Settings	1	0 to 250	1%						

Call 1(800)985-6929 fbertaaleetrives.salers@deltaacdrives.com

#### Call 1(800)985-6929 for tales rives.sales@deltaacdrives.com


Chapter 4 Parameters | VFD-VL

06-1	0 <b>∕</b> Over	✓ Over-torque Detection Time (OT2)							
Contro mode	VI	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory setting: 0.1	
	Setting	s 0.	.0 to 60	0 sec					
Ĥ	Pr.06-05 a	nd Pr.06	-08 dete	ermine th	e operat	ion mode	of the dri	ve after the over-torque is	

detected via the following method: if the output current exceeds the over-torque detection level (Pr.06-06) and also exceeds the Pr.06-07 Over-Torque Detection Time, the fault code

"OT1/OT2" is displayed. If a Multi-Functional Output Terminal is to over-torque detection, the

output is on. Please refer to Pr.02-11~02-22 for details.



06-11	🖌 Current L	✓ Current Limit								
Control mode	FOCPG TQC	PG FOCPM	Factory setting: 200							
	Settings	0 to 250%								

It is used to set the current limit.

06-12	Electron	lectronic Thermal Relay Selection								
Control mode	VF	VFPG	SVC	FOCPG TQCPG	FOCPM	Factory setting: 2				
	Settings	0	In	verter motor						
		1	St	andard motor						
		2	Di	isabled						

It is used to prevent self-cooled motor overheats under low speed. User can use electrical thermal relay to limit driver's output power.

06-13	<b>⊮</b> Electr	onic The	rmal C	haracteri	stic	
Control mode	VF	VFPG	SVC	FOCPG	TQCPG FOCPM	Factory setting: 60.0
	Settings	30	).0 to 6	00.0 sec		


Call 1(800)985-6929 for talestrives.sales@deltaacdrives.com

#### Call 1(800)985-6929 fbertaaledrives.salers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

The parameter is set by the output frequency, current and operation time of the drive for activating the l<sup>2</sup>t electronic thermal protection function. The function will be activated for the

150% \* setting current for the setting of Pr.06-13.



06-14	🖌 Heat	✓ Heat Sink Over-heat (OH) Warning							
Control mode	VF	VFPG	SVC	FOCPG TQCP	G FOCPM		Factory setting: 85.0		
	Settings	<b>s</b> 0.	0 to 11	0.0 °C					


06-15	✓ Stall	Prevent	ion Limit Level	
Control mode	VF	VFPG	SVC	Factory setting: 50
	Settings	s 0	to 100% (refer to Pr.06-02, Pr.06-03)	

When the operating frequency is larger than Pr.01-01, Pr06-02=150%, Pr. 06-03=100% and Pr.

06-15=80%:

Stall Prevention Level during acceleration = 06-02x06-15=150x80%=120%.

Stall Prevention Level at constant speed= 06-03x06-15=100x80%=80%.



Call 1(800)985-6929 ther taaleer ives.seelers@deltaacdrives.com

# Call 1(800)985-6929 the tales rives.com

#### Chapter 4 Parameters | VFD-VL

Chapter 4	Paramet	ers   VFD	-VL					
06-16	Presen	t Fault Re	ecord					
06-17	Second	d Most Re	ecent l	Fault Record				
06-18	Third Most Recent Fault Record							
06-19	Fourth	Fourth Recent Fault Record						
06-20	Fifth M	ost Rece	nt Fau	It Record				
06-21	Sixth M	lost Rece	ent Fa	ult Record				
Control mode	VF	VFPG	SVC	FOCPG TQCPG FOCPM	Factory setting: 0			
	Readin	gs O		No fault				
		1		Over-current during acceleration (ocA)				
		2		Over-current during deceleration (ocd)				
		3		Over-current during constant speed (ocn)				
		4		Ground fault (GFF)				
		5		IGBT short-circuit (occ)				
		6		Over-current at stop (ocS)				
		7		Over-voltage during acceleration (ovA)				
		8		Over-voltage during deceleration (ovd)				
		9		Over-voltage during constant speed (ovn)				
		10	1	Over-voltage at stop (ovS)				
		11		Low-voltage during acceleration (LvA)				
		12		Low-voltage during deceleration (Lvd)				
		13		Low-voltage during constant speed (Lvn)				
		14		Low-voltage at stop (LvS)				
		15	i	Phase loss (PHL)				
		16	i	IGBT heat sink over-heat (oH1)				
		17		Heat sink over-heat (oH2)(for 40HP above)				
		18	1	TH1 open loop error (tH1o)				
		19	)	TH2 open loop error (tH2o)				
		20	)	Fan error signal output				
		21		Over-load (oL) (150% 1Min)				
		22		Motor over-load (EoL1)				
		23	1	Reserved				
		24		Motor PTC overheat (oH3)				
		25	;	Reserved				
		26	i	Over-torque 1 (ot1)				
		27		Over-torque 1 (ot2)				
		28		Reserved				

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

Chapter 4 Parameters | VFD-VL

29	Reserved
30	Memory write-in error (cF1)
31	Memory read-out error (cF2)
32	Isum current detection error (cd0)
33	U-phase current detection error (cd1)
34	V-phase current detection error (cd2)
35	W-phase current detection error (cd3)
36	Clamp current detection error (Hd0)
37	Over-current detection error (Hd1)
38	Over-voltage detection error (Hd2)
39	Ground current detection error (Hd3)
40	Auto tuning error (AuE)
41	PID feedback loss (AFE)
42	PG feedback error (PGF1)
43	PG feedback loss (PGF2)
44	PG feedback stall (PGF3)
45	PG slip error (PGF4)
46	PG ref input error (PGr1)
47	PG ref loss (PGr2)
48	Analog current input error (ACE)
49	External fault input (EF)
50	Emergency stop (EF1)
51	Reserved
52	Password error (PcodE)
53	Reserved
54	Communication error (cE1)
55	Communication error (cE2)
56	Communication error (cE3)
57	Communication error (cE4)
58	Communication Time-out (cE10)

Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

## Call 1(800)985-6929 fberltaaledrives.seelers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

59	PU time-out (cP10)
60	Brake chopper error (bF)
61-62	Reserved
63	Safety loop error (Sry)
64	Mechanical brake error (MBF)
65	PGF5 hardware error
66	Magnetic contactor error (MCF)
67	Phase loss of drive output (MPHL)

It will record when the fault occurs and force stopping. For the Lv, it will record when it is operation, or it will warn without record.

06-3	🖌 Sett	ing Metho	od of Fa	ult Outp	ut						
Contro mode		VFPG	SVC	FOCPG	TQCPG	FOCPM	Factory setting: 0				
	Setting	ıs 0	By	/ setting	s of Pr.0	6-22~06-25					
		1	Ву	the bina	ary settir	ıg					
Ĥ	It is used v	with the s	ettings 3	5~38 of	Pr.02-1	1~02-22 (Mul	ti-function Output). The fault output				
	selection 1	1~4 corres	sponds	to Bit 0~	3.						
	This parar	neter prov	vides tw	o setting	method	s for the faul	t output: setting 0: it is set by the				
	settings of Pr.06-22~Pr.06-25; setting 1: it is set by the binary setting and please refer to the										
	following example for details.										
	Example:										
	Assume th	nat									
	Pr.02-15 (	Multi-func	tion Ou	tput 5 (N	1O3)) is	set to 35 Fau	It output option 1 (Pr.06-22).				
	Pr.02-17 (	Multi-func	tion Ou	tput 7 (N	1O5)) is	set to 36 Fau	It output option 2 (Pr.06-23).				
	Pr.02-19 (	Multi-func	tion Ou	tput 9 (N	107)) is	set to 37 Fau	It output option 3 (Pr.06-24).				
	Pr.02-21 (	Multi-func	tion Ou	tput 11 (	MO9)) is	set to 38 Fa	ult output option 4 (Pr.06-25).				
	Assume th	nat extern	al faults	output v	vith the f	ollowing sign	al: MO3=1, MO5=1, MO7=0 and				
	MO9=1. T	he corres	ponding	Bit 3~0	is 1011.						
	Bit 3	Bit 2	Bit 1	Bit	D		Fault code				
	-	-	-	-		o fault					
	0	0	0	1			uring acceleration (ocA)				
							uring deceleration (ocd)				
						ver-current du round fault (G	uring constant speed (ocn)				
						BT short-circ					

4-74

Call 1(800)985-6929 foor tales frives.sales @deltaacdrives.com

# Call 1(800)985-6929 the tales rives.com

#### Chapter 4 Parameters | VFD-VL

Bit 3	Bit 2	Bit 1	Bit 0	Fault code
				6: Over-curent at stop (ocS)
				7: Over-voltage during acceleration (ovA)
0	0	1	0	8: Over-voltage during deceleration (ovd)
Ū	Ŭ			9: Over-voltage during constant speed (ovn)
				10: Over-voltage at stop (ovS)
				11: Low-voltage during acceleration (LvA)
				12: Low-voltage during deceleration (Lvd)
0	0	1	1	13: Low-voltage during constant speed (Lvn)
				14: Low-voltage at stop (LvS)
				15: Phase loss (PHL)
				16: IGBT heat sink over-heat (oH1)
0	1	0	0	17: Heat sink over-heat (oH2)(for 40HP above)
0	1	0	0	18: TH1 open loop error (tH10)
				19: TH2 open loop error (tH2o)
1	0	0	0	20: Fan error signal output
0	1	0	1	21: over-load (oL) (150% 1Min)
			•	22: Motor 1 over-load (EoL1)
0	1	1	0	24: Motor PTC overheat (oH3)
				26: over-torque 1 (ot1)
0	1	1	1	27: over-torque 1 (ot2)
				30: Memory write-in error (cF1)
				31: Memory read-out error (cF2)
				32: Isum current detection error (cd0)
				33: U-phase current detection error (cd1)
				34: V-phase current detection error (cd2)
1	0	0	0	35: W-phase current detection error (cd3)
				36: Clamp current detection error (Hd0)
				37: Over-current detection error (Hd1)
				38: Over-voltage detection error (Hd2)
				39: Ground current detection error (Hd3)
1	0	0	1	40: Auto tuning error (AuE)
		, v		41: PID feedback loss (AFE)
1	0	1	0	42: PG feedback error (PGF1)
•	Ŭ		Ŭ	43: PG feedback loss (PGF2)
0	1	1	1	44: PG feedback stall (PGF3)
0				45: PG slip error (PGF4)
				46: PG ref input error (PGr1)
1	0	1	0	47: PG ref loss (PGr2)
				48: Analog current input error (ACE)
				49: External fault input (EF)
1	0	1	1	50: Emergency stop (EF1)
1	0	0	1	52: Password error (PcodE)
I	U	U		54: Communication error (cE1)
				55: Communication error (cE2)
				56: Communication error (cE3)
1	1	0	0	57: Communication error (CE3)
				58: Communication Time-out (cE10)
				59: PU time-out (cP10)
4	0	0	^	60: Brake chopper error (bF)
1	0	0	0	
	U		Ĩ	63: Safety loop error (Sry)

Call 1(800)985-6929 food the tales of the second se

## Call 1(800)985-6929 foortSalestrives.sales@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

Bit 3	Bit 2	Bit 1	Bit 0	Fault code
				64: Mechanical brake error (MBF)
1	0	0	0 65: PGF5 hardware error	
1	0	1	1	66: Magnetic contactor error (MCF)
1	0	1	1	67: Phase loss of drive output (MPHL)

06-22	✓ Fault Output Option 1	✓ Fault Output Option 1						
06-23	✓ Fault Output Option 2							
06-24	✓ Fault Output Option 3	✓ Fault Output Option 3						
06-25								
Control mode	VF VFPG SVC FOCPG TQCPG FOCPM	Factory setting: 0						
	Settings 0 to 65535 sec (refer to bit table for fault code)							

These parameters can be used with multi-function output (set Pr.02-11 to Pr.02-22 to 35-38) for the specific requirement. When the fault occurs, the corresponding terminals will be

activated (It needs to convert binary value to decimal value to fill in Pr.06-22 to Pr.06-25).

Fault code	Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6
Fault code	current	Volt.	OL	SYS	FBK	EXI	CE
0: No fault							
1: Over-current during acceleration (ocA)	•						
2: Over-current during deceleration (ocd)	•						
3: Over-current during constant speed (ocn)	•						
4: Ground fault (GFF)						•	
5: IGBT short-circuit (occ)	•						
6: Over-curent at stop (ocS)	•						
7: Over-voltage during acceleration (ovA)		•					
8: Over-voltage during deceleration (ovd)		•					
9: Over-voltage during constant speed (ovn)		•					
10: Over-voltage at stop (ovS)		•					

Call 1(800)985-6929 foortaaleestrives.scalers@deltaacdrives.com

# Call 1(800)985-6929 the tales rives.com

Chapter 4 Parameters | VFD-VL

Fould and a	Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6
Fault code	current	Volt.	OL	SYS	FBK	EXI	CE
11: Low-voltage during acceleration (LvA)		•					
12: Low-voltage during deceleration (Lvd)		•					
13: Low-voltage during constant speed (Lvn)		•					
14: Low-voltage at stop (LvS)		٠					
15: Phase loss (PHL)						•	
16: IGBT heat sink over-heat (oH1)			•				
17: Heat sink over-heat (oH2)(for 40HP above)			•				
18: TH1 open loop error (tH1o)			•				
19: TH2 open loop error (tH2o)			•				
20: Fan error signal output						•	
21: over-load (oL) (150% 1Min)			•				
22: Motor 1 over-load (EoL1)			•				
23: Reserved							
24: Motor PTC overheat (oH3)			•				
25: Reserved							
26: over-torque 1 (ot1)			•				
27: over-torque 1 (ot2)			•				
28: Reserved							
29: Reserved							
30: Memory write-in error (cF1)				•			
31: Memory read-out error (cF2)				•			
32: Isum current detection error (cd0)				•			
33: U-phase current detection error (cd1)				٠			
34: V-phase current detection error (cd2)				•			

# Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

# Call 1(800)985-6929 the tales rives.com

#### Chapter 4 Parameters | VFD-VL

Fault code	Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6
Fault code	current	Volt.	OL	SYS	FBK	EXI	CE
35: W-phase current detection error (cd3)				•			
36: Clamp current detection error (Hd0)				•			
37: Over-current detection error (Hd1)				٠			
38: Over-voltage detection error (Hd2)				•			
39: Ground current detection error (Hd3)				•			
40: Auto tuning error (AuE)				•			
41: PID feedback loss (AFE)					•		
42: PG feedback error (PGF1)					٠		
43: PG feedback loss (PGF2)					٠		
44: PG feedback stall (PGF3)					•		
45: PG slip error (PGF4)					•		
46: PG ref input error (PGr1)					•		
47: PG ref loss (PGr2)						•	
48: Analog current input error (ACE)						•	
49: External fault input (EF)						•	
50: Emergency stop (EF1)						•	
51: Reserved							
52: Password error (PcodE)				•			
53: Reserved							
54: Communication error (cE1)							•
55: Communication error (cE2)							•
56: Communication error (cE3)							•
57: Communication error (cE4)							•
58: Communication Time-out (cE10)							•
59: PU time-out (cP10)							•

Call 1(800)985-6929 footsalestrives.scalers@deltaacdrives.com

## Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

Fault code	Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6
	current	Volt.	OL	SYS	FBK	EXI	CE
60: Brake chopper error (bF)						•	
61-62: Reserved							
63: Safety loop error (Sry)				٠			
64: Mechanical brake error (MBF)						•	
65: PGF5 hardware error				•			
66: Magnetic contactor error (MCF)						٠	
67: Phase loss of drive output (MPHL)						•	

06-26	✓ PTC	PTC (Positive Temperature Coefficient) Detection Selection								
Control mode	VF	VFPG	SVC	FOCPG	TQCPG FOCPM	Factory setting: 0				
	Settings	0	Warn and keep operating							
		1	W	arn and ra	amp to stop					

It is used to set the treatment after detecting PTC.

06-27	<pre> <i>★</i>PTC I </pre>	_evel					
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	Factory setting: 50.0
	Settings	. 0.	0 to 10	0.0%			

It is used to set the PTC level, and the corresponding value for 100% is max. analog input value.

06-28	🖌 Filter	Time fo	r PTC D	etection						
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	Factory setting: 0.20			
	Settings	0	.00 to 10	0.00 sec						
06-29	Voltage of Emergency Power									
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	Factory setting: 48.0/96.0			
	Settings	4	8.0~375	.0Vdc						
		9	6.0~750	.0Vdc						

Call 1(800)985-6929 fbertaaledrives.salers@deltaacdrives.com

## Call 1(800)985-6929 fbertaaleetrives.salers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

It is used with the setting 43 (EPS function) of Pr.02-01~02-08 (Multi-Function Input Command).

06-31	Phase Loss Detection of Drive Output at Start-Up(MPHL)											
Control mode	VF	VFPG	SVC	FOCPG	TQCPG FOCPM	Factory setting: 0						
	Settings	0	Disa	able								
		1	Ena	able								

When it is set to 1, it will auto detect if the connection between the drive and motor is normal whenever the drive runs. If errors occur to the connection between the drive and the motor, the drive will display fault code "67" to indicate motor output phase loss.

	Settings 00 to 1439 min	
Control mode	VF VFPG SVC FOCPG TQCPG FOCPM	Factory setting: 0
06-42	Accumulative Drive Power-on Time at the Sixth Fault (min.)	
06-40	Accumulative Drive Power-on Time at the Fifth Fault (min.)	
06-38	Accumulative Drive Power-on Time at the Fourth Fault (min.)	
06-36	Accumulative Drive Power-on Time at the Third Fault (min.)	
06-34	Accumulative Drive Power-on Time at the Second Fault (min.)	
06-32	Accumulative Drive Power-on Time at the First Fault (min.)	

06-33	Accumulative Drive Power-on Time at the First Fault (day)	
06-35	Accumulative Drive Power-on Time at the Second Fault (day)	
06-37	Accumulative Drive Power-on Time at the Third Fault (day)	
06-39	Accumulative Drive Power-on Time at the Fourth Fault (day)	
06-41	Accumulative Drive Power-on Time at the Fifth Fault (day)	
06-43	Accumulative Drive Power-on Time at the Sixth Fault (day)	
Control mode	VF VFPG SVC FOCPG TQCPG FOCPM	Factory setting: 0
	Settings 00 to 65535 day	

06-44	🖌 Oper	ation Sp	eed of I	Emergen	cy Power Mode	
Control mode	VF	VFPG	SVC	FOCPG	TQCPG FOCPM	Factory setting: 0.00
	Settings	0.	00 to 4	00.00Hz		

Call 1(800)985-6929 foortaaleestrives.scalers@deltaacdrives.com

Max. operation speed F<sub>EPS</sub> in emergency power mode:

 $F_{EPS}=06-29/01-02^{*}(1/\sqrt{2})^{*}01-01^{*}(1/2)$ 

When Pr.06-44 > F<sub>EPS</sub>, the speed in emergency power mode will be operated by F<sub>EPS</sub>.

When Pr.06-44 ≤ F<sub>EPS</sub>, the speed in emergency power mode will be operated by Pr.06-44.

06-45	🖌 Low-\	oltage P	rotectio	on		
Control mode	VF	VFPG	SVC	FOCPG	TQCPG FOCPM	Factory setting: 0
	Settings	0	Di	splay Lv	fault and coast to stop	
		1	Di	splay Lv	warn and coast to stop	
		2	Fa	in lock, fa	ault and coast to stop	
		3	Fa	in lock, v	warn and coast to stop	


06-46	🖌 Low-v	voltage F	Protecti	on				
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	F	actory setting: 0
	Settings	0	0	perate by	current	command		
		1	0	perate by	the dire	ection of pow	ver generating mode	

Pr.06-46 is enabled when the external terminal is detecting for the emergency power.

- When Pr.06-46 is set to 1 and a forward/reverse run command is given, the drive will begin to detect for the elevator loading and operates in the power regeneration direction (the motor is in power generating status). The drive will use and operate in the direction that was detected as its power regeneration direction. The drive will not operate in user command direction for safety purpose, to prevent voltage drop of emergency power.
- VF and SVC control mode: within the time setting of Pr.06-47, the drive detects the elevator loading status by performing forward/reverse run. Then the elevator operates in power regeneration direction (the motor id in power generating status). Refer to the diagram below for the Auto-Detection Time Graph.

## Call 1(800)985-6929 foor tales trives.com

#### Chapter 4 Parameters | VFD-VL




FOCPG/PM Control Mode: within the time setting of Pr.06-47, the drive maintains at zerospeed and it is able to determine the elevator loading without performing forward/reverse run. Then the elevator operates in power regeneration direction (the motor is in power generating status). Refer to the diagram below for the Auto-Detection Time Graph.

4-82

Call 1(800)985-6929 the tale drives. sales @deltaacdrives.com

#### Call 1(800)985-6929 foortSalestrives.scollers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL



06-48	🖌 Pow	er Capac	ity of E	mergency	Power		
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	Factory setting: 0.0
	Setting	S	0.	0~100.0 k	VA		

When using emergency power, user must input the required power capacity for the emergency power and then the AC drive will calculate the acceptable elevator speed (Pr.06-44) by following equation.

$$V_{eps\_max} = \frac{06 - 48 \times 0.5}{\sqrt{3} \times I_{motor\_rated}}$$

$$f_{eps\_limit} = \frac{V_{eps\_max}}{01 - 02} \times 01 - 01 \times 0.5$$

$$I_{motor\_rated} = 05 - 01 \text{ (Induction Motor)/ } 08 - 01 \text{ (PM Motor)}$$

 $\square$  When Frequency Command > fEPS, the operation speed of emergency power is fEPS  $\circ$ 

When Freuquency Command ≤ f<sub>EPS</sub>, the operation speed of emergency power is set by current frequency command.

#### Call 1(800)985-6929 thertSalectrives.scales@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

#### 4.2.8 Group 7 Special Parameters

07-00	🖌 Brake	e Chopp	er Leve	91	
Control mode	VF	VFPG	SVC	FOCPG TQCPG FOCPM	
	Settings	230V	series	350.0~450.0Vdc	Factory Setting: 380.0
		460V	series	700.0~900.0Vdc	Factory Setting: 760.0

This parameter sets the DC-bus voltage at which the brake chopper is activated.

07-01 Reserved
----------------

07-02	🖌 DC B	rake Cur	rent Level	
Control mode	VF	VFPG	SVC	Factory Setting: 0
	Settings	0 t	to 100%	

This parameter sets the level of DC Brake Current output to the motor during start-up and stopping. When setting DC Brake Current, the Rated Current (Pr.00-01) is regarded as 100%. It is recommended to start with a low DC Brake Current Level and then increase until proper holding torque has been attained.

When it is in FOCPG/TQCPG/FOCPM mode, it can enable DC brake function by setting to any value.

07-03	🖌 DC B	rake Act	ivation	Time		
Control mode	VF	VFPG	SVC	FOCPG	FOCPM	Factory Setting: 0.0
	Settings	0.0	0 to 60.	0 sec		

This parameter sets the duration of DC Brake current is supplied to motor when activating the drive.

	C Brake Sto	opping	Time	
Control V mode	F VFPG	SVC	FOCPG FOCPM	Factory Setting: 0.0
Sett	ings 0	.0 to 60	.0 sec	

This parameter sets the duration of DC Brake current is supplied to motor when stopping the drive.

## Call 1(800)985-6929 the tales rives scales @deltaacdrives.com

# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

Chapter 4 Parameters | VFD-VL


Control mode	VF	VFPG	SVC	FOCPG	Factory Setting: 0.00
	Settings	s 0.	.00 to 4	00.00Hz	
🕮 Th	is param	neter det	ermines	the frequency when DC Brake will beg	gin during deceleration. Whe
the	e setting	is less th	nan star	t frequency (Pr.01-09), start-point for D	C brake will begin from the
mi	n. freque				
		Outp	out frequ	le ncy	
			DC Bral Activati Time 4	on 01-09 07-05 Stop Start DC brake frequency frequency	Brake pping e >
	F	Run/Stop		ON	Time
				DC Brake Time	
07.00				0.1	
07-06	DC Bra	ke Propo	ortional	Gain	
Control	1/5	VEDO	01/0		Footony Sotting: FO
Control mode	VF	VFPG	SVC		Factory Setting: 50
	VF Settings		SVC	Hz	Factory Setting: 50
mode	Settings	s 1	to 500H	Hz voltage gain when DC brake.	Factory Setting: 50
mode	Settings s used to	s 1 o set the	to 500H output	voltage gain when DC brake.	Factory Setting: 50
mode	Settings s used to	s 1 o set the II Time a	to 500H output	voltage gain when DC brake.	
mode	Settings s used to	s 1 o set the	to 500H output	voltage gain when DC brake.	Factory Setting: 50
mode It is 07-07 Control mode	Settings s used to $\checkmark$ Dwe VF Settings	s 1 o set the II Time a <b>VFPG</b> s 0.	to 500H output t Accel. svc 00 to 6	voltage gain when DC brake. FOCPG FOCPM 00.00 sec	
mode It i: 07-07 Control mode 07-08	Settings s used to // Dwe VF Settings // Dwe	s 1 o set the II Time a VFPG s 0. II Freque	to 500H output t Accel. svc 00 to 6	voltage gain when DC brake. FOCPG FOCPM 00.00 sec	Factory Setting: 0.00
mode It is 07-07 Control mode	Settings s used to $\checkmark$ Dwe VF Settings	s 1 o set the II Time a <b>VFPG</b> s 0.	to 500H output t Accel. svc 00 to 6	voltage gain when DC brake. FOCPG FOCPM 00.00 sec	
mode It is 07-07 Control mode 07-08 Control	Settings s used to // Dwe VF Settings // Dwe	s 1 o set the II Time a VFPG s 0. II Freque VFPG	to 500H output t Accel. svc 00 to 6 ncy at / svc	voltage gain when DC brake. FOCPG FOCPM 00.00 sec Accel.	Factory Setting: 0.00
mode It i: 07-07 Control mode 07-08 Control	Settings s used to VF Settings VF Settings	s 1 o set the II Time a VFPG s 0. II Freque VFPG	to 500H output t Accel. <b>svc</b> 00 to 6 ncy at <i>i</i> <b>svc</b> 00 to 4	voltage gain when DC brake. FOCPG FOCPM 00.00 sec Accel. FOCPG FOCPM 00.00 Hz	Factory Setting: 0.00
mode It is 07-07 Control mode 07-08 Control mode	Settings s used to VF Settings VF Settings	s         1           o set the         II Time a           II Time a         VFPG           s         0.           II Freque         VFPG           s         0.           s         0.	to 500H output t Accel. <b>svc</b> 00 to 6 ncy at <i>i</i> <b>svc</b> 00 to 4	voltage gain when DC brake. FOCPG FOCPM 00.00 sec Accel. FOCPG FOCPM 00.00 Hz	Factory Setting: 0.00
mode I t i: 07-07 Control mode 07-08 Control mode 07-09 Control	Settings s used to VF Settings VF Settings VF	s         1           o set the         1           II Time a         VFPG           s         0.           II Freque         VFPG           s         0.           II Time a         VFPG           s         0.           II Time a         VFPG           vFPG         0.	to 500H output t Accel. <b>svc</b> 00 to 6 ncy at / <b>svc</b> 00 to 4 t Decel. <b>svc</b>	voltage gain when DC brake. FOCPG FOCPM 00.00 sec Accel. FOCPG FOCPM 00.00 Hz	Factory Setting: 0.00
mode I t i: 07-07 Control mode 07-08 Control mode 07-09 Control	Settings s used to VF Settings VF Settings VF Settings	s         1           o set the         1           II Time a         VFPG           s         0.           II Freque         VFPG           s         0.           II Time a         VFPG           s         0.           II Time a         VFPG           vFPG         0.	to 500H output + t Accel. <b>svc</b> 00 to 6 ncy at / <b>svc</b> 00 to 4 t Decel. <b>svc</b> 00 to 6	FOCPG FOCPM         00.00 sec         Accel.         FOCPG FOCPM         00.00 Hz         .         FOCPG FOCPM         00.00 Hz         .         FOCPG FOCPM         00.00 bc         .         <	Factory Setting: 0.00
mode 1 It i: 07-07 Control mode 07-09 Control mode	Settings s used to VF Settings VF Settings VF Settings	s         1           o set the         II Time a           VFPG         0.           II Freque         VFPG           vFPG         0.           II Time a         0.           VFPG         0.           s         0.	to 500H output + t Accel. <b>svc</b> 00 to 6 ncy at / <b>svc</b> 00 to 4 t Decel. <b>svc</b> 00 to 6	FOCPG FOCPM         00.00 sec         Accel.         FOCPG FOCPM         00.00 Hz         .         FOCPG FOCPM         00.00 Hz         .         FOCPG FOCPM         00.00 bc         .         <	Factory Setting: 0.00

Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

## Call 1(800)985-6929 foortaaleestrives.scalers@deltaacdrives.com

### Chapter 4 Parameters | VFD-VL

Pr.07-07 to Pr.07-10 are for heavy load to prevent OV or OC occurs.



07-11	🖌 Fan C	Control				
Control mode	VF	VFPG	SVC	FOCPG	TQCPG FOCPM	Factory Setting: 2
	Settings	0	Fa	an always	s ON	
		1	1	minute a	fter AC motor drive sto	ops, fan will be OFF
		2	A	C motor o	drive runs and fan ON	, AC motor drive stops and fan OFF
		3	Fa	an ON to	run when preliminary	heat sink temperature attained
		4	Fa	an always	s OFF	

This parameter is used for the fan control.

When setting to 3, fan will start to run until temperature is less than 40°C if temperature exceeds 40°C.

07-12	🖌 Torque	✓ Torque Command					
Control mode	TQCPG		Factory Setting: 0.0				
	Settings	-100.0 to 100.0% (Pr. 07-14 setting=100%)					

This parameter is torque command. When Pr.07-14 is 250% and Pr.07-12 is 100%, the actual torque command = 250X100% X motor rated torque.

07-13	🖌 Torque (	Torque Command Source				
Control mode	TQCPG			Factory Setting: 2		
	Settings	0	Digital keypad			
		1	RS485 serial communication (RJ-11)			
_		2	Analog signal (Pr.03-00)			

This parameter is torque command source and the torque command is in Pr.07-12.

# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

					Chapter 4 Parameters   VFD-V
07-14	🖌 Maxi	mum Toi	que Co	ommand	
Control mode	VF	VFPG	SVC	FOCPG TQCPG FOCPM	Factory Setting: 100
	Settings	0	to 300%	0	
🕮 Tł	nis param	eter is fo	r the m	ax. torque command (moto	or rated torque is 100%).
07-15		Time of	Torque	Command	
Control mode	TQCPG				Factory Setting: 0.000
	Settings	0.	000 to 1	1.000 sec	
۱۸/	hon the s	ottina is	too sho	g, the control will be stable	ckly but the control maybe unstable
	ser can a	Ū	setting		ckly but the control maybe unstable.
U	ser can a	djust the	setting	rt, the response will be qui	
Us 07-16 Control	ser can a	djust the	setting	rt, the response will be qui	se situation.
Us 07-16 Control	Speed L	djust the	setting ection By I	rt, the response will be qui by the control and respons	Factory Setting: 0

07-17	✓ Torque	✓ Torque Mode+Speed Limit							
07-18	🖌 Torque	✓ Torque Mode-Speed Limit							
Control mode	TQCPG		Factory Setting: 10						
	Settings	0 to 120%							

Ш These parameters are used in the torque mode to limit the running direction and opposite

direction. (Pr.01-00 max. output frequency=100%)

# Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

Chapter 4 Parameters | VFD-VL

07-19	N Sour	ce of To	rque Off	set		
Control mode	SVC	FOCPG	TQCPG	FOCPM		Factory Setting: 0
	Setting	s 0	Disa	able		
		1	Ana	log input (Pr.03	-00)	
		2	Tore	que offset setting	g (Pr.07-20)	
		3	Con	trol by external t	erminal (by Pr.07-21 to Pr	.07-23)
🕮 Tł	nis paran	neter is t	he sourc	e of torque offse	t.	
🕮 W	'hen it is	set to 3,	the sour	ce of torque offs	et will decide to Pr.07-21,	Pr.07-22 and Pr.07-23
by	/ the mul	ti-functio	n input te	erminals setting	(31, 32 or 33).	
02-01~02	2-08 is se	et to 31	02-01~0	2-08 is set to 32	02-01~02-08 is set to 33	Torque offset
	OFF			OFF	OFF	None
	OFF			OFF	ON	07-23
	OFF			ON	OFF	07-22
	OFF			ON	ON	07-23+07-22
	ON			OFF	OFF	07-21
	ON			OFF	ON	07-21+07-23
	ON			ON	OFF	07-21+07-22
	ON			ON	ON	07-21+07-22+07-23
07-20	✓ Tore	ue Offse	et Setting	1		
Control mode	SVC		TQCPG			Factory Setting: 0.0
	Setting	s 0	.0 to 100	.0%		
II II	nis paran	neter is t	orque off	set. The motor r	ated torque is 100%.	
07-21	🖌 High	Torque	Offset			
Control mode	SVC	FOCPG	TQCPG	FOCPM		Factory Setting: 30.0
	Setting	s 0	.0 to 100	.0%		
07-22	⊮ Mide	dle Torqu	ie Offset			
Control	SVC	· · ·	TQCPG			Factory Setting: 20.0
mode						

## Call 1(800)985-6929 fbertSalestrives.szellers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

07-23	✓ Low Torque Offset							
Control mode	SVC FOCF	G TQCPG FOCPM	Factory Setting: 10.0					
5	Settings	0.0 to 100.0%						


When it is set to 3, the source of torque offset will decide to Pr.07-21, Pr.07-22 and Pr.07-23

by the multi-function input terminals setting (19, 20 or 21). The motor rated torque is 100%.

07-24	✓ Forward Motor Torque Limit						
07-25	✓ Forward Regenerative Torque Limit						
07-26	✓ Reverse Motor Torque Limit						
07-27	✓ Reverse Regenerative Torque Limit						
Control mode	FOCPG TQCPG FOCPM	Factory Setting: 200					
	Settings 0 to 300%						

The motor rated torque is 100%. The settings for Pr.07-24 to Pr.07-27 will compare with Pr.03-

00=5, 6, 7, 8. The minimum of the comparison result will be torque limit.



# Call 1(800)985-6929 foortSalestrives.sales@deltaacdrives.com

Chapter 4 Parameters | VFD-VL


07-28	🖌 Emer	✓ Emergency Stop (EF) & Forced Stop Selection					
Control mode	VF	VFPG	ŝ	VC FOCPG TQCPG FOCPM	Factory Setting: 0		
	Settings		0	Coast to stop			
			1	By deceleration Time 1			
			2	By deceleration Time 2			
			3	By deceleration Time 3			
			4	By deceleration Time 4			
			5	By Pr.01-31			

When the multi-function input terminal is set to 10 or 14 and it is ON, the AC motor drive will be operated by Pr.07-28.

07-	-29	🖌 Time for	✓ Time for Decreasing Torque at Stop					
Con mo								
		Settings	0.000 to 1.000 sec					
	W	hen the elev	ator is stop and the mechanical brake is er	ngaged, the drive will stop output. At				

the same time, it will produce the noise from the reacting force between the motor and the mechanical brake. This parameter can be used to decrease this reacting force and lower the noise.

It is used to set the time for decreasing torque to 0%. RUN/STOP



 $\frac{i}{00-01} \times \frac{100\%}{300\%} \times (07-29) = t$ 

Call 1(800)985-6929 the tales rives.com

# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

Chapter 4 Parameters | VFD-VL

08	3-00	Motor Au	ιto Τι	uning
	ntrol ode	FOCPM		Factory setting: 0
		Settings	0	No function
			1	Only for the unloaded motor, auto measure the angle between magnetic pole and PG origin (08-09)
			2	For PM parameters
			3	Auto measure the angle between magnetic pole and PG origin (08-09)
	Fo	r setting 1	: It ca	an auto measure the angle between magnetic pole and PG origin. Please
	no	tice the fo	llowir	ng items when measuring:
	1.	Please	unloa	ad before tuning.
	2.	If brake	is c	ontrolled by drive, the drive will act by the normal operation to finish tuning
		after wi	ring a	and setting brake control parameters.
	3.	If brake	is co	ontrolled by the host controller, it needs to make sure that brake is in release
		state be	fore	tuning.
	4.	Make s	ure tl	he setting of Pr.10-02 is correct. Because the wrong setting of Pr.10-02 will
		cause v	vrong	position of magnetic pole and also the wrong angle between magnetic pole
		and PG	origi	n.
ш	Fo	r setting 2	: Sta	rting auto tuning by pressing RUN key and it will write the measure value into
	Pr	.08-05, Pr	.08-0	7 (Rs, Lq) and Pr.08-08 (back EMF).
	Th	e steps to	AUT	O-Tuning are: (Dynamic measure)
	1.	Make s	ure th	at all the parameters are set to factory settings and the motor wiring is
		correct.		
	2.	Motor: F	-ill in	Pr.08-01, Pr.08-02, Pr.08-03 and Pr.08-04 with correct values. Refer to
		motor c	apaci	ity to set accel./decel. time.
	3.	When F	r.08-	00 is set to 2, the AC motor drive will execute auto-tuning immediately after
		receivin	ga"	RUN" command. (NOTE: the motor will run! The shaft needs to be locked
		with ext	ernal	force.)
	4.	After ex	ecuti	ng, please check if all values are filled in Pr.08-05 and Pr.08-07.
ш	Fo	r setting 3	: It ca	an auto measure the angle between magnetic pole and PG origin. Please
	no	tice the fo	llowir	ng items when measuring:
	1.	lt can b	e loa	ded motor or unloaded motor before tuning.

# 4.2.9 Group 8 PM Parameters

# Call 1(800)985-6929 the tales rives.com

Call 1(800)985-6929 fterltaatestrives.salers@deltaacdrives.com Chapter 4 Parameters | VFD-VL

- If brake is controlled by drive, the drive will act by the normal operation to finish tuning after wiring and setting brake control parameters.
- If brake is controlled by the host controller, it needs to make sure that brake is in release state before tuning.

# 

- The rated speed can't be larger or equal to 120f/p.
- Please notice that if the electromagnetic valve and brake is not controlled by the AC motor drive, please release it by manual.
- It is recommended to set Pr.08-00 to 1 (unloaded motor) for the accurate calculation. If it needs to execute this function with loaded motor, please balance the carriage before execution.
- if it doesn't allow balancing the carriage in the measured environment, it can set Pr.08-00=3 for executing this function. It can execute this function with loaded motor by setting Pr.08-00=3. It will have a difference of 15~30° by the different encoder type.
- It will display the warning message "Auto tuning" on the digital keypad during measuring until the measure is finished. Then, the result will be saved into Pr.08-09.
- It will display "Auto Tuning Err" on the keypad when stopping by the fault of the AC motor drive or human factor to show the failed detection. At this moment, please check the connections of the wirings of the AC motor drives. If it displays "PG Fbk Error" on the digital keypad, please change the setting of Pr.10-02 (if it is set to 1, please change it to 2). If it displays "PG Fbk Loss" on the digital keypad, please check the feedback of Z-phase pulse.

08-	01	Full-load 0	Current of Motor Unit: Amper
Con mo		FOCPM	Factory setting: #.##
		Settings	(40 to 120%)*Pr.00-01 Amps
	T۲	nis value sh	ould be set according to the rated frequency of the motor as indicated on the
	m	otor namep	late. The factory setting is 90% X rated current.

Example: if the rated current for 7.5hp (5.5kW) models is 25A and the factory setting is 22.5A. In this way, the current range will be from 10A (25\*40%) to 30A (25\*120%).

# Call 1(800)985-6929 the tales rives.com

Chapter 4 Parameters | VFD-VL

			- · ·
08-02		ower of Motor	
Control mode	FOCPM		Factory setting: #.##
	Settings	0.00 to 655.35 kW	
🕮 Iti	s used to se	t rated power of the motor. The factory setting is the p	oower of the drive.
08-03	✓ Rated S	peed of Motor (rpm)	
Control mode	FOCPM		Factory setting: 1710
	Settings	0 to 65535 rpm	
🕮 lti	s used to se	t the rated speed of the motor and need to set accord	ing to the value indicated
on	the motor n	ameplate.	
08-04	Number of	Motor Poles	
Control mode	FOCPM		Factory setting: 4
	Settings	2 to 96	
🕮 lti	s used to se	t the number of motor poles (must be an even numbe	r).
08-05	Rs of Moto	n	
Control mode	FOCPM		Factory setting: 0.000
	Settings	0.000~65.535Ω	
08-06	Ld of Motor	r	
Control mode	FOCPM		Factory setting: 0.0
08-07	Lq of Motor	r	
Control mode	FOCPM		Factory setting: 0.0
	Settings	0.0~6553.5mH	
08-08	Back Electr	romotive Force	
Control mode	FOCPM		Factory setting: 0.0
	Settings	0.0~6553.5Vrms	
🕮 Th	nis paramete	r is used to set back electromotive force (phase-phase	e RMS value) when the
	-	ted in the rated speed.	·

# Call 1(800)985-6929 thertSalectrives.scales@deltaacdrives.com

## Chapter 4 Parameters | VFD-VL

It can get RMS value by Pr.08-00=2 (Motor Auto Tuning).

08-09	Angle bet	Angle between Magnetic Pole and PG Origin											
Control mode	FOCPM		Factory setting: 360.0										
	Settings	0.0~360.0°											

This function is used to measure the angle between magnetic pole and PG origin.

08-10	Magnetic Pole Re-orientation									
Control mode	FOCPM			Factory setting: 0						
	Settings	0	Disable							
		1	Enable							

Please use with Pr.11-00 bit15=1.

This function is used for searching magnetic pole position and only for permanent magnet motor.

When it doesn't have origin-adjustment for encoder (Pr.08-09 is 360.0), it can only ensure that the motor operation efficiency can be up to 86% of the best efficiency. In this situation, when the operation efficiency needs to be improved, user can re-power on or set Pr.08-10 to 1 to get the magnetic pole orientation.

# Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL

## 4.2.10 Group 9: Communication Parameters

When the AC motor drive is controlled by RS-485 serial communication, a converter, VFD-USB01 or IFD8500, should be connected between the AC motor drive and PC.

	Serial interface
6←1	1: +EV
	2: GND
[]	3: SG-
<u> </u>	4: SG+
RS-485	5: NC
	6: NC

09-00	<b>∦</b> Comr	Communication Address										
Control mode	VF	VFPG	SVC	FOCPG TQCPG FOCPM	Factory Setting: 1							
	Settings	s 1	to 254									

If the AC motor drive is controlled by RS-485 serial communication, the communication address for this drive must be set via this parameter. And the communication address for each AC motor drive must be different and unique.

09-01	✓ Transmission Speed											
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory Setting: 9.6				
	Settings	4.8	8 to 115	5.2kbps								

This parameter is used to set the transmission speed between the RS485 master (PLC, PC,

etc.) and AC motor drive.

09-02	🖌 Trans	<ul> <li>Transmission Fault Treatment</li> </ul>									
Control mode	VF VFPG SVC FOCPG TQCPG FOCPM Factory S										
	Settings	0	N	arn and	keep operating						
		1	Warn and R		RAMP to stop						
		2	Reserved								
		3	N	o action a	and no display						

Description: This parameter is set to how to react if transmission errors occur.

09-03	🖌 Time						
Control mode	VF	VFPG	SVC	FOCPG	TQCPG FOCPM		Factory Setting: 0.0
	Settings		0.0 ~ 1	00.0 sec	(0.0: disable)		

It is used to set the communication time-out time.

## Call 1(800)985-6929 foortSalestrives.scales@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

09-04	✓ Communication Protocol									
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM	Factory Setting: 13			
	Settings	0	Ν	lodbus A	SCII mo	de, protocol <7,N,1>				
		1	N	odbus A	SCII moo	de, protocol <7,N,2>				
		2	N	odbus A	SCII moo	de, protocol <7,E,1>				
		3	N	odbus A	SCII moo	de, protocol <7,0,1>				
		4	N	odbus A	SCII moo	de, protocol <7,E,2>				
		5	N	odbus A	SCII moo	de, protocol <7,0,2>				
		6	N	odbus A	SCII moo	de, protocol <8,N,1>				
		7	N	odbus A	SCII moo	de, protocol <8,N,2>				
		8	N	odbus A	SCII moo	de, protocol <8,E,1>				
		9	N	odbus A	SCII moo	de, protocol <8,O,1>				
		10	N	odbus A	SCII moo	de, protocol <8,E,2>				
		11	N	odbus A	SCII moo	de, protocol <8,0,2>				
		12	N	odbus R	TU mode	e, protocol <8,N,1>				
		13	N	odbus R	TU mode	e, protocol <8,N,2>				
		14	N	odbus R	TU mode	e, protocol <8,E,1>				
		15	N	odbus R	TU mode	e, protocol <8,O,1>				
		16	N	odbus R	TU mode	e, protocol <8,E,2>				
		17	N	odbus R	TU mode	e, protocol <8,0,2>				

1. Control by PC or PLC

★A VFD-VL can be set up to communicate on Modbus networks using one of the following modes: ASCII (American Standard Code for Information Interchange) or RTU (Remote Terminal Unit). Users can select the desired mode along with the serial port communication protocol in Pr.09-04.

★Code Description:

## ASCII mode:

Each 8-bit data is the combination of two ASCII characters. For example, a 1-byte data:

					,		,	
Character	'0'	'1'	'2'	'3'	'4'	'5'	'6'	'7'
ASCII code	30H	31H	32H	33H	34H	35H	36H	37H

Character	'8'	<b>'</b> 9'	'A'	'B'	ʻC'	'D'	'E'	'F'
ASCII code	38H	39H	41H	42H	43H	44H	45H	46H

### RTU mode:


Each 8-bit data is the combination of two 4-bit hexadecimal characters. For example, 64

Hex.

2. Data Format

# Call 1(800)985-6929 the talestrives.com

### Chapter 4 Parameters | VFD-VL



- 3. Communication Protocol
- 3.1 Communication Data Frame:

## ASCII mode:

STX	Start character ':' (3AH)
Address Hi	Communication address:
Address Lo	8-bit address consists of 2 ASCII codes
Function Hi	Command code:
Function Lo	8-bit command consists of 2 ASCII codes
DATA (n-1)	Contents of data:
to	Nx8-bit data consist of 2n ASCII codes
DATA 0	n<=16, maximum of 32 ASCII codes
LRC CHK Hi	LRC check sum:
LRC CHK Lo	8-bit check sum consists of 2 ASCII codes
END Hi	End characters:
END Lo	END1= CR (0DH), END0= LF(0AH)

# Call 1(800)985-6929 foortSalestrives.sales@deltaacdrives.com

### Chapter 4 Parameters | VFD-VL

## RTU mode:

START	A silent interval of more than 10 ms
Address	Communication address: 8-bit address
Function	Command code: 8-bit command
DATA (n-1) to DATA 0	Contents of data: n×8-bit data, n<=16
CRC CHK Low	CRC check sum:
CRC CHK High	16-bit check sum consists of 2 8-bit characters
END	A silent interval of more than 10 ms

3.2 Address (Communication Address)

Valid communication addresses are in the range of 0 to 254. A communication address equal to 0, means broadcast to all AC drives (AMD). In this case, the AMD will not reply any message to the master device.

00H: broadcast to all AC drives 01H: AC drive of address 01 0FH: AC drive of address 15 10H: AC drive of address 16 ...

FEH: AC drive of address 254

For example, communication to AMD with address 16 decimal (10H):

ASCII mode: Address='1','0' => '1'=31H, '0'=30H RTU mode: Address=10H

## 3.3 Function (Function code) and DATA (data characters)

The format of data characters depends on the function code.

03H: read data from register

06H: write single register

08H: loop detection

10H: write multiple registers

The available function codes and examples for VFD-VL are described as follows:

(1) 03H: multi read, read data from registers.

Example: reading continuous 2 data from register address 2102H, AMD address is 01H.

ASCII mode:

Command message:		
STX	·.'	
Address	'0'	
Address	'1'	
<b>F</b>	'0'	
Function	'3'	
	'2'	
Starting data	'1'	
address	'0'	
	'2'	
Number of data	'0'	
(count by word)	'0'	

Response message:

STX	:: :
Address	·0'
Address	'1'
	·0'
Function	'3'
Number of data	ʻ0'
(Count by byte)	'4'
Content of starting	'1'
Content of starting address	'7'
2102H	'7'
210211	·0'

# Call 1(800)985-6929 the tales rives.com

## Chapter 4 Parameters | VFD-VL

Command message:	
------------------	--

	·0'
	'2'
LRC Check	'D'
LING CHECK	'7'
END	CR
END	LF

## RTU mode:

Command message:

oominana moodago.		
Address	01H	
Function	03H	
Starting data	21H	
address	02H	
Number of data	00H	
(count by word)	02H	
CRC CHK Low	6FH	
CRC CHK High	F7H	

Response message:

	'0'
Content of address	·0'
2103H	·0'
	·0'
I RC Check	'7'
LING OHECK	'1'
END	CR
	LF

Response message:

neeponoo moooago.	
Address	01H
Function	03H
Number of data (count by byte)	04H
Content of address	17H
2102H	70H
Content of address	00H
2103H	00H
CRC CHK Low	FEH
CRC CHK High	5CH

(2) 06H: single write, write single data to register.

Example: writing data 6000(1770H) to register 0100H. AMD address is 01H. ASCII mode:

Command message:			
STX	·.'		
Address	·0'		
Address	'1'		
Function	ʻ0'		
T unction	·6'		
	ʻ0'		
Data address	'1'		
Data address	·0'		
	ʻ0'		
	'1'		
Data content	'7'		
Data content	'7'		
	·0'		
LRC Check	'7'		
LING ONECK	'1'		
END	CR		
LIND	LF		

RTU mode:

Command message:		
Address	01H	
Function	06H	
Data address	01H	
Data audress	00H	
Data content	17H	
	70H	

Response message:

ricoponioo moodugo.				
STX	·.'			
Address	ʻ0'			
Audress	'1'			
Function	ʻ0'			
TUTICION	'6'			
	ʻ0'			
Data address	'1'			
Data audiess	ʻ0'			
	ʻ0'			
	'1'			
Data content	'7'			
Data content	'7'			
	ʻ0'			
LRC Check	'7'			
LING OTHECK	'1'			
END	CR			
LIND	LF			

Response message:

Address	01H
Function	06H
Data address	01H
Data audress	00H
Data content	17H
Data content	70H

# Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

## Chapter 4 Parameters | VFD-VL

CRC CHK Low	86H	CRC CHK Low	
CRC CHK High	22H	CRC CHK High	

(3) 10H: write multiple registers (write multiple data to registers)

Example: Set the multi-step speed,

Pr.04-00=50.00 (1388H), Pr.04-01=40.00 (0FA0H). AC drive address is 01H.

ASCII Mode:

Command message:		
STX	·.,	
Address 1	'0'	
Address 0	'1'	
Function 1	'1'	
Function 0	ʻ0'	
	ʻ0'	
Starting data	'5'	
address	ʻ0'	
	ʻ0'	
	'0'	
Number of data	'0'	
(count by word)	'0'	
	'2'	
Number of data	'0'	
(count by byte)	'4'	
	'1'	
The first data	'3'	
content	'8'	
	'8'	
	'0'	
The second data	'F'	
content	'A'	
	'0'	
LRC Check	'9'	
LING OHECK	'A'	
END	CR	
LIND	LF	

Response message:		
STX	·.'	
Address 1	ʻ0'	
Address 0	'1'	
Function 1	'1'	
Function 0	·0'	
	ʻ0'	
Starting data	'5'	
address	ʻ0'	
	ʻ0'	
	ʻ0'	
Number of data	ʻ0'	
(count by word)	ʻ0'	
	'2'	
LRC Check	'E'	
LING OHECK	'8'	
END	CR	
END	LF	

86H 22H

RTU mode:

Command message:		
Address	01H	
Function	10H	
Starting data	05H	
address	00H	
Number of data	00H'	
(count by word)	02H	
Number of data	04	
(count by byte)		
The first data	13H	
content	88H	
The second data	0FH	
content	A0H	
CRC Check Low	<b>'</b> 9'	
CRC Check High	'A'	

Response	message:
----------	----------

ricepense meesuge.		
Address	01H	
Function	10H	
Starting data address	05H	
	00H	
Number of data	00H	
(count by word)	02H	
CRC Check Low	41H	
CRC Check High	04H	

4-100

Call 1(800)985-6929 food the tales by sealing a construction of the sealing and the sealing a construction of the sealing a construction of the sealing and the sealing a construction of the sealing a construction of

3.4 Check sum

ASCII mode:

LRC (Longitudinal Redundancy Check) is calculated by summing up, module 256, the values of the bytes from ADR1 to last data character then calculating the hexadecimal representation of the 2's-complement negation of the sum.

For example, reading 1 word from address 0401H of the AC drive with address 01H.

STX	· · ·
Address 1	<b>'</b> 0'
Address 0	'1'
Function 1	<b>'</b> 0'
Function 0	'3'
	<b>'</b> 0'
Starting data address	'4'
Starting data address	·0'
	'1'
	<b>'</b> 0'
Number of data	<b>'</b> 0'
Number of data	<b>'</b> 0'
	'1'
LRC Check 1	'F'
LRC Check 0	'6'
END 1	CR
END 0	LF

01H+03H+04H+01H+00H+01H=0AH, the 2's-complement negation of 0AH is <u>F6</u>H. RTU mode:

Address	01H
Function	03H
Starting data address	21H
	02H
Number of data	00H
(count by word)	02H
CRC CHK Low	6FH
CRC CHK High	F7H

CRC (Cyclical Redundancy Check) is calculated by the following steps:

Step 1: Load a 16-bit register (called CRC register) with FFFFH.

Step 2: Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, putting the result in the CRC register.

Step 3: Examine the LSB of CRC register.

**Step 4:** If the LSB of CRC register is 0, shift the CRC register one bit to the right with MSB zero filling, then repeat step 3. If the LSB of CRC register is 1, shift the CRC register one bit to the right with MSB zero filling, Exclusive OR the CRC register with the polynomial value A001H, then repeat step 3.

Step 5: Repeat step 3 and 4 until eight shifts have been performed. When this is done, a complete 8-bit byte will have been processed.

**Step 6:** Repeat step 2 to 5 for the next 8-bit byte of the command message. Continue doing this until all bytes have been processed. The final contents of the CRC register are the CRC value. When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, i.e. the lower order byte will be transmitted first.

4-101

Call 1(800)985-6929 ther tales by seven we have a seven we hav

# Call 1(800)985-6929 foot Sales ives.com

## Chapter 4 Parameters | VFD-VL

The following is an example of CRC generation using C language. The function takes two arguments:

Unsigned char\* data ← a pointer to the message buffer

Unsigned char length ← the quantity of bytes in the message buffer

The function returns the CRC value as a type of unsigned integer.

Unsigned int crc\_chk(unsigned char\* data, unsigned char length){

```
int j;
unsigned int reg_crc=0xFFFF;
while(length--){
    reg_crc ^= *data++;
    for(j=0;j<8;j++){
        if(reg_crc & 0x01){ /* LSB(b0)=1 */
        reg_crc=(reg_crc>>1) ^ 0xA001;
    }else{
        reg_crc=reg_crc >>1;
    }
    }
    return reg_crc;
}
```

## 3.5 Address list

The contents of available addresses are shown as below:

Content	Address	Function	
AC drive Parameters	GGnn H	GG means parameter group, nn means parameter number, for example, the address of Pr 4-01 is 0401H. Referencing to chapter 5 for the function of each parameter. When reading parameter by command code 03H, only one parameter can be read at one time.	
Command Write only	2000H	Bit 0-3	0: No function 1: Stop 2: Run 3: Jog + Run
		Bit 4-5	00B: No function 01B: FWD 10B: REV 11B: Change direction
		Bit 6-7	00B: 1st accel/decel 01B: 2nd accel/decel 10B: 3rd accel/decel 11B: 4th accel/decel
		Bit 8-11	Represented 16 step speeds.

Call 1(800)985-6929 fbertaaleetrives.salers@deltaacdrives.com

# Call 1(800)985-6929 the tales rives.com

## Chapter 4 Parameters | VFD-VL

Content	Address	Function		
ooment	, laui 035	i unction		
		Bit 12	1: disable bit 06-11	
		Bit 13~14	00B: No function	
			01B: operated by digital keypad	
			02B: operated by Pr.00-15 setting	
			03B: change operation source	
		Bit 15	Reserved	
	2001H	Frequency		
		Bit 0	1: EF (external fault) on	
	2002H	Bit 1	1: Reset	
	200211	Bit 2	1: B.B. ON	
		Bit 3-15	Reserved	
	2100H		refer to Pr.06-16 to Pr.06-21	
		Bit 0-Bit 1		
			01: deceleration	
		_	10: Ready for operation	
			11: operation	
		Bit 2	1:JOG command	
		_	00: FWD command, FWD output	
Status		Bit 3-Bit 4	01: FWD command, REV output	
monitor Read			10: REV command, FWD output	
only			11: Reserved	
	044011	Bit 5	Reserved	
	2119H	Bit 6	Reserved	
		Bit 7	Reserved	
		Bit 8	1: Master frequency Controlled by communication interface	
		Bit 9	1: Master frequency controlled by analog/external terminals signal	
		Bit 10	1: Operation command controlled by communication interface	
		Bit 11	1: Parameters have been locked	
		Bit 12	1: enable to copy parameter from keypad	
		Bit 13-15	Reserved	
	2102H		command (F)	
	2102H	Output free		
	2100H		rent (AXXX.X)	
	2105H		oltage (UXXX.X)	
	2106H		age (EXXX.X)	
	2100H		p number of Multi-Step Speed Operation	
	2116H	Multi-functi	on display (Pr.00-04)	
	2120H	Frequency	command when malfunction	
	2121H		quency when malfunction	
	2122H		rent when malfunction	
	2123H		uency when malfunction	
	2124H		age when malfunction	
	2125H	DC-bus vo	Itage when malfunction	
	2126H		ver when malfunction	
	2127H	Output torc	que when malfunction	
			perature of Power Module at Present Fault	

4-103

# Call 1(800)985-6929 food the tales of the second se

# Call 1(800)985-6929 foortSalestrives.scales@deltaacdrives.com

### Chapter 4 Parameters | VFD-VL

Content	Address	Function
	2129H	Input status of multi-function terminal when malfunction
		(format is the same as Pr.00-04=16)
	212AH	Output status of multi-function terminal when malfunction (format is the same as Pr.00-04=17)
	212BH	Drive status when malfunction (format is the same as 2119H)
	2201H	Pr.00-05 user-defined setting
	2203H	AUI1 analog input (XXX.XX %)
	2204H	ACI analog input (XXX.XX %)
	2205H	AUI2 analog input (XXX.XX %)
	2206H	Display temperature of IGBT (°C)
	2207H	Display temperature of heatsink (°C) (only for model 40HP
		and above)
	2208H	Digital input state
	2209H	Digital output state

3.6 Exception response:

The AC motor drive is expected to return a normal response after receiving command messages from the master device. The following depicts the conditions when no normal response is replied to the master device.

The AC motor drive does not receive the messages due to a communication error; thus, the AC motor drive has no response. The master device will eventually process a timeout condition.

The AC motor drive receives the messages without a communication error, but cannot handle them. An exception response will be returned to the master device and an error message "CExx" will be displayed on the keypad of AC motor drive. The xx of "CExx" is a decimal code equal to the exception code that is described below.

In the exception response, the most significant bit of the original command code is set to 1, and an exception code which explains the condition that caused the exception is returned.

Example of an exception response of command code 06H and exception code 02H:

ASCII mode	:
STX	·.'
Address Low	ʻ0'
Address High	'1'
Function Low	'8'
Function High	'6'
Exception code	ʻ0'
Exception code	'2'
LRC CHK Low	'7'
LRC CHK High	'7'
END 1	CR
END 0	LF

RTU mode:							
Address	01H						
Function	86H						
Exception code	02H						
CRC CHK Low	C3H						
CRC CHK High	A1H						

The explanation of exception codes:

Exception code	Explanation
01	Illegal function code: The function code received in the command message is not available for the AC motor drive.
02	Illegal data address: The data address received in the command message is not available for the AC motor drive.

4-104

# Call 1(800)985-6929 the tales rives.com


### Chapter 4 Parameters | VFD-VL

Exception code	Explanation
03	Illegal data value: The data value received in the command message is not available for the AC drive.
04	Slave device failure: The AC motor drive is unable to perform the requested action.
10	Communication time-out: If Pr.09-03 is not equal to 0.0, Pr.09-02=0~1, and there is no communication on the bus during the Time Out detection period (set by Pr.09-03), "cE10" will be shown on the keypad.

09-05	9-05 × Response Delay Time								
Control mode	VF	VFPG	Factory Setting: 2.0						
	Settings	0.	0 ~ 200	).0 ms					

Description: This parameter is the response delay time after AC drive receives communication command

as shown in the following.



Chapter 4 Parameters | VFD-VL

10-00	PG Signal T	Гуре			
Contro mode		CPG	TQCPG	FOCPM	Factory Setting: 0
	Settings		0 No	function	
			1 AE	3Z	
			2 AE	3Z+ Hall	
			3 SI	N/COS+Sinusoidal	
			4 SI	N/COS+Endat	
			5 SI	N/COS	
			6 SI	N/COS + Hiperface	
ш ,	When Pr.10-00	) is se	et to 3, e	encoder will have one sine and one cosine	signal for each
I	revolution. The	e sigr	nal musi	be: 0.75 to 1.2Vpp for the amplitude with	phase angle 90°±5 elec.
	(EX: ERN 1185	5 ERI	N 1387)		
ш ,	When setting is	s 4 or	r 6, it ne	eds to wait for 2 seconds after applying th	e power to execute RUN
	command.				
	Detection of the	e ma	gnetic p	ole:	
:	Setting 1 or 5:	The /	AC moto	or drive will output short circuit to detect th	e position of the magnetion
	pole. At this mo	omen	it, the m	otor will generate a little noise.	
:	Setting 2: The	AC m	notor dri	ve will detect the position of the magnetic	pole by the UVW signal

## 4.2.11 Group 10 Speed Feedback Control Parameters

of encoder.

Setting 3: The AC motor drive will detect the position of the magnetic pole by the sine signal of encoder.

Setting 4 or 6: The AC motor drive will detect the position of the magnetic pole by the communication signal of encoder.

## Ш

## Reference table for tuning

Setting of PG signal type	PG signal type	Applicable PG card	Pr.08-00=1	Pr.08-00=3
10-00=1	A, B, Z	EMVL-PGABO/ABL	Motor will run	Motor will run
10-00=2	A, B, Z+U, V, W	EMVL-PGABL	Motor will run	Motor will run
10-00=3	SIN/COS+ Sinusoidal	EMVL-PGH01/02	Motor will run	Motor will run

# Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

## Chapter 4 Parameters | VFD-VL

Setting of PG signal type	PG signal type	Applicable PG card	Pr.08-00=1	Pr.08-00=3
10-00=4	SIN/COS+Endat	EMVL-PGS01	Motor will run	Motor won't run
10-00=5	SIN/COS	EMVL-PGH01/02	Motor will run	Motor will run
10-00=6	SIN/COS + Hiperface	EMVL-PGS01	Motor will run	Motor won't run

10-01 Encoder Pulse	
Control VFPG FOCPG TQCPG FOCPM mode	Factory Setting: 600
Settings 1 to 20000	

A Pulse Generator (PG) or encoder is used as a sensor that provides a feedback signal of the

motor speed. This parameter defines the number of pulses for each cycle of the PG control.

10-02	Encode	r Input T	Гуре S	etting	
Control mode	VFPG	FOCPG	TQCF	PG FOCPM	Factory Setting: 0
	Settings	3	0	Disable	
				Phase A leads in a forward run command and pha reverse run command FWD	ase B leads in a
			1	Forward B	
				Phase B leads in a forward run command and pha reverse run command	ase A leads in a
			2		
				Phase A is a pulse input and phase B is a directio input=reverse direction, high input=forward directi	
			3	Forward B B	
				Phase A is a pulse input and phase B is a directio input=forward direction, high input=reverse directi	
			4	Forward B	REV

# Call 1(800)985-6929 fberltaaleetrives.scalers@deltaacdrives.com

# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

## Chapter 4 Parameters | VFD-VL

	i urumet					
			Si	ngle-phase input		
			5 ((	Forward		
🕮 lt	is helpfu	I for the	stable co	ontrol by inputting	correct pulse type.	
10-03	🖌 Ence	oder Fee	dback F	ault Treatment (PC	GF1, PGF2)	
Control mode	VFPG	FOCPG	TQCPG			Factory Setting: 2
	Setting	S	0 W	arn and keep oper	ation	
			1 W	arn and RAMP to	stop	
			2 W	arn and stop opera	ation	
10-04	🖌 Dete	ection Tir	ne for Er	ncoder Feedback I	Fault	
Control mode	VFPG	FOCPG	TQCPG	FOCPM		Factory Setting: 1.0
	Setting	s 0	.0 to 10.	0 sec		
🕮 w	hen PG	loss, end	oder sig	nal error, pulse sig	nal setting error or sign	al error, if time exceeds
th	e detecti	on time t	or encod	ler feedback fault	(Pr.10-04), the PG sign	al error will occur. Refer
to	the Pr.1	0-03 for	encoder	feedback fault trea	atment.	
10-05	⊮ Enc	oder Sta	I Level (	PGF5)		
Control mode	VFPG	SVC	FOCPG	FOCPM		Factory Setting: 115
	Setting	s 0	to 120%	o (0: disable)		
III III	nis paran	neter det	ermines	the maximum end	oder feedback signal al	lowed before a fault
00	curs. (m	ax. outp	ut freque	ncy Pr.01-00 =100	)%)	
10-06	🖌 Ence	oder Sta	ll Detecti	on Time		
Control mode	VFPG	SVC	FOCPG	FOCPM		Factory Setting: 0.1
	Setting	s C	.0 to 2.0	sec		
10-07	🖌 Enc	oder Slip	Range	(PGF7)		
Control mode	VFPG	SVC	FOCPG	FOCPM		Factory Setting: 50
	Setting	s C	to 50%	(0: disable)		

# Call 1(800)985-6929 fbertaaledrives.salers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL


10-08	🖌 Encod	der Slip	Detectio	on Time			
Control mode	VFPG	svc	FOCPG	FOCPM	Factory Setting: 0.5		
	Settings	C	0.0 to 10.	) sec			
10-09	🖌 Enco	✓ Encoder Stall and Slip Error Treatment					
Control mode	VFPG	SVC	FOCPG	FOCPM	Factory Setting: 2		
	Settings	C	) W	arn and keep operating			
		1	ı w	arn and RAMP to stop			
		2	2 W	arn and COAST to stop			

When the value of (rotation speed – motor frequency) exceeds Pr.10-07 setting, detection time exceeds Pr.10-08 or motor frequency exceeds Pr.10-05 setting, it will start to accumulate time. If detection time exceeds Pr.10-06, the encoder feedback signal error will occur. Refer to Pr.10-09 encoder stall and slip error treatment.

10-10	Mode Selection for UVW Input						
Control mode	VFPG FO	CPG TQC	CPG FOCPM	Factory Setting: 0			
	Settings	0	Z signal is at the falling edge of U-phase				
		1	Z signal is at the rising edge of U-phase				

Setting 0: when the operation is U->V->W, Z signal is at the falling edge of U-phase.

Setting 1: when the operation is U->V->W, Z signal is at the rising edge of U-phase.



10-11	✓ ASR (Auto Speed Regulation) Control (P) of Zero Speed				
Control mode	VF	VFPG	SVC	FOCPG FOCPM	Factory Setting: 100.0

# Call 1(800)985-6929 foortSalestrives.sales@deltaacdrives.com

### Chapter 4 Parameters | VFD-VL

	Settings	0.	0 to 50	0.0%		
10-12	🖌 ASR	(Auto Sp	eed Re	egulation	) Control (I) of Zero S	Speed
Control mode	VF	VFPG	SVC	FOCPG	FOCPM	Factory Setting: 0.100
	Settings	0.	000 to	10.000 s	ec	
10-13	₩ASR (	Auto Spe	eed Re	gulation)	control (P) 1	
Control mode	VF	VFPG	SVC	FOCPG	FOCPM	Factory Setting: 100.0
	Settings	0.	0 to 50	0.0%		
10-14	🖌 ASR	(Auto Sp	eed Re	egulation	) control (I) 1	
Control mode	VF	VFPG	SVC	FOCPG	FOCPM	Factory Setting: 0.100
	Settings	0.	000 to	10.000 s	ec	
10-15	🖌 ASR	(Auto Sp	eed Re	egulation	) control (P) 2	
Control mode	VF	VFPG	SVC	FOCPG	FOCPM	Factory Setting: 100.0
	Settings	0.	0 to 50	0.0%		
10-16	🖌 ASR	(Auto Sp	eed Re	egulation	) control (I) 2	
Control mode	VF	VFPG	SVC	FOCPG	FOCPM	Factory Setting: 0.100
	Settings	0.	000 to	10.000 s	ec	
10-17	🖌 ASR	1/ASR2	Switch	Frequen	су	
Control mode	VF	VFPG	SVC	FOCPG	FOCPM	Factory Setting: 7.00
	Settings	0.	00 o 40	0.00Hz		
		0.	00: dis	able		


ASR P determines Proportional control and associated gain (P). ASR I determines integral control and associated gain (I).

When integral time is set to 0, it is disabled. Pr.10-17 defines the switch frequency for the ASR1 (Pr.10-13, Pr.10-14) and ASR2 (Pr.10-15, Pr.10-16).

4-110


# Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL



When using multi-function input terminals to switch ASR1/ASR2, the diagram will be shown as

follows.



10-18	✓ ASR Primary Low Pas	s Filter Gain	
Control mode	VF VFPG SVC	FOCPG FOCPM	Factory Setting: 0.008
	Settings 0.000 to 0.	350 sec	
🕮 lt e	lefines the filter time of the	e ASR command.	
₽ W	hen setting to 1, this functi	ion is disabled.	
10-19	✓ Zero Speed Gain (P)		
Control mode	FOCPM		Factory Setting: 80.00
	Settings 0.00 to 65	5.00%	
₩ W	hen Pr.11-00 is set to Bit 7	7=1, Pr.10-19 is valid.	
10-20	✔ Zero Speed/ASR1 Wid	dth Adjustment	
Control mode	VFPG FOCPG FOCPM		Factory Setting: 5.00
	Settings 0.0 to 400.	.00Hz	
10-21	✔ ASR1/ASR2 Width Ad	justment	
Control mode	VFPG FOCPG FOCPM		Factory Setting: 5.00
	Settings 0.0 to 400.	.00Hz	


Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

# Call 1(800)985-6929 fbertaaledrives.salers@deltaacdrives.com

## Chapter 4 Parameters | VFD-VL

I These two parameters are used to decide width of slope of ASR command during zero speed

to low speed or Pr.10-17 to high speed.




10-22	🖌 Zero S	peed Posi	tion Hold	ing Time		
Control mode	FOCPM					Factory Setting: 0.250
	Settings	0.001	to 65.53	35sec		
10-23	🖌 Filter T	Time at Zei	o Speed			
Control mode	FOCPM					Factory Setting: 0.004
	Settings	0.001	to 65.53	35sec		
10-24	🖌 Time f	or Executi	ng Zero S	Speed		
Control mode	FOCPM					Factory Setting: 0
	Settings	0	After t	he brake rel	ease set in P	r.02-29
		1	After t	he brake sig	nal input (Pr	.02-01~02-08 is set to 42)
		-24=0, the a in Pr.02-3		ed control n	eeds to be us	ed with Pr.02-29. (refer to the
10-25	🖌 Elevat	or Leveling	g (Zero S	peed Gain I	<sup>&gt;</sup> )	
Control mode	VF	VFPG	SVC	FOCPG	FOCPM	Factory Setting: 0
	Settings	0~1	000.0%			
10-26	⊮ Elev	ator Leveli	ng (Zero	Speed Integ	gral I)	
Control mode	VF	VFPG	SVC	FOCPG	FOCPM	Factory Setting: 0
	Settings	0~1	0.000 se	ec		

Call 1(800)985-6929 foortaalestrives.salers@deltaacdrives.com

# Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

Chapter 4 Parameters | VFD-VL




Chapter 4 Parameters | VFD-VL

11-00 System Control						
Control mode	FOCPG FO	СРМ	Factory Setting: 0			
	Settings	Bit 0=0	No function			
		Bit 0=1	ASR Auto tuning, PDFF enable			
		Bit 7=0	No function			
		Bit 7=1	When position control is enabled, it doesn't need to set Pr.07-02 (DC Brake Current Level)			
		Bit 15=0	when power is applied, it will detect the position of magnetic pole again			
		Bit 15=1	when power is applied, it will start from the magnetic pole position of previous power failure			

# 4.2.12 Group 11 Advanced Parameters


Bit 0=1: PDFF function is enabled and system will generate an ASR setting, Pr. 10-11~10-16

will be invalid and Pr.11-09 to 11-10 will be valid.



# Call 1(800)985-6929 food latestrives.sales@deltaacdrives.com


#### Chapter 4 Parameters | VFD-VL



Call 1(800)985-6929 foortaalestrives.salers@deltaacdrives.com

# Call 1(800)985-6929 fbertaaledrives.salers@deltaacdrives.com

#### Chapter 4 Parameters | VFD-VL



11-05	🖌 Inertial Rat	io	
Control mode	FOCPG FOCP	M	Factory Setting: 40
	Settings	1 to 300%	

The load inertia can be calculated by the settings of motor parameter, Pr.11-02 Sheave Diameter, Pr.11-14 Motor Current at Accel. and Pr.11-15 Elevator Acceleration. This

parameter can be used to adjust inertia ratio of load.

11-06	✓ Zero-spe	ed Bandwidth					
11-07	✓ Low-spee	Low-speed Bandwidth					
11-08	✓ High-spe						
Control mode	FOCPG FOC	PM	Factory Setting: 10				
	Settings	0 to 40Hz					

After estimating inertia and set Pr.11-00=1 (auto tuning), user can adjust parameters Pr.11-06, 11-07 and 11-08 separately by speed response. The larger number you set, the faster response you will get. Pr.10-08 is the switch frequency for low-speed/high-speed bandwidth.


11-09	✓ PDFF Gain Value					
Control mode	FOCPG FOCI	PM	Factory Setting: 30			
	Settings	0 to 200%				


# Call 1(800)985-6929 fbertaaledrives.salers@deltaacdrives.com

### Chapter 4 Parameters | VFD-VL

- After finishing estimating and set Pr.11-00=1 (auto tuning), using Pr.11-09/11-10 to reduce overshoot. Please adjust PDFF gain value by actual situation.
- Besides traditional PI control, it also provides PDFF function to reduce overshoot for speed control.
  - 1. Get system inertia
  - 2. Set Pr.11-00 to 1
  - 3. Adjust Pr.11-09/11-10 (the larger number is set and the suppressed overshoot function will

be better. But it needs to be used by the actual condition)





Pr.11-09 and Pr.11-10 will be enabled when Pr.11-00 is set to Bit0=1.

11-1	11	✓ Notch Filt	er Depth				
Cont		FOCPG FOC	РМ	Factory Setting: 0			
		Settings	0 to 20 db				
11-1	12	🖋 Notch Filt	er Frequency				
Cont		FOCPG FOC	РМ	Factory Setting: 0.00			
		Settings	0.00 to 200.00Hz				
	Thi	is parameter	is used to set resonance frequency of mechanica	I system. It can be used to			
	sup	opress the res	sonance of mechanical system.				
	The	The larger number you set Pr.11-11, the better suppression resonance function you will get.					

The notch filter frequency is the resonance of mechanical frequency.

## Call 1(800)985-6929 ther tales by seven we have a seven we hav


# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

Chapter 4 Parameters | VFD-VL

Control	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		Factory Setting: 0.500
mode								
	Settings	0.0	001 to 6	65.535 s				
🕮 lti	s used to	lower th	e blinki	ng freque	ency of	LCD displa	ay.	
11-14	🖌 Motor	Current	at Acc	el.				
Control mode	FOCPM							Factory Setting: 150
	Settings	50	to 200	%				
11-15	🖌 Elevat	tor Acce	leratior	ı				
Control mode	FOCPM							Factory Setting: 0.75


Call 1(800)985-6929 food the tales of the second se

# 4.2.13 Group 12 User-defined Parameters



Call 1(800)985-6929 fbrit@alextrives.szalers@deltaacdrives.com Chapter 4 Parameters | VFD-VL

Example 2: If it needs to enter parameter address 2102H and 211BH by the digital keypad,
 211BH needs to be converted to binary value before entering.




The setting method of 2102H

# Call 1(800)985-6929 the tales rives.com

Chapter 4 Parameters | VFD-VL

The setting method of 211BH

Convert 211BH (hexadecimal) to decimal value:



### Call 1(800)985-6929 foortSalestrives.sales@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

In the following, it shows the factory setting of Pr.12-00 to Pr.12-29. You can change the setting as required.

	ao roquire							
12-00	✓ Prese	nt Fault F	Record					
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		
	Settings	0610						
12-01	🖌 Prese	nt Fault 1	Fime of	f Motor C	Operation	n (min.)		
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		
	Settings	0620						
12-02	✓ Prese	nt Fault	Time of	f Motor C	Operation	n (day)		
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		
	Settings	0621						
12-03	🖌 Frequ	ency Cor	nmanc	d at Pres	ent Faul	t		
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		
	Settings	2120						
12-04	🖌 Outpu	it Freque	ncy at	Preset F	ault			
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		
	Settings	2121						
12-05	🖌 Outpu	t Current	at Pre	esent Fau	ult			
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		
	Settings	2122						
12-06	× Motor	Frequen	cy at F	Present F	ault		 	 
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM		
	Settings	2123						
-								

Call 1(800)985-6929 fbertaaledrives.salers@deltaacdrives.com

# Call 1(800)985-6929 (the tales rives.sales@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

12-07	🖌 Outpu	ut Voltage	e at Pre	esent Fai	ult	
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	2124				
12-08	🖌 DC-B	us Voltag	ge at P	resent Fa	ault	
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	2125				
12-09		it Power		sent Faul	t	
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	2126				
12-10	🖌 Outpu	ut Torque	at Pre	sent Fau	ılt	
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	2127				
12-11	🖌 IGBT	Tempera	ature of	f Power I	Module a	at Present Fault
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	2128				
12-12	🖌 Multi-	function <sup>-</sup>	Termin	al Input S	Status at	Present Fault
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	2129				
12-13						at Present Fault
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	212A				

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

## Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

Chapter 4 Parameters | VFD-VL

-						
12-14	🖌 Drive	Status a	Prese	ent Fault		
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	212B				
12-15	🖌 Seco	nd Most F	Recent	Fault Re	ecord	
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	0611				
12-16	🖌 Secor	nd Most F	Recent	Fault Tir	me of Mo	otor Operation (min.)
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	0622				
12-17	🖌 Secor	nd Most F	Recent	Fault Tir	me of Mo	otor Operation (day)
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	0623				
12-18	🖌 Third	Most Re	cent Fa	ault Reco	ord	
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	0612				
12-19	🖌 Third	Most Re	cent Fa	ault Time	of Moto	r Operation (min.)
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	0624				
12-20	🖌 Third	Most Re	cent Fa	ault Time	of Moto	r Operation (day)
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	0625				

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

## Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

Chapter 4 Parameters | VFD-VL

12-21	🖌 Fourt	h Most R	ecent	Fault Red	cord	
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	0613				
12-22	🖌 Fourt	h Most R	ecent	Fault Tim	e of Mot	or Operation (min.)
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	ГОСРМ
	Settings	0626				
12-23	✓ Fourt	h Most R	ecent	Fault Tim	e of Mot	or Operation (day)
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	0627				
12-24	🖌 Fifth	Most Red	ent Fa	ult Recor	ď	
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	0614				
12-25	🖌 Fifth	Most Red	ent Fa	ult Time	of Motor	Operation (min.)
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	0628				
12-26	🖌 Fifth	Most Red	ent Fa	ult Time	of Motor	Operation (day)
Control mode	VF	VFPG	svc	FOCPG	TQCPG	FOCPM
	Settings	0629				
12-27	🖌 Sixth	Most Re	cent Fa	ault Reco	rd	
Control mode	VF	VFPG	SVC	FOCPG	TQCPG	FOCPM
	Settings	0615				

## Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

Chapter 4 Parameters | VFD-VL

12-28	🖌 Sixth	Most Re	cent Fa	ault Time of Motor Operation (min.)
Control mode	VF	VFPG	SVC	FOCPG TQCPG FOCPM
	Settings	662A		
12-29	N Sixth	Most Re	cent Fa	ault Time of Motor Operation (day)
Control mode	VF	VFPG	SVC	FOCPG TQCPG FOCPM
	Settings	6062B		

Chapter 4 Parameters | VFD-VL


### 4.2.14 Group 13 View User-defined Parameters

13-00   13-31	View Us	ser-define	ed Para	meters			
Control mode	VF	VFPG	SVC	FOCPG	TQCPG FOC	РМ	Factory Setting: -
	Settings	3	-				

Refer to group 12 for details.


Call 1(800)985-6929 the talestrives.scales@deltaacdrives.com

# Chapter 5 Troubleshooting




Chapter 5 Troubleshooting | VFD-VL

### 5.2 Ground Fault




### 5.4 Low Voltage (Lv)




Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

Chapter 5 Troubleshooting | VFD-VL

### 5.5 Over Heat (OH)




### 5.6 Overload




Call 1(800)985-6929 foortaaleetrives.scalers@deltaacdrives.com

### 5.7 Display of KPVL-CC01 is Abnormal




## 5.8 Phase Loss (PHL)



Call 1(800)985-6929 fueltSalestrives.scalers@deltaacdrives.com


Chapter 5 Troubleshooting | VFD-VL

### 5.9 Motor cannot Run



Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com


### 5.10 Motor Speed cannot be Changed




Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

Chapter 5 Troubleshooting | VFD-VL

### 5.11 Motor Stalls during Acceleration



### 5.12 The Motor does not Run as Expected



### Call 1(800)985-6929 thertaaleetrives.scalers@deltaacdrives.com

#### Chapter 5 Troubleshooting | VFD-VL

#### 5.13 Electromagnetic/Induction Noise

There are many noises surround the AC motor drives and invade it by radiation or power circuit. It may cause the misoperation of control circuit and even damage the AC motor drive. Of course, that is a solution to increase the noise tolerance of AC motor drive. But it is not the best one due to the limit. Therefore, solve it from the outside as following will be the best.

- 1. Add surge killer on the relay or contact to suppress switching surge between ON/OFF.
- Shorten the wiring length of the control circuit or serial circuit and separate from the main circuit wiring.

 Comply with the wiring regulation for those shielded wire and use isolation amplifier for long wire.

- The grounding terminal should comply with the local regulation and ground independently, i.e. not to have common ground with electric welding machine and power equipment.
- Connect a noise filter at the input terminal of the AC motor drive to prevent noise from power circuit.

In a word, three-level solutions for electromagnetic noise are "no product", "no spread" and "no receive".

#### 5.14 Environmental Condition

Since AC motor drive is an electronic device, you should comply with the environmental condition stated in the appendix A. Following are the remedial measures for necessary.

- To prevent vibration, anti-vibration spacer is the last choice. The vibration tolerance must be within the specification. The vibration effect is equal to the mechanical stress and it cannot occur frequently, continuously or repeatedly to prevent damaging AC motor drive.
- Store in a clean and dry location free from corrosive fumes/dust to prevent rustiness, poor contact. It also may cause short by low insulation in a humid location. The solution is to use both paint and dust-proof. For particular occasion, use the enclosure with whole-seal structure.
- 3. The surrounding temperature should be within the specification. Too high or low temperature will affect the lifetime and reliability. For semiconductor components, damage will occur once any specification is out of range. Therefore, it is necessary to clean and periodical check for the air cleaner and cooling fan besides having cooler and sunshade.

### Call 1(800)985-6929 therital alcohrives.com

### Call 1(800)985-6929 fbertaaledrives.salers@deltaacdrives.com

#### Chapter 5 Troubleshooting | VFD-VL

In additional, the microcomputer may not work in extreme low temperature and needs to have heater.

Store within a relative humidity range of 0% to 90% and non-condensing environment. Do
not turn off the air conditioner and have exsiccator for it.


#### 5.15 Affecting Other Machines

AC motor drive may affect the operation of other machine due to many reasons. The solutions are as follows.

High Harmonic at Power Side

If there is high harmonic at power side during running, the improved methods are:

- 1. Separate power system: use transformer for AC motor drive.
- Use reactor at the power input terminal of AC motor drive or decrease high harmonic by multiple circuit.
- If there is phase lead capacitor, it should use serial reactor to prevent capacitor damage from high harmonic.



Motor Temperature Rises

When the motor is induction motor with ventilation-cooling-type used in variety speed operation, bad cooling will happen in the low speed. Therefore, it may overheat. Besides, high harmonic is in output waveform to increase copper loss and iron loss. Following measures should be used by load situation and operation range when necessary.

- 1. Use the motor with independent power ventilation or increase the horsepower.
- 2. Use inverter duty motor.
- 3. Do NOT run in the low speed

Call 1(800)985-6929 thertaaleetrives.scalers@deltaacdrives.com

# Chapter 6 Fault Code Information

### 6.1 Fault Code Information

The AC motor drive has a comprehensive fault diagnostic system that includes several different alarms and fault messages. Once a fault is detected, the corresponding protective functions will be activated. The following faults are displayed as shown on the AC motor drive digital keypad display. The six most recent faults can be read from the digital keypad or communication.

The AC motor drive is made up by numerous components, such as electronic components, including IC, resistor, capacity, transistor, and cooling fan, relay, etc. These components can't be used permanently. They have limited-life even under normal operation. Preventive maintenance is required to operate this AC motor drive in its optimal condition, and to ensure a long life.

Basic check-up items to detect if there were any abnormalities during operation are:


		Wait 5 seconds after a fault has been cleared before performing reset
		via keypad of input terminal.
CAUTION	•	When the power is off after 5 minutes for $\leq$ 22kW models and 10
		minutes for $\geqq$ 30kW models, please confirm that the capacitors have
		fully discharged by measuring the voltage between DC+ and DC The
		voltage between DC+ and DC- should be less than 25VDC.
	•	Only qualified personnel can install, wire and maintain AC motor
		drives. Please take off any metal objects, such as watches and rings,
		before operation. And only insulated tools are allowed.
	•	Never reassemble internal components or wiring.
	•	Make sure that installation environment comply with regulations
		without abnormal noise, vibration and smell.

Call 1(800)985-6929 for the tales rives.com

Chapter 6 Fault Code Information | VFD-VL

### 6.1.1 Common Problems and Solutions

Following fault name will only be displayed when using with optional digital keypad KPVL-CC01.



Display	Description
	Over-current during acceleration (Output current exceeds triple rated current during acceleration.)
oc at Accel Fo FaultCode:01	<ol> <li>Corrective Actions:         <ol> <li>Short-circuit at motor output: Check for possible poor insulation at the output lines.</li> <li>Acceleration Time too short: Increase the Acceleration Time.</li> <li>AC motor drive output power is too small: Replace the AC motor drive with the next higher power model.</li> </ol> </li> </ol>
oc at Decel Fª FaultCode: 02	<ul> <li>Over-current during deceleration (Output current exceeds triple rated current during deceleration.)</li> <li>Corrective Actions: <ol> <li>Short-circuit at motor output: Check for possible poor insulation at the output line.</li> <li>Deceleration Time too short: Increase the Deceleration Time.</li> <li>AC motor drive output power is too small: Replace the AC motor drive with the next higher power model.</li> </ol></li></ul>
	Over-current during steady state operation (Output current exceeds triple rated current during constant speed.)
oc at Normal SPD F& FaultCode:03	<ol> <li>Corrective Actions:</li> <li>Short-circuit at motor output: Check for possible poor insulation at the output line.</li> <li>Sudden increase in motor loading: Check for possible motor stall.</li> <li>AC motor drive output power is too small: Replace the AC motor drive with the next higher power model.</li> </ol>

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

# Call 1(800)985-6929 footsalestrives.scalers@deltaacdrives.com

#### Chapter 6 Fault Code Information | VFD-VL

Display	Description
Ground Fault Fo FaultCode:04	<ul> <li>Ground fault</li> <li>Corrective Actions:</li> <li>When (one of) the output terminal(s) is grounded, short circuit current is more than 75% of AC motor drive rated current, the AC motor drive power module may be damaged.</li> <li>NOTE: The short circuit protection is provided for AC motor drive protection, not for protection of the user.</li> <li>Check the wiring connections between the AC motor drive and motor for possible short circuits, also to ground.</li> <li>Check whether the IGBT power module is damaged.</li> <li>Check for possible poor insulation at the output line.</li> </ul>
Short Fault F• FaultCode:05	Short-circuit is detected between upper bridge and lower bridge of the IGBT module. Corrective Actions: Return to the factory
oc at Stop Fo FaultCode:06	Over-current at stop Corrective Actions: Return to the factory
ov at Accel Fo FaultCode:07	<ul> <li>DC BUS over-voltage during acceleration (230V: DC 450V; 460V: DC 900V)</li> <li>Corrective Actions: <ol> <li>Check if the input voltage falls within the rated AC motor drive input voltage range.</li> <li>Check for possible voltage transients.</li> <li>If DC BUS over-voltage due to regenerative voltage, please increase the Deceleration Time or add an optional brake resistor.</li> </ol> </li> </ul>
ov at Decel Fo FaultCode:08	<ul> <li>DC BUS over-voltage during deceleration (230V: DC 450V; 460V: DC 900V)</li> <li>Corrective Actions: <ol> <li>Check if the input voltage falls within the rated AC motor drive input voltage range.</li> <li>Check for possible voltage transients.</li> <li>If DC BUS over-voltage due to regenerative voltage, please increase the Deceleration Time or add an optional brake resistor.</li> </ol> </li> </ul>
ov at Normal SPD F• FaultCode:09	<ul> <li>DC BUS over-voltage during constant speed (230V: DC 450V; 460V: DC 900V)</li> <li>Corrective Actions: <ol> <li>Check if the input voltage falls within the rated AC motor drive input voltage range.</li> <li>Check for possible voltage transients.</li> <li>If DC BUS over-voltage due to regenerative voltage, please increase the Deceleration Time or add an optional brake resistor.</li> </ol></li></ul>

Call 1(800)985-6929 food the tales of the second se

# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

#### Chapter 6 Fault Code Information | VFD-VL

Display	Description				
	DC BUS over-voltage at stop				
ov at Stop F• FaultCode:10	<ol> <li>Corrective Actions:</li> <li>Check if the input voltage falls within the rated AC motor drive input voltage range.</li> <li>Check for possible voltage transients.</li> </ol>				
Lv at Accel Fo FaultCode:11	<ul> <li>DC BUS voltage is less than Pr.06-00 during acceleration.</li> <li>Corrective Actions: <ol> <li>Check if the input voltage is normal</li> <li>Check for possible sudden load</li> </ol> </li> </ul>				
Lv at Decel Fo FaultCode: 12	DC BUS voltage is less than Pr.06-00 during deceleration. Corrective Actions: 1. Check if the input voltage is normal 2. Check for possible sudden load				
Lv at Normal SPD F• FaultCode:13	DC BUS voltage is less than Pr.06-00 during constant speed. <b>Corrective Actions:</b> 1. Check if the input voltage is normal 2. Check for possible sudden load				
Lv at Stop Fo FaultCode:14	Low voltage at stop Corrective Actions: 1. Check if the input voltage is normal 2. Check for possible sudden load				
Phase Loss F• FaultCode:15	Phase loss Corrective Actions: Check Power Source Input if all 3 input phases are connected without loose contacts.				
I GBT Over Heat Fa FaultCode: 16	<ul> <li>IGBT overheating</li> <li>IGBT temperature exceeds protection level</li> <li>1 to15HP: 90 °C</li> <li>20 to 100HP: 100 °C</li> <li>Corrective Actions: <ol> <li>Ensure that the ambient temperature falls within the specified temperature range.</li> <li>Make sure that the ventilation holes are not obstructed.</li> <li>Remove any foreign objects from the heatsinks and check for possible dirty heat sink fins.</li> <li>Check the fan and clean it.</li> <li>Provide enough spacing for adequate ventilation.</li> </ol> </li> </ul>				

# Call 1(800)985-6929 footsalestrives.scalers@deltaacdrives.com

#### Chapter 6 Fault Code Information | VFD-VL

Display	Description
	IGBT overheating IGBT temperature exceeds protection level 40 to100HP: 100 °C
Heat Sink oH Fo FaultCode: 17	<ol> <li>Corrective Actions:</li> <li>Ensure that the ambient temperature falls within the specified temperature range.</li> <li>Make sure that the ventilation holes are not obstructed.</li> <li>Demons on terminal chiests from the besteinke and</li> </ol>
	<ol> <li>Remove any foreign objects from the heatsinks and check for possible dirty heat sink fins.</li> <li>Check the fan and clean it.</li> <li>Provide enough spacing for adequate ventilation.</li> </ol> IGBT hardware failure
IGBT HW Err F• FaultCode:18	Corrective Actions: Return to the factory
Heat Sink HW Err Fo FaultCode:19	Heatsink overheating Corrective Actions: Return to the factory
Fan Locked Fo FaultCode:20	Fan failure         Corrective Actions:         1. Make sure that the fan is not obstructed.         2. Return to the factory
Inverter oL Fo FaultCode: 21	Overload The AC motor drive detects excessive drive output current. NOTE: The AC motor drive can withstand up to 150% of the rated current for a maximum of 60 seconds. Corrective Actions: 1. Check whether the motor is overloaded.
	2. Take the next higher power AC motor drive model. Motor 1 overload
Thermal Relay 1 Fo FaultCode: 22	<ol> <li>Corrective Actions:         <ol> <li>Check whether the motor is overloaded.</li> <li>Check whether the rated current of motor (Pr.05-01) is suitable</li> <li>Take the next higher power AC motor drive model.</li> </ol> </li> </ol>
Motor Over Heat Fo FaultCode:24	Motor overheating         The AC motor drive detects that the internal temperature exceeds Pr.06-30 (PTC level)         Corrective Actions:         1. Make sure that the motor is not obstructed.         2. Ensure that the ambient temperature falls within the specified temperature range.         3. Take the next higher power AC motor drive model.

# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

#### Chapter 6 Fault Code Information | VFD-VL

Display	Description
	Electronic Thermal Relay 1 Protection
Over Torque 1 Fo FaultCode:26	<ol> <li>Corrective Actions:         <ol> <li>Check whether the motor is overloaded.</li> <li>Check whether motor rated current setting (Pr.05-01) is suitable</li> <li>Check electronic thermal relay function</li> <li>Take the next higher power AC motor drive model.</li> </ol> </li> <li>Electronic Thermal Relay 2 Protection</li> </ol>
Over Torque 2 Fo FaultCode: 27	<ol> <li>Corrective Actions:         <ol> <li>Check whether the motor is overloaded.</li> <li>Check whether motor rated current setting (Pr.05-01) is suitable</li> <li>Check electronic thermal relay function</li> <li>Take the next higher power AC motor drive model.</li> </ol> </li> </ol>
EEPROM Write Err Fo FaultCode: 30	Internal EEPROM can not be programmed. Corrective Actions: 1. Press "RESET" key to the factory setting. 2. Return to the factory.
EEPROM Read Err Fo FaultCode: 31	Internal EEPROM can not be read. Corrective Actions: 1. Press "RESET" key to the factory setting. 2. Return to the factory.
Isum Sensor Err F• FaultCode: 32	Hardware failure in current detection Corrective Actions: Re-power on to try it. If fault code is still displayed on the keypad, please return to the factory.
las Sensor Err F• FaultCode:33	U-phase error Corrective Actions: Re-power on to try it. If fault code is still displayed on the keypad, please return to the factory.
lbs Sensor Err Fo FaultCode: 34	V-phase error Corrective Actions: Re-power on to try it. If fault code is still displayed on the keypad, please return to the factory. W-phase error
Ics Sensor Err Fo FaultCode: 35	Corrective Actions: Re-power on to try it. If fault code is still displayed on the keypad, please return to the factory. CC (current clamp)
cc HW Error Fo FaultCode: 36	Corrective Actions: Re-power on to try it. If fault code is still displayed on the keypad, please return to the factory.

Call 1(800)985-6929 food the tales of the second se

# Call 1(800)985-6929 fterltaaledrives.scalers@deltaacdrives.com

#### Chapter 6 Fault Code Information | VFD-VL

Display	Description
	OC hardware error
oc HW Error F• FaultCode:37	Corrective Actions: Re-power on to try it. If fault code is still displayed on the keypad, please return to the factory.
ov HW Error Fo FaultCode:38	OV hardware error Corrective Actions: Re-power on to try it. If fault code is still displayed on the keypad, please return to the factory.
GFF HW Error Fo FaultCode: 39	GFF hardware error Corrective Actions: Re-power on to try it. If fault code is still displayed on the keypad, please return to the factory.
	Auto tuning error
Auto Tuning Err Fo FaultCode:40	Corrective Actions: 1. Check cabling between drive and motor 2. Check the motor capacity and parameters settings 3. Retry again
	PID loss (ÁCI)
PID Fbk Error F• FaultCode:41	Corrective Actions: 1. Check the wiring of the PID feedback 2. Check the PID parameters settings
	PG feedback error
PG Fbk Error F∝ FaultCode:42	Corrective Actions: Check if Pr.10-01 is not set to 0 when it is PG feedback control
	PG feedback loss
PG Fbk Loss F• FaultCode:43	Corrective Actions: Check the wiring of the PG feedback
	PG feedback stall
PG Fbk Over SPD F• FaultCode:44	Corrective Actions: 1. Check the wiring of the PG feedback 2. Check if the setting of PI gain and deceleration is suitable 3. Return to the factory
	PG slip error
PG Fbk Deviate F• FaultCode:45	<ol> <li>Corrective Actions:</li> <li>Check the wiring of the PG feedback</li> <li>Check if the setting of PI gain and deceleration is suitable</li> <li>Return to the factory</li> </ol>

Call 1(800)985-6929 foor tales frives.sales @deltaacdrives.com

# Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

Chapter 6 Fault Code Information | VFD-VL

Display	Description
PG Ref Error Fo FaultCode:46	Pulse input error         Corrective Actions:         1.       Check the pulse wiring         2.       Return to the factory
PG Ref Loss F• FaultCode:47	Pulse input loss         Corrective Actions:         1.       Check the pulse wiring         2.       Return to the factory
ACI Loss Fo FaultCode:48	ACI loss Corrective Actions: 1. Check the ACI wiring 2. Check if the ACI signal is less than 4mA
External Fault Fo FaultCode: 49	<ul> <li>External Fault</li> <li>Corrective Actions: <ol> <li>Input EF (N.O.) on external terminal is closed to GND.</li> <li>Output U, V, W will be turned off.</li> </ol> </li> <li>Give RESET command after fault has been cleared.</li> </ul>
Emergency Stop Fo FaultCode:50	<ul> <li>Emergency stop</li> <li>Corrective Actions: <ol> <li>When the multi-function input terminals MI1 to MI8 are set to emergency stop and the AC motor drive stops output.</li> <li>Press RESET after fault has been cleared.</li> </ol> </li> </ul>
Base Block Fo FaultCode:51	<ul> <li>Base Block</li> <li>Corrective Actions: <ol> <li>When the multi-function input terminals MI1 to MI8 are set to base block and the AC motor drive stops output.</li> <li>Press RESET after fault has been cleared.</li> </ol> </li> </ul>
Password Error Fo FaultCode:52	Password is locked Corrective Actions: Keypad will be locked. Turn the power ON after power OFF to re-enter the correct password. See Pr.00-07 and 00-08.
PC Err Command F• FaultCode:54	Illegal function code Corrective Actions: Check if the function code is correct (function code must be 03, 06, 10, 63)
PC Err Address Fo FaultCode:55	Illegal data length Corrective Actions: Check if the communication data length is correct.
PC Err Data F@ FaultCode: 56	Illegal data value Corrective Actions: Check if the data value exceeds max./min. value.

Call 1(800)985-6929 footsalestrives.scalers@deltaacdrives.com

## Call 1(800)985-6929 for the tales rives.com

#### Chapter 6 Fault Code Information | VFD-VL

Display	Description
PC Slave Fault F& FaultCode:57	illegal communication address Corrective Actions: Check if the communication address is correct.
PC Time Out Fo FaultCode:58	Communication time-out Corrective Actions: Check if the wiring for the communication is correct.
PU Time Out Fo FaultCode:59	Keypad (KPVL-CC01) communication time-out         Corrective Actions:         1.       Check if the wiring for the communication is correct         2.       Check if there is any wrong with the keypad
Brk Chopper Fail F& FaultCode:60	Brake chopper fail Corrective Actions: Press RESET key to correct it. If fault code is still displayed on the keypad, please return to the factory.
Safety Relay Err Fo FaultCode:63	<ul> <li>Safety loop error</li> <li>Corrective Actions: <ol> <li>Check if the jumper JP18 is short circuit.</li> <li>Re-power on to try it. If fault code is still displayed on the keypad, please return to the factory.</li> </ol> </li> </ul>
Mech Brake Fail Fo FaultCode:64	<ul> <li>Mechanical brake error</li> <li>Corrective Actions:</li> <li>1. Check if the mechanical brake signal is correct.</li> <li>2. Check if the detection time setting of mechanical brake (Pr.02-35) is correct.</li> </ul>
PG HW Error F⊙ FaultCode:65	<ul> <li>PG hardware error</li> <li>Corrective Actions: <ol> <li>Check if the wiring of PG feedback is correct.</li> <li>If fault code is still displayed on the keypad with correct PG feedback, please return to the factory.</li> </ol> </li> </ul>
Contactor Fail Fo FaultCode:66	Electromagnetic valve error Corrective Actions: 1. Check if the signal of electromagnetic valve is correct. 2. Check if the setting of Pr.02-36 is correct.

### 6.1.2 Reset

There are three methods to reset the AC motor drive after solving the fault:

1. Press RESET key on KPVL-CC01.

Call 1(800)985-6929 foot Sales ives.com

### Call 1(800)985-6929 food the tales by sealing a construction of the sealing and the sealing a construction of the sealing a construction of the sealing and the sealing a construction of the sealing a construction of

#### Chapter 6 Fault Code Information | VFD-VL

- 2. Set external terminal to "RESET" and then set to be ON.
- 3. Send "RESET" command by communication.



Make sure that RUN command or signal is OFF before executing RESET to prevent damage or personal injury due to immediate operation.

# Appendix A Specifications

There are 230V and 460V models for customers to choose by their requirement.

	Voltage Class	230V Class							
	Model Number VFD-XXXVL	055	075	110	150	185	220	300	370
Ma	ax. Applicable Motor Output (kW)	5.5	7.5	11	15	18.5	22	30	37
Ma	ax. Applicable Motor Output (hp)	7.5	10	15	20	25	30	40	50
	Rated Output Capacity (kVA)	9.5	12.5	19	25	29	34	46	55
Rating	Rated Output Current for General Purposes (A)	21.9	27.1	41.1	53	70	79	120	146
ut Rat	**Rated Output Current for Elevators (A)	25	31	47	60	80	90	150	183
Output	Maximum Output Voltage (V)	3-Phase Proportional to Input Voltage							
0	Output Frequency (Hz)	0.00~120.00 Hz							
	Carrier Frequency (kHz)		12kHz		9kHz			6kHz	
b	Rated Input Current (A)	25	31	47	60	80	90	106	126
Rating	Rated Voltage/Frequency	3-phase 200-240V, 50/60Hz							
put	Voltage Tolerance	±10%(180~264 V)							
Ē	Frequency Tolerance	±5%(47~63 Hz)							
С	ooling Method	Fan Cooled							
N	/eight (kg)	8	10	10	13	13	13	36	36

	Voltage Class	460V Class										
	Model Number VFD-XXXVL	055	075	110	150	185	220	300	370	450	550	750
Ma	ax. Applicable Motor Output (kW)	5.5	7.5	11	15	18.5	22	30	37	45	55	75
M	ax. Applicable Motor Output (hp)	7.5	10	15	20	25	30	40	50	60	75	100
	Rated Output Capacity (kVA)	9.9	13.7	18	24	29	34	46	56	69	80	100
bu	Rated Output Current for General Purposes (A)	12.3	15.8	21	27	34	41	60	73	91	110	150
Output Rating	**Rated Output Current for Elevators (A)	14	18	24	31	39	47	75	91	113	138	188
utpu	Maximum Output Voltage (V)	3-phase Proportional to Input Voltage										
õ	Output Frequency (Hz)	0.00~120.00 Hz										
	Carrier Frequency (kHz)		15kHz		9kHz				6kHz			
þ	Rated Input Current (A)	14	18	24	31	39	47	56	67	87	101	122
Rating	Rated Voltage	3-phase 380 to 480 V, 50/60Hz										
Input F	Voltage Tolerance	±10%(342~528 V)										
lnp	Frequency Tolerance	±5%(47~63 Hz)										
С	ooling Method					Fa	an Cool	ed				
W	'eight (kg)	8	10	10	13	13	13	36	36	36	50	50


Call 1(800)985-6929 fbertaaleetrives.salers@deltaacdrives.com

## Call 1(800)985-6929 the tales rives.com

Appendix A Specifications | VFD-VL



\*\*Rated Output Current for Elevators (A)



Event	Description	Time(s)	Current	
#1	Per torque	1.5	100%	
#2	Accel up	3	175%	
#3	Cruise	10	100%	
#4	Decel up	3	115%	
#5	Post	1.5	140%	
#6	Per torque	1	100%	
#7	Rest	10	0%	
*1	Per torque	1.5	100%	
*2	Accel up	3	140%	
*3	Cruise	10	80%	
*4	Decel up	3	140%	
*5	Post	1.5	140%	
*6	Per torque	1	100%	
*7	Rest	10	0%	

# Call 1(800)985-6929 fterltaaledrives.scalers@deltaacdrives.com

Appendix A Specifications | VFD-VL

	General Specifications								
	Control System	1: V/f, 2: VF+PG, 3: SVC, 4: FOC+PG, 5: TQR+PG, 6:FOC+PM							
	Start Torque	Starting torque is 150% at 0.5Hz and 0Hz with control modes FOC + PG and FOC+PM							
	Speed Control Range	1:100 Sensorless vector (up to 1:1000 when using PG card)							
6	Speed Control Resolution	$\pm 0.5\%$ Sensorless vector (up to $\pm 0.02\%$ when using PG card)							
stic	Speed Response Ability	5Hz (up to 30Hz for vector control)							
teri	Max. Output Frequency	0.00 to 120.00Hz							
arac	Output Frequency Accuracy	Digital command $\pm 0.005\%$ , analog command $\pm 0.5\%$							
Control Characteristics	Frequency Setting Resolution	Digital command $\pm 0.01 Hz,$ analog command: 1/4096(12-bit) of the max. output frequency							
onti	Torque Limit	Max. is 200% torque current							
0	Torque Accuracy	±5%							
	Accel/Decel Time	0.00 to 600.00/0.0 to 6000.0 seconds							
	V/f Curve	Adjustable V/f curve using 4 independent points and square curve							
	Frequency Setting Signal	0-+10V, ±10V, 4~20mA							
	Brake Torque	About 20%							
	Motor Protection	Electronic thermal relay protection							
ics	Over-current Protection	The current forces 220% of the over-current protection and 300% of the rated current							
cterist	Ground Leakage Current Protection	Higher than 50% rated current							
ara	Overload Ability	Constant torque: 150% for 60 seconds, variable torque: 200% for 3 seconds							
ch	Over-voltage Protection	Over-voltage level: Vdc > 400/800V; low-voltage level: Vdc < 200/400V							
Protection Characteristics	Over-voltage Protection for the Input Power	Varistor (MOV)							
Pro	Over-temperature Protection	Built-in temperature sensor							
	Compensation for the Momentory Power Loss	Up to 5 seconds for parameter setting							
ns	Protection Level	NEMA 1/IP20							
Environmental Conditions	Operation Temperature	-10°C to 45°C							
Co	Storage Temperature	-20°C to 60°C							
nenta	Ambient Humidity	Below 90% RH (non-condensing)							
ironr	Vibration	$9.80665 \text{m/s}^2$ (1G) less than 20Hz, $5.88 \text{m/s}^2$ (0.6G) at 20 to 50Hz							
Env	Installation Location	Altitude 1,000 m or lower, keep from corrosive gasses, liquid and dust							
Ap	Approvals CE								

## Call 1(800)985-6929 for the tales rives.com

Appendix A Specifications | VFD-VL

This page intentionally left blank

Call 1(800)985-6929 fbertaaleetrives.salers@deltaacdrives.com

Appendix B Accessories | VFD-VL

# Appendix B Accessories

General Pre	ecautions	
CAUTION	•	This VFD-VL AC motor drive has gone through rigorous quality control tests at the factory before shipment. If the package is damaged during shipping, please contact your dealer. The accessories produced by Delta are only for using with Delta AC motor drive. Do NOT use with other drive to prevent damage.

Appendix B Accessories | VFD-VL

### B.1 All Brake Resistors & Brake Units Used in AC Motor Drives

	cable otor		* <sup>1</sup> 1259	* <sup>2</sup> Max. Brake Torque					
		Brake Unit	Resistor Value of	Brake Re	esistor	Total Braking		Max. Total	Peak
HP	kW	VFDB	Each AC Motor Drive			Current (A)		Braking Current (A)	
7.5	5.5	-	1000W 20Ω	BR1K0W020*1	-	19	15.6	24.4	9.3
10	7.5	-	1500W 13Ω	BR1K5W013*1	-	29	11.5	33.0	12.5
15	11	-	1500W 13Ω	BR1K5W013*1	-	29	9.5	40.0	15.2
20	15	-	2000W 8.6Ω	BR1K0W4P3*2	2 Series	44	8.3	46.0	17.5
25	18	-	2400W 7.8Ω	BR1K2W3P9*2	2 Series	49	5.8	66.0	25.1
30	22	-	3000W 6.6Ω	BR1K5W3P3*2	2 Series	58	5.8	66.0	25.1
40	30	2015*2	4000W 5.1Ω	BR1K0W5P1*2	2 Series	75	4.8	80.0	30.4
50	37	2022*2	4800W 3.9Ω	BR1K2W3P9*2	2 Series	97	3.2	120.0	45.6

Appli Mo			* <sup>1</sup> 125%		* <sup>2</sup> Max. Brake Torque				
		Brake Resistor Brake Resistor		Total Braking	Min. Resistor	Max. Total	Peak		
HP	KW VFDB Each AC * <sup>3</sup> Braking Resi		* <sup>3</sup> Braking Resis each Bral		Current (A)	Value (Ω)	Braking Current (A)		
7.5	5.5	-	1000W 75Ω	BR1K0W075*1	-	10.2	48.4	15.7	11.9
10	7.5	-	1500W 43Ω	BR1K5W043*1	-	17.6	39.4	19.3	14.7
15	11	-	1500W 43Ω	BR1K5W043*1	BR1K5W043*1 -		30.8	24.7	18.8
20	15	-	2000W 32Ω	BR1K0W016*2	2 Series	24	25.0	30.4	23.1
25	18	-	3000W 26Ω	BR1K5W013*2	2 Series	29	20.8	36.5	27.7
30	22	-	3000W 26Ω	BR1K5W013*2	2 Series	29	19.0	40.0	30.4
40	30	4030*1	3000W 20.4Ω	BR1K0W5P1*4	4 Series	37	19.0	40.0	30.4
50	37	4045*1	4800W 15Ω	BR1K2W015*4	2 parallel 2 Series	50	12.7	60.0	45.6
60	45	4045*1	6000W 13Ω	BR1K5W013*4 2 paralle 2 Series		59	12.7	60.0	45.6
75	55	4030*2	7200W 10Ω	BR1K2W015*4 4 Series		76	9.5	80.0	60.8
100	75	4045*2	9600W 7.5Ω	BR1K2W015*4	2 parallel 2 Series	100	6.3	120.0	91.2

\*<sup>1</sup> Calculation for 125% brake toque: (kw)\*125%\*0.8; where 0.8 is motor efficiency.

Because there is a resistor limit of power consumption, the longest operation time for 10%ED is 10sec (on: 10sec/ off: 90sec).

\*<sup>2</sup> Please refer to the Brake Performance Curve for "Operation Duration & ED" vs. "Braking Current".


\*<sup>3</sup> For heat dissipation, a resistor of 400W or lower should be fixed to the frame and maintain the surface temperature below 50°C; a resistor of 1000W and above should maintain the surface temperature below 350°C.

### Call 1(800)985-6929 ther tales brives scales @deltaacdrives.com

# 

- 1. Please select the recommended resistance value (Watt) and the duty-cycle value (ED%).
- 2. Definition for Brake Usage ED%

Explanation: The definition of the brake usage ED(%) is for assurance of enough time for the brake unit and brake resistor to dissipate away heat generated by braking. When the brake resistor heats up, the resistance would increase with temperature, and brake torque would decrease accordingly. Recommended cycle time is one minute.



Note1: When using the AC drive with DC reactor, please refer to wiring diagram in the AC drive user manual for the wiring of terminal +(P) of Braking unit.

Note2: Do NOT wire terminal -(N) to the neutral point of power system.

- 3. For safety consideration, install an overload relay between the brake unit and the brake resistor. In conjunction with the magnetic contactor (MC) prior to the drive, it can perform complete protection against abnormality. The purpose of installing the thermal overload relay is to protect the brake resistor from damage due to frequent brake, or due to brake unit keeping operating resulted from unusual high input voltage. Under such circumstance, just turn off the power to prevent damaging the brake resistor.
- If damage to the drive or other equipment are due to the fact that the brake resistors and the brake modules in use are not provided by Delta, the warranty will be void.
- 5. Take into consideration the safety of the environment when installing the brake resistors.
- If the minimum resistance value is to be utilized, consult local dealers for the calculation of the Watt figures.
- 7. Please select thermal relay trip contact to prevent resistor over load. Use the contact to switch power off to the AC motor drive!
- When using more than 2 brake units, equivalent resistor value of parallel brake unit can't be less than the value in the column "Minimum Equivalent Resistor Value for Each AC Drive" (the

### Call 1(800)985-6929 the tales trives scales @deltaacdrives.com

### Call 1(800)985-6929 fbertaaleetrives.salers@deltaacdrives.com


#### Appendix B Accessories | VFD-VL


right-most column in the table).

 This chart is for normal usage; if the AC motor drive is applied for frequent braking, it is suggested to enlarge 2~3 times of the Watts.

### **B.1.1 Dimensions and Weights for Brake Resistors**

(Dimensions are in millimeter)






Model no.	L1	L2	Н	D	W	Max. Weight (g)	
BR080W200	140	405	20	5.0	<u> </u>	100	
BR080W750	140	125	20	5.3	60	160	
BR300W070			30	5.3	60	750	
BR300W100	045						
BR300W250	215	200					
BR300W400							
BR400W150	005		20				
BR400W040	265	250	30	5.3	60	930	

Call 1(800)985-6929 the Halestrives.sales@deltaacdrives.com

### Call 1(800)985-6929 the tales trives.com


Appendix B Accessories | VFD-VL



Model no.	L1	L2	Н	D	W	Max. Weight (g)
BR500W030	225	200	20	5.3	<u></u>	1100
BR500W100	335	335 320	30	5.5	60	1100
BR1K0W020	400	005	50	5.0	100	0000
BR1K0W075	400	385	50	5.3	100	2800

#### Brake Resistor

Order P/N: BR1K0W050, BR1K2W008, BR1K2W6P8, BR1K5W005, BR1K5W040



Call 1(800)985-6929 for the tales rives.com

#### Appendix B Accessories | VFD-VL

### **B.1.2 Specifications for Brake Unit**

	<u> </u>	230V	Series	460V	Series	
		2015	2022	4030	4045	
	Max. Motor Power (kW)	15	22	30	45	
d rt	Max. Peak Discharge Current (A) 10%ED	40	60	40	60	
Output Rating	Continuous Discharge Current (A)	15	20	15	18	
	Brake Start-up Voltage (DC)	330/345/360/3	80/400/415±3V	660/690/720/7	60/800/830±6V	
Input Rating	DC Voltage	200~400VDC		400~8	400~800VDC	
on	Heat Sink Overheat	Temperature over +95°C (203 °F)				
Protection	Alarm Output	Relay contact 5A 120VAC/28VDC (RA, RB, RC)				
Pro	Power Charge Display	Blackout until bus (+~-) voltage is below 50VDC				
t	Installation Location	Indoor (no co	prrosive gases, n	netallic dust)		
Environment	Operating Temperature	-10°C ~ +50°C (14°F to 122°F)				
μu	Storage Temperature	-20°C ~ +60°C (-4°F to 140°F)				
virc	Humidity	90% Non-condensing				
E         9.8m/s² (1G) under 20Hz           2m/s² (0.2G) at 20~50Hz						
W	all-mounted Enclosed Type		IP50		IP10	


Call 1(800)985-6929 for the tales rives.com


Appendix B Accessories | VFD-VL

### **B.1.3 Dimensions for Brake Unit**

VFDB2015, VFDB2022, VFDB4030, VFDB4045

(Dimensions are in millimeter[inch])





Call 1(800)985-6929 the tales rives.com

### **B.2 Non-fuse Circuit Breaker Chart**

Comply with UL standard: Per UL 508, paragraph 45.8.4, part a, The current rating of the breaker shall be within 2-4 times maximum input current rating.

3-phase						
Model	Recommended Input Current (A)	Model	Recommended Input Current (A)			
VFD055VL23A	50	VFD220VL23A	175			
VFD055VL43A	30	VFD220VL43A	100			
VFD075VL23A	60	VFD300VL23A	225			
VFD075VL43A	40	VFD300VL43A	125			
VFD110VL23A	100	VFD370VL23A	250			
VFD110VL43A	50	VFD370VL43A	150			
VFD150VL23A	125	VFD450VL43A	175			
VFD150VL43A	60	VFD550VL43A	250			
VFD185VL23A	150	VFD750VL43A	300			
VFD185VL43A	75					

#### **B.3 Fuse Specification Chart**

Smaller fuses than those shown in the table are permitted.

Model	I (A)	I (A)	Lir	ne Fuse
Model	Input	Output	I (A)	Bussmann P/N
VFD055VL23A	26	25	50	JJN-50
VFD055VL43A	14	13	30	JJN-30
VFD075VL23A	34	33	60	JJN-60
VFD075VL43A	19	18	40	JJN-40
VFD110VL23A	50	49	100	JJN-100
VFD110VL43A	25	24	50	JJN-50
VFD150VL23A	60	65	125	JJN-125
VFD150VL43A	32	32	60	JJN-60
VFD185VL23A	75	75	150	JJN-150
VFD185VL43A	39	38	75	JJN-70
VFD220VL23A	90	90	175	JJN-175
VFD220VL43A	49	45	100	JJN-100

Call 1(800)985-6929 for talestrives.com

### Call 1(800)985-6929 foor tales frives.sales @deltaacdrives.com

#### Appendix B Accessories | VFD-VL

Model	I (A)	I (A)	Line Fuse		
model	Input	Output	I (A)	Bussmann P/N	
VFD300VL23A	110	120	225	JJN-225	
VFD300VL43A	60	60	125	JJN-125	
VFD370VL23A	142	145	250	JJN-250	
VFD370VL43A	63	73	150	JJN-150	
VFD450VL43A	90	91	175	JJN-175	
VFD550VL43A	130	110	250	JJN-250	
VFD750VL43A	160	150	300	JJN-300	

Call 1(800)985-6929 the tales rives.com

### **B.4 AC Reactor**

460V, 50	460V, 50/60Hz, 3-Phase							
1.3.67	Fundam	Fundamental	Max.	Inductance (mH)				
kW	HP	Amps	continuous Amps	3% impedance	5% impedance			
5.5	7.5	12	18	2.5	4.2			
7.5	10	18	27	1.5	2.5			
11	15	25	37.5	1.2	2			
15	20	35	52.5	0.8	1.2			
18.5	25	35	52.5	0.8	1.2			
22	30	45	67.5	0.7	1.2			
30	40	55	82.5	0.5	0.85			
37	50	80	120	0.4	0.7			
45	60	80	120	0.4	0.7			
55	75	100	150	0.3	0.45			
75	100	130	195	0.2	0.3			

### **B.4.1 AC Input Reactor Recommended Value**

### **B.4.2 AC Output Reactor Recommended Value**

230V, 50/60HZ, 3-Pilase							
kW	V HP Fundamental		Max.	Inductance (mH)			
K V V	ΠF	Amps	continuous Amps	3% impedance	5% impedance		
5.5	7.5	25	37.5	0.5	1.2		
7.5	10	35	52.5	0.4	0.8		
11	15	55	82.5	0.25	0.5		
15	20	80	120	0.2	0.4		
18.5	25	80	120	0.2	0.4		
22	30	100	150	0.15	0.3		
30	40	130	195	0.1	0.2		
37	50	160	240	0.075	0.15		

230V. 50/60Hz. 3-Phase

### Call 1(800)985-6929 foortSatestrives.scalers@deltaacdrives.com

#### Appendix B Accessories | VFD-VL


		3-Phase Fundamental	Max.	Inductar	nce (mH)
kW	HP	Amps	continuous Amps	3% impedance	5% impedance
5.5	7.5	18	27	1.5	2.5
7.5	10	18	27	1.5	2.5
11	15	25	37.5	1.2	2
15	20	35	52.5	0.8	1.2
18.5	25	45	67.5	0.7	1.2
22	30	45	67.5	0.7	1.2
30	40	80	120	0.4	0.7
37	50	80	120	0.4	0.7
45	60	100	150	0.3	0.45
55	75	130	195	0.2	0.3
75	100	160	240	0.15	0.23

460V. 50/60Hz. 3-Phase

### **B.4.3 Applications for AC Reactor**

Connected in input circuit

Application 1	Question
When more than one AC motor drive is connected to the same power, one of them is ON during operation.	When applying to one of the AC motor drive, the charge current of capacity may cause voltage ripple. The AC motor drive may damage when over current occurs during operation.




### Call 1(800)985-6929 for the tales rives.com


#### Appendix B Accessories | VFD-VL

Application 2	Question		
Silicon rectifier and AC motor drive is connected to the same power.	Surges will be generated at the instant of silicon rectifier switching on/off. These surges may damage the mains circuit.		

Correct wiring



Application 3	Question
Used to improve the input power factor, to reduce harmonics and provide protection from AC line disturbances- (surges, switching spikes, short interruptions, etc.). AC line reactor should be installed when the power supply capacity is 500kVA or more and exceeds 6 times the inverter capacity, or the mains wiring distance $\leq 10m$ .	When power capacity is too large, line impedance will be small and the charge current will be too large. That may damage AC motor drive due to higher rectifier temperature.




Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

Appendix B Accessories | VFD-VL

### B.5 Zero Phase Reactor (RF220X00A)

Dimensions are in millimeter and (inch)




Cable type	Reco	mmend Size	ed Wire	Qty.	Wiring	
(Note)	AWG	mm²	Nominal (mm <sup>2</sup> )	Qty.	Method	
Single-	≦10	≦5.3	≦5.5	1	Diagram A	
core	≦2	≦33.6	≦38	4	Diagram B	
Three-	≦12	≦3.3	≦3.5	1	Diagram A	
core	≦1	≦42.4	≦50	4	Diagram B	

Note: 600V Insulated unshielded Cable.

Note 1: The table above gives approximate wire size for the zero phase reactors but the selection is ultimately governed by the type and diameter of cable fitted i.e. the cable must fit through the center hole of zero phase reactors.


**Note 2:** Only the phase conductors should pass through, not the earth core or screen.

Note 3: When long motor output cables are used an output zero phase reactor may be required to reduce radiated emissions from the cable




#### Diagram A

Please wind each wire 4 times around the core. The reactor must be put at inverter output as close as possible.



#### Diagram B

Please put all wires through 4 cores in series without winding.



Call 1(800)985-6929 thertaaleetrives.scalers@deltaacdrives.com

### **B.6 DC Choke Recommended Values**

#### 230V DC Choke

Input voltage	kW	HP	DC Amps	Inductance (mh)
	5.5	7.5	32	0.85
	7.5	10	40	0.75
	11	15	62	Built-in
230Vac	15	20	92	Built-in
50/60Hz	18.5	25	110	Built-in
3-Phase	22	30	125	Built-in
	30	40	-	Built-in
	37	50	-	Built-in

#### 460V DC Choke

Input voltage	kW	HP	DC Amps	Inductance (mh)
	5.5	7.5	18	3.75
	7.5	10	25	4.00
	11	15	32	Built-in
	15	20	50	Built-in
460Vac	18.5	25	62	Built-in
400Vac 50/60Hz	22	30	80	Built-in
3-Phase	30	40	92	Built-in
	37	50	110	Built-in
	45	60	125	Built-in
	55	75	200	Built-in
	75	100	240	Built-in

Call 1(800)985-6929 the talestrives.com

Call 1(800)985-6929 the taaledrives.com

Appendix B Accessories | VFD-VL

### B.7 Digital Keypad KPVL-CC01

The digital keypad is the display of VFD-VL series. The following keypad appearance is only for reference and please see the product for actual appearance.

### B.7.1 Description of the Digital Keypad KPVL-CC01



Display Message	Descriptions
FREQ. SETPOINT So 60.00Hz Press MODE key	Displays the AC drive Master Frequency
FIESS WODL KEY	
OUTPUT FREQ. So 0.00Hz	Displays the actual output frequency present at terminals U/T1, V/T2, and $W/T3$
Press MODE key	

Call 1(800)985-6929 foortSalestrives.sales@deltaacdrives.com

# Call 1(800)985-6929 the tales rives.com

#### Appendix B Accessories | VFD-VL


Display Message	Descriptions	
DC-BUS VOLTAGE Ra 716.0Vdc Press MODE key	Displays the voltage of DC BUS	
OUTPUT CURRENT Se 0.00Amps Press MODE key	Displays the output current present at terminals U/T1, V/T2, and W/T3	
OUTPUT VOLTAGE Se 0.0Volt Press MODE key	Displays the output voltage of motor	
U: Out put Cur r ent So 0. 0 Amps Press MODE key	User defined unit (Where U= Pr.00-04)	
PARAM COPY So READ 1	Copy the first set of parameter groups from the drive to the keypad. It can save two sets of parameter groups to keypad. (one set is from group 0 to group 13)	
PARAM COPY So SAVE 1 v1.00	Save the first set of parameter groups from the keypad to other drive. The firmware version is 1.00.	
SYSTEM PARAMETER So 00-	Displays the group number	
Rated Current 27.10Amp	Displays the actual stored value of the selected parameter	
External Fault F• FaultCode:60	External Fault	
End	Display "End" for approximately 1 second if input has been accepted by pressing PROG/DATA key. After a parameter value has been set, the new value is automatically stored in memory.	
Err	Display "Err", if the input is invalid.	


Call 1(800)985-6929 for the tales rives sales @deltaacdrives.com

Appendix B Accessories | VFD-VL

### B.7.2 How to Operate the Digital Keypad KPVL-CC01

Selection Mode






Call 1(800)985-6929 food the tales by sealing a construction of the sealing and the sealing a construction of the sealing a construction of the sealing and the sealing a construction of the sealing a construction of

### Call 1(800)985-6929 the tales rives.com


Appendix B Accessories | VFD-VL



Call 1(800)985-6929 foortaatedrives.scalers@deltaacdrives.com

Call 1(800)985-6929 foortSalestrives.salers@deltaacdrives.com

Appendix B Accessories | VFD-VL




### B.7.3 Dimension of the Digital Keypad

Unit: mm [inch]

# B.7.4 Recommended Position the Rubber Magnet of the Digital Keypad

This rubber magnet is shipped with the digital keypad. Users can adhere to anywhere of the back of the digital keypad to stick on the case of the AC motor drive. Please don't stick on the communication port to prevent reducing magnetic force.



B-20

Call 1(800)985-6929 fberltaaleetrives.scalers@deltaacdrives.com

### B.8 PG Card (for Encoder)

### B.8.1 EMVL-PGABL-1



1. Terminals descriptions

т	erminal Symbols	Descriptions	Specifications
	VP	Power source of encoder (use SW2 to switch 12V/5V)	Voltage: +5V±0.5V or +12V±1V Current: 200mA max.
	0V	Power source common for encoder	Reference level of the power of encoder
	$A,\overline{A}, B,\overline{B}, Z,\overline{Z}$	Incremental line driver input	Line driver RS422 Max. input frequency: 100 kHz
	$U, \overline{U}, V, \overline{V}, W, \overline{W}$	Absolute line driver input (UVW 3-bit code)	Line driver RS422 Max. input frequency: 50 kHz
TB1	A/O, <u>A</u> /O, B/O, <del>B</del> /O, Z/O, Z/O	Signal output for PG feedback card and can be used as a frequency divider.	Line driver RS422 Max. output frequency: 100 kHz
J3	٢	Grounding	Connected to the grounding of the power of the AC motor drive and used for PG shielding


### Call 1(800)985-6929 foortSalestrives.sales@deltaacdrives.com

#### Appendix B Accessories | VFD-VL

2. Wire length

Types of Pulse Generators	Maximum Wire Length	Wire Gauge
Line Driver	100m	1.25mm <sup>2</sup> (AWG16) or above

3. Types of Pulse Generators (Encoders)




4. Output Signal Setting of the Frequency Divider

It generates the output signal of division factor	RESERVE: reserved bit (PIN1)
"n" after dealing with the input pulse. Please set by the switch SW1 on the card.	I/MODE: input type setting of the division pulse (PIN 2)
	O/MODE: output type setting of the division pulse (PIN 3)
	RST: clock reset bit (PIN 4)
	Division factor: setting for division factor n: 1~256 (PIN5~12)


### Call 1(800)985-6929 the tales rives scales @deltaacdrives.com

### Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

#### Appendix B Accessories | VFD-VL



Settings and explanations



Call 1(800)985-6929 the tales rives scales @deltaacdrives.com

### Call 1(800)985-6929 foortaaleestrives.scalers@deltaacdrives.com

#### Appendix B Accessories | VFD-VL

- When the switch is ON, it means logic 0.
- A-/A and B-/B are the input signals of PG card. A/O-/A/O and B/O-/B/O are the line driver outputs of the frequency divider measured by the differential probe.
- PIN1 is reserved.
- PIN 5~12 are the denominator for the frequency divider. PIN 5 is the low bit (EX: the setting of XXXX10101010 is that the input signal divides by 85).
- When PIN 2 and PIN 3 are set to 0, the input signals (A-/A and B-/B) of PG card should be square wave and A/O-/A/O and B/O-/B/O are the outputs of frequency divider.
- When PIN 2 is set to 0 and PIN 3 is set to 1, the input signals (A-/A and B-/B) of PG card should be square wave and B/O-/B/O is the indication of phase A and B. (EX: LOW means A leads B and HIGH means B leads A). A/O-/A/O is the output of frequency divider.
- When PIN 2 is set to 1 and PIN 3 is set to X, B-/B should be the input signal of direction indication. (EX: when B-/B is LOW, it means that A leads B. When B-/B is HIGH, it means that B leads A. A-/A is a square wave input. B/O-/B/O and B-/B should be input synchronously. A/O-/A/O is the output of frequency divider.
- Z/O-/Z/O of the PG card will act by the input signal of Z-/Z and don't have the function of frequency divider.
- When changing the denominator of the frequency divider or input/output type, it needs to clear the counter value by clock reset bit (PIN4) before operation. Please set the switch to 1 after reset.

#### **B.8.2 EMVL-PGABO**



Call 1(800)985-6929 the taaledrives.com

# Call 1(800)985-6929 the tales rives.com

Appendix B Accessories | VFD-VL



#### Terminals descriptions

Те	erminal Symbols	Descriptions	Specifications
	VP	Power source of encoder	Voltage: +12V±1V Current: 200mA max.
	0V	Power source common for encoder	Reference level of the power of encoder
	$A,\overline{A}, B,\overline{B}, Z,\overline{Z}$	Incremental line driver input	Open collector signal input. Max. bandwidth is $\frac{100 \text{kHz}}{\overline{A}, \overline{B}, \overline{Z}}$ and Please notice that $\overline{\overline{A}, \overline{B}, \overline{Z}}$ and 0V should be short circuit.
TB1	A/O, <u>A</u> /O, B/O,B/O, Z/O, Z/O	Pulse output for PG feedback card and can be used as a frequency divider.	Line driver RS422 Max. output frequency: 100 kHz
	O/A ∖ O/B	Pulse output for PG feedback card and can be used as a frequency divider.	Open loop Max. output frequency 100kHz Max. 24Vdc, 50mA
	Vc	Signal output for power input side	Voltage: +24V±1V Current : 50mA
	٢	Grounding	Connected to the grounding of the power of the AC motor drive and used for PG shielding


#### 2. Wire length

Output Type of the Encoder	Maximum Wire Length	Wire Gauge
Open collector	50m	1.25mm <sup>2</sup> (AWG16) or above

Call 1(800)985-6929 footsalestrives.scalers@deltaacdrives.com


#### Call 1(800)985-6929 the taaled rives.com

#### Appendix B Accessories | VFD-VL



4. Output Signal Setting of the Frequency Divider

It generates the output signal of division factor "n" after dealing with the input pulse. Please set by the switch SW1 on the card.



RESERVE: reserved bit (PIN1)

I/MODE: input type setting of the division pulse (PIN 2)

O/MODE: output type setting of the division pulse (PIN 3)

RST: clock reset bit (PIN 4)


Division factor: setting for division factor n: 1~256 (PIN5~12)

Settings and explanations

#### Call 1(800)985-6929 fbertSaledrives.com

### Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

Appendix B Accessories | VFD-VL



# 

- When the switch is ON, it means logic 0.
- A-/A and B-/B are the input signals of PG card. A/O-/A/O and B/O-/B/O are the line driver outputs of the frequency divider measured by the differential probe.
- PIN1 is reserved.
- PIN 5~12 are the denominator for the frequency divider. PIN 5 is the low bit (EX: the setting of XXXX10101010 is that the input signal divides by 85).
- When PIN 2 and PIN 3 are set to 0, the input signals (A-/A and B-/B) of PG card should be square wave and A/O-/A/O and B/O-/B/O are the outputs of frequency divider.
- When PIN 2 is set to 0 and PIN 3 is set to 1, the input signals (A-/A and B-/B) of PG card should be square wave and B/O-/B/O is the indication of phase A and B. (EX:

#### Call 1(800)985-6929 thertSalectrives.scales@deltaacdrives.com

### Call 1(800)985-6929 foortaaleetrives.scalers@deltaacdrives.com

#### Appendix B Accessories | VFD-VL


LOW means A leads B and HIGH means B leads A). A/O-/A/O is the output of frequency divider.

- When PIN 2 is set to 1 and PIN 3 is set to X, B-/B should be the input signal of direction indication. (EX: when B-/B is LOW, it means that A leads B. When B-/B is HIGH, it means that B leads A. A-/A is a square wave input. B/O-/B/O and B-/B should be input synchronously. A/O-/A/O is the output of frequency divider.
- Z/O-/Z/O of the PG card will act by the input signal of Z-/Z and don't have the function of frequency divider.
- When changing the denominator of the frequency divider or input/output type, it needs to clear the counter value by clock reset bit (PIN4) before operation. Please set the switch to 1 after reset.

#### -Wiring Method

#### Encoder Feedback

 If the encoder type is line driver, the PG card will only output +12V signal. Set switch SW2 to EXT24V.




Call 1(800)985-6929 the taaledrives.com

### Call 1(800)985-6929 the tales rives.com


#### Appendix B Accessories | VFD-VL

2. If the encoder type is open collector, wire connection method shown in the figure below can be used. For terminals  $\overline{A} \, \times \, \overline{B} \, \times \, \overline{Z}$ , set switch SW2 to INT12V.



#### Pulse Output of PG Card


1. Common voltage input terminal S/S




### Call 1(800)985-6929 food factorives.com

#### Appendix B Accessories | VFD-VL

2. Common voltage output terminal S/S




 If the encoder type is line driver, when switch SW2 is set to +12V or +24V, the PG card will only output 5V.



#### 

### B.8.3 EMVL-PGH01 (only for Heidenhain ERN1387)

1. Sinusoidal Encoder Function



Heidenhain ERN1387


		•		B ►A
Pin NO	Terminal Name		Pin NO	Terminal Name
5a	B-		1b	UP
NC	NC		1a	C-
4b	R+		7b	C+
4a	R-		2b	D+
6a	A+		6a	D-
2a	A-		-	-
5b	0V		-	-
3b	B+			


Call 1(800)985-6929 for talestrives.sales@deltaacdrives.com

### Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

#### Appendix B Accessories | VFD-VL

2. Terminals descriptions **Terminal Symbols** Descriptions Specifications Specific power output of Voltage: +5V±0.5V +5V encoder Current: 200mA max. Power source common for Reference level of the power of 0V encoder encoder 360°el. 0-А 90°el Sine line driver input A+, A-, B+, B-, Z+. Z-0 B (incremental signal) ц 0 360°mech 0 Sine line driver input signal SIN, SIN', 90°mech COS, COS' (absolute signal) 0 cos Signal output for PG feedback Line driver RS422 card and can be used as a





B-32


Call 1(800)985-6929 the tales rives sales @deltaacdrives.com

### Call 1(800)985-6929 the tales rives.com

#### Appendix B Accessories | VFD-VL

4. Output Signal Setting of the Frequency Divider

It generates the output signal of division factor "n" after dealing with the input pulse. Please set by the switch SW1 on the card.



RESERVE: reserved bit (PIN1)


I/MODE: input type setting of the division pulse (PIN 2)

O/MODE: output type setting of the division pulse (PIN 3)

RST: clock reset bit (PIN 4)

Division factor: setting for division factor n: 1~256 (PIN5~12)

#### Settings and explanations



Call 1(800)985-6929 fter tales rives.sales@deltaacdrives.com

Call 1(800)985-6929 the tale drives. sales @deltaacdrives.com


#### Appendix B Accessories | VFD-VL

# 

- When the switch is ON, it means logic 0.
- A-/A and B-/B are the input signals of PG card. A/O-/A/O and B/O-/B/O are the line drivers of the frequency divider measured by the differential probe.
- PIN1 is reserved.
- PIN 5~12 are the denominator for the frequency divider. PIN 5 is the low bit (EX: the setting of XXXX10101010 is that the input signal divides by 85).
- When PIN 2 and PIN 3 are set to 0, the input signals (A-/A and B-/B) of PG card should be square wave and A/O-/A/O and B/O-/B/O are the outputs of frequency divider.
- When PIN 2 is set to 0 and PIN 3 is set to 1, the input signals (A-/A and B-/B) of PG card should be square wave and B/O-/B/O is the indication of phase A and B. (EX: LOW means A leads B and HIGH means B leads A). A/O-/A/O is the output of frequency divider.
- When PIN 2 is set to 1 and PIN 3 is set to X, B-/B should be the input signal of direction indication. (EX: when B-/B is LOW, it means that A leads B. When B-/B is HIGH, it means that B leads A. A-/A is a square wave input. B/O-/B/O and B-/B should be input synchronously. A/O-/A/O is the output of frequency divider.
- Z/O-/Z/O of the PG card will act by the input signal of Z-/Z and don't have the function of frequency divider.
- When changing the denominator of the frequency divider or input/output type, it needs to clear the counter value by clock reset bit (PIN4) before operation. Please set the switch to 1 after reset.

#### Appendix B Accessories | VFD-VL

### B.8.4 EMVL-PGS01



Applicable encoders for EMVL-PGS01:

- EnDat2.1: EQN425, EQN1325, ECN113, ECN413, ECN1113, ECN1313
- HIPERFACE: SRS50/60
- 1. Pin description

r. Fin descript				
VFD-VL Series		VFD-VL Series	Corresponding terminal	
		Pin No.	EnDat	HIPERFACE®
		1	B-	REFSIN
◎\ 10	98760	2	0V	0V
	$ \begin{array}{c} 9 & 8 & 7 & 6 \\ \hline 14 & 13 & 12 & 1 \\ \end{array} $	3	0V	0V
		4	0V	0V
		5	A+	+COS
		6	A-	REFCOS
		7	0V	0V
		8	B+	+SIN
		9	VP	VP
		10	Data+	Data+
		11	Data-	Data-
		12	CLOCK+	-
		13	CLOCK-	-
		14	VP	VP
		15	0V	0V
EMVL-PGS	01	1 -		
VP○           0V○           A+ (+COS)○           A- (REFCOS)○           B+ (+SIN)○           B- (REFSIN)○           B- (REFSIN)○           B/O           Data+○           ○ B/O           CLOCK+○           ○ B           ○ GND			PG	ler

Call 1(800)985-6929 fberltaaleetrives.scalers@deltaacdrives.com

### Call 1(800)985-6929 the tales rives sales @deltaacdrives.com


#### Appendix B Accessories | VFD-VL

#### 2 Terminals descriptions

Terr	ninal Symbols	Descriptions	Specifications	
J3	VP	Power source of encoder	Voltage: +5VDC±5% or +8.3 VDC±6%	
		(use SW2 to switch 12V/5V)	Current: 250mA max.	
	0V	Power source common for encoder	Reference level of the power of encoder	
	A+, A-, B+, B-	Sine line drive input (incremental signal)	Input frequency: 40kHz max. $360^{\circ}el$ 0 $90^{\circ}el$ 0 0 B 0.81.2Vss $(\approx 1Vss; Z_{o}=120 \Omega)$	
	+SIN, +COS REFSIN, REFCOS	Sine line drive input (incremental signal)	Input frequency: 20kHz max.	
	CLOCK+, CLOCK-	CLOCK line drive output	Line Driver RS422 Level output	
	Data+, Data-		RS485 communication interface	
			Terminal resistor: about 130 $\Omega$	
TB1	A/O, A/O,	Signal output for PG		
	B/O, $\overline{B}$ /O	feedback card and can be used as a frequency divider.	Line Driver RS422 Level output	
TB2	÷	Open collector output signal	Transistor open collector output	
	ОВ	and can be used as a	• Max. 24VDC, 30mA	
		frequency divider	• VOL≦1.5V(IOL=30mA)	
			· IOH≦200µA(VOH=24VDC)	
	GND	Open collector output common	Reference level of NPN transistor open collector output	
J4	÷	Grounding	Connected to the grounding of the power of the AC motor drive and used for PG shielding	

4. Output Signal Setting of the Frequency Divider

It generates the output signal of division factor O/MODE: output type setting of the division "n" after dealing with the input pulse. Please set by the switch SW1 on the card.



pulse

RST: clock reset bit


Division factor: setting for division factor n: 1~31

Settings and explanations

### Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

### Call 1(800)985-6929 foortSalestrives.scalers@deltaacdrives.com

#### Appendix B Accessories | VFD-VL



# 

- When the switch is ON, it means logic 0.
- A-/A and B-/B are the input signals of PG card. A/O-/A/O and B/O-/B/O are the line driver outputs of the frequency divider measured by the differential probe.
- Bit 0-4 are the denominators for the frequency divider. Bit 0 is the low bit (EX: the setting of 10110 is that the input signal divides by 13).
- When the output pulse type of frequency divider is set to 0, A/O-/A/O, B/O-/B/O, OA-GND and OB-GND are the outputs of frequency divider.
- When the output pulse type of frequency divider is set to 1, B/O-/B/O and OB-GND are the indication of phase A and B. (EX: LOW means A leads B and HIGH means B leads A). A/O-/A/O and OA-GND are the output of frequency dividers.
- When changing the denominator of the frequency divider or output type, it needs to clear the counter value by clock reset bit before operation.

#### Call 1(800)985-6929 thertaaleetrives.scalers@deltaacdrives.com

Appendix B Accessories | VFD-VL

#### **B.9 AMD-EMI Filter Cross Reference**

230V 3-phase Model	Filter Model Name	230V 3-phase Model	Filter Model Name
VFD055VL23A	KMF336A	VFD055VL43A	KMF318A
VFD075VL23A	KMF336A	VFD075VL43A	KMF325A
VFD110VL23A	KMF350A	VFD110VL43A	KMF325A
VFD150VL23A	KMF370A	VFD150VL43A	KMF336A
VFD185VL23A	KMF3100A	VFD185VL43A	KMF350A
VFD220VL23A	KMF3100A	VFD220VL43A	KMF350A
VFD300VL23A	KMF3150A	VFD300VL43A	KMF370A
VFD370VL23A	KMF3150A	VFD370VL43A	KMF370A
		VFD450VL43A	KMF3100A
		VFD550VL43A	KMF3150A
		VFD750VL43A	KMF3150A

For more detail information of filter, please see http://www.dem-uk.com/jkcm/Home

#### Installation

All electrical equipment, including AC motor drives, will generate high-frequency/low-frequency noise and will interfere with peripheral equipment by radiation or conduction when in operation. By using an EMI filter with correct installation, much interference can be eliminated. It is recommended to use DELTA EMI filter to have the best interference elimination performance.

We assure that it can comply with following rules when AC motor drive and EMI filter are installed and wired according to user manual:

- EN61000-6-4
- EN61800-3: 1996
- EN55011 (1991) Class A Group 1

#### General precaution

- 1. EMI filter and AC motor drive should be installed on the same metal plate.
- Please install AC motor drive on footprint EMI filter or install EMI filter as close as possible to the AC motor drive.
- 3. Please wire as short as possible.
- 4. Metal plate should be grounded.
- The cover of EMI filter and AC motor drive or grounding should be fixed on the metal plate and the contact area should be as large as possible.

#### Choose suitable motor cable and precautions

Improper installation and choice of motor cable will affect the performance of EMI filter. Be sure to observe the following precautions when selecting motor cable.


1. Use the cable with shielding (double shielding is the best).

#### Call 1(800)985-6929 thertaaleetrives.scalers@deltaacdrives.com

### Call 1(800)985-6929 the talestrives.com

#### Appendix B Accessories | VFD-VL

- The shielding on both ends of the motor cable should be grounded with the minimum length and maximum contact area.
- 3. Remove any paint on metal saddle for good ground contact with the plate and shielding.



Saddle on one end

#### The length of motor cable

When motor is driven by an AC motor drive of PWM type, the motor terminals will experience surge voltages easily due to components conversion of AC motor drive and cable capacitance. When the motor cable is very long (especially for the 460V series), surge voltages may reduce insulation quality. To prevent this situation, please follow the rules below:

#### Call 1(800)985-6929 thertSalectrives.scales@deltaacdrives.com

### Call 1(800)985-6929 fbertaaleetrives.salers@deltaacdrives.com

#### Appendix B Accessories | VFD-VL

- Use a motor with enhanced insulation.
- Connect an output reactor (optional) to the output terminals of the AC motor drive
- The length of the cable between AC motor drive and motor should be as short as possible (10 to 20 m or less)
- For models 7.5hp/5.5kW and above:

Insulation level of motor	1000V	1300V	1600V
460VAC input voltage	66 ft (20m)	328 ft (100m)	1312 ft (400m)
230VAC input voltage	1312 ft (400m)	1312 ft (400m)	1312 ft (400m)

# 

When a thermal O/L relay protected by motor is used between AC motor drive and motor, it may malfunction (especially for 460V series), even if the length of motor cable is only 165 ft (50m) or less. To prevent it, please use AC reactor and/or lower the carrier frequency (Pr. 00-17 PWM carrier frequency).



Never connect phase lead capacitors or surge absorbers to the output terminals of the AC motor drive.


- If the length is too long, the stray capacitance between cables will increase and may cause leakage current. It will activate the protection of over current, increase leakage current or not insure the correction of current display. The worst case is that AC motor drive may damage.
- If more than one motor is connected to the AC motor drive, the total wiring length is the sum of the wiring length from AC motor drive to each motor.

Call 1(800)985-6929 the taaledrives.sales@deltaacdrives.com

#### Appendix B Accessories | VFD-VL

### B.10 EMVL-IOA01






Terminals	Descriptions		
AVO1-AGND	Multifunction analog voltage output terminal		
AVO2-AGND	-10.0V~10.0V		
	The analog output is defined by Pr.03-17 and Pr.03-20.		
MO3~MO10	The AC motor drive outputs every monitor signal, such as		
Multifunction output	operation indication, frequency attained and overload indication by		
terminals	the transistor (open collector). Refer to Pr.02-15~02-22		
(photocoupler)	multifunction output terminals for details.		
	Max: +24V/5mA		
	MO3~MO10 internal circuit		

Call 1(800)985-6929 the tales rives.sales@deltaacdrives.com

Call 1(800)985-6929 fbertaaleetrives.salers@deltaacdrives.com

Appendix B Accessories | VFD-VL


### B.11 Safety Relay EMVL-SAF01



## **B.11.1 Functions of the Terminals**

Terminals		Descriptions	Specifications
J1	S1	+24VDC power Input	Min. activation voltage: +19Vdc
	S2	+24VDC, reference level of the power	<ul> <li>Impedance: 720+10%Ω</li> <li>Rated power: about 800mW</li> </ul>
	S3	A dry contact of a relay	Rated current: 8 A
	S4	A dry contact of a relay	Rated voltage/max. switch voltage: 240/400 VAC
			Contact material: AgSnO2
			Contact impedance:
			$\leq$ 100 mOhm / 1 A / 24 VDC
			$\leq$ 20 Ohm / 10 mA / 5 VDC
			Mechanical endurance: 10x10 <sup>6</sup> cycles
			Rated operation frequency: 6 min <sup>-1</sup> / 150 min <sup>-1</sup> (loaded/unloaded)

### B.11.2 Wiring of the Safety Relay



Call 1(800)985-6929 for the tales rives.com

# Call 1(800)985-6929 the tales rives.com

#### Appendix B Accessories | VFD-VL

#### Descriptions

- When the power +24VDC is applied to S1 and S2 (S1 is +), the relay contacts of S3 and S4 are ON. When the power +24VDC isn't applied to S1 and S2, the relay contacts of S3 and S4 are OFF. At the meanwhile, EMVL-SAF01 can stop the output of the AC motor drive by connecting to JP19 on the control board. It can also be used with MI8 to achieve two safety-loop protections via hardware.
- 2. Multifunction input MI8

(1) Please remove JP1 from the control board before using safety-loop function. At the meanwhile, the multifunction input MI8 can control the output of the AC motor drive.

(2) operation method:

MI8 is ON: the AC motor drive can output

MI8 is OFF: the AC motor drive can't output

NOTE: Please insert JP1 into the control board when this function is disabled.

3. Safety-Relay EMVL-SAF01

(1) Please connect the power of J3 to JP19 on the control board and remove JP18 on the control board.

(2) Operation method:

When the power is applied to S1-S2: It is ON and the AC motor drive can output When the power isn't applied to S1-S2: it is OFF and the AC motor drive can't output (3) S3-S4 are the monitor contacts and user can check the safety-loop by this contact.

# 

- Please notice that when J3 of relay board is connected to JP19 of control board, JP18 must be removed when using EMVL-SAF01.
- Please supply the power +24VDC to S1 and S2 before the AC motor drive is powered on to drive relay.

Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

Call 1(800)985-6929 the talestrives.scales@deltaacdrives.com

# Appendix C How to Select the Right AC Motor Drive

The choice of the right AC motor drive for the application is very important and has great influence on its lifetime. If the capacity of AC motor drive is too large, it cannot offer complete protection to the motor and motor maybe damaged. If the capacity of AC motor drive is too small, it cannot offer the required performance and the AC motor drive maybe damaged due to overloading.

But by simply selecting the AC motor drive of the same capacity as the motor, user application requirements cannot be met completely. Therefore, a designer should consider all the conditions, including load type, load speed, load characteristic, operation method, rated output, rated speed, power and the change of load capacity. The following table lists the factors you need to consider, depending on your requirements.

		F	Related Sp	ecification	
	ltem		Time ratings	Overload capacity	Starting torque
Load type	Friction load and weight load Liquid (viscous) load Inertia load Load with power transmission	•			•
Load speed and torque characteristics	Constant torque Constant output Decreasing torque Decreasing output	•	•		
Load characteristics	Constant load Shock load Repetitive load High starting torque Low starting torque	•	•	•	•
	tion, Short-time operation on at medium/low speeds		•	•	
	current (instantaneous) urrent (continuous)	•		•	
Maximum frequer	icy, Base frequency	•			
Power supply transformer capacity or percentage impedance Voltage fluctuations and unbalance Number of phases, single phase protection Frequency				•	•
Mechanical friction	Mechanical friction, losses in wiring			•	•
Duty cycle modific	cation		●		

Call 1(800)985-6929 the talestrives.sales@deltaacdrives.com

## Call 1(800)985-6929 foortSalestrives.salers@deltaacdrives.com

Appendix C How to Select the Right AC Motor Drive | VFD-VL

### **C.1 Capacity Formulas**

#### 1. When one AC motor drive operates one motor

The starting capacity should be less than 1.5x rated capacity of AC motor drive

The starting capacity=

$$\frac{k \times N}{973 \times \eta \times \cos \varphi} \left( T_L + \frac{GD^2}{375} \times \frac{N}{t_A} \right) \le 1.5 \times the \_capacity\_of\_AC\_motor\_drive(kVA)$$

#### 2. When one AC motor drive operates more than one motor

- 2.1 The starting capacity should be less than the rated capacity of AC motor drive
- Acceleration time ≤60 seconds

The starting capacity=

$$\frac{k \times N}{\eta \times \cos \varphi} \left[ n_{\tau} + n_{s} \left( k_{s-1} \right) \right] = P_{C1} \left[ 1 + \frac{n_{s}}{n_{\tau}} \left( k_{s-1} \right) \right] \leq 1.5 \times the \_capacity\_of\_AC\_motor\_drive(kVA)$$

■ Acceleration time ≥60 seconds

The starting capacity=

$$\frac{k \times N}{\eta \times \cos \varphi} [n_{\tau} + n_{s}(k_{s-1})] = P_{C1} \left[ 1 + \frac{n_{s}}{n_{\tau}} (k_{s-1}) \right] \leq the \_capacity\_of\_AC\_motor\_drive(kVA)$$

2.2 The current should be less than the rated current of AC motor drive(A)

■ Acceleration time ≤60 seconds

$$n_{\tau} + I_{M} \Big[ 1 + \frac{n_{s}}{n_{\tau}} \Big( k_{s} - 1 \Big) \Big] \leq 1.5 \times the \_rated \_current \_of \_AC\_motor \_drive(A)$$

■ Acceleration time ≥60 seconds

$$n_{\tau} + I_{M} \Big[ 1 + \frac{n_{s}}{n_{\tau}} (k_{s} - 1) \Big] \leq the \_rated \_current \_of \_AC\_motor \_drive(A)$$

### Call 1(800)985-6929 ther taaledrives.scalers@deltaacdrives.com

# Call 1(800)985-6929 foot Sales ives.com

Appendix C How to Select the Right AC Motor Drive | VFD-VL

2.3 When it is running continuously

 The requirement of load capacity should be less than the capacity of AC motor drive(kVA)

The requirement of load capacity=

$$\frac{k \times P_M}{\eta \times \cos\varphi} \le the \_capacity\_of \_AC\_motor\_drive(kVA)$$

The motor capacity should be less than the capacity of AC motor drive

$$k \times \sqrt{3} \times V_M \times I_M \times 10^{-3} \le the \_capacity\_of \_AC\_motor\_drive(kVA)$$

The current should be less than the rated current of AC motor drive(A)

$$k \times I_M \leq the\_rated\_current\_of\_AC\_motor\_drive(A)$$

#### Symbol explanation

Рм	: Motor shaft output for load (kW)
η	: Motor efficiency (normally, approx. 0.85)
$\cos \varphi$	: Motor power factor (normally, approx. 0.75)
$V_M$	: Motor rated voltage(V)
Ім	: Motor rated current(A), for commercial power
k	: Correction factor calculated from current distortion factor (1.05-1.1, depending on $\ensuremath{PWM}$ method)
$P_{C1}$	: Continuous motor capacity (kVA)
ks	: Starting current/rated current of motor
$n_T$	: Number of motors in parallel
ns	: Number of simultaneously started motors
$GD^2$	: Total inertia (GD <sup>2</sup> ) calculated back to motor shaft (kg $\ensuremath{m}^2\xspace)$
$T_L$	: Load torque
tA	: Motor acceleration time
N	: Motor speed

### Call 1(800)985-6929 the taaleed rives.scales @deltaacdrives.com

Appendix C How to Select the Right AC Motor Drive | VFD-VL

### **C.2 General Precaution**

#### Selection Note

- 1. When the AC Motor Drive is connected directly to a large-capacity power transformer (600kVA or above) or when a phase lead capacitor is switched, excess peak currents may occur in the power input circuit and the converter section may be damaged. To avoid this, use an AC input reactor (optional) before AC Motor Drive mains input to reduce the current and improve the input power efficiency.
- When a special motor is used or more than one motor is driven in parallel with a single AC Motor Drive, select the AC Motor Drive current ≥1.25x(Sum of the motor rated currents).
- 3. The starting and accel./decel. characteristics of a motor are limited by the rated current and the overload protection of the AC Motor Drive. Compared to running the motor D.O.L. (Direct On-Line), a lower starting torque output with AC Motor Drive can be expected. If higher starting torque is required (such as for elevators, mixers, tooling machines, etc.) use an AC Motor Drive of higher capacity or increase the capacities for both the motor and the AC Motor Drive.
- 4. When an error occurs on the drive, a protective circuit will be activated and the AC Motor Drive output is turned off. Then the motor will coast to stop. For an emergency stop, an external mechanical brake is needed to quickly stop the motor.

#### Parameter Settings Note

- The AC Motor Drive can be driven at an output frequency up to 400Hz (less for some models) with the digital keypad. Setting errors may create a dangerous situation. For safety, the use of the upper limit frequency function is strongly recommended.
- High DC brake operating voltages and long operation time (at low frequencies) may cause overheating of the motor. In that case, forced external motor cooling is recommended.
- 3. Motor accel./decel. time is determined by motor rated torque, load torque, and load inertia.
- 4. If the stall prevention function is activated, the accel./decel. time is automatically extended to a length that the AC Motor Drive can handle. If the motor needs to decelerate within a certain time with high load inertia that can't be handled by the AC Motor Drive in the

### Call 1(800)985-6929 thertaaleetrives.scalers@deltaacdrives.com

### Call 1(800)985-6929 for the tales rives.com

#### Appendix C How to Select the Right AC Motor Drive | VFD-VL


required time, either use an external brake resistor and/or brake unit, depending on the model, (to shorten deceleration time only) or increase the capacity for both the motor and the AC Motor Drive.

### C.3 How to Choose a Suitable Motor

#### Standard motor

When using the AC Motor Drive to operate a standard 3-phase induction motor, take the following precautions:

- 5. The energy loss is greater than for an inverter duty motor.
- Avoid running motor at low speed for a long time. Under this condition, the motor temperature may rise above the motor rating due to limited airflow produced by the motor's fan. Consider external forced motor cooling.
- When the standard motor operates at low speed for long time, the output load must be decreased.
- 8. The load tolerance of a standard motor is as follows:



- If 100% continuous torque is required at low speed, it may be necessary to use a special inverter duty motor.
- Motor dynamic balance and rotor endurance should be considered once the operating speed exceeds the rated speed (60Hz) of a standard motor.

### Call 1(800)985-6929 the tale drives.com

# Call 1(800)985-6929 for the tales rives.com

#### Appendix C How to Select the Right AC Motor Drive | VFD-VL

- Motor torque characteristics vary when an AC Motor Drive instead of commercial power supply drives the motor. Check the load torque characteristics of the machine to be connected.
- Because of the high carrier frequency PWM control of the VFD series, pay attention to the following motor vibration problems:
  - Resonant mechanical vibration: anti-vibration (damping) rubbers should be used to mount equipment that runs at varying speed.
  - Motor imbalance: special care is required for operation at 50 or 60 Hz and higher frequency.
  - To avoid resonances, use the Skip frequencies.
- 13. The motor fan will be very noisy when the motor speed exceeds 50 or 60Hz.

#### Special motors:

1. Pole-changing (Dahlander) motor:

The rated current is differs from that of a standard motor. Please check before operation and select the capacity of the AC motor drive carefully. When changing the pole number the motor needs to be stopped first. If over current occurs during operation or regenerative voltage is too high, please let the motor free run to stop (coast).

2. Submersible motor:

The rated current is higher than that of a standard motor. Please check before operation and choose the capacity of the AC motor drive carefully. With long motor cable between AC motor drive and motor, available motor torque is reduced.

3. Explosion-proof (Ex) motor:

Needs to be installed in a safe place and the wiring should comply with the (Ex) requirements. Delta AC Motor Drives are not suitable for (Ex) areas with special precautions.

4. Gear reduction motor:

The lubricating method of reduction gearbox and speed range for continuous operation will be different and depending on brand. The lubricating function for operating long time at low speed and for high-speed operation needs to be considered carefully.

5. Synchronous motor:

The rated current and starting current are higher than for standard motors. Please check before operation and choose the capacity of the AC motor drive carefully. When the AC

### Call 1(800)985-6929 the taaledrives.sales@deltaacdrives.com

## Call 1(800)985-6929 foot Sales @deltaacdrives.com

#### Appendix C How to Select the Right AC Motor Drive | VFD-VL

motor drive operates more than one motor, please pay attention to starting and changing

the motor.


#### Power Transmission Mechanism

Pay attention to reduced lubrication when operating gear reduction motors, gearboxes, belts and chains, etc. over longer periods at low speeds. At high speeds of 50/60Hz and above, lifetime reducing noises and vibrations may occur.

#### Motor torque

The torque characteristics of a motor operated by an AC motor drive and commercial mains power are different.

Below you'll find the torque-speed characteristics of a standard motor (4-pole, 15kW):



Call 1(800)985-6929 thertSalectrives.scales@deltaacdrives.com

Call 1(800)985-6929 the talestrives.scales@deltaacdrives.com

# Appendix D Suggestions and Error Corrections for Standard AC Motor Drives

The AC motor drive has a comprehensive fault diagnostic system that includes several different alarms and fault messages. Once a fault is detected, the corresponding protective functions will be activated. The following faults are displayed as shown on the AC motor drive digital keypad display. The six most recent faults can be read from the digital keypad or communication.

The AC motor drive is made up by numerous components, such as electronic components, including IC, resistor, capacity, transistor, and cooling fan, relay, etc. These components can't be used permanently. They have limited-life even under normal operation. Preventive maintenance is required to operate this AC motor drive in its optimal condition, and to ensure a long life.

Basic check-up items to detect if there were any abnormalities during operation are:

	-	Wait 5 seconds after a fault has been cleared before performing reset
		via keypad of input terminal.
CAUTION		When the power is off after 5 minutes for $\leq$ 22kW models and 10
		minutes for $\geqq$ 30kW models, please confirm that the capacitors have
		fully discharged by measuring the voltage between + and The
		voltage between + and - should be less than 25VDC.
	•	Only qualified personnel can install, wire and maintain drives. Please
		take off any metal objects, such as watches and rings, before
		operation. And only insulated tools are allowed.
	•	Never reassemble internal components or wiring.
	•	Make sure that installation environment comply with regulations
		without abnormal noise, vibration and smell.

# Call 1(800)985-6929 foortaaleedrives.scalers@deltaacdrives.com

Appendix D Suggestions and Error Corrections for Standard AC motor Drive | VFD-VL

### **D.1 Maintenance and Inspections**

Before the check-up, always turn off the AC input power and remove the cover. Wait at least 10 minutes after all display lamps have gone out, and then confirm that the capacitors have fully discharged by measuring the voltage between DC+ and DC-. The voltage between DC+ and DC- should be less than 25VDC.

#### Ambient environment

			Maintenance Period		
Check Items	Methods and Criterion	Daily	Half Year	One Year	
Check the ambient temperature, humidity, vibration and see if there are any dust, gas, oil or water drops	Visual inspection and measurement with equipment with standard specification	0			
If there are any dangerous objects	Visual inspection	0			

#### Voltage

	Methods and Criterion	Maintenance Period		
Check Items		Daily	Half Year	One Year
Check if the voltage of main circuit and control circuit is correct	Measure with multimeter with standard specification	0		

#### Keypad

Oh och kanna	Methods and Criterion	Main P		
Check Items		Daily	Half Year	One Year
Is the display clear for reading	Visual inspection	0		
Any missing characters	Visual inspection	0		

Call 1(800)985-6929 thertSalectrives.scales@deltaacdrives.com

# Call 1(800)985-6929 footBalestrives.scales@deltaacdrives.com

Appendix D Suggestions and Error Corrections for Standard AC motor Drive | VFD-VL

#### Mechanical parts

Check Items	Methods and Criterion	Maintenance Period			
		Daily	Half Year	One Year	
If there is any abnormal sound or vibration	Visual and aural inspection		0		
If there are any loose screws	Tighten the screws		0		
If any part is deformed or damaged	Visual inspection		0		
If there is any color change by overheating	Visual inspection		0		
If there is any dust or dirt	Visual inspection		0		

#### Main circuit

Check Items			Maintenance Period			
	Methods and Criterion	Daily	Half Year	One Year		
If there are any loose or missing screws	Tighten or replace the screw	0				
If machine or insulator is deformed, cracked, damaged or with color change due to overheating or ageing	Visual inspection NOTE: Please ignore the color change of copper plate		0			
If there is any dust or dirt	Visual inspection		0			

#### Terminals and wiring of main circuit

Check Items	Methods and Criterion		Maintenance Period		
Check tiems	methous and Chienon	Daily	Half Year	One Year	
If the terminal or the plate is color change or deformation due to overheat	Visual inspection		0		
If the insulator of wiring is damaged or color change	Visual inspection		0		
If there is any damage	Visual inspection	0			

### Call 1(800)985-6929 the tales rives scales @deltaacdrives.com

# Call 1(800)985-6929 fbr talestrives.sales@deltaacdrives.com

Appendix D Suggestions and Error Corrections for Standard AC motor Drive | VFD-VL

#### DC capacity of main circuit

Check Items			Maintenance Period		
	Methods and Criterion	Daily	Half Year	One Year	
If there is any leak of liquid, color change, crack or deformation	Visual inspection	0			
If the safety valve is not removed? If valve is inflated?	Visual inspection	0			
Measure static capacity when required		0			

#### Resistor of main circuit

		Maintenance Period			
Check Items	Methods and Criterion		Half Year	One Year	
If there is any peculiar smell or insulator cracks due to overheat	Visual inspection, smell	0			
If there is any disconnection	Visual inspection	0			
If connection is damaged?	Measure with multimeter with standard specification	0			

#### Transformer and reactor of main circuit

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there is any abnormal vibration or peculiar smell	Visual, aural inspection and smell	0		

Call 1(800)985-6929 footsalestrives.scalers@deltaacdrives.com

# Call 1(800)985-6929 fbr talestrives.sales@deltaacdrives.com

Appendix D Suggestions and Error Corrections for Standard AC motor Drive | VFD-VL

#### Magnetic contactor and relay of main circuit

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there are any loose screws	Visual and aural inspection	0		
If the contact works correctly	Visual inspection	0		

#### Printed circuit board and connector of main circuit

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there are any loose screws and connectors	Tighten the screws and press the connectors firmly in place.		0	
If there is any peculiar smell and color change	Visual and smell inspection		0	
If there is any crack, damage, deformation or corrosion	Visual inspection		0	
If there is any liquid is leaked or deformation in capacity	Visual inspection		0	

#### Cooling fan of cooling system

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there is any abnormal sound or vibration	Visual, aural inspection and turn the fan with hand (turn off the power before operation) to see if it rotates smoothly		0	
If there is any loose screw	Tighten the screw		0	
If there is any color change due to overheat	Change fan		0	

### Call 1(800)985-6929 the tales trives scales @deltaacdrives.com

# Call 1(800)985-6929 footsaledrives.scalers@deltaacdrives.com

Appendix D Suggestions and Error Corrections for Standard AC motor Drive | VFD-VL

#### Ventilation channel of cooling system

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there is any obstruction in the heat sink, air intake or air outlet	Visual inspection		0	



Please use the neutral cloth for clean and use dust cleaner to remove dust when necessary.

Call 1(800)985-6929 the tales rives.com

# Call 1(800)985-6929 foot Sales ives.com

Appendix D Suggestions and Error Corrections for Standard AC motor Drive | VFD-VL

### **D.2 Greasy Dirt Problem**

Serious greasy dirt problems generally occur in processing industries such as machine tools, punching machines and so on. Please be aware of the possible damages that greasy oil may cause to your drive:

- 1. Electronic components that silt up with greasy oil may cause the drive to burn out or even explode.
- 2. Most greasy dirt contains corrosive substances that may damage the drive.

#### Solutions:

Install the AC motor drive in a standard cabinet to keep it away from dirt. Clean and remove greasy dirt regularly to prevent damage to the drive.





# Call 1(800)985-6929 footsaledrives.scalers@deltaacdrives.com

Appendix D Suggestions and Error Corrections for Standard AC motor Drive | VFD-VL

### **D.3 Fiber Dust Problem**

Serious fiber dust problems generally occur in the textile industry. Please be aware of the possible damages that fiber may cause to your drives:

- 1. Fiber that accumulates or adheres to the fans will lead to poor ventilation and cause overheating problems.
- Plant environments in the textile industry have higher degrees of humidity that may cause the drive to burn out, become damaged or explode due to wet fiber dust adhering to the devices.

#### Solutions:

Install the AC motor drive in a standard cabinet to keep it away from fiber dust. Clean and remove fiber dust regularly to prevent damage to the drive.







# Call 1(800)985-6929 fbr talestrives.sales@deltaacdrives.com

Appendix D Suggestions and Error Corrections for Standard AC motor Drive | VFD-VL

### **D.4 Erosion Problem**

Erosion problems may occur if any fluids flow into the drives. Please be aware of the damages that erosion may cause to your drive.


1. Erosion of internal components may cause the drive to malfunction and possibility to explode.

#### Solutions:

Install the AC motor drive in a standard cabinet to keep it away from fluids. Clean the drive regularly to prevent erosion.







# Call 1(800)985-6929 foot Sales @deltaacdrives.com

Appendix D Suggestions and Error Corrections for Standard AC motor Drive | VFD-VL

### **D.5 Industrial Dust Problem**

Serious industrial dust pollution frequently occurs in stone processing plants, flour mills, cement plants, and so on. Please be aware of the possible damage that industrial dust may cause to your drives:

- 1. Dust accumulating on electronic components may cause overheating problem and shorten the service life of the drive.
- 2. Conductive dust may damage the circuit board and may even cause the drive to explode.

**Solutions:** Install the AC motor drive in a standard cabinet and cover the drive with a dust cover. Clean the cabinet and ventilation hole regularly for good ventilation.





# Call 1(800)985-6929 for the tales rives.com

Appendix D Suggestions and Error Corrections for Standard AC motor Drive | VFD-VL

### **D.6 Wiring and Installation Problem**

When wiring the drive, the most common problem is wrong wire installation or poor wiring. Please be aware of the possible damages that poor wiring may cause to your drives:

- 1. Screws are not fully fastened. Occurrence of sparks as impedance increases.
- 2. If a customer has opened the drive and modified the internal circuit board, the internal components may have been damaged.

**Solutions:** Ensure all screws are fastened when installing the AC motor drive. If the AC motor drive functions abnormally, send it back to the repair station. DO NOT try to reassemble the internal components or wire.







# Call 1(800)985-6929 food the tales by seven a seven a

Appendix D Suggestions and Error Corrections for Standard AC motor Drive | VFD-VL

### D.7 Multi-function Input/Output Terminals Problem

Multi-function input/output terminal errors are generally caused by over usage of terminals and not following specifications. Please be aware of the possible damages that errors on multi-function input/output terminals may cause to your drives:

1. Input/output circuit may burns out when the terminal usage exceeds its limit.

**Solutions:** Refer to the user manual for multi-function input output terminals usage and follow the specified voltage and current. DO NOT exceed the specification limits.





