

Industrial Automation Headquarters

Delta Electronics, Inc.

Taoyuan Technology Center No.18, Xinglong Rd., Taoyuan District, Taoyuan City 33068, Taiwan

TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Delta Electronics (Shanghai) Co., Ltd.

No.182 Minyu Rd., Pudong Shanghai, P.R.C.

Post code : 201209

TEL: 86-21-6872-3988 / FAX: 86-21-6872-3996

Customer Service: 400-820-9595

Delta Electronics (Japan), Inc.

Tokyo Office

Industrial Automation Sales Department

2-1-14 Shibadaimon, Minato-ku

Tokyo, Japan 105-0012

TEL: 81-3-5733-1155 / FAX: 81-3-5733-1255

Delta Electronics (Korea), Inc.

1511, 219, Gasan Digital 1-Ro., Geumcheon-gu,

Seoul. 08501 South Korea

TEL: 82-2-515-5305 / FAX: 82-2-515-5302

Delta Energy Systems (Singapore) Pte Ltd.

4 Kaki Bukit Avenue 1, #05-04, Singapore 417939 TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.

Plot No.43, Sector 35, HSIIDC Gurgaon, PIN 122001, Haryana, India

TEL: 91-124-4874900 / FAX: 91-124-4874945

Delta Electronics (Thailand) PCL.

909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z),

Pattana 1 Rd., T.Phraksa, A.Muang,

Samutprakarn 10280, Thailand

TEL: 66-2709-2800 / FAX: 662-709-2827

Delta Energy Systems (Australia) Pty Ltd.

Unit 20-21/45 Normanby Rd., Notting Hill Vic 3168, Australia

TEL: 61-3-9543-3720

Americas

Delta Electronics (Americas) Ltd.

P.O. Box 12173, 5101 Davis Drive,

Research Triangle Park, NC 27709, U.S.A.

TEL: 1-919-767-3813 / FAX: 1-919-767-3969

Delta Greentech (Brasil) S/A

São Paulo Office

Rua Itapeva, 26 – 3° Andar - Bela Vista

CEP: 01332-000 - São Paulo - SP - Brasil

TEL: 55-11-3530-8642 / 55-11-3530-8640

Delta Electronics International Mexico S.A. de C.V.

Vía Dr. Gustavo Baz No. 2160, Colonia La Loma,

54060 Tlalnepantla Estado de Mexico

TEL: 52-55-2628-3015 #3050/3052

EMEA

Headquarters: Delta Electronics (Netherlands) B.V.

Sales: Sales.IA.EMEA@deltaww.com

Marketing: Maketing.IA.EMEA@deltaww.com

Technical Support: iatechnicalsupport@deltaww.com

Customer Support: Customer-Support@deltaww.com

Service: Service.IA.emea@deltaww.com

TEL: +31(0)40 800 3800

BENELUX: Delta Electronics (Netherlands) B.V.

De Witbogt 20, 5652 AG Eindhoven, The Netherlands

Mail: Sales.IA.Benelux@deltaww.com TEL: +31(0)40 800 3800

DACH: Delta Electronics (Netherlands) B.V.

Coesterweg 45, D-59494 Soest, Germany

Mail: Sales.IA.DACH@deltaww.com

TEL: +49(0)2921 987 0

France: Delta Electronics (France) S.A.

ZI du bois Challand 2,15 rue des Pyrénées,

Lisses, 91090 Evry Cedex, France

Mail: Sales.IA.FR@deltaww.com

TEL: +33(0)1 69 77 82 60

Iberia: Delta Electronics Solutions (Spain) S.L.U

Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed

Hormigueras – P.I. de Vallecas 28031 Madrid

TEL: +34(0)91 223 74 20

C/Llull, 321-329 (Edifici CINC) | 22@Barcrelona, 08019 Barcelona

Mail: Sales.IA.Iberia@deltaww.com

TEL: +34 93 303 00 60

Italy: Delta Electronics (Italy) S.r.l.

Ufficio di Milano Via Senigallia 18/2 20161 Milano (MI) Piazza Grazioli 18 00186 Roma Italy

Mail: Sales.IA.Italy@deltaww.com

TEL: +39 02 64672538

Russia: Delta Energy System LLC

Vereyskaya Plaza II, office 112 Vereyskaya str.

17 121357 Moscow Russia

Mail: Sales.IA.RU@deltaww.com

TEL: +7 495 644 3240

Turkey: Delta Greentech Elektronik San. Ltd. Sti. (Turkey)

Şerifali Mah. Hendem Cad. Kule Sok. No:16-A

34775 Ümraniye – İstanbul

Mail: Sales.IA.Turkey@deltaww.com

TEL: + 90 216 499 9910

GCC: Delta Energy Systems AG (Dubai BR)

P.O. Box 185668, Gate 7, 3rd Floor, Hamarain Centre

Dubai, United Arab Emirates

Mail: Sales.IA.MEA@deltaww.com TEL: +971(0)4 2690148

Egypt + North Africa: Delta Electronics 511 Cairo Business Plaza, North 90 street,

New Cairo, Cairo, Egypt

Mail: Sales.IA.MEA@deltaww.com





an

ua


(1)

S ta

nd

<u>a</u>

7





Delta Standard Compact Drive MS300 Series User Manual





Copyright notice

©Delta Electronics, Inc. All rights reserved.

All information contained in this user manual is the exclusive property of Delta Electronics Inc. (hereinafter referred to as "Delta") and is protected by copyright law and all other laws. Delta retains the exclusive rights of this user manual in accordance with the copyright law and all other laws. No parts in this manual may be reproduced, transmitted, transcribed, translated or used in any other ways without the prior consent of Delta.

Limitation of Liability

The contents of this user manual are only for the use of the AC motor drives manufactured by Delta. Except as defined in special mandatory laws, Delta provides this user manual "as is" and does not offer any kind of warranty through this user manual for using the product, either express or implied, including but not limited to the following: (i) this product will meet your needs or expectations; (ii) the information contained in the product is current and correct; (iii) the product does not infringe any rights of any other person. You shall bear your own risk to use this product.

In no event shall Delta, its subsidiaries, affiliates, managers, employees, agents, partners and licensors be liable for any direct, incidental, special, derivative or consequential damages (including but not limited to the damages for loss of profits, goodwill, use or other intangible losses) unless the laws contains special mandatory provisions to the contrary.

Delta reserves the right to make changes to the user manual and the products described in the user manual without prior notice and afterwards.

PLEASE READ PRIOR TO INSTALLATION FOR SAFETY.



- ☑ Disconnect AC input power before connecting any wiring to the AC motor drive.
- ☑ There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. Take anti-static measures before touching these components or the circuit boards. These components are especially sensitive to static electricity. Please do not touch these components or the circuit boards before taking anti-static measures.
- ☑ Never modify the internal components or wiring.
- ☑ Ground the AC motor drive by using the ground terminal. The grounding method must comply with the laws of the country where the AC motor drive is to be installed.
- ☑ DO NOT install the AC motor drive in a place subjected to high temperature, direct sunlight and inflammables.



- ☑ Never connect the AC motor drive output terminals U/T1, V/T2 and W/T3 directly to the AC mains circuit power supply.
- After finishing the wiring of the AC motor drive, check if U/T1, V/T2 and W/T3 are short-circuited to ground with a multimeter. Do NOT power the drive if short circuits occur. Eliminate the short circuits before the drive is powered.
- ☑ Rated voltage of power system to install motor drives is as below, make sure that the installation voltage is within the ranges mentioned below while installing the motor drives:

For 115V models, the range is between 85–132 V.

For 230V models, the range is between 170-264 V.

For 460V models, the range is between 323-528 V.

For 575V models, the range is between 425V–660V.

☑ Refer to the table below for short circuit rating:

Model (Power)	Short circuit rating		
115V	5 kA		
230V	5 kA		
460V	5 kA		
575V	5 kA		

- ☑ Only qualified persons are allowed to install, wire and maintain the AC motor drives.
- ☑ Even if the three-phase AC motor is stopped, a charge with hazardous voltages may still remain in the main circuit terminals of the AC motor drive.
- ☐ The performance of electrolytic capacitor will degrade if it is not charged for a long time. It is recommended to charge the drive which is stored in no charge condition every 2 years for 3–4 hours to restore the performance of electrolytic capacitor in the motor drive.

Note: When power up the motor drive, use adjustable AC power source (ex. AC autotransformer) to charge the drive at 70%–80% of rated voltage for 30 minutes (do not run the motor drive). Then charge the drive at 100% of rated voltage for an hour (do not run the motor drive). By doing these, restore the performance of electrolytic

- capacitor before starting to run the motor drive. Do NOT run the motor drive at 100% rated voltage right away.
- ☑ Pay attention to the following when transporting and installing this package (including wooden crate and wood stave).
 - If you need to deworm the wooden crate, do not use fumigation or you will damage the drive. Any damage to the drive caused by using fumigation voids the warranty.
 - 2 Use other methods, such as heat treatment or any other non-fumigation treatment, to deworm the wood packaging material.
 - 3 If you use heat treatment to deworm, leave the packaging materials in an environment of over 56°C for a minimum of thirty minutes.
- ☑ Connect the drive to a three-phase three-wire or three-phase four-wire Wye system to comply with UL standards.
- ☑ If the motor drive produces a leakage current of over 3.5mA AC or over 10mA DC on the Protective Earthing conductor, the minimum specifications required of the Protective Earthing conductor to be installed have to comply with the national, local laws and regulations or follow IEC61800-5-1 to do grounding.

NOTE

- In the pictures in this manual, the cover or safety shield is disassembled only when explaining the details of the product. During operation, install the top cover and wiring correctly according to the provisions. Refer to the operation descriptions in the manual to ensure safety.
- The figures in this instruction are only for reference and may be slightly different depending on your model, but it will not affect your customer rights.
- The content of this manual may be revised without prior notice. Consult our distributors or download the latest version at http://www.deltaww.com/iadownload acmotordrive.

Table of Contents

CHAPT	ER 1 INTRODUCTION	1-1
1-1	Nameplate Information	1-2
1-2	Model Name	1-3
1-3	Serial Number	1-3
1-4	Apply After Service by Mobile Device	1-4
1-5	RFI Jumper	1-5
CHAPT	ER 2 DIMENSIONS	2-1
2-1	Frame A	2-2
2-2	Frame B	2-3
2-3	Frame C	2-4
2-4	Frame D	2-5
2-5	Frame E	2-6
2-6	Frame F	2-7
2-7	Digital Keypad	2-8
CHAPT	ER 3 INSTALLATION	3-1
3-1	Mounting Clearance	3-2
3-2	Airflow and Power Dissipation	3-3
СНАРТ	ER 4 WIRING	4-1
4-1	System Wiring Diagram	4-3
	Wiring	
CHAPT	ER 5 MAIN CIRCUIT TERMINALS	5-1
5-1	Main Circuit Diagram	5-4
5-2	Main Circuit Terminals Specifications	5-5
	Frame A	5-6
	Frame B	5-7
	Frame C	5-8
	Frame D	5-9
	Frame E	5-10
	Frame F	5-11
CHPATI	ER 6 CONTROL TERMINALS	6-1
6-1	Control Terminal Specifications	6-4

CHAPTER 7 OPTIONAL ACCESSORIES	7-1
7-1 Brake Resistors and Brake Units Used in AC Motor Drives	7-2
7-2 Magnetic Contactor / Air Circuit Breaker and Non-fuse Circuit Breaker	7-6
7-3 Fuse Specification Chart	
7-4 AC / DC Reactor	
7-5 Zero Phase Reactors	7-35
7-6 EMC Filter	7-38
7-7 EMC Shield Plate	7-44
7-8 Capacitive Filter	7-47
7-9 NEMA 1 / UL Type 1 Kit	7-49
7-10 Fan Kit	7-57
7-11 Keypad Panel Mounting	7-58
7-12 DIN-Rail Mounting	7 - 59
7-13 Mounting Adapter Plate	7-61
7-14 Digital Keypad - KPC-CC01	7-66
CHAPTER 8 OPTION CARDS	8-1
8-1 Option Card Installation	8-2
8-2 CMM-PD02 Communication Extension Card, PROFIBUS DP	8-8
8-3 CMM-DN02 Communication Extension Card, DeviceNet	8-10
8-4 CMM-EIP02 Communication Extension Card, EtherNet/IP	8-13
8-5 CMM-COP02 Communication Extension Card, CANopen	8-17
8-6 CMM-EC02 Communication Extension Card, EtherCAT	8-19
8-7 EMM-BPS02 +24 V _{DC} Power Extension Card	8-20
8-8 Delta Standard Fieldbus Cables	8-21
CHAPTER 9 SPECIFICATION	9-1
9-1 115V Models	9-2
9-2 230V Models	9-3
9-3 460V Models	9-5
9-4 575V Models	9-7
9-5 General Specifications	9-8
9-6 Environment for Operation, Storage and Transportation	9-9
9-7 Derating for Ambient Temperature, Altitude and Carrier Frequency	9-10
CHAPTER 10 DIGITAL KEYPAD	10-1
CHAPTER 11 SUMMARPY OF PARAMETERS SETTINGS	11-1

CHAPTE	R 12 DESCRIPTION OF PARAMETER SETTINGS	12-00-1
12-1	Description of Parameter Settings	12-00-1
	00 Drive Parameters	
	01 Basic Parameters	12.1-01-1
	02 Digital Input / Output Parameters	12.1-02-1
	03 Analog Input / Output Parameters	12.1-03-1
	04 Multi-step Speed Parameters	12.1-04-1
	05 Motor Parameters	12.1-05-1
	06 Protection Parameters (1)	12.1-06-1
	07 Special Parameters	12.1-07-1
	08 High-function PID Parameters	12.1-08-1
	09 Communication Parameters	12.1-09-1
	10 Speed Feedback Control Parameters	12.1-10-1
	11 Advanced Parameters	12.1-11-1
	13 Industry Application Parameters	12.1-13-1
	14 Protection Parameters (2)	12.1-14-1
12-2	Adjustment & Application	12.2-1
CHAPTE	R 13 WARNING CODES	13-1
CHAPTE	R 14 ERROR CODES	14-1
CHAPTE	R 15 CANOPEN OVERVIEW	15-1
15-1	CANopen Ovreview	15-3
15-2	Wiring for CANopen	15-7
15-3	CANopen Communication Interface Descriptions	15-8
15-4	CANopen Supporting Index	15-16
15-5	CANopen Fault Codes	15-21
15-6	CANopen LED Function	15-24
CHAPTE	R 16 PLC FUNCTION APPLICATIONS	16-1
16-1	PLC Summary	16-2
	Notes Before Using a PLC	
16-3	-	
16-4		
16-5	Various PLC Device Functions	
16-6		
16-7	Error Display and Handling	16-106
16-8	Explanation of PLC Speed Mode Control	
	Count Function Using Pulse Input	

CHAPTE	CHAPTER 17 SAFE TORQUE OFF FUNCTION				
17-1	Basic Function Description	17-2			
17-2	Safe Torque Off Terminal Function Description	17-3			
17-3	Wiring Diagram	17-4			
17-4	Failure Rate of the Drive Safety Function	17-5			
17-5	Reset the Parameter Settings	17-5			
17-6	Timing Diagram Description	17-6			
17-7	Error Code and Troubleshooting Instructions	17-9			
17-8	Test and Fault Confirmation	17-11			
APPEND	IX A-REVISION HISTORY				

Issued Edition: 03

Firmware Version: V1.XX (Refer to Parameter 00-06 on the product to get the firmware version.)

Issued Date: 2020/04

[This page intentionally left blank]

Chapter 1 Introduction


- 1-1 Nameplate Information
- 1-2 Model Name
- 1-3 Serial Number
- 1-4 Apply After Service by Mobile Device
- 1-5 RFI Jumper

Chapter 1 Introduction | MS300


After receiving the AC motor drive, check for the following:

- 1. Inspect the unit after unpacking to ensure that it was not damaged during shipment. Make sure that the part number printed on the package matches the part number indicated on the nameplate.
- 2. Make sure that the mains voltage is within the range indicated on the nameplate. Install the AC motor drive according to the instructions in this manual.
- 3. Before applying power, make sure that all devices, including mains power, motor, control board and digital keypad, are connected correctly.
- 4. When wiring the AC motor drive, make sure that the wiring of input terminals "R/L1, S/L2, T/L3" and output terminals "U/T1, V/T2, W/T3" are correct to prevent damage to the drive.
- 5. When power is applied, use the digital keypad (KPMS-LE01) to select the language and set parameters. When executing a trial run, begin with a low speed and then gradually increase the speed to the desired speed.

1-1 Nameplate Information




1-2 Model Name



- *1. For IP20 models only.
- *2. Not applicable for models of 575V input voltage.
- *3. Not applicable for models of 115V and 575V input voltage.
- *4. For 230V input voltage (one-phase) and 460V input voltage (three-phase) models only.


1-3 Serial Number




1-4 Apply After Service by Mobile Device

1-4-1 Location of Service Link Label

Service link label (Service Label) is pasted on the area as the drawing below shows.



1-4-2 Service Link Label



Scan QR Code to request service

- 1. Find the QR code sticker (as shown above).
- 2. Use a smartphone to run a QR Code reader APP.
- 3. Point your camera at the QR Code. Hold your camera steady until the QR code comes into focus.
- 4. Access the Delta After Service website.
- 5. Fill your information into the column marked with an orange star.
- 6. Enter the CAPTCHA and click "Submit" to complete the application.

Cannot find the QR Code?

- 1. Open a web browser on your computer or smartphone.
- 2. Enter https://service.deltaww.com/ia/repair in browser address bar and press the Enter key.
- 3. Fill your information into the columns marked with an orange star.
- 4. Enter the CAPTCHA and click "Submit" to complete the application.


1-5 RFI Jumper

- The drive contains Varistors / MOVs that are connected from phase to phase and from phase to ground to prevent the drive from unexpected stop or damage caused by mains surges or voltage spikes. Because the Varistors / MOVs from phase to ground are connected to ground with the RFI jumper, removing the RFI jumper disables the protection.
- In models with a built-in EMC filter, the RFI jumper connects the filer capacitors to ground to form a return path for high frequency noise in order to isolate the noise from contaminating the mains power. Removing the RFI jumper strongly reduces the effect of the built-in EMC filter. Although a single drive complies with the international standards for leakage current, an installation with several drives with built-in EMC filters can trigger the RCD. Removing the RFI jumper helps, but the EMC performance of each drive is no longer guaranteed.

Frame A–F Screw Torque: 4–6 kg-cm / [3.5–5.2 lb-in.] / [0.39–0.59 Nm]


Loosen the screw and remove the RFI jumper (as shown below).

Tighten the screw again after you remove the RFI jumper.



Frame B-F (model with built-in EMC filter)

Remove the RFI jumper with a slotted screwdriver (as shown below).




Isolating main power from ground:

When the power distribution system for the drive is a floating ground system (IT Systems) or an asymmetric ground system (Corner Grounded TN Systems), you must remove the RFI jumper. Removing the RFI jumper disconnects the internal capacitors from ground to avoid damaging the internal circuits and to reduce the ground leakage current.

Important points regarding ground connection

- ☑ To ensure the safety of personnel, proper operation, and to reduce electromagnetic radiation, you must properly ground the motor and drive during installation.
- ☑ The diameter of the grounding cables must comply with the local safety regulations.
- ☑ You must connect the shielded cable to the motor drive's ground to meet safety regulations.
- ☑ Only use the shielded cable as the ground for equipment when the aforementioned points are met.
- ☑ When installing multiple drives, do not connect the grounds of the drives in series but connect each drive to ground. The following pictures show the correct and wrong ways to connect the grounds.



Pay particular attention to the following points:

- ☑ Do not remove the RFI jumper while the power is on.
- ☑ Removing the RFI jumper also cuts the capacitor conductivity of the surge absorber to ground and the built-in EMC filter capacitors. Compliance with the EMC specifications is no longer guaranteed.
- ☑ Do not remove the RFI jumper if the mains power is a symmetrical grounded power system in order to maintain the efficiency for EMC circuit.
- ☑ Remove the RFI jumper when conducting high voltage tests. When conducting a high voltage test to the entire facility, disconnect the mains power and the motor if the leakage current is too high.

Floating Ground System (IT Systems)

A floating ground system is also called an IT system, an ungrounded system, or a high impedance/resistance (greater than 30 Ω) grounded system.

- ☑ Remove the RFI jumper to disconnect the ground cable from the internal filter capacitor and surge absorber.
- ☑ Do not install an external RFI/EMC filter. The external EMC filter passes through a filter capacitor and connects power input to the ground. This is very dangerous and damages the motor drive.
- ☑ In situations where EMC is required, use an EMC filter specifically for IT system if necessary. Disconnecting the ground cable from the filter prevents damage to the motor drive but compliance with EMC is no longer guaranteed.
- ☑ In situations where EMC is required, check for excess electromagnetic radiation affecting nearby low-voltage circuits. In some situations, the adapter and cable naturally provide enough suppression. If in doubt, install an extra electrostatic shielded cable on the power supply side between the main circuit and the control terminals to increase shielding.


Asymmetric Ground System (Corner Grounded TN Systems)

Caution: Do not remove the RFI jumper while power to the input terminal of the drive is ON. In the following four situations, you must remove the RFI jumper. This is to prevent the system from


grounding through the RFI and filter capacitors and damaging the drive.

You must remove the RFI jumper for an asymmetric ground system


1. Grounding at a corner in a triangle configuration




2. Grounding at a midpoint in a polygonal configuration



3. Grounding at one end in a single-phase configuration




4. No stable neutral grounding in a three-phase autotransformer configuration



You can use the RFI jumper for a symmetrical grounding power system

In a situation with a symmetrical grounding power system, you can use the RFI jumper to maintain the effect of the built-in EMC filter and surge absorber. For example, the diagram on the right is a symmetrical grounding power system.



Chapter 1 Introduction | MS300

[This page intentionally left blank]

Chapter 2 Dimensions

- 2-1 Frame A
- 2-2 Frame B
- 2-3 Frame C
- 2-4 Frame D
- 2-5 Frame E
- 2-6 Frame F
- 2-7 Digital Keypad

2-1 Frame A

A1: VFD1A6MS11ANSAA; VFD1A6MS11ENSAA; VFD1A6MS21ANSAA; VFD1A6MS21ENSAA;

VFD1A6MS23ANSAA; VFD1A6MS23ENSAA


A2: VFD2A8MS23ANSAA; VFD2A8MS23ENSAA


A3: VFD2A5MS11ANSAA; VFD2A5MS11ENSAA; VFD2A8MS21ANSAA; VFD2A8MS21ENSAA


A4: VFD1A5MS43ANSAA; VFD1A5MS43ENSAA

A5: VFD4A8MS23ANSAA; VFD4A8MS23ENSAA; VFD2A7MS43ANSAA; VFD2A7MS43ENSAA;

VFD1A7MS53ANSAA







Detail B (Mounting Hole)

Frame	W	Н	D	W1	H1	D1	S1
A1	68.0 [2.68]	128.0 [5.04]	96.0 [3.78]	56.0 [2.20]	118.0 [4.65]	3.0 [0.12]	5.2 [0.20]
A2	68.0 [2.68]	128.0 [5.04]	110.0 [4.33]	56.0 [2.20]	118.0 [4.65]	3.0 [0.12]	5.2 [0.20]
A3	68.0 [2.68]	128.0 [5.04]	125.0 [4.92]	56.0 [2.20]	118.0 [4.65]	3.0 [0.12]	5.2 [0.20]
A4	68.0 [2.68]	128.0 [5.04]	129.0 [5.08]	56.0 [2.20]	118.0 [4.65]	3.0 [0.12]	5.2 [0.20]
A5	68.0 [2.68]	128.0 [5.04]	143.0 [5.63]	56.0 [2.20]	118.0 [4.65]	3.0 [0.12]	5.2 [0.20]


2-2 Frame B


B1: VFD7A5MS23ANSAA; VFD7A5MS23ENSAA; VFD4A2MS43ANSAA; VFD4A2MS43ENSAA; VFD3A0MS53ANSAA

B2: VFD4A8MS21ANSAA; VFD4A8MS21ENSAA

B3: VFD1A6MS21AFSAA; VFD2A8MS21AFSAA; VFD4A8MS21AFSAA; VFD1A5MS43AFSAA;

VFD2A7MS43AFSAA; VFD4A2MS43AFSAA





Detail B (Mounting Hole)


- 1	Init:	mm	lincl
	'I II L.	111111	шы


Frame	W	Н	D	W1	H1	D1	S1
B1	72.0 [2.83]	142.0 [5.59]	143.0 [5.63]	60.0 [2.36]	130.0 [5.63]	6.4 [0.25]	5.2 [0.20]
B2	72.0 [2.83]	142.0 [5.59]	143.0 [5.63]	60.0 [2.36]	130.0 [5.63]	3.0 [0.12]	5.2 [0.20]
В3	72.0 [2.83]	142.0 [5.59]	159.0 [6.26]	60.0 [2.36]	130.0 [5.63]	4.3 [0.17]	5.2 [0.20]

2-3 Frame C


C1: VFD4A8MS11ANSAA; VFD4A8MS11ENSAA; VFD7A5MS21ANSAA; VFD7A5MS21ENSAA; VFD11AMS21ANSAA; VFD11AMS21ENSAA; VFD11AMS23ANSAA; VFD11AMS23ENSAA; VFD17AMS23ANSAA; VFD17AMS23ENSAA; VFD5A5MS43ANSAA; VFD5A5MS43ENSAA; VFD7A3MS43ANSAA; VFD7A3MS43ENSAA; VFD9A0MS43ANSAA; VFD9A0MS43ENSAA; VFD4A2MS53ANSAA; VFD6A6MS53ANSAA

C2: VFD7A5MS21AFSAA; VFD11AMS21AFSAA; VFD5A5MS43AFSAA; VFD7A3MS43AFSAA; VFD9A0MS43AFSAA





Detail A (Mounting Hole)




Detail B (Mounting Hole)


							Office Hilling [Hilloring
Frame	W	Н	D	W1	H1	D1	S1
C1	87.0 [3.43]	157.0 [6.18]	152.0 [5.98]	73.0 [2.87]	144.5 [5.69]	5.0 [0.20]	5.5 [0.22]
C2	87.0 [3.43]	157.0 [6.18]	179.0 [7.05]	73.0 [2.87]	144.5 [5.69]	5.0 [0.20]	5.5 [0.22]


2-4 Frame D

D1: VFD25AMS23ANSAA; VFD25AMS23ENSAA; VFD13AMS43ANSAA; VFD13AMS43ENSAA; VFD17AMS43ANSAA; VFD17AMS43ENSAA; VFD9A9MS53ANSAA; VFD12AMS53ANSAA


D2: VFD13AMS43AFSAA; VFD17AMS43AFSAA












Detail B (Mounting Hole)


Frame	W	Н	D	W1	H1	D1	S1
D1	109.0 [4.29]	207.0 [8.15]	154.0 [6.06]	94.0 [3.70]	193.8 [7.63]	6.0 [0.24]	5.5 [0.22]
D2	109.0 [4.29]	207.0 [8.15]	187.0 [7.36]	94.0 [3.70]	193.8 [7.63]	6.0 [0.24]	5.5 [0.22]

2-5 Frame E


E1: VFD33AMS23ANSAA; VFD33AMS23ENSAA; VFD49AMS23ANSAA; VFD49AMS23ENSAA; VFD25AMS43ANSAA; VFD25AMS43ENSAA; VFD32AMS43ANSAA; VFD32AMS43ENSAA

E2: VFD25AMS43AFSAA; VFD32AMS43AFSAA










Detail B (Mounting Hole)


Frame	W	Н	D	W1	H1	D1	S1
E1	130.0 [5.12]	250.0 [9.84]	185.0 [7.83]	115.0 [4.53]	236.8 [9.32]	6.0 [0.24]	5.5 [0.22]
E2	130.0 [5.12]	250.0 [9.84]	219.0 [8.62]	115.0 [4.53]	236.8 [9.32]	6.0 [0.24]	5.5 [0.22]


2-6 Frame F


F1: VFD65AMS23ANSAA; VFD65AMS23ENSAA; VFD38AMS43ANSAA; VFD38AMS43ENSAA;

VFD45AMS43ANSAA; VFD45AMS43ENSAA F2: VFD38AMS43AFSAA; VFD45AMS43AFSAA











Detail B (Mounting Hole)


Frame	W	Н	D	W1	H1	D1	S1
F1	175.0 [6.89]	300.0 [11.81]	192.0 [7.56]	154.0 [6.06]	279.5 [11.00]	6.5 [0.26]	8.4 [0.33]
F2	175.0 [6.89]	300.0 [11.81]	244.0 [9.61]	154.0 [6.06]	279.5 [11.00]	6.5 [0.26]	8.4 [0.33]


2-7 Digital Keypad

KPMS-LE01









W	W1	W2	W3	Н	H1	H2
68.0 [2.67]	63.8 [2.51]	45.2 [1.78]	8.0 [0.31]	46.8 [1.84]	42.0 [1.65]	26.0 [1.02]

H3	D	D1	D2	D3	D4	S1
7.5 [0.31]	30.0 [1.18]	22.7 [0.89]	2.0 [0.08]	2.2 [0.09]	1.3 [0.05]	M3*0.5(2X)

Chapter 3 Installation

- 3-1 Mounting Clearance
- 3-2 Airflow and Power Dissipation


3-1 Mounting Clearance

- ☑ Prevent fiber particles, scraps of paper, shredded wood, sawdust, metal particles, etc. from adhering to the heat sink.
- ☑ Install the AC motor drive in a metal cabinet. When installing one drive below another one, use a metal separator between the AC motor drives to prevent mutual heating and to prevent the risk of fire accident.
- ☑ Install the AC motor drive in a Pollution Degree 2 environment with clean and circulating air. A clean and circulating environment means air without polluting substances and dust.
- Mount the drive in an IP54 cabinet in order to maintain the Pollution Degree 2 or in a pollution-controlled environment. When installing the AC motor drive in a Pollution Degree 2 (IEC/EN 60664-1) environment, only nonconductive pollution occurs for the electrical equipment in the cabinet and thermostatic chamber and temporary conductivity caused by condensation is expected.

The appearances shown in the following figures are for reference only. The actual motor drives may look different.

Airflow direction: (Blue arrow) Inflow
Single drive installation

(Red arrow) Outflow ←→ (Black) Distance
 Side-by-side horizontal installation /
 Zero stack installation








Figure 3-2

Minimum mounting clearance

Installation method	A [mm]	B [mm]	C [mm]	Ambient temperature (°C)		
installation method	Aliiiii			Max. (Without derating)	Max. (derating)	
Single drive installation	50	30	-	50	60	
Side-by-side horizontal installation	50	30	30	50	60	
Zero stack installation	50	30	0	40	50	

Table 3-1



The minimum mounting clearances A–C stated in the table above apply to AC motor drives installation.

Failing to follow the minimum mounting clearances may cause the fan to malfunction and heat dissipation problems.

Ambient Temperature Derating for Each Installation Method

Single drive installation




Figure 3-3

Side-by-side horizontal installation




Figure 3-4

Zero stack installation




Figure 3-5

3-2 Airflow and Power Dissipation

Frame	Airflow Rate	Power Dissipation for AC Motor Drive				
rame	Model No.	Flow Rate (Unit: cfm)	Flow Rate (Unit: m³ / hr)	Loss External (Heat sink, unit: W)	Internal (Unit: W)	Total (Unit: W)
	VFD1A6MS11ANSAA VFD1A6MS11ENSAA		0.0	8.0	10.0	18.0
	VFD2A5MS11ANSAA VFD2A5MS11ENSAA			14.2	13.1	27.3
A	VFD1A6MS21ANSAA VFD1A6MS21ENSAA			8.0	10.3	18.3
	VFD2A8MS21ANSAA VFD2A8MS21ENSAA			16.3	14.5	30.8
	VFD1A6MS23ANSAA VFD1A6MS23ENSAA	0.0		8.6	10.0	18.6
	VFD2A8MS23ANSAA VFD2A8MS23ENSAA			16.5	12.6	29.1
	VFD4A8MS23ANSAA VFD4A8MS23ENSAA			31.0	13.2	44.2
	VFD1A5MS43ANSAA VFD1A5MS43ENSAA			17.6	11.1	28.7
	VFD2A7MS43ANSAA VFD2A7MS43ENSAA			30.5	17.8	48.3
	VFD1A7MS53ANSAA			23.5	12.5	36
	VFD1A6MS21AFSAA	0.0	0.0	8.0	10.3	18.3
	VFD2A8MS21AFSAA	10.0	16.99	16.3	14.5	30.8
	VFD4A8MS21ANSAA VFD4A8MS21ENSAA	0.0	0.0	29.1	20.1	49.2
	VFD4A8MS21AFSAA		16.99	29.1	20.1	49.2
В	VFD7A5MS23ANSAA VFD7A5MS23ENSAA			50.1	24.2	74.3
	VFD1A5MS43AFSAA			17.6	11.1	28.7
	VFD2A7MS43AFSAA	10.0		30.5	17.8	48.3
	VFD4A2MS43ANSAA VFD4A2MS43ENSAA VFD4A2MS43AFSAA			45.9	21.7	67.6
	VFD3A0MS53ANSAA	_		38.1	19	57.1
	VFD4A8MS11ANSAA VFD4A8MS11ENSAA		27.2	29.1	23.9	53.0
С	VFD7A5MS21ANSAA VFD7A5MS21ENSAA VFD7A5MS21AFSAA	-		46.5	31.0	77.5
	VFD11AMS21ANSAA VFD11AMS21ENSAA VFD11AMS21AFSAA	16.0		70.0	35	105
	VFD11AMS23ANSAA VFD11AMS23ENSAA			76.0	30.7	106.7
	VFD17AMS23ANSAA VFD17AMS23ENSAA			108.2	40.1	148.3

Chapter 3 Installation | MS300

Frame	Airflow Rate	Power Dissipation for AC Motor Drive				
Traine	Model No.	Flow Rate (Unit: cfm)	Flow Rate (Unit: m³ / hr)	Loss External (Heat sink, unit: W)	Internal (Unit: W)	Total (Unit: W)
	VFD5A5MS43ANSAA VFD5A5MS43ENSAA VFD5A5MS43AFSAA	16.0	27.2	60.6	22.8	83.4
С	VFD7A3MS43ANSAA VFD7A3MS43ENSAA VFD7A3MS43AFSAA			75.2	30	105.2
	VFD9A0MS43ANSAA VFD9A0MS43ENSAA VFD9A0MS43AFSAA			93.1	42	135.1
	VFD4A2MS53ANSAA			46.6	22.2	68.8
	VFD6A6MS53ANSAA			76.1	30	106.1
	VFD25AMS23ANSAA VFD25AMS23ENSAA	23.4	39.7	192.8	53.3	246.1
D	VFD13AMS43ANSAA VFD13AMS43ENSAA VFD13AMS43AFSAA			132.8	39.5	172.3
	VFD17AMS43ANSAA VFD17AMS43ENSAA VFD17AMS43AFSAA			164.7	55.8	220.5
	VFD9A9MS53ANSAA			93.9	37	130.9
	VFD12AMS53ANSAA			108.4	51	159.4
	VFD33AMS23ANSAA VFD33AMS23ENSAA	53.7	91.2	244.5	79.6	324.1
	VFD49AMS23ANSAA VFD49AMS23ENSAA			374.2	86.2	460.4
E	VFD25AMS43ANSAA VFD25AMS43ENSAA VFD25AMS43AFSAA			234.5	69.8	304.3
	VFD32AMS43ANSAA VFD32AMS43ENSAA VFD32AMS43AFSAA			319.8	74.3	394.1
F	VFD65AMS23ANSAA VFD65AMS23ENSAA	67.9	115.2	492.0	198.2	690.2
	VFD38AMS43ANSAA VFD38AMS43ENSAA VFD38AMS43AFSAA			423.5	181.6	605.1
	VFD45AMS43ANSAA VFD45AMS43ENSAA VFD45AMS43AFSAA			501.1	200.3	701.4

Table 3-2

Chapter 3 Installation | MS300

[This page intentionally left blank]

Chapter 4 Wiring

- 4-1 System Wiring Diagram
- 4-2 Wiring

Chapter 4 Wiring | MS300

After removing the front cover, verify that the power and control terminals are clearly noted. Read the following precautions before wiring.



- Turn off the AC motor drive power before doing any wiring. A charge with hazardous voltages may remain in the DC bus capacitors even after the power has been turned off for a short time. Measure the remaining voltage with a DC voltmeter on +1/DC+ and DC- before doing any wiring. For your safety, do not start wiring before the voltage drops to a safe level (less than 25 V_{DC}). Installing wiring with a residual voltage may cause personal injury, sparks and a short circuit.
- ☑ Only qualified personnel familiar with AC motor drives are allowed to perform installation, wiring and commissioning. Make sure the power is turned off before wiring to prevent electric shock.
- ☑ Make sure that power is only applied to the R/L1, S/L2, and T/L3 terminals. Failure
 to comply may result in damage to the equipment. The voltage and current must be
 in the range indicated on the nameplate (refer to Section 1-1 Nameplate
 Information for details).
- ☑ All units must be grounded directly to a common ground terminal to prevent damage from a lightning strike or electric shock and reduce noise interference.
- ☑ Tighten the screws of the main circuit terminals to prevent sparks caused by screws loosened due to vibration.



- ☑ For you safety, choose wires that comply with local regulations when wiring.
- ☑ Check the following items after finishing the wiring:
 - 1. Are all connections correct?
 - 2. Are there any loose wires?
 - 3. Are there any short circuits between the terminals or to ground?

4-1 System Wiring Diagram

	Power input terminal	Supply power according to the rated power specifications indicated in the manual (refer to Chapter 9 Specification).			
	NFB or fuse	There may be a large inrush current during power on. Refer to Section 7-2 NFB to select a suitable NFB or Section 7-3 Fuse Specification Chart.			
Power input terminal NFB or fuse	Electromagnetic	Switching the power ON/OFF on the primary side of the electromagnetic contactor can turn the drive ON/OFF, but frequent switching can cause machine failure. Do not switch ON/OFF more than once an hour.			
Electromagnetic	contactor	Do not use the electromagnetic contactor as the power switch for the drive; doing so shortens the life of the drive.			
contactor		Refer to Section 7-2 Magnetic Contactor / Air Circuit Breaker to select the electromagnetic contactor that meets your requirement.			
AC reactor (input terminal) Zero-phase reactor	AC reactor (input terminal)	When the main power supply capacity is greater than 500 kVA, or when it switches into the phase capacitor, the instantaneous peak voltage and current generated may destroy the internal circuit of the drive.			
EMC filter FR/L1 S/L2 T/L3 +		It is recommended that you install an input side AC reactor in the drive. This also improves the power factor and reduces power harmonics. The wiring distance should be within 10 m. Refer to Section 7-4 AC/DC Reactor for details.			
B20 Brake U/T1 V/T2 W/T3 😩 0 resistor	Zero phase	Used to reduce radiated interference, especially in environments with audio devices, and reduce input and output side interference.			
Zero-phase reactor	reactor	The effective range is AM band to 10 MHz. Refer to Section 7-5 Zero Phase Reactors for details.			
AC reactor (output terminal)	EMC filter	Can be used to reduce electromagnetic interference. Refer to Section 7-6 EMC Filter for details.			
Motor	Brake module	Used to shorten the deceleration time of the			
Figure 4-1	& Brake resistor (BR)	motor. Refer to Section 7-1 Brake Resistors and Brake Units Used in AC Motor Drives for details.			
	AC reactor (output terminal)	The motor cable length affects the size of the reflected wave on the motor end. It is recommended that you install an AC output reactor when the motor wiring length exceeds the value listed in Section 7-4.			
	Table 4.1				

Table 4-1

4-2 Wiring




Figure 4-2

Chapter 5 Main Circuit Terminals

- 5-1 Main Circuit Diagram
- 5-2 Main Circuit Terminal Specifications



- ☑ Tighten the screws in the main circuit terminal to prevent sparks caused by screws loosened due to vibration.
- ☑ If necessary, use an inductive filter only at the motor output terminals U/T1, V/T2, W/T3 of the AC motor drive. DO NOT use phase-compensation capacitors or L-C (Inductance-Capacitance) or R-C (Resistance-Capacitance), unless approved by Delta.
- ☑ DO NOT connect phase-compensation capacitors or surge absorbers at the output terminals of AC motor drives.
- ☑ DO NOT connect brake resistors directly to +1/DC+ to DC-, +2/B1 to DC- to prevent damage to the drive or to the brake resistors.
- ☑ Ensure proper insulation of the main circuit wiring in accordance with the relevant safety regulations.



Main input power terminals

- ☑ R/L1, S/L2 and T/L3 have no phase-sequence requirement; they can be connected in any sequence.
- Add a magnetic contactor (MC) to the power input wiring to cut off power quickly and reduce malfunctions when the AC motor drive protection function activates. Both ends of the MC should have an R-C surge absorber.
- ☑ Use voltage and current within the specifications in Chapter 09. Refer to Chapter 09 Specifications for details.
- Although the leakage current of one single MS300 drive is less than 10_{DC} mA, electric shock may still occur due to the leakage current from other equipment such as motors and leads. Therefore, it is recommended that you install one of the followings to prevent danger caused by electric shock.
 - 1. Use a copper wire with a cross-section of 10 mm² or above or an aluminum wire of 16 mm² as the connection between the casing and the ground.
 - 2. Install an Earth Leakage Circuit Breaker (ELCB).
- ☑ Due to the high frequency current of the leakage current of the AC motor drive, select a Type B ELCB specifically for the drive when using an ELCB. For tripping or malfunctions on the usage of ELCB, refer to Section 7-8 Capacitive Filter for details. The power system of the AC motor drive affects the power factor, so select a MCCB with larger capacity.
- ☑ Use shielded wire or conduit for the power wiring and ground the two ends of the shielding or conduit.
- ☑ DO NOT run and stop the AC motor drives by turning the power ON and OFF. Run and stop the AC motor drives by sending the RUN and STOP commands through the control terminals or the keypad. If you still need to run and stop the AC motor drives by turning the power ON and OFF, do so no more often than ONCE per hour.
- ☑ To comply with UL standards, connect the drive to a three-phase three-wire or three-phase four-wire Wye system type of mains power system.

Output terminals of the main circuit

- ☑ Use well-insulated motors to prevent any electric leakage from motors.
- ☑ When the AC drive output terminals U/T1, V/T2, and W/T3 are connected to the motor terminals U/T1, V/T2, and W/T3 respectively, the FWD LED indicator on the digital keypad is ON. This means the AC motor drive executes running forward, and the motor rotates counterclockwise (viewed from the shaft end of the motor, as shown in Figure 5-1).

On the contrary, when the REV LED indicator lights, the AC motor drive executes running in reverse, and the motor rotates in an opposite direction to Figure 5-1. If the AC motor drive executes running forward but the motor rotates in a reverse direction, exchange any two of the U/T1, V/T2 and W/T3 motor leads.




Figure 5-1

Terminals for connecting DC reactor, external brake resistor and DC circuit

- ☑ Use the terminals, as shown in Figure 5-2, to connect a DC reactor to improve the power factor and reduce harmonics. A jumper is connected to these terminals at the factory. Remove that jumper before connecting to a DC reactor.
- ☐ Tighten the jumper if a DC reactor is not connected and DC+/+1 and +2/B1 terminals are used for common DC bus or brake resistors in order to prevent the AC motor drive from losing power and damage to the terminals. If the jumper is missing due to wiring, refer to the recommended main circuit terminal wire gauge mentioned in Section 5-2 to short-circuit the DC+/+1 and +2/B1 terminals.




Figure 5-2

☐ Install an external brake resistor for applications in frequent deceleration to stop, short deceleration time (such as high frequency operation and heavy load operation), too low braking torque, or increased braking torque.





Figure 5-3

- ☑ Connect the external brake resistor to +2/B1, B2 terminals of the AC motor drives.
- ☑ DO NOT connect two ends of the brake resistor directly to DC+/+1 and DC-, +2/B1 to DC- to prevent damage to the drive and to the brake resistor.
- ☑ When connecting DC+/+1 and DC- in common DC bus applications, refer to Section 5-2 (Main Circuit Terminal Specifications) for the wiring terminal specification and the wire gauge information.

Remove the front cover

- Remove the front cover before wiring the main circuit terminals and control circuit terminals. Remove the cover according to the figures below.
- The example uses the Frame A model. For different frame size models, use the same removing method.



Press the clip on both sides, and then remove the cover by rotating it.

Figure 5-4

5-1 Main Circuit Diagram

Input: one-phase / three-phase power




Figure 5-5

Terminals	Descriptions				
R/L1, S/L2	Mains input terminals (one-phase)				
R/L1, S/L2, T/L3	Mains input terminals (three-phase)				
U/T1, V/T2, W/T3	AC motor drive output terminals for connecting three-phase IM and PM motors.				
+1, +2	Connections for DC reactor to improve the power factor. Remove the jumper before installing a DC reactor.				
DC+, DC-	Connections for brake unit (VFDB series) Common DC bus				
B1, B2 Connections for brake resistor (optional). Refer to Section 7-1 for details.					
	Ground connection; comply with local regulations.				


Table 5-1

5-2 Main Circuit Terminal Specifications

- Use the specified ring lug for main circuit terminal wiring.
 See Figure 5-6 and Figure 5-7 for ring lug specifications. For other types of wiring, use the wires that comply with the local regulations.
- After crimping the wire to the ring lug (must be UL and CSA approved R/C (YDPU2)), install heat shrink tubing rated at a minimum of 600 V_{AC} insulation over the live part. Refer to Figure 5-7.
- Main circuit terminals:

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, , DC-, DC+/+1, +2/B1, B2

Note: There is no T/L3 terminal for one-phase models.








Figure 5-7

Dimensions of Ring Lug

The part # of the ring lugs (produced by K.S. Terminals Inc.) in the table below are for reference only. You can buy other ring lugs of your choice to match with different frame sizes.

Unit: mm

Frame	*AWG	Kit P/N	A (MAX)	B (MAX)	C (MIN)	D (MAX)	d2 (MIN)	E (MIN)	F (MIN)	W (MAX)	t (MAX)
	18	RNBS 1-3.7									
Α	16	RNBS 2-3.7	9.8	3.2	4.8	4.1	3.7	13.0	4.2	6.6	8.0
	14	RNBS 2-3.7									
	18	RNBS1-4									
В	16	RNBS1-4	12.1	3.6	6.1	E G	4.2	12.0	1 E	7.0	1
Ь	14	RNBS2-4	12.1	3.0	6.1	5.6	4.3	13.0	4.5	7.2	ı
	12	RNBS5-4									į.
	14	RNBS2-4									
С	12	RNBS5-4	17.8	5.0	6.1	7.2	4.3	13.0	5.5	10.5	1.2
	10	RNBS5-4	17.0	5.0	0.1	1.2	4.3	13.0	5.5	10.5	1.2
	8	RNBS8-4									
D	10	RNBS5-4	17.8	5.0	6.1	7.2	4.3	13.0	5.5	10.5	1.2
D	8	RNBS8-4	17.0	5.0	0.1	1.2	4.3	13.0	5.5	10.5	1.2
Е	6	RNB14-5	27.1	6.1	10.5	11.5	5.3	13.0	6.5	12.6	1.7
	4	RNBS22-5	21.1	0.1	10.5	11.5	5.5	13.0	0.5	12.0	1.7
	6	RNBS14-6									
F	4	RNBS22-6	35.0	9.0	13.3	14.0	6.2	13.0	10.0	19.5	1.8
	2	RNBS38-6									

Table 5-2

^{*}AWG: Refer to the following tables for the wire size specification for models in each frame.

Frame A




Figure 5-8

- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 90°C or above.
- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 75°C or 90°C.
- For VFD2A5MS11ANSAA and VFD2A5MS11ENSAA models: If you install at Ta 40°C above environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistance of 75°C, in accordance with UL requirements and recommendations.

 Do not reduce the wire gauge when using high-temperature resistant wires.

Models	R/L1, S/L2,	Main Circuit Terminals R/L1, S/L2, T/L3, U/T1, V/T2, W/T DC-, DC+/+1, +2/B1, B2			Grounding Terminals		
iviodeis	Max. Wire Gauge	Min. Wire Gauge	Screw Size & Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Size & Torque (±10%)	
VFD1A6MS11ANSAA							
VFD1A6MS11ENSAA		2.5 mm ²					
VFD2A5MS11ANSAA		[14 AWG]					
VFD2A5MS11ENSAA							
VFD1A6MS21ANSAA		1.5 mm ²					
VFD1A6MS21ENSAA		[16 AWG]					
VFD2A8MS21ANSAA		2.5 mm ²					
VFD2A8MS21ENSAA		[14 AWG]					
VFD1A6MS23ANSAA	0.5		M3.5	2 7	0.5	M3.5	
VFD1A6MS23ENSAA	2.5 mm ² [14 AWG]	0.75 mm ²	9 kg-cm [7.8 lb-in.]	2.5 mm ² [14 AWG]	2.5 mm ² [14 AWG]	9 kg-cm [7.8 lb-in.]	
VFD2A8MS23ANSAA	[117410]	[18 AWG]	[0.88 Nm]	[117,1170]	[117410]	[0.88 Nm]	
VFD2A8MS23ENSAA							
VFD4A8MS23ANSAA		1.5 mm ²					
VFD4A8MS23ENSAA		[16 AWG]					
VFD1A5MS43ANSAA							
VFD1A5MS43ENSAA		0.75					
VFD2A7MS43ANSAA		0.75 mm ² [18 AWG]					
VFD2A7MS43ENSAA		[107.110]					
VFD1A7MS53ANSAA							

Frame B




Figure 5-9

- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 90°C or above.
- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 75°C or 90°C.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistance of 75°C, in accordance with UL requirements and recommendations.

 Do not reduce the wire gauge when using high-temperature resistant wires.

Models	Main Circuit Terminals R/L1, S/L2, T/L3, U/T1, V/T2, W/T DC-, DC+/+1, +2/B1, B2			Gro	unding Termi ⊕	nals
Models	Max. Wire Gauge	Min. Wire Gauge	Screw Size & Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Size & Torque (±10%)
VFD1A6MS21AFSAA		1.5 mm ² [16 AWG]		2.5 mm ²	2.5 mm ²	
VFD2A8MS21AFSAA		2.5 mm ² [14 AWG]		[14 AWG]	[14 AWG]	
VFD4A8MS21AFSAA		-				
VFD4A8MS21ANSAA						
VFD4A8MS21ENSAA		4 mm ² [12 AWG]		4 mm ² [12 AWG]	4 mm ² [12 AWG]	
VFD7A5MS23ANSAA	4 mm ²	[1271110]	M4 15 kg-cm	[127,000]	[1271110]	M4 15 kg-cm
VFD7A5MS23ENSAA	[12 AWG]		[13.0 lb-in.]			[13.0 lb-in.]
VFD1A5MS43AFSAA		0.75 mm ²	[1.47 Nm]			[1.47 Nm]
VFD2A7MS43AFSAA		[18 AWG]		0 = 2	0.5	
VFD4A2MS43ANSAA		2		2.5 mm ² [14 AWG]	2.5 mm ² [14 AWG]	
VFD4A2MS43ENSAA		2.5 mm ² [14 AWG]		[[[]]]	[117,110]	
VFD4A2MS43AFSAA		[117,010]				
VFD3A0MS53ANSAA		0.75 mm ² [18 AWG]		2.5 mm ² [14 AWG]	2.5 mm ² [14 AWG]	

Table 5-4

Frame C




Figure 5-10

- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 90°C or above.
- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 75°C or 90°C.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistance of 75°C, in accordance with UL requirements and recommendations.
 Do not reduce the wire gauge when using high-temperature resistant wires.

Models	R/L1, S/L2,	n Circuit Term T/L3, U/T1, \ DC+/+1, +2/E	V/T2, W/T3, 31, B2	Gro	unding Termi ⊕	nals
Wodels	Max. Wire Gauge	Min. Wire Gauge	Screw Size & Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Size & Torque (±10%)
VFD4A8MS11ANSAA						
VFD4A8MS11ENSAA						
VFD7A5MS21ANSAA]					
VFD7A5MS21ENSAA		10 mm ²		10 mm ²	10 mm ²	
VFD7A5MS21AFSAA		[8 AWG]		[8 AWG]	[8 AWG]	
VFD11AMS21ANSAA						
VFD11AMS21ENSAA						
VFD11AMS21AFSAA						
VFD11AMS23ANSAA		6 mm ²		6 mm ²	6 mm ²	
VFD11AMS23ENSAA		[10 AWG]		[10 AWG]	[10 AWG]	
VFD17AMS23ANSAA		10 mm ²	M4	10 mm ²	10 mm ²	M4
VFD17AMS23ENSAA	10 mm ²	[8 AWG]	20 kg-cm	[8 AWG]	[8 AWG]	20 kg-cm
VFD5A5MS43ANSAA	[8 AWG]		[17.4 lb-in.]			[17.4 lb-in.]
VFD5A5MS43ENSAA			[1.96 Nm]			[1.96 Nm]
VFD5A5MS43AFSAA		2.5 mm ²		2.5 mm ²	2.5 mm ²	
VFD7A3MS43ANSAA		[14AWG]		[14 AWG]	[14AWG]	
VFD7A3MS43ENSAA						
VFD7A3MS43AFSAA]]			
VFD9A0MS43ANSAA		4 mm ²		4 marra?	4 mm ²	
VFD9A0MS43ENSAA		4 mm² [12 AWG]		4 mm ² [12 AWG]	4 mm² [12 AWG]	
VFD9A0MS43AFSAA]	_]	_	-	
VFD4A2MS53ANSAA		2.5 mm ² [14 AWG]		2.5 mm ² [14 AWG]	2.5 mm ² [14 AWG]	
VFD6A6MS53ANSAA		4 mm ² [12 AWG]		4 mm ² [12 AWG]	4 mm ² [12 AWG]	

Frame D




Figure 5-11

- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 90°C or above.
- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 75°C or 90°C.
- For VFD25AMS23ANSAA and VFD25AMS23ENSAA models: If you install at Ta 45°C above environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistance of 75°C, in accordance with UL requirements and recommendations.

 Do not reduce the wire gauge when using high-temperature resistant wires.

Madala	R/L1, S/L2,	Circuit Term T/L3, U/T1, \ DC+/+1, +2/E	1, V/T2, W/T3, Groundii		unding Termi ⊕		
Models	Max. Wire Gauge	Min. Wire Gauge	Screw Size & Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Size & Torque (±10%)	
VFD25AMS23ANSAA		10 mm ²		10 mm ²	10 mm ²		
VFD25AMS23ENSAA		[8 AWG]		[8 AWG]	[8 AWG]		
VFD13AMS43ANSAA		C2		C2	02		
VFD13AMS43ENSAA		6 mm ² [10 AWG]	M4	6 mm ² [10 AWG]	6 mm ² [10 AWG]	M4	
VFD13AMS43AFSAA	10 mm ²	[.070]	20 kg-cm	[,]	[.070]	20 kg-cm	
VFD17AMS43ANSAA	[8 AWG]	40 2	[17.4 lb-in.]	10 2	40 2	[17.4 lb-in.]	
VFD17AMS43ENSAA		10 mm ² [8 AWG]	[1.96 Nm]	10 mm² [8 AWG]	10 mm ² [8 AWG]	[1.96 Nm]	
VFD17AMS43AFSAA		[071110]		[07.110]	[071110]		
VFD9A9MS53ANSAA		6 mm ²		6 mm ²	6 mm ²		
VFD12AMS53ANSAA		[10 AWG]		[10 AWG]	[10 AWG]		

Table 5-6

Frame E




Figure 5-12

- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 90°C or above.
- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 75°C or 90°C.
- For VFD33AMS23ANSAA and VFD33AMS23ENSAA models: If you install at Ta 40°C above environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 90°C or above.
- For VFD49AMS23ANSAA and VFD49AMS23ENSAA models: If you install at Ta 35°C above environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 90°C or above.
- For VFD32AMS43ANSAA, VFD32AMS43ENSAA, and VFD32AMS43AFSAA models: If you install at Ta 45°C above environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistance of 75°C, in accordance with UL requirements and recommendations.
 Do not reduce the wire gauge when using high-temperature resistant wires.
- **Wire these drives by ring lugs with specified dimensions.

Madala	R/L1, S/L2,	Circuit Term T/L3, U/T1, \ DC+/+1, +2/E	V/T2, W/T3,	Grounding Terminals		nals
Models	Max. Wire Gauge	Min. Wire Gauge	Screw Size & Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Size & Torque (±10%)
VFD33AMS23ANSAA	16 mm ²	16 mm ²		16 mm ²		
VFD33AMS23ENSAA	[6 AWG]	[6 AWG]		[6 AWG]		
VFD49AMS23ANSAA**	25 mm ²	25 mm ²		25 mm ²		
VFD49AMS23ENSAA**	[4 AWG]	[4 AWG]	M5	[4 AWG]		M5
VFD25AMS43ANSAA			25 kg-cm		16 mm ²	25 kg-cm
VFD25AMS43ENSAA			[21.7 lb-in.]	16 mm² [6 AWG]	[6 AWG]	[21.7 lb-in.] [2.45 Nm]
VFD25AMS43AFSAA	16 mm ²	16 mm ²	[2.45 Nm]			
VFD32AMS43ANSAA	[6 AWG]	[6 AWG]				
VFD32AMS43ENSAA						
VFD32AMS43AFSAA						

Table 5-7

Frame F




Figure 5-13

- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 90°C or above.
- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 75°C or 90°C.
- For VFD65AMS23ANSAA and VFD65AMS23ENSAA models: If you install at Ta 35°C above environment, use copper wires that have a voltage rating of 600 V and are temperature resistant to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistance of 75°C, in accordance with UL requirements and recommendations.
 Do not reduce the wire gauge when using high-temperature resistant wires.

Madala	R/L1, S/L2,	Circuit Term T/L3, U/T1, \ DC+/+1, +2/E	V/T2, W/T3,	Gro	unding Termi ⊕	nals
Models	Max. Wire Gauge	Min. Wire Gauge	Screw Size & Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Size & Torque (±10%)
VFD65AMS23ANSAA		35 mm ²		35 mm ²		
VFD65AMS23ENSAA		[2 AWG]		[2 AWG]		
VFD38AMS43ANSAA		25 2	M6	25 2		M6
VFD38AMS43ENSAA	35 mm ²	25 mm ² [4 AWG]	40 kg-cm	25 mm ² [4 AWG]	16 mm ²	40 kg-cm
VFD38AMS43AFSAA	[2 AWG]	[47,00]	[34.7 lb-in.]	[+7,00]	[6 AWG]	[34.7 lb-in.]
VFD45AMS43ANSAA		2- 2	[3.92 Nm]	2		[3.92 Nm]
VFD45AMS43ENSAA		35 mm ² [2 AWG]		35 mm ² [2 AWG]		
VFD45AMS43AFSAA		[27,000]		[27,000]		

Table 5-8

Chapter 6 Control Terminals

6-1 Control Terminal Specifications



Analog input terminals (AVI, ACI, ACM)

- Analog input signals are easily affected by external noise. Use shielded wiring and keep it as short as possible (less than 20 m) with proper grounding. If the noise is inductive, connecting the shield to the ACM terminal can reduce interference.
- ☑ Use twisted-pair wire for weak analog signals.
- ☑ If the analog input signals are affected by noise from the AC motor drive, connect a capacitor and a ferrite core as shown in Figure 6-1.





Figure 6-1

Contact input terminals (MI1-MI7, DCM, +24 VDC)





oxdots When the photo coupler uses the internal power supply, the switch connection for Sink and Source modes shows as Figure 6-2 and Figure 6-3: MI-DCM: Sink mode; MI-+24 V_{DC} : Source mode.

Transistor output terminals (MO1, MO2, MCM)

- ☑ Connect the digital outputs to the correct polarity.
- ☑ When connecting a relay to the digital outputs, connect a surge absorber across the coil and check the polarity.

6-1 Control Terminal Specifications





Control Terminal Distribution Diagram

Figure 6-6

Control Terminal Location Diagram
Figure 6-7

Wiring precautions:

- 1. The factory default is +24 V_{DC}/S1/S2 short-circuited by jumper, as shown in Area 1 in Figure 6-6. Refer to Figure 4-2 in Chapter 4 WIRING for details.
- 2. Use the +24 V_{DC} power supply of the safety function (as shown in Area 2 in Figure 6-7) for STO only. Do NOT use it for other purposes.
- 3. The RELAY terminal uses the PCB terminal block (as shown in Area 3 in Figure 6-6):
 - Tighten the wiring with a 3.5 mm width and 0.6 mm thickness slotted screwdriver.
 - The ideal length of stripped wire at the connection side is 6–7 mm.
 - When wiring bare wires, ensure that they are perfectly arranged to go through the wiring holes.
- 4. The Control terminal uses the push-in spring terminal block (as shown in Area 4 in Figure 6-6):
 - Tighten the wiring with a 2.5 mm width and 0.4 mm thickness slotted screwdriver.
 - The ideal length of stripped wire at the connection side is 9 mm.
 - When wiring bare wires, ensure that they are perfectly arranged to go through the wiring holes.

Wiring Specifications of Control Terminal

Terminal Name	Wiring Specifications of Control Terminals	Stripping Length (mm)	Maximum Wire Gauge	Minimum Wire Gauge	Tightening Torque (±10%)
RELAY	Solid	<u> </u>	1.5 mm ²	0.2 mm ²	5 Kg-cm
Terminals	Strand	6–7	[16 AWG]	[24 AWG]	[4.3 lb-in.] [0.49 Nm]
	Solid	9	0.75 mm ²		
Control	Strand	9	[18 AWG]	0.2 mm ²	
Terminals	Stranded with ferrules with plastic sleeve	9	0.5 mm ² [20 AWG]	[24 AWG]	

Table 6-1




Figure 6-8

Recommended models or dimensions for crimping terminals

Unit: mm

						•
Wire Gauge	Manufacturer	Model Name	A (MAX)	B (MAX)	D (MAX)	W (MAX)
0.2 mm ² [24 AWG]	PHOENIX CONTACT	AI 0,25- 8 YE	12.5	8	2.6	1.1
0.34 mm ² [22 AWG]	PHOENIX CONTACT	AI 0,34- 8 TQ	12.5	8	3.3	1.3
0.5 mm ² [20 AWG]	PHOENIX CONTACT	AI 0,5 - 8 WH	14	8	3.5	1.4

Recommended specifications and models for crimping tool:

CRIMPFOX 10S - 1212045, Manufacturer: PHOENIX CONTACT

DNT13-0101, Manufacturer: DINKLE

Table 6-2

Terminals	Terminal Function	Description
+24 V _{DC}	Digital control signal common (Source)	+24 V _{DC} ± 10 % 100 mA
MI1 - MI7	Multi-function input 1–7	Refer to Pr.02-01–02-07 to program the multi-function inputs MI1–MI7. Source Mode ON: activation current 3.3 mA ≥ 11 V _{DC} OFF: cut-off voltage ≤ 5 V _{DC} Sink Mode ON: activation current 3.3 mA ≤ 13 V _{DC} OFF: cut-off voltage ≥ 19 V _{DC} When Pr.02-00=0, MI1 and MI2 can be programmed. When Pr.02-00≠0, the functions of MI1 and MI2 act according to Pr.02-00 setting. When Pr.02-07=0, MI7 is pulse input terminal. MI7 uses pulse input, and the maximum input frequency=33 kHz. You can use it as frequency command source or connect it to the encoder for motor
		 closed-loop control. MI7 motor closed-loop control only supports VFPG control mode.

Chapter 6 Control Terminals | MS300

Terminals	Terminal Function	Description
DFM	Digital frequency signal output Max 30 Vpc 30 mA DFM R DCM Figure 6-9	DFM uses pulse voltage as an output monitoring signal; Duty-cycle: 50 % Min. load impedance R _L : $1 \text{ k}\Omega$ / 100 pF Max. current endurance: 30 mA Max. voltage: $30 \text{ V}_{DC} \pm 1 \text{ %}$ (when 30 V_{DC} / 30 mA / RL= 100 pF) Max. output frequency: 33 kHz
DCM	Digital control / Frequency signal common (Sink)	Current-limiting resistor R: \geq 1 K Ω Output load impedance R _L Capacitive load \leq 100 pF Resistive load \geq 1 k Ω , resistance determines the output voltage value. DFM-DCM voltage = external voltage * (R _L / (R _L +R))
MO1	Multi-function Output 1 (photo coupler)	The AC motor drive outputs various monitoring signals, such as drive in operation, frequency reached, and overload indication through a transistor (open collector).
MO2	Multi-function Output 2 (photo coupler)	Max 48 Vpc 50 mA
MCM	Multi-function Output Common (photo coupler)	Max. 48 V _{DC} 50 mA Figure 6-10
RA	Multi-function relay output 1 (N.O.) a	Resistive Load 3 A (N.O.) / 3 A (N.C.) 250 V _{AC} 5 A (N.O.) / 3 A (N.C.) 30 V _{DC}
RB	Multi-function relay output 1 (N.C.) b	Inductive Load (COS 0.4) 1.2 A (N.O.) / 1.2 A (N.C.) 250 V _{AC} 2.0 A (N.O.) / 1.2 A (N.C.) 30 V _{DC}
RC	Multi-function relay common	To output different kinds of monitoring signals such as motor drive in operation, frequency reached, and overload indication.
+10 V	Potentiometer power supply	Power supply for analog frequency setting: $\pm 10.5 \pm 0.5 V_{DC}$ / 20 mA
AVI	Analog voltage frequency command Figure 6-11 AVI (-10V~+10V) ACM AVI (-10V~+10V) ACM Internal circuit Figure 6-12	Impedance: 20 kΩ Range: 0–10 V / -10–10 V = 0–Maximum Operation Frequency (Pr.01-00) Mode switching by setting Pr.03-00, Pr.03-28 AVI resolution=10 bits

Terminals	Terminal Function	Description				
ACI	Analog current frequency command ACI ACI circuit ACM Internal circuit	Impedance: Current mode=250 Ω, Voltage mode=20 kΩ Range: 0–20 mA / 4–20 mA / 0–10 V = 0–Maximum Operation Frequency (Pr.01-00) Mode switching by setting Pr.03-01, Pr. 03-29 ACI resolution = 12 bits				
	Figure 6-13					
AFM	Multi-function analog voltage output AFM ACM B Figure 6-14	Switch: The AFM default is 0–10 V (voltage mode). To switch to the current mode, follow the instructions indicated on the inner side of the front cover or refer to page 6-2 in the user manual to switch AFM to the current mode position (0–20 mA / 4–20 mA) and set Pr.03.31. Voltage mode Range: 0–10 V (Pr.03-31=0) corresponds to the maximum operating range of the control target Max. output current: 2 mA Max. Load: 5 k Ω Current mode Range: 0–20 mA (Pr.03-31=1) / 4–20 mA (Pr.03-31=2) corresponds to the maximum operating range of the control target, maximum load 500 Ω AFM resolution=10 bits				
ACM	Analog Signal Common	Analog signal common terminal				
S1, S2	Rated current: 6.67 mA ± 10 % STO activation mode Input voltage level: 0 V _{DC} < S1-	maximum voltage: 30 V_{DC} ±10 % DCM or S2-DCM < 5 V_{DC}				
DCM	STO response time \leq 20 ms (S1 / S2 operates until the AC motor drive stops outputting current) STO cut-off mode Input voltage level: 11 V_{DC} < S1-DCM and S2-DCM < 30 V_{DC} Power removal safety function per EN 954-1 and IEC / EN 61508 Note: Refer to Chapter 17 SAFE TORQUE OFF FUNCTION for details.					
SG+	Modbus RS-485					
SG-		CRIPTIONS OF PARAMETER SETTINGS parameter group				
SGND	09 Communication Parameters	,				
RJ45	PIN 1, 2, 6: Reserved	PIN 3, 7: SGND PIN 4: SG-PIN 8: +10 VS (provides KPC-CC01(optional) power supply)				

^{*} Analog control signal wiring specification: 0.82 mm² [18 AWG] with shielded stranded wire.

Table 6-3

Chapter 6 Control Terminals | MS300

[This page intentionally left blank]

- 7-1 Brake Resistors and Brake Units Used in AC Motor Drives
- 7-2 Magnetic Contactor / Air Circuit Breaker and Non-fuse Circuit
 Breaker
- 7-3 Fuse Specification Chart
- 7-4 AC / DC Reactor
- 7-5 Zero Phase Reactors
- 7-6 EMC Filter
- 7-7 EMC Shield Plate
- 7-8 Capacitive Filter
- 7-9 NEMA Kit
- 7-10 Fan Kit
- 7-11 Keypad Panel Mounting
- 7-12 DIN-Rail Mounting
- 7-13 Mounting Adapter Plate
- 7-14 Digital Keypad KPC-CC01

The optional accessories listed in this chapter are available upon request. Installing additional accessories to your drive substantially improves the drive's performance. Select accessories according to your need or contact your local distributor for suggestions.

7-1 Brake Resistors and Brake Units Used in AC Motor Drives

115V one-phase

		cable otor	*1 125% Braking Torque / 10% ED						Max. Braking Torque			
Model	HP	KW	*2 Braking Torque	Resistor Value Spec. for Each		esistor for rake Unit		Braking Current	Min. Resistor	Max. Total Braking	Peak Power	
			(kg-m)	AC Motor Drive	* ³ Part No.	Q'ty	Usage		Value (Ω)	Current (A)	(kW)	
VFD1A6MS11XNSAA	0.25	0.2	0.1	80W 750 Ω	BR080W750	1	-	0.5	190.0	2	0.8	
VFD2A5MS11XNSAA	0.5	0.4	0.3	80W 200 Ω	BR080W200	1	-	1.9	95.0	4	1.5	
VFD4A8MS11XNSAA	1	0.75	0.5	80W 200 Ω	BR080W200	1	-	1.9	63.3	6	2.3	

Table 7-1-1

230V one-phase

		cable otor		*1 125% Braking Torque / 10% ED					Max. Braking Torque			
Model	HP	KW	*2 Braking Torque	Resistor Value Spec. for Each	Brake Resistor for each Brake Unit			Braking Current	Min. Resistor	Max. Total Braking	Peak Power	
			(kg-m)	AC Motor Drive	* ³ Part No.	Q'ty	Usage		Value (Ω)	Current (A)	(kW)	
VFD1A6MS21XNSAA VFD1A6MS21AFSAA	0.25	0.2	0.1	80 W 750 Ω	BR080W750	1	-	0.5	190.0	2	0.8	
VFD2A8MS21XNSAA VFD2A8MS21AFSAA	0.5	0.4	0.3	80 W 200 Ω	BR080W200	1	-	1.9	95.0	4	1.5	
VFD4A8MS21XNSAA VFD4A8MS21AFSAA	1	0.75	0.5	80 W 200 Ω	BR080W200	1	-	1.9	63.3	6	2.3	
VFD7A5MS21XNSAA VFD7A5MS21AFSAA	2	1.5	1	200 W 91 Ω	BR200W091	1	-	4.2	47.5	8	3.0	
VFD11AMS21XNSAA VFD11AMS21AFSAA	3	2.2	1.5	300 W 70 Ω	BR300W070	1	-	5.4	38.0	10	3.8	

Table 7-1-2

230V three-phase

		cable otor		* ¹ 125% Braking Torque / 10% ED						Max. Braking Torque		
Model		1014	*2 Braking	Resistor Value		esistor for rake Unit	r	Braking Current (A)	Min.	Max. Total	Peak	
	HP	HP KW	Torque (kg-m)	Spec. for Each AC Motor Drive	* ³ Part No.	Q'ty	Usage		Resistor Value (Ω)	Braking Current (A)	Power (kW)	
VFD1A6MS23XNSAA	0.25	0.2	0.1	80 W 750 Ω	BR080W750	1	-	0.5	190.0	2	0.8	
VFD2A8MS23XNSAA	0.5	0.4	0.3	80 W 200 Ω	BR080W200	1	-	1.9	95.0	4	1.5	
VFD4A8MS23XNSAA	1	0.75	0.5	80 W 200 Ω	BR080W200	1	-	1.9	63.3	6	2.3	
VFD7A5MS23XNSAA	2	1.5	1	200 W 91 Ω	BR200W091	1	-	4.2	47.5	8	3.0	
VFD11AMS23XNSAA	3	2.2	1.5	300 W 70 Ω	BR300W070	1	-	5.4	38.0	10	3.8	
VFD17AMS23XNSAA	5	3.7/4	2.5	400 W 40 Ω	BR400W040	1	-	9.5	19.0	20	7.6	
VFD25AMS23XNSAA	7.5	5.5	3.7	1000 W 20 Ω	BR1K0W020	1	-	19	16.5	23	8.7	
VFD33AMS23XNSAA	10	7.5	5.1	1000 W 20 Ω	BR1K0W020	1	-	19	14.6	26	9.9	
VFD49AMS23XNSAA	15	11	7.4	1500 W 13 Ω	BR1K5W013	1	-	29	12.6	29	11.0	
VFD65AMS23XNSAA	20	15	10.2	2000 W 8.6 Ω	BR1K0W4P3	2	2 in series	44	8.3	46	17.5	

Table 7-1-3

460V three-phase

		icable otor		* ¹ 125% E	Braking Torque / 10% ED				Max. Braking Torque		
Model	HP	KW	*2 Braking Torque	Resistor Value Spec. for Each	each B	esistor fo rake Unit		Braking Current	Min. Resistor	Max. Total Braking	Peak Power
			(kg-m)	AC Motor Drive	* ³ Part No.	Q'ty	Usage	(A)	Value (Ω)	Current (A)	(kW)
VFD1A5MS43XNSAA VFD1A5MS43AFSAA	0.5	0.4	0.3	80 W 750 Ω	BR080W750	1		1	380.0	2	1.5
VFD2A7MS43XNSAA VFD2A7MS43AFSAA	1	0.75	0.5	80 W 750 Ω	BR080W750	1		1	190.0	4	3.0
VFD4A2MS43XNSAA VFD4A2MS43AFSAA	2	1.5	1	200 W 360 Ω	BR200W360	1		2.1	126.7	6	4.6
VFD5A5MS43XNSAA VFD5A5MS43AFSAA	3	2.2	1.5	300 W 250 Ω	BR300W250	1		3	108.6	7	5.3
VFD7A3MS43ANSAA VFD7A3MS43ENSAA VFD7A3MS43AFSAA	4	3	2	400W 150Ω	BR400W150	1	2 in series	5.1	95.0	8	6.1
VFD9A0MS43XNSAA VFD9A0MS43AFSAA	5	3.7/4	2.5	400 W 150 Ω	BR400W150	1		5.1	84.4	9	6.8
VFD13AMS43XNSAA VFD13AMS43AFSAA	7.5	5.5	3.7	1000 W 75 Ω	BR1K0W075	1		10.2	50.7	15	11.4
VFD17AMS43XNSAA VFD17AMS43AFSAA	10	7.5	5.1	1000 W 75 Ω	BR1K0W075	1		10.2	40.0	19	14.4
VFD25AMS43XNSAA VFD25AMS43AFSAA	15	11	7.4	1500 W 43 Ω	BR1K5W043	1		17.6	33.0	23	17.5
VFD32AMS43XNSAA VFD32AMS43AFSAA	20	15	10.2	2000 W 32 Ω	BR1K0W016	2	2 in series	24	26.2	29	22.0
VFD38AMS43XNSAA VFD38AMS43AFSAA	25	18	12.2	2000 W 32 Ω	BR1K0W016	2	2 in series	24	26.2	29	22.0
VFD45AMS43XNSAA VFD45AMS43AFSAA	30	22	14.9	3000 W 26 Ω	BR1K5W013	2	2 in series	29	23.0	33	25.1

Table 7-1-4

575V three-phase

Applicab Motor				*1 125% Braking Torque / 10% ED						Max. Braking Torque		
Model	- 15	*2 E	*2 Braking	Resistor Value	Brake Resistor for each Brake Unit			Braking	Min.	Max. Total	Peak	
	HP KW		Torque (kg-m)	Spec. for Each AC Motor Drive	* ³ Part No.	Q'ty	Usage	Current (A)	Resistor Value (Ω)	Braking Current (A)	Power (kW)	
VFD1A7MS53ANSAA	1	0.75	0.5	80W 750Ω	BR080W750	1	-	1.2	280.0	4	4.5	
VFD3A0MS53ANSAA	2	1.5	1	200W 360Ω	BR200W360	1	-	2.6	186.7	6	6.7	
VFD4A2MS53ANSAA	3	2.2	1.5	300W 400Ω	BR300W400	1	-	2.3	160.0	7	7.8	
VFD6A6MS53ANSAA	5	3.7	2.5	500W 100Ω	BR500W100	1	-	9.2	93.3	12	13.4	
VFD9A9MS53ANSAA	7.5	5.5	3.7	750W 140Ω	BR750W140	1	-	6.6	80.0	14	15.7	
VFD12AMS53ANSAA	10	7.5	5.1	1000W 75Ω	BR1K0W075	1	-	12.3	70.0	16	17.9	

Table 7-1-5


- Calculation for 125% brake torque: (kW)*125%*0.8; where 0.8 is motor efficiency.

 Because of the limited resistor power, the longest operation time for 10% ED is 10 seconds (ON: 10 sec. / OFF: 90 sec.).
- ^{*2} The calculation of the brake resistor is based on a four-pole motor (1800 rpm).
- For heat dissipation, a resistors of 400 W or lower should be fixed to the frame and maintain the surface temperature below 250°C; a resistor of 1000 W and above should maintain the surface temperature below 350°C.
 - (If the surface temperature is higher than the temperature limit, install extra cooling or increase the size of the resistor.)



1. Select the resistance value, power and brake usage (ED %) according to Delta rules.

Definition for Brake Usage ED%



 $ED\% = T1 / T0 \times 100(\%)$


Explanation:

Brake usage ED (%) is the amount of time needed for the brake unit and brake resistor to dissipate heat generated by braking. When the brake resistor heats up, the resistance increases with temperature, and braking torque decreases accordingly.

Figure 7-1-1

For safety, install a thermal overload relay (O.L) between the brake unit and the brake resistor in conjunction with the magnetic contactor (MC) before the drive for additional protection. The thermal overload relay protects the brake resistor from damage due to frequent or continuous braking. Under such circumstances, turn off the power to prevent damage to the brake resistor, brake unit and drive.

NOTE: Never use it to disconnect the brake resistor.



- When AC Drive is equipped with a DC reactor, please read user manual for the correct wiring for the brake unit input circuit +(P).
- DO NOT connect input circuit -(N) to the neutral point of the power system.

Figure 7-1-2

- 2. Any damage to the drive or other equipment caused by using brake resistors and brake modules that are not provided by Delta voids the warranty.
- 3. Consider environmental safety factors when installing the brake resistors. If you use the minimum resistance value, consult local dealers for the power calculation.
- 4. When using more than two brake units, the equivalent resistor value of the parallel brake unit cannot be less than the value in the column "Min. Resistor Value (Ω)". Read the wiring information in the brake unit instruction sheet thoroughly prior to operation. Visit the following links to get the instruction sheets for the wiring in the brake unit:
 - VFDB2015 / 2022 / 4030 / 4045 / 5055 Braking Modules Instruction Sheet
 http://www.deltaww.com/filecenter/Products/download/06/060101/Option/DELTA_IA-MDS_VFDB_IEN_20070719.pdf

- VFDB4110 / 4160 / 4185 Braking Modules Instruction Sheet
 http://www.deltaww.com/filecenter/Products/download/06/060101/Option/DELTA_IA-MDS_VFDB41
 10-4160-4185 I EN 20101011.pdf
- VFDB6055 / 6110 / 6160 / 6200 Braking Modules Instruction Sheet
 http://www.deltaww.com/filecenter/Products/download/06/060101/Option/DELTA_IA-MDS_VFDB60
 55-6110-6160-6200 I TSE 20121030.pdf
- 5. The selection tables are for normal usage. If the AC motor drive requires frequent braking, increase the Watts by two to three times.
- 6. Thermal Overload Relay (TOR):

Thermal overload relay selection is based on its overload capacity. A standard braking capacity of the MS300 is 10% ED (Tripping time=10 s). As shown in the figure below, a 460V, 1kw MS300 required the thermal relay to take 260% overload capacity for 10 seconds (hot starting) and the braking current is 24A. In this case, select a thermal overload relay rated at 10 A (10 * 260% = 26 A > 24 A). The property of each thermal relay may vary among different manufacturers. Carefully read the specification before using it.




Figure 7-1-3

7-2 Magnetic Contactor / Air Circuit Breaker and Non-fuse Circuit Breaker

Magnetic Contactor (MC) and Air Circuit Breaker (ACB)

It is recommended the surrounding temperature for MC should be \geq 60°C and that for ACB should be \geq 50°C. In the meanwhile, consider temperature derating for components with ON / OFF switch in accordance with the ambient temperature of the on-site distribution panel.

115V Models

Frame	Model	Model Heavy Duty Heavy Duty Output Current [A] Input Current [A]		MC/ACB Selection
^	VFD1A6MS11ANSAA	6	1.6	11
A -	VFD2A5MS11ANSAA	9.4	2.5	18
С	VFD4A8MS11ANSAA	18	4.8	32

Table 7-2-1

230V Models

Frame	Model	Heavy Duty	Heavy Duty	MC/ACB Selection
Traine		Output Current [A]	Input Current [A]	[A]
	VFD1A6MS21ANSAA	5.1	1.6	9
	VFD2A8MS21ANSAA	7.3	2.8	13
Α	VFD1A6MS23ANSAA	1.9	1.6	9
	VFD2A8MS23ANSAA	3.4	2.8	9
	VFD4A8MS23ANSAA	5.8	4.8	11
	VFD1A6MS21AFSAA	5.1	1.6	9
	VFD2A8MS21AFSAA	7.3	2.8	13
В	VFD4A8MS21AFSAA	10.8	4.8	18
	VFD4A8MS21ANSAA	10.8	4.8	18
	VFD7A5MS23ANSAA	9	7.5	18
	VFD7A5MS21ANSAA	16.5	7.5	32
	VFD11AMS21ANSAA	24.2	11	40
С	VFD7A5MS21AFSAA	16.5	7.5	32
C	VFD11AMS21AFSAA	24.2	11	40
	VFD11AMS23ANSAA	13.2	11	22
	VFD17AMS23ANSAA	20.4	17	32
D	VFD25AMS23ANSAA	30	25	55
_	VFD33AMS23ANSAA	39.6	33	65
E	VFD49AMS23ANSAA	58.8	49	105
F	VFD65AMS23ANSAA	78	65	130

Table 7-2-2

460V Models

Frame	Model	Heavy Duty Output Current [A]	Heavy Duty Input Current [A]	MC/ACB Selection [A]
Δ.	VFD1A5MS43ANSAA	2.1	1.5	7
A	VFD2A7MS43ANSAA	3.7	2.7	7
	VFD4A2MS43ANSAA	5.8	4.2	9
В	VFD1A5MS43AFSAA	2.1	1.5	7
Б	VFD2A7MS43AFSAA	3.7	2.7	7
	VFD4A2MS43AFSAA	5.8	4.2	9
	VFD5A5MS43ANSAA	6.1	5.5	12
	VFD7A3MS43ANSAA	8.1	7.3	18
С	VFD9A0MS43ANSAA	9.9	9	18
	VFD5A5MS43AFSAA	6.1	5.5	12
	VFD7A3MS43AFSAA	8.1	7.3	18
	VFD9A0MS43AFSAA	9.9	9	18
	VFD13AMS43ANSAA	14.3	13	22
	VFD13AMS43AFSAA	14.3	13	22
D	VFD17AMS43ANSAA	18.7	17	32
	VFD17AMS43AFSAA	18.7	17	32
	VFD25AMS43ANSAA	27.5	25	65
E	VFD32AMS43ANSAA	35.2	32	65
_	VFD25AMS43AFSAA	27.5	25	65
	VFD32AMS43AFSAA	35.2	32	65
	VFD38AMS43ANSAA	41.8	38	65
F	VFD45AMS43ANSAA	49.5	45	75
	VFD38AMS43AFSAA	41.8	38	65
	VFD45AMS43AFSAA	49.5	45	75

Table 7-2-3

575V Models

37 3 V 1VIOC	ov Models								
Frame	Model	Heavy Duty	Heavy Duty	MC/ACB Selection					
Tame	Wodel	Output Current [A]	Input Current [A]	[A]					
Α	VFD1A7MS53ANSAA	2	1.7	6					
В	VFD3A0MS53ANSAA	3.5	3	6					
С	VFD4A2MS53ANSAA	4.9	4.2	12					
	VFD6A6MS53ANSAA	7.7	6.6	12					
D	VFD9A9MS53ANSAA	11.5	9.9	20					
	VFD12AMS53ANSAA	14.2	12.2	28					

Table 7-2-4

Non-fuse Circuit Breaker

Comply with the UL standard: Per UL 508, paragraph 45.8.4, part a.

The rated current of the non-fuse circuit breaker should be 1.6–2.6 times the drive's rated input current. The recommended current values are shown in the table below. Compare the time characteristics of the non-fuse circuit breaker with those of the drive's overheated protection to ensure that there is no tripping.

Model	Voltage / One-phase (Three-phase)	Breaker Rated Input Recommended Current [A]
VFD1A6MS11ANSAA VFD1A6MS11ENSAA		20
VFD2A5MS11ANSAA VFD2A5MS11ENSAA	115V / One-phase	25
VFD4A8MS11ANSAA VFD4A8MS11ENSAA		50
VFD1A6MS21ANSAA VFD1A6MS21ENSAA VFD1A6MS21AFSAA		15
VFD2A8MS21ANSAA VFD2A8MS21ENSAA VFD2A8MS21AFSAA		20
VFD4A8MS21ANSAA VFD4A8MS21ENSAA VFD4A8MS21AFSAA	230V / One-phase	30
VFD7A5MS21ANSAA VFD7A5MS21ENSAA VFD7A5MS21AFSAA		45
VFD11AMS21ANSAA VFD11AMS21ENSAA VFD11AMS21AFSAA		70
VFD1A6MS23ANSAA VFD1A6MS23ENSAA		15
VFD2A8MS23ANSAA VFD2A8MS23ENSAA		15
VFD4A8MS23ANSAA VFD4A8MS23ENSAA		15
VFD7A5MS23ANSAA VFD7A5MS23ENSAA		25
VFD11AMS23ANSAA VFD11AMS23ENSAA	230\/ / Thron phage	40
VFD17AMS23ANSAA VFD17AMS23ENSAA	230V / Three-phase	60
VFD25AMS23ANSAA VFD25AMS23ENSAA		63
VFD33AMS23ANSAA VFD33AMS23ENSAA		90
VFD49AMS23ANSAA VFD49AMS23ENSAA		125
VFD65AMS23ANSAA VFD65AMS23ENSAA		160

Model	Voltage / One-phase (Three-phase)	Breaker Rated Input Recommended Current [A]
VFD1A5MS43ANSAA		
VFD1A5MS43ENSAA		15
VFD1A5MS43AFSAA		
VFD2A7MS43ANSAA		
VFD2A7MS43ENSAA		15
VFD2A7MS43AFSAA		
VFD4A2MS43ANSAA		
VFD4A2MS43ENSAA		15
VFD4A2MS43AFSAA		
VFD5A5MS43ANSAA		
VFD5A5MS43ENSAA		20
VFD5A5MS43AFSAA		
VFD7A3MS43ANSAA		05
VFD7A3MS43ENSAA		25
VFD7A3MS43AFSAA VFD9A0MS43ANSAA		
VFD9A0MS43ANSAA VFD9A0MS43ENSAA		30
VFD9A0MS43AFSAA		30
VFD13AMS43ANSAA	460V / Three-phase	
VFD13AMS43ENSAA		32
VFD13AMS43AFSAA		92
VFD17AMS43ANSAA		
VFD17AMS43ENSAA		45
VFD17AMS43AFSAA		
VFD25AMS43ANSAA		
VFD25AMS43ENSAA		60
VFD25AMS43AFSAA		
VFD32AMS43ANSAA		
VFD32AMS43ENSAA		80
VFD32AMS43AFSAA		
VFD38AMS43ANSAA		00
VFD38AMS43AFSAA		90
VFD38AMS43AFSAA		
VFD45AMS43ANSAA VFD45AMS43ENSAA		100
VFD45AMS43AFSAA VFD45AMS43AFSAA		100
VFD1A7MS53ANSAA		6
VFD3A0MS53ANSAA		10
VFD4A2MS53ANSAA		16
VFD4A2MS33ANSAA VFD6A6MS53ANSAA	575V / Three-phase	25
VFD9A9MS53ANSAA		25
VFD12AMS53ANSAA		32

Table 7-2-5

7-3 Fuse Specification Chart

- ☑ Fuse specifications lower than the table below are allowed.
- ☑ For installation in the United States, branch circuit protection must be provided in accordance with the National Electrical Code (NEC) and any applicable local codes. Use UL classified fuses to fulfill this requirement.
- ☑ For installation in Canada, branch circuit protection must be provided in accordance with Canadian Electrical Code and any applicable provincial codes. Use UL classified fuses to fulfill this requirement.

Model	Voltage / One-phase (Three-phase)	Branch Circuit Fuses Output [A]		
VFD1A6MS11ANSAA		7.2		
VFD1A6MS11ENSAA		Class T JJS-10 600 V _{AC}		
VFD2A5MS11ANSAA	115V / One-phase	10.8		
VFD2A5MS11ENSAA		Class T JJS-10 600 V _{AC}		
VFD4A8MS11ANSAA		22		
VFD4A8MS11ENSAA		Class T JJS-25 600 V _{AC}		
VFD1A6MS21ANSAA		7.2		
VFD1A6MS21ENSAA		Class T JJS-10 600 V _{AC}		
VFD1A6MS21AFSAA		Class 1 JJS-10 600 VAC		
VFD2A8MS21ANSAA		12.8		
VFD2A8MS21ENSAA		Class T JJS-15 600 V _{AC}		
VFD2A8MS21AFSAA	-			
VFD4A8MS21ANSAA VFD4A8MS21ENSAA	230V / One-phase	20		
VFD4A8MS21AFSAA	250V / Offe-priase	Class T JJS-20 600 V _{AC}		
VFD7A5MS21ANSAA	-	24		
VFD7A5MS21ENSAA		34		
VFD7A5MS21AFSAA		Class T JJS-35 600 V _{AC}		
VFD11AMS21ANSAA		50		
VFD11AMS21ENSAA				
VFD11AMS21AFSAA		Class T JJS-50 600 V _{AC}		
VFD1A6MS23ANSAA		7.2		
VFD1A6MS23ENSAA		Class T JJS-10 600 V _{AC}		
VFD2A8MS23ANSAA		12.8		
VFD2A8MS23ENSAA		Class T JJS-15 600 V _{AC}		
VFD4A8MS23ANSAA		20		
VFD4A8MS23ENSAA	_	Class T JJS-20 600 V _{AC}		
VFD7A5MS23ANSAA		32		
VFD7A5MS23ENSAA	-	Class T JJS-35 600 V _{AC}		
VFD11AMS23ANSAA		50		
VFD11AMS23ENSAA	230V / Three-phase	Class T JJS-50 600 V _{AC}		
VFD17AMS23ANSAA	· .	78		
VFD17AMS23ENSAA	-	Class T JJS-80 600 V _{AC}		
VFD25AMS23ANSAA	-	59.4		
VFD25AMS23ANSAA	-	Class T JJS-60 600 V _{AC} 79.2		
VFD33AMS23ANSAA VFD33AMS23ENSAA		79.2 Class T JJS-80 600 V _{AC}		
VFD49AMS23ANSAA	-	112.2		
VFD49AMS23ANSAA VFD49AMS23ENSAA		Class T JJS-110 600 V _{AC}		
VFD65AMS23ANSAA	-	151.8		
VFD65AMS23ENSAA		Class T JJS-150 600 V _{AC}		

Model	Voltage / One-phase (Three-phase)	Branch Circuit Fuses Output [A]		
VFD1A5MS43ANSAA		7.2		
VFD1A5MS43ENSAA		Class T JJS-10 600 V _{AC}		
VFD1A5MS43AFSAA	-			
VFD2A7MS43ANSAA VFD2A7MS43ENSAA		12		
VFD2A7MS43AFSAA		Class T JJS-15 600 V _{AC}		
VFD4A2MS43ANSAA	1	18.4		
VFD4A2MS43ENSAA				
VFD4A2MS43AFSAA		Class T JJS-20 600 V _{AC}		
VFD5A5MS43ANSAA		26		
VFD5A5MS43ENSAA VFD5A5MS43AFSAA		Class T JJS-25 600 V _{AC}		
VFD7A3MS43ANSAA	1	35		
VFD7A3MS43ENSAA				
VFD7A3MS43AFSAA		Class T JJS-35 600 V _{AC}		
VFD9A0MS43ANSAA		42		
VFD9A0MS43AFSAA		Class T JJS-45 600 V _{AC}		
VFD9A0MS43AFSAA VFD13AMS43ANSAA	460V / Three-phase	-		
VFD13AMS43ENSAA		34.54		
VFD13AMS43AFSAA		Class T JJS-35 600 V _{AC}		
VFD17AMS43ANSAA]	45.1		
VFD17AMS43ENSAA				
VFD17AMS43AFSAA		Class T JJS-45 600 V _{AC}		
VFD25AMS43ANSAA VFD25AMS43ENSAA		61.6		
VFD25AMS43AFSAA		Class T JJS-60 600 V _{AC}		
VFD32AMS43ANSAA		79.2		
VFD32AMS43ENSAA				
VFD32AMS43AFSAA		Class T JJS-80 600 V _{AC}		
VFD38AMS43ANSAA		91.3		
VFD38AMS43AFSAA		Class T JJS-90 600 V _{AC}		
VFD38AMS43AFSAA VFD45AMS43ANSAA	1			
VFD45AMS43ANSAA VFD45AMS43ENSAA		107.8		
VFD45AMS43AFSAA		Class T JJS-110 600 V _{AC}		
VFD1A7MS53ANSAA		4.62		
VFDTA/WS33ANSAA		Class T JJS-6 600 V _{AC}		
VFD3A0MS53ANSAA		7.92		
VEDSAUNISSSANSAA		Class T JJS-10 600 V _{AC}		
VFD4A2MS53ANSAA		11		
VI DAZIVIOSSANOAA	575V / Three-phase	Class T JJS-10 600 V _{AC}		
VFD6A6MS53ANSAA	3737 7 Three-phase	17.6		
VI DOMONICO MACA		Class T JJS-20 600 V _{AC}		
VFD9A9MS53ANSAA		25.3		
		Class T JJS-25 600 V _{AC}		
VFD12AMS53ANSAA		33		
		Class T JJS-30 600 V _{AC}		

Table 7-3-1

7-4 AC / DC Reactor

AC Input Reactor

Installing an AC reactor on the input side of an AC motor drive can increase line impedance, improve the power factor, reduce input current, increase system capacity, and reduce interference generated from the motor drive. It also reduces momentary voltage surges or abnormal current spikes from the mains power, further protecting the drive. For example, when the main power capacity is higher than 500 kVA, or when using a phase-compensation capacitor, momentary voltage and current spikes may damage the AC motor drive's internal circuit. An AC reactor on the input side of the AC motor drive protects it by suppressing surges.

Install an AC input reactor in series between the main power and the three input phases R S T, as shown in the figure below:




Figure 7-4-1

AC Output Reactor

When using drives in long wiring output application, ground fault (GFF), over-current (OC) and motor over-voltage (OV) often occur. GFF and OC cause errors due to the drive's self-protective mechanism; over-voltage damages motor insulation.

The excessive length of the output wires makes the grounded stray capacitance too large, increase the three-phase output common mode current, and the reflected wave of the long wires makes the motor dv / dt and the motor terminal voltage too high. Thus, installing a reactor on the drive's output side can increases the high-frequency impedance to reduce the dv / dt and terminal voltage to protect the motor.

Install an AC output reactor in series between the three output phases U V W and the motor, as shown in the figure below:




Figure 7-4-2

DC Reactor

A DC reactor can also increase line impedance, improve the power factor, reduce input current, increase system power, and reduce interference generated from the motor drive. A DC reactor stabilizes the DC bus voltage. Compared with an AC input reactor, a DC reactor is in smaller size, lower price, and lower voltage drop (lower power dissipation).

Install a DC reactor between terminals +1 and +2. Remove the jumper, as shown in the figure below, before installing a DC reactor.

Note: 115V models have no DC choke.




Figure 7-4-3

Applicable Reactors

115V, 50-60 Hz / One-phase - Normal Duty

Model	Rated Current [Arms]	Saturation Current [Arms]	Input / DC Reactor [mH]	Input / DC Reactor Delta Part #	Output Reactor [mH]	Output Reactor Delta Part #
VFD1A6MS11ANSAA VFD1A6MS11ENSAA	1.8	2.7	3.66	DR008D0366	2.54	DR005L0254
VFD2A5MS11ANSAA VFD2A5MS11ENSAA	2.7	4.05	2.66	DR011D0266	2.54	DR005L0254
VFD4A8MS11ANSAA VFD4A8MS11ENSAA	5.5	8.25	1.17	DR025D0117	1.59	DR008L0159

Table 7-4-1

115V, 50-60 Hz / One-phase - Heavy Duty

Model	Rated Current [Arms]	Saturation Current [Arms]	Input / DC Reactor [mH]	Input / DC Reactor Delta Part #	Output Reactor [mH]	Output Reactor Delta Part #
VFD1A6MS11ANSAA VFD1A6MS11ENSAA	1.6	3.2	3.66	DR008D0366	2.54	DR005L0254
VFD2A5MS11ANSAA VFD2A5MS11ENSAA	2.5	5	2.66	DR011D0266	2.54	DR005L0254
VFD4A8MS11ANSAA VFD4A8MS11ENSAA	5	9.6	1.17	DR025D0117	2.54	DR005L0254

Table 7-4-2

230V, 50-60 Hz / One-phase - Normal Duty

2001, 00 0011270	Rated					
Model	Current [Arms]	Saturation Current [Arms]	Input / DC Reactor [mH]	Input / DC Reactor Delta Part #	Output Reactor [mH]	Output Reactor Delta Part #
VFD1A6MS21ANSAA						
VFD1A6MS21ENSAA	1.8	2.7	5.857	DR005D0585	2.54	DR005L0254
VFD1A6MS21AFSAA						
VFD2A8MS21ANSAA						
VFD2A8MS21ENSAA	3.2	4.8	3.66	DR008D0366	2.54	DR005L0254
VFD2A8MS21AFSAA						
VFD4A8MS21ANSAA						
VFD4A8MS21ENSAA	5	7.5	2.66	DR011D0266	2.54	DR005L0254
VFD4A8MS21AFSAA						
VFD7A5MS21ANSAA						
VFD7A5MS21ENSAA	8.5	12.75	1.72	DR017D0172	1.15	DR011L0115
VFD7A5MS21AFSAA						
VFD11AMS21ANSAA						
VFD11AMS21ENSAA	12.5	18.75	1.17	DR025D0117	0.746	DR017LP746
VFD11AMS21AFSAA						

Table 7-4-3

230V, 50-60 Hz / One-phase - Heavy Duty

Model	Rated Current [Arms]	Saturation Current [Arms]	Input / DC Reactor [mH]	Input / DC Reactor Delta Part #	Output Reactor [mH]	Output Reactor Delta Part #
VFD1A6MS21ANSAA VFD1A6MS21ENSAA VFD1A6MS21AFSAA	1.6	3.2	5.857	DR005D0585	2.54	DR005L0254
VFD2A8MS21ANSAA VFD2A8MS21ENSAA VFD2A8MS21AFSAA	2.8	5.6	3.66	DR008D0366	2.54	DR005L0254
VFD4A8MS21ANSAA VFD4A8MS21ENSAA VFD4A8MS21AFSAA	4.8	9.6	2.66	DR011D0266	2.54	DR005L0254
VFD7A5MS21ANSAA VFD7A5MS21ENSAA VFD7A5MS21AFSAA	7.5	15	1.72	DR017D0172	1.59	DR008L0159
VFD11AMS21ANSAA VFD11AMS21ENSAA VFD11AMS21AFSAA	11	22	1.17	DR025D0117	1.15	DR011L0115

Table 7-4-4

230V, 50-60 Hz / Three-phase - Normal Duty

Model	Rated Current [Arms]	Saturation Current [Arms]	Input / Output Reactor [mH]		Output Reactor Delta Part #	DC Reactor [mH]	DC Reactor Delta Part #
VFD1A6MS23ANSAA VFD1A6MS23ENSAA	1.8	2.7	2.536	DR005A0254	DR005L0254	5.857	DR005D0585
VFD2A8MS23ANSAA VFD2A8MS23ENSAA	3.2	4.8	2.536	DR005A0254	DR005L0254	5.857	DR005D0585
VFD4A8MS23ANSAA VFD4A8MS23ENSAA	5	7.5	2.536	DR005A0254	DR005L0254	5.857	DR005D0585
VFD7A5MS23ANSAA VFD7A5MS23ENSAA	8	12	1.585	DR008A0159	DR008L0159	3.66	DR008D0366
VFD11AMS23ANSAA VFD11AMS23ENSAA	12.5	18.75	0.746	DR017AP746	DR017LP746	2.662	DR011D0266
VFD17AMS23ANSAA VFD17AMS23ENSAA	19.5	29.25	0.507	DR025AP507	DR025LP507	1.722	DR017D0172
VFD25AMS23ANSAA VFD25AMS23ENSAA	27	40.5	0.32	DR033AP320	DR033LP320	1.172	DR025D0117

Model	Rated Current [Arms]	Saturation Current [Arms]	Input / Output Reactor [mH]	Input Reactor Delta Part #	Output Reactor Delta Part #	DC Reactor [mH]	DC Reactor Delta Part #
VFD33AMS23ANSAA VFD33AMS23ENSAA	36	54	0.216	DR049AP215	DR049LP215	0.851	DR033DP851
VFD49AMS23ANSAA VFD49AMS23ENSAA	51	76.5	0.216	DR049AP215	DR049LP215	0.574	DR049DP574
VFD65AMS23ANSAA VFD65AMS23ENSAA	69	103.5	0.169	DR075AP170	DR075LP170	0.432	DR065DP432

Table 7-4-5

230V, 50-60 Hz / Three-phase - Heavy Duty

Model	Rated Current [Arms]	Saturation Current [Arms]	Input / Output Reactor [mH]	Input Reactor Delta Part #	Output Reactor Delta Part #	DC Reactor [mH]	DC Reactor Delta Part #
VFD1A6MS23ANSAA VFD1A6MS23ENSAA	1.6	3.2	2.536	DR005A0254	DR005L0254	5.857	DR005D0585
VFD2A8MS23ANSAA VFD2A8MS23ENSAA	2.8	5.6	2.536	DR005A0254	DR005L0254	5.857	DR005D0585
VFD4A8MS23ANSAA VFD4A8MS23ENSAA	4.8	9.6	2.536	DR005A0254	DR005L0254	5.857	DR005D0585
VFD7A5MS23ANSAA VFD7A5MS23ENSAA	7.5	15	1.585	DR008A0159	DR008L0159	3.66	DR008D0366
VFD11AMS23ANSAA VFD11AMS23ENSAA	11	22	1.152	DR011A0115	DR011L0115	2.662	DR011D0266
VFD17AMS23ANSAA VFD17AMS23ENSAA	17	34	0.746	DR017AP746	DR017LP746	1.722	DR017D0172
VFD25AMS23ANSAA VFD25AMS23ENSAA	25	50	0.507	DR025AP507	DR025LP507	1.172	DR025D0117
VFD33AMS23ANSAA VFD33AMS23ENSAA	33	66	0.32	DR033AP320	DR033LP320	0.851	DR033DP851
VFD49AMS23ANSAA VFD49AMS23ENSAA	46	92	0.216	DR049AP215	DR049LP215	0.574	DR049DP574
VFD65AMS23ANSAA VFD65AMS23ENSAA	65	130	0.163	DR065AP162	DR065LP162	0.432	DR065DP432

Table 7-4-6

460V, 50-60 Hz / Three-phase - Normal Duty

460V, 50–60 Hz / Three-phase - Normai Duty								
Model	Rated Current [Arms]	Saturation Current [Arms]	Input / Output Reactor [mH]	Input Reactor Delta Part #	Output Reactor Delta Part #	DC Reactor [mH]	DC Reactor Delta Part #	
VFD1A5MS43ANSAA VFD1A5MS43ENSAA VFD1A5MS43AFSAA	1.8	2.7	8.102	DR003A0810	DR003L0810	18.709	DR003D1870	
VFD2A7MS43ANSAA VFD2A7MS43ENSAA VFD2A7MS43AFSAA	3	4.5	6.077	DR004A0607	DR004L0607	18.709	DR003D1870	
VFD4A2MS43AFSAA VFD4A2MS43ANSAA VFD4A2MS43ENSAA	4.6	6.9	4.05	DR006A0405	DR006L0405	14.031	DR004D1403	
VFD5A5MS43AFSAA VFD5A5MS43ANSAA VFD5A5MS43ENSAA	6.5	9.75	2.7	DR009A0270	DR009L0270	9.355	DR006D0935	
VFD7A3MS43ANSAA VFD7A3MS43ENSAA VFD7A3MS43AFSAA	8.9	13.35	2.7	DR009A0270	DR009L0270	6.236	DR009D0623	

Model	Rated Current [Arms]	Saturation Current [Arms]	Input / Output Reactor [mH]	Input Reactor Delta Part #	Output Reactor Delta Part #	DC Reactor [mH]	DC Reactor Delta Part #
VFD9A0MS43AFSAA VFD9A0MS43ANSAA VFD9A0MS43ENSAA	10.5	15.75	2.315	DR010A0231	DR010L0231	5.345	DR010D0534
VFD13AMS43AFSAA VFD13AMS43ANSAA VFD13AMS43ENSAA	15.7	23.55	1.174	DR018A0117	DR018L0117	3.119	DR018D0311
VFD17AMS43AFSAA VFD17AMS43ANSAA VFD17AMS43ENSAA	20.5	30.75	0.881	DR024AP881	DR024LP881	3.119	DR018D0311
VFD25AMS43AFSAA VFD25AMS43ANSAA VFD25AMS43ENSAA	28	42	0.66	DR032AP660	DR032LP660	2.338	DR024D0233
VFD32AMS43AFSAA VFD32AMS43ANSAA VFD32AMS43ENSAA	36	54	0.639	DR038AP639	DR038LP639	1.754	DR032D0175
VFD38AMS43AFSAA VFD38AMS43ANSAA VFD38AMS43ENSAA	41.5	62.25	0.541	DR045AP541	DR045LP541	1.477	DR038D0147
VFD45AMS43AFSAA VFD45AMS43ANSAA VFD45AMS43ENSAA	49	73.5	0.405	DR060AP405	DR060LP405	1.247	DR045D0124

Table 7-4-7

460V, 50-60 Hz / Three-phase - Heavy Duty

460V, 50–60 HZ / Tr					• • •		
Model	Rated Current [Arms]	Saturation Current [Arms]	Input / Output Reactor [mH]	Input Reactor Delta Part #	Output Reactor Delta Part #	DC Reactor [mH]	DC Reactor Delta Part #
VFD1A5MS43ANSAA VFD1A5MS43ENSAA VFD1A5MS43AFSAA	1.5	3	8.102	DR003A0810	DR003L0810	18.709	DR003D1870
VFD2A7MS43ANSAA VFD2A7MS43ENSAA VFD2A7MS43AFSAA	2.7	5.4	8.102	DR003A0810	DR003L0810	18.709	DR003D1870
VFD4A2MS43AFSAA VFD4A2MS43ANSAA VFD4A2MS43ENSAA	4.2	8.4	6.077	DR004A0607	DR004L0607	14.031	DR004D1403
VFD5A5MS43AFSAA VFD5A5MS43ANSAA VFD5A5MS43ENSAA	5.5	11	4.05	DR006A0405	DR006L0405	9.355	DR006D0935
VFD7A3MS43ANSAA VFD7A3MS43ENSAA VFD7A3MS43AFSAA	8.1	16.2	2.7	DR009A0270	DR009L0270	6.236	DR009D0623
VFD9A0MS43AFSAA VFD9A0MS43ANSAA VFD9A0MS43ENSAA	9	18	2.7	DR009A0270	DR009L0270	6.236	DR009D0623
VFD13AMS43AFSAA VFD13AMS43ANSAA VFD13AMS43ENSAA	13	26	1.174	DR018A0117	DR018L0117	4.677	DR012D0467
VFD17AMS43AFSAA VFD17AMS43ANSAA VFD17AMS43ENSAA	17	34	1.174	DR018A0117	DR018L0117	3.119	DR018D0311
VFD25AMS43AFSAA VFD25AMS43ANSAA VFD25AMS43ENSAA	25	50	0.881	DR024AP881	DR024LP881	2.338	DR024D0233

Model	Rated Current [Arms]	Saturation Current [Arms]	Input / Output Reactor [mH]	Input Reactor Delta Part #	Output Reactor Delta Part #	DC Reactor [mH]	DC Reactor Delta Part #
VFD32AMS43AFSAA VFD32AMS43ANSAA VFD32AMS43ENSAA	32	64	0.66	DR032AP660	DR032LP660	1.754	DR032D0175
VFD38AMS43AFSAA VFD38AMS43ANSAA VFD38AMS43ENSAA	38	76	0.639	DR038AP639	DR038LP639	1.477	DR038D0147
VFD45AMS43AFSAA VFD45AMS43ANSAA VFD45AMS43ENSAA	45	90	0.541	DR045AP541	DR045LP541	1.247	DR045D0124

Table 7-4-8

575V, 50-60 Hz / Three-phase - Normal Duty

Model	Rated Current [Arms]	Saturation Current [Arms]	AC Reactor [mH]	DC Reactor [mH]	
VFD1A7MS53ANSAA	2.1	3.15	13.13	17.50	
VFD3A0MS53ANSAA	3.6	5.4	7.66	10.21	
VFD4A2MS53ANSAA	5	7.5	5.51	7.35	
VFD6A6MS53ANSAA	8	12	3.45	4.59	
VFD9A9MS53ANSAA	11.5	17.25	2.40	3.20	
VFD12AMS53ANSAA	15	22.5	1.84	2.45	

Table 7-4-9

575V, 50-60 Hz / Three-phase - Heavy Duty

Model Rated Current [Arms]		Saturation Current [Arms]	AC Reactor [mH]	DC Reactor [mH]	
VFD1A7MS53ANSAA	1.7	3.4	16.22	37.45	
VFD3A0MS53ANSAA	3	6	9.19	21.22	
VFD4A2MS53ANSAA	4.2	8.4	6.56	15.16	
VFD6A6MS53ANSAA	6.6	13.2	4.18	9.65	
VFD9A9MS53ANSAA	9.9	19.8	2.78	6.43	
VFD12AMS53ANSAA	12.2	24.4	2.26	5.22	

Table 7-4-10

The table below shows the THDi specification when using Delta's drives to work with AC/DC reactors.

The table below shows the THDI specification when using Delta's drives to work with AC/DC reactors.								
Drive Spec.	Models without Built-in DC Reactors				Models with Built-in DC Reactors			
Reactor Spec.	No AC/DC Reactor	3% Input AC Reactor	5% Input AC Reactor	4% DC Reactor	No AC/DC Reactor	3% Input AC Reactor	5% Input AC Reactor	
5th	73.3%	38.5%	30.8%	25.5%	31.16%	27.01%	25.5%	
7th	52.74%	15.3%	9.4%	18.6%	23.18%	9.54%	8.75%	
11th	7.28%	7.1%	6.13%	7.14%	8.6%	4.5%	4.2%	
13th	0.4%	3.75%	3.15%	0.48%	7.9%	0.22%	0.17%	
THDi	91%	43.6%	34.33%	38.2%	42.28%	30.5%	28.4%	
Note	The THDi specification listed here assumes that there is 0.8% resistance (mains electricity) before the reactors							
	and may be slightly different from the actual THDi, depending on the installation and environmental conditions							
	(wires, motors).							

Table 7-4-11

Reactor Dimension and Specifications

AC Input Reactor




Figure 7-4-4

AC Input Reactors Delta Part #	А	В	С	D1*D2	Е	G1	G2	PE D
DR005A0254	100	115	65	6*9	45	60	40	M4
DR008A0159	100	115	65	6*9	45	60	40	M4
DR011A0115	130	135	95	6*12	60	80.5	60	M4
DR017AP746	130	135	100	6*12	65	80.5	60	M4

Table 7-4-12




Figure 7-4-5

AC Input Reactors Delta Part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR025AP215	130	195	100	6*12	65	80.5	60	M4
DR033AP163	130	195	100	6*12	65	80.5	60	M4
DR049AP163	160	200	125	6*12	90	107	75	M4

Table 7-4-13




Figure 7-4-6

AC Input Reactor	
Delta Part #	Dimensions are as shown in the figures above.
DR065AP162	

Table 7-4-14




Figure 7-4-7

	1:4.	
ι	Jnit:	mm

		OTTICE TITLE
AC Input Reactor		
Delta Part #	Dimensions are as shown in the figures above.	
DR075AP170	v	

Table 7-4-15




Figure 7-4-8

Unit: mm

								OTHE THIS
AC Input Reactors Delta Part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR003A0810	100	125	65	6*9	43	60	40	M4
DR004A0607	100	125	65	6*9	43	60	40	M4
DR006A0405	130	15	95	6*12	60	80.5	60	M4
DR009A0270	160	160	105	6*12	75	107	75	M4
DR010A0231	160	160	115	6*12	90	107	75	M4
DR012A0202	160	160	115	6*12	90	107	75	M4
DR018A0117	160	160	115	6*12	90	107	75	M4

Table 7-4-16




Figure 7-4-9

AC Input Reactors Delta Part #	Α	В	С	D1*D2	Н	G1	G2	PE D
DR024AP881	160	175	115	6*12	90	107	75	M4
DR032AP660	195	200	145	6*12	115	122	85	M6
DR038AP639	190	200	145	6*12	115	122	85	M6
DR045AP541	190	200	145	6*12	115	122	85	M6

Table 7-4-17




Figure 7-4-10

AC Input Reactor Delta Part #	Dimensions are as shown in the figures above.
DR060AP405	· ·

Table 7-4-18

AC Output Reactor




Figure 7-4-11

AC Output Reactors Delta Part #	Α	В	С	D1*D2	E	G1	G2	PE D
DR005L0254	96	110	70	6*9	42	60	40	M4
DR008L0159	120	135	96	6*12	60	80.5	60	M4
DR011L0115	120	135	96	6*12	60	80.5	60	M4
DR017LP746	120	135	105	6*12	65	80.5	60	M4
DR025LP507	150	160	120	6*12	88	107	75	M4
DR033LP320	150	160	120	6*12	88	107	75	M4

Table 7-4-19




Figure 7-4-12

AC Output Reactors Delta Part #	Α	В	С	D1*D2	Н	G	G1	Q	М	PE D
DR049LP215	180	205	175	6*12	115	85	122	16	1.2-1.4	M4
DR065LP162	180	215	185	6*12	115	85	122	35	2.5-3.0	M4

Table 7-4-20






Figure 7-4-13

AC Output Reactor Delta Part #	Α	A1	В	B1	B2	С	C1	D1*D2	Е	G1	Н	M*T
DR049LP215	240	228	215	44	170	151	100	7*13	152	176	85	20*3

Table 7-4-21



Tightening torque 0.6-0.8Nm






Figure 7-4-14

Unit: mm

AC Output Reactors Delta Part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR003L0810	96	115	65	6*9	42	60	40	M4
DR004L0607	120	135	95	6*12	60	80.5	60	M4
DR006L0405	120	135	95	6*12	60	80.5	60	M4
DR009L0270	150	160	100	6*12	74	107	75	M4
DR010L0231	150	160	115	6*12	88	107	75	M4
DR012L0202	150	160	115	6*12	88	107	75	M4
DR018L0117	150	160	115	6*12	88	107	75	M4
DR024LP881	150	160	115	6*12	88	107	75	M4
DR032LP660	180	190	145	6*12	114	122	85	M6

Table 7-4-22




Figure 7-4-15

								Offic. Hilli
AC Output Reactors Delta Part #	Α	В	С	D1*D2	Н	G1	G2	PE D
DR038LP639	180	205	170	6*12	115	85	122	M4
DR045LP541	235	245	155	7*13	85	1	176	M6

Table 7-4-23




Figure 7-4-16

_													71111. 111111
	AC Output Reactors Delta Part #	А	A1	В	B1	B2	С	C1	D1*D2	E	G1	н	M*T
	DR060LP405	240	228	215	44	170	163	110	7*13	152	176	97	20*3
	DR073LP334	250	235	235	44	186	174	115	11*18	160	190	124	20*3
	DR091LP267	250	240	235	44	186	174	115	11*18	160	190	124	20*3
	DR110LP221	270	260	245	50	192	175	115	10*18	176	200	106	20*3

Table 7-4-24

DC Reactor




Figure 7-4-17

DC Reactors Delta Part #	Rated Current [Arms]	Saturation Current [Arms]	DC Reactors [mH]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	R [mm]
DR005D0585	5	8.64	5.857	79	78	112	64±2	56±2	9.5*5.5
DR008D0366	8	12.78	3.660	79	78	112	64±2	56±2	9.5*5.5
DR011D0266	11	18	2.662	79	92	112	64±2	69.5±2	9.5*5.5
DR017D0172	17	28.8	1.722	79	112	112	64±2	89.5±2	9.5*5.5
DR025D0117	25	43.2	1.172	99	105	128	79±2	82.5±2	9.5*5.5
DR033DP851	33	55.8	0.851	117	110	156	95±2	87±2	10*6.5
DR049DP574	49	84.6	0.574	117	120	157	95±2	97±2	10*6.5
DR065DP432	65	111.6	0.432	117	140	157	95±2	116.5±2	10*6.5
DR003D1870	3	5.22	18.709	79	78	112	64±2	56±2	9.5*5.5
DR004D1403	4	6.84	14.031	79	92	112	64±2	69.5±2	9.5*5.5
DR006D0935	6	10.26	9.355	79	92	112	64±2	69.5±2	9.5*5.5
DR009D0623	9	14.58	6.236	79	112	112	64±2	89.5±2	9.5*5.5
DR010D0534	10.5	17.1	5.345	99	93	128	79±2	70±2	9.5*5.5
DR012D0467	12	19.8	4.677	99	105	128	79±2	82.5±2	9.5*5.5
DR018D0311	18	30.6	3.119	117	110	144	95±2	87±2	10*6.5
DR024D0233	24	41.4	2.338	117	120	144	95±2	97±2	10*6.5
DR032D0175	32	54	1.754	117	140	157	95±2	116.5±2	10*6.5
DR038D0147	38	64.8	1.477	136	135	172	111±2	112±2	10*6.5
DR045D0124	45	77.4	1.247	136	135	173	111±2	112±2	10*6.5

The Motor Cable Length

1. Consequence of leakage current on the motor

If the cable length is too long, the stray capacitance between cables increases and may cause leakage current. In this case, It activates the over-current protection, increases leakage current, or may affect the current display. The worst case is that it may damage the AC motor drive. If more than one motor is connected to one AC motor drive, the total wiring length should be the sum of the wiring length from AC motor drive to each motor.

For the 460V models AC motor drive, when you install an overload thermal relay between the drive and the motor to protect the motor from overheating, the connecting cable must be shorter than 50 m; however, an overload thermal relay malfunction may still occur. To prevent the malfunction, install an output reactor (optional) to the drive or lower the carrier frequency setting (see Pr.00-17 Carrier Frequency).

2. Consequence of the surge voltage on the motor

When a motor is driven by a PWM-type AC motor drive, the motor terminals experience surge voltages (dv/dt) due to power transistor conversion of AC motor drive. When the motor cable is very long (especially for the 460V models), surge voltages (dv/dt) may damage the motor insulation and bearing. To prevent this, follow these rules:

- Use a motor with enhanced insulation.
- b. Reduce the cable length between the AC motor drive and motor to suggested values.
- c. Connect an output reactor (optional) to the output terminals of the AC motor drive.

Refer to the following tables for the suggested motor shielded cable length. For drive models < 480V, use a motor with a rated voltage \leq 500 V_{AC} and an insulation level \geq 1.35 kV_{p-p} in accordance with IEC 60034-17. For the 575V drive model, use a motor with a rated voltage \leq 600 V_{AC} and an insulation level \geq 1.79 kV_{p-p} in accordance with IEC 60034-25.

110V One-phase	Normal Duty	Without an AC	With an AC Output Reactor		
Drive Model	Rated Current	Shielded Cable	Non-shielded		Non-shielded
Brive Wieder	[Arms]	[meter]	Cable [meter]	Cable [meter]	Cable [meter]
VFD1A6MS11ANSAA VFD1A6MS11ENSAA	1.8				
VFD2A5MS11ANSAA VFD2A5MS11ENSAA	2.7	50	75	75	115
VFD4A8MS11ANSAA VFD4A8MS11ENSAA	5.5				

Table 7-4-26

230V One-phase	Normal Duty	Without an AC	Output Reactor	With an AC Output Reactor		
Drive Model	Rated Current	Shielded Cable	Non-shielded		Non-shielded	
	[Arms]	[meter]	Cable [meter]	Cable [meter]	Cable [meter]	
VFD1A6MS21ANSAA VFD1A6MS21ENSAA VFD1A6MS21AFSAA	1.8	50	75	75	115	
VFD2A8MS21ANSAA VFD2A8MS21ENSAA VFD2A8MS21AFSAA	3.2	30	73	73	113	

230V One-phase	Normal Duty	Without an AC	Output Reactor	With an AC Output Reactor		
Drive Model	Rated Current	Shielded Cable	Non-shielded		Non-shielded	
Drive Model	[Arms]	[meter]	Cable [meter]	Cable [meter]	Cable [meter]	
VFD4A8MS21ANSAA VFD4A8MS21ENSAA VFD4A8MS21AFSAA	5					
VFD7A5MS21ANSAA VFD7A5MS21ENSAA VFD7A5MS21AFSAA	8.5	50	75	75	115	
VFD11AMS21ANSAA VFD11AMS21ENSAA VFD11AMS21AFSAA	12.5					

Table 7-4-27

230V Three-phase	Normal Duty	Without an AC	Output Reactor	With an AC Output Reactor		
Drive Model	Rated Current	Shielded Cable	Non-shielded	Shielded	Non-shielded	
Drive Woder	[Arms]	[meter]	Cable [meter]	Cable [meter]	Cable [meter]	
VFD1A6MS23ANSAA VFD1A6MS23ENSAA	1.8					
VFD2A8MS23ANSAA VFD2A8MS23ENSAA	3.2					
VFD4A8MS23ANSAA VFD4A8MS23ENSAA	5					
VFD7A5MS23ANSAA VFD7A5MS23ENSAA	8	50	75	75	115	
VFD11AMS23ANSAA VFD11AMS23ENSAA	12.5					
VFD17AMS23ANSAA VFD17AMS23ENSAA	19.5					
VFD25AMS23ANSAA VFD25AMS23ENSAA	27					
VFD33AMS23ANSAA VFD33AMS23ENSAA	36					
VFD49AMS23ANSAA VFD49AMS23ENSAA	51	100	150	150	225	
VFD65AMS23ANSAA VFD65AMS23ENSAA	69					

Table 7-4-28

460V Three-phase	Normal Duty	Without an AC	Output Reactor	With an AC C	utput Reactor
Drive Model	Rated Current	Shielded Cable	Non-shielded		Non-shielded
Drive Model	[Arms]	[meter]	Cable [meter]	Cable [meter]	Cable [meter]
VFD1A5MS43ANSAA VFD1A5MS43ENSAA VFD1A5MS43AFSAA	1.8				
VFD2A7MS43ANSAA VFD2A7MS43ENSAA VFD2A7MS43AFSAA	3	35	50	50	90
VFD4A2MS43ANSAA VFD4A2MS43ENSAA VFD4A2MS43AFSAA	4.6				
VFD5A5MS43ANSAA VFD5A5MS43ENSAA VFD5A5MS43AFSAA	6.5	50	75	75	115

460V Three-phase	Normal Duty	Without an AC	Output Reactor	With an AC O	utput Reactor
Drive Model	Rated Current	Shielded Cable	Non-shielded	Shielded	Non-shielded
Drive Model	[Arms]	[meter]	Cable [meter]	Cable [meter]	Cable [meter]
VFD7A3MS43ANSAA VFD7A3MS43ENSAA VFD7A3MS43AFSAA	8.9	75	150	150	225
VFD9A0MS43ANSAA VFD9A0MS43ENSAA VFD9A0MS43AFSAA	10.5	50	75	75	15
VFD13AMS43ANSAA VFD13AMS43ENSAA VFD13AMS43AFSAA	15.7	50	75	75	15
VFD17AMS43ANSAA VFD17AMS43ENSAA VFD17AMS43AFSAA	20.5				
VFD25AMS43ANSAA VFD25AMS43ENSAA VFD25AMS43AFSAA	28				
VFD32AMS43ANSAA VFD32AMS43ENSAA VFD32AMS43AFSAA	36	100	150	150	225
VFD38AMS43ANSAA VFD38AMS43ENSAA VFD38AMS43AFSAA	41.5				
VFD45AMS43ANSAA VFD45AMS43ENSAA VFD45AMS43AFSAA	49				

Table 7-4-29

575V Three-phase	Normal Duty	Without an AC C	Output Reactor*1	With an AC O	utput Reactor
Drive Model	Rated Current	Shielded Cable	Non-shielded		Non-shielded
Brive Wieder	[Arms]	[meter]	Cable [meter]	Cable [meter]	Cable [meter]
VFD1A7MS53ANSAA	2.1	15	55		
VFD3A0MS53ANSAA	3.6	50	80		
VFD4A2MS53ANSAA	5	65	120	N/A	N/A
VFD6A6MS53ANSAA	8.5	00	295	IN/A	
VFD9A9MS53ANSAA	11.5	145 320			
VFD12AMS53ANSAA	15	145	320		

Table 7-4-30

^{*1} Without an AC output reactor: Use the motor cable length of the 575V drive model only for 4 kHz carrier frequency (Pr.00-17=4). If you use it for > 4 kHz carrier frequency, you may need to reduce the motor cable length to prevent over-current protection caused by large leakage current, depending on the actual on-site situations.

7-5 Zero Phase Reactors

You can also suppress interference by installing a zero phase reactor at the main input or the motor output of the drive, depending on the location of the interference. Delta provides two types of zero phase reactors to solve interference problems.

A. Casing with mechanical fixed part

Used for the zero phase reactor at the main input/motor output. It withstands large current load and is used for high frequencies. You can get higher impedance by increasing the number of turns.




Figure 7-5-1

								Unit. mm
Model	Α	В	С	D	Е	F	G(Ø)	To use w/
RF008X00A	99	73	36.5	29	56.5	86	5.5	Motor cable

Table 7-5-1

I Inite man

B. Casing without mechanical fixed part

Adopts nanocrystalline core developed by VAC[®], and has high initial permeability, high saturation induction density, low iron loss and perfect temperature characteristic. If the zero phase reactor does not need to be fixed mechanically, use this solution.




Figure 7-5-2

Unit: mm

Model	Α	В	С
T60006L2040W453	22.5	43.1	18.5
T60006L2050W565	36.3	53.5	23.4

Table 7-5-2

Installation

During installation, pass the cable through at least one zero phase reactor. Use a suitable cable type (pressure endurance, current endurance, insulation class, and wire gauge) so that the cable passes easily through the zero phase reactor. Do not pass the grounding cable through the zero phase reactor; only pass the motor wire and power cable through the zero phase reactor. With longer motor cables the zero-phase reactor can effectively reduce interference at the motor output. Moreover, pay extra attention to the large leakage current due to long cable length. This may cause temperature rise in the zero phase reactor. Install the zero phase reactor as close to the output of the drive as possible. Figure 7-5-3 below shows the installation diagram for a single turn zero phase reactor. If the wire diameter allows several turns, Figure 7-5-4 shows the installation of a multi-turn zero phase reactor. The more turns, the better the noise suppression effect.




Figure 7-5-3 Single turn wiring diagram for shielding wire with a zero phase reactor




Figure 7-5-4 Multi-turn zero phase reactor

Installation Precaution

Install the zero phase reactor at the drive's output terminal (U/T1, V/T2, W/T3). After the zero phase reactor is installed, it reduces the electromagnetic radiation and load stress emitted by the wiring of the drive. The number of zero phase reactors required for the drive depends on the wiring length and the drive voltage.

The normal operating temperature of the zero phase reactor should be lower than 85°C (176°F). However, when the zero phase reactor is saturated, its temperature may exceed 85°C (176°F). In this case, increase the number of zero phase reactors to avoid saturation. The following are reasons that might cause saturation of the zero phase reactors: the drive wiring is too long; the drive has several sets of loads; the wiring is in parallel; or the drive uses high capacitance wiring. If the temperature of the zero phase reactor exceeds 85°C (176°F) during the operation of the drive, increase the number of zero phase reactors.

Recommended maximum wiring gauge when installing a zero phase reactor

Zero Phase Reactor	Max. Wire Gauge	Max. Wire Gau	ge AWG (1Cx3)	Max. Wire Gau	ge AWG (4Cx1)
Model No.	or LUG width	75°C 90°C		75°C	90°C
RF008X00A	13 mm	3 AWG	1 AWG	3 AWG	1 AWG
T600006L2040W453	11 mm	9 AWG	4 AWG	6 AWG	6 AWG
T600006L2050W565	16 mm	1 AWG	2/0 AWG	1 AWG	1/0 AWG

Table 7-5-3

Zero Phase Reactor for Signal Cable

To solve interference problems between signal cables and electrical equipment, install a zero phase reactor on the signal cable. Refer to the table below for models and dimensions. Installing a zero phase reactor on the signal cable at the source of the interference suppresses the interference and noise between signal cables.




Figure 7-5-5

Unit: mm

			•
Model	Α	В	С
T60004L2016W620	10.7	17.8	8.0
T60004L2025W622	17.5	27.3	12.3

Table 7-5-4

7-6 EMC Filter

Use EMC filters to enhance the EMC performance for the environment and machines and to comply with EMC regulations, further reducing EMC problems. If you purchase a motor drive without a built-in EMC filter, it is recommended that you select the EMC filters as shown below. For some motor drive models, you need to work with zero phase reactors to be compliant with EMC regulations. Refer to the table and figure below for the recommended model, setting method, and maximum motor cable length of the EMC filter and zero phase reactor.

IIIE LI	VIC filter and zero	priase	reactor.				_				\ I. 1		
						ducte			Radiate				
			Maximum Mo		Recommended Model of			Emission Maximum Moto			Emission Maximum Motor		
		lnnut							Cable Length				
Frame	Motor Drive	Input Current	Filter Model #		hase Reactors		C1		C2		C2	J	
1 141116	Model #	(A)	i iitoi iviodoi //				30 m	l	100 m		100 m		
		` ,				Pos	sition	to in	stall a z	zero phase reactor			
				DELTA	. ®					-	*1 *2 *3		
_				DELTA	VAC®	*1	*2	*3	N/A	""]	"2	-3	
Α	VFD1A6MS11ANSAA	6.8	EMF11AM21A	RF008X00A	T60006L2040W453				NA				
Α	VFD1A6MS21ANSAA	3.8	EMF11AM21A	RF008X00A	T60006L2040W453		✓	1	NA		1	1	
Α	VFD2A8MS21ANSAA	6.7	EMF11AM21A	RF008X00A	T60006L2040W453		✓	✓	NA		1	✓	
Α	VFD1A6MS23ANSAA	2.2	EMF10AM23A	RF008X00A	T60006L2040W453		1	1	NA		✓	✓	
Α	VFD2A8MS23ANSAA	3.8	EMF10AM23A	RF008X00A	T60006L2040W453		1	1	NA		✓	✓	
Α	VFD4A8MS23ANSAA	6	EMF10AM23A	RF008X00A	T60006L2040W453		1	1	NA		✓	✓	
Α	VFD1A5MS43ANSAA	2.5	EMF6A0M43A	RF008X00A	T60006L2040W453			1	NA			1	
Α	VFD2A7MS43ANSAA	4.2	EMF6A0M43A	RF008X00A	T60006L2040W453			1	NA			1	
Α	VFD1A7MS53ANSAA	2.4	EMF6A0M63B	RF008X00A	T60006L2040W453				NA*				
Α	VFD2A5MS11ANSAA	10.1	EMF11AM21A	RF008X00A	T60006L2040W453				NA				
В	VFD4A8MS21ANSAA	10.5	EMF11AM21A	RF008X00A	T60006L2040W453		1	1	NA		1	1	
В	VFD7A5MS23ANSAA	9.6	EMF10AM23A	RF008X00A	T60006L2040W453		1	1	NA		1	1	
В	VFD3A0MS53ANSAA	4.2	EMF6A0M63B	RF008X00A	T60006L2040W453				NA*				
В	VFD4A2MS43ANSAA	6.4	EMF6A0M43A	RF008X00A	T60006L2040W453			1	NA			1	
С	VFD4A8MS11ANSAA	20.6	EMF27AM21B	RF008X00A	T60006L2040W453				NA				
С	VFD7A5MS21ANSAA	17.9	EMF27AM21B	RF008X00A	T60006L2040W453			1	NA			1	
С	VFD11AMS21ANSAA	26.3	EMF27AM21B	RF008X00A	T60006L2040W453			1	NA			1	
С	VFD11AMS23ANSAA	15	EMF24AM23B	RF008X00A	T60006L2040W453		1	1	NA		/	1	
С	VFD17AMS23ANSAA	23.4	EMF24AM23B	RF008X00A	T60006L2040W453		1	1	NA		/	1	
С	VFD5A5MS43ANSAA	7.2	EMF12AM43B	RF008X00A	T60006L2040W453				NA				
С	VFD4A2MS53ANSAA	5.8	EMF16AM63B	RF008X00A	T60006L2040W453				NA*				
С	VFD6A6MS53ANSAA	9.3	EMF16AM63B	RF008X00A	T60006L2040W453				NA				
С	VFD7A3MS43ANSAA	8.9	EMF12AM43B	RF008X00A	T60006L2040W453		1	1	NA		1	1	
С	VFD9A0MS43ANSAA	11.6	EMF12AM43B	RF008X00A	T60006L2040W453		1	1	NA		1	1	
D	VFD25AMS23ANSAA	32.4	EMF33AM23B	RF008X00A	T60006L2050W565	1	1		NA	1	1		
D	VFD13AMS43ANSAA	17.3	EMF23AM43B	RF008X00A		1	1	1	NA	1	1	1	
D	VFD9A9MS53ANSAA	13.4	EMF16AM63B	RF008X00A	T60006L2040W453				N/A	•			
D	VFD9A9MS53ANSAA	17.5	EMF16AM63B	RF008X00A	T60006L2040W453				N/A				
D	VFD17AMS43ANSAA	22.6	EMF23AM43B	RF008X00A	T60006L2050W565	1	1	1	NA	1	1	1	
E	VFD33AMS23ANSAA	43.2	B84143D0075R127	RF008X00A	T60006L2050W565		1	1	NA	•	1	1	
E	VFD49AMS23ANSAA	61.2	B84143D0075R127	RF008X00A	T60006L2050W565		1	1	NA NA		✓ ✓	1	
-	VFD25AMS43ANSAA	30.8	B84143D0075R127	RF008X00A	T60006L2050W565		•	•			•	_	
E E			B84143D0050R127	RF008X00A	T60006L2050W565		/	1	NA NA				
	VFD32AMS43ANSAA	39.6							NA		√	√	
F	VFD65AMS23ANSAA	82.8	B84143D0090R127	RF008X00A	T60006L2050W565		√	√	NA		√	√	
F	VFD38AMS43ANSAA	45.7	B84143D0075R127	RF008X00A	T60006L2050W565		√	√	NA		√	√	
F	VFD45AMS43ANSAA	53.9	B84143D0075R127	RF008X00A	T60006L2050W565		✓	✓	NA		1	✓	

Note 1: It is not necessary to add a zero phase reactor for passing the C2 conducted emission test.

Table 7-6-1

The maximum motor cable length of the conducted emission C2 class for VFD1A7MS53ANSAA, VFD3A0MS53ANSAA and VFD4A2MS53ANSAA is 75 m, others are 100 m.

Zero phase reactor installation position diagram:




Figure 7-6-1

- *1 Install at the cable between the power supply and the EMC filter
- *2 Install at the cable between the EMC filter and the drive
- *3 Install at the cable between the drive and the motor

Filter Dimension

EMF11AM21A EMF10AM23A

EMF6A0M43A

Screw	Torque
M5 * 2	16–20 kg-cm / [13.9–17.3 lb-in.] / [1.56–1.96 Nm]
M4 * 2	14-16 kg-cm / [12.2-13.8 lb-in.] / [1.38-1.56 Nm]




Figure 7-6-2

EMF27AM21B; EMF24AM23B EMF33AM23B; EMF12AM43B EMF23AM43B; EMF6A0M63B;

EMF16AM63B

Screw	Torque
M5 * 4	16-20 kg-cm / [13.9-17.3 lb-in.] / [1.56-1.96 Nm]





Figure 7-6-3

TDK B84143D0050R127 (50A)



Unit: mm

Figure 7-6-4

TDK B84143D0075R127 (75A), TDK B84143D0090R127 (90A)




Figure 7-6-5

The table below is the maximum shielded cable length for drive models with built-in EMC filters. You can choose the corresponding shielded cable length according to the required noise emission and electromagnetic interference class.

	Drive Models with Built-in Filters	Rated Current		Compliance with EMC (IEC 61800-3) Class C3		ИС s C2
Frame	Models	(HD)	Shielded Cable Length	Fc	Shielded Cable Length	Fc
	VFD1A5MS43AFSAA	1.5				
	VFD2A7MS43AFSAA	2.7				
В	VFD4A2MS43AFSAA	4.2				
Ь	VFD1A6MS21AFSAA	1.6				
	VFD2A8MS21AFSAA	2.8				
	VFD4A8MS21AFSAA	4.8				
	VFD5A7MS43AFSAA	5.7				
	VFD7A5MS21AFSAA	7.5				4 kHz
С	VFD7A3MS43AFSAA	8.9	30 m	4 kHz	20 m	
	VFD9A0MS43AFSAA	9				
	VFD11AMS21AFSAA	11				
D	VFD13AMS43AFSAA	13				
D	VFD17AMS43AFSAA	17				
E	VFD25AMS43AFSAA	25				
	VFD32AMS43AFSAA	32				
F	VFD38AMS43AFSAA	38				
Г	VFD45AMS43AFSAA	45				

Table 7-6-2

7-7 EMC Shield Plate

EMC Shield Plate (for use with shielded cable)

Frame	Model of EMC Shield Plate	Reference Figure
А	MKM-EPA	Figure 7-7-1
В	MKM-EPB	Figure 7-7-2
С	MKM-EPC	Figure 7-7-3
		rigule 7-7-3
D	MKM-EPD	
		Figure 7-7-4
E	MKM-EPE	Figure 7-7-5
F	MKM-EPF	Figure 7-7-6

Installation

(This example uses Frame A model)

1. As shown in the right figure, fix the shield plate on the AC motor drive.

Torque value:

Frame	Screw	Torque
Α	M3.5	6-8 kg-cm / [5.2-6.9 lb-in.] / [0.59-0.78 Nm]
В	M4	6–8 kg-cm / [5.2–6.9 lb-in.] / [0.59–0.78 Nm]
С	M4	6–8 kg-cm / [5.2–6.9 lb-in.] / [0.59–0.78 Nm]
D	М3	4–6 kg-cm / [3.5–5.2 lb-in.] / [0.39–0.59 Nm]
E	М3	4–6 kg-cm / [3.5–5.2 lb-in.] / [0.39–0.59 Nm]
F	M4	6–8 kg-cm / [5.2–6.9 lb-in.] / [0.59–0.78 Nm]






Figure 7-7-7

2. Select a suitable R-clip according to the wire gauge used, and then fix the R-clip on the shield plate.

Screw	Torque
M4	6-8 kg-cm / [5.2-6.9 lb-in.] / [0.59-0.78 Nm]





	Dimensions of Shield Plate				
Model	Unit: mm [inch]				
	а	b			
MKM-EPA	69.3 [2.73]	80.0 [3.15]			
MKM-EPB	67.7 [2.67]	79.7 [3.14]			
MKM-EPC	78.0 [3.07]	91.0 [3.58]			
MKM-EPD	103.4 [4.07]	97.0 [3.82]			
MKM-EPE	124.3 [4.89]	77.4 [3.05]			
MKM-EPF	168.0 [6.61]	80.0 [3.15]			

Recommended wiring method

Frame	Model of EMC Shield Plate	Reference Figure
А	MKM-EPA	€ © CTL CTL © € (O T T T T T T T T T T T T T T T T T T
В	MKM-EPB	Figure 7-7-11
С	MKM-EPC	Figure 7-7-12
D	MKM-EPD	CTL
E	MKM-EPE	Figure 7-7-14
F	MKM-EPF	Figure 7-7-15

7-8 Capacitive Filter

The capacitive filter (CXY101-43A) is a simple filter that supports basic filtering and noise interference reduction and applicable for models below 460V.

Installation diagram:




Figure 7-8-1

Wiring diagram for the capacitive filter and the drive:




Figure 7-8-2

Specifications:


Model	Applicable Voltage	Temperature Range	Capacitance	
CXY101-43A	110-480 V _{AC}	-40-85°C	Cx: 1uF ± 20%	Cy: 0.1uF ± 20%


Table 7-8-1


Note: CXY101-43A is not applicable for 575V models.

Dimensions:

CXY101-43A










Figure 7-8-3


7-9 NEMA 1 / UL Type 1 Kit


Conduit boxes installation


Frame A (A1, A2)


Conduit box model: MKM-CBA0


Frame A (A3–A5) Conduit box model: MKM-CBA













Unit: mm [inch] Unit: mm [inch]

Figure 7-9-1 Figure 7-9-2

Frame B
Conduit box model: MKM-CBB








Figure 7-9-3

Frame C
Conduit box model: MKM-CBC




Figure 7-9-4

Frame D

Conduit box model: MKM-CBD




Figure 7-9-5

Frame E
Conduit box model: MKM-CBE




Figure 7-9-6

Frame F

Conduit box model: MKM-CBF




Figure 7-9-7

Unit: mm [inch]

Installation

Recommended screw size and torque value: M3: 4-6 kg-cm / [3.5-5.2 lb-in.] / [0.39-0.59 Nm]

M3.5: 4–6 kg-cm / [3.5–5.2 lb-in.] / [0.39–0.59 Nm]

M4: 6-8 kg-cm / [5.2-6.9 lb-in.] / [0.59-0.78 Nm]

Frame A

1) Aim the clips at the slots to assemble the conduit box.




Figure 7-9-8

3) Install the front cover of the motor.






Figure 7-9-10



4) Install the front cover of the conduit box and tighten the screw.



5) Attach the dust patch.




Figure 7-9-12

Frame B-F

1) Aim the clips at the slots to assemble the conduit box.




Figure 7-9-13

3) Install the front cover of the motor.




Figure 7-9-15

2) Tighten the screws to connect with the motor.




Figure 7-9-14

4) Install the front cover of the conduit box and tighten the screw.





Figure 7-9-16







Figure 7-9-17

7-10 Fan Kit

Frame	Fan Model	Fan Kit
А	MKM-FKMA	
В	MKM-FKMB	
С	MKM-FKMC	
D	MKM-FKMD	
E	MKM-FKME	
F	MKM-FKMF	Figure 7-10-1

Fan Removal



7-11 Keypad Panel Mounting

KPMS-LE01 Keypad Panel Mounting:

In order to avoid the motor damage, please be sure to refer to the screw size and torque values to tighten the screws..

1. Install the extension cable to motor:




Figure 7-11-1

The extension cable models and cable length specifications are listed in the table below.

Models	EG0610C	EG1010C	EG2010C	EG3010C	EG5010C
Extension Cable Length	600	1000	2000	3000	5000
(Unit: mm [inch])	[23.62]	[39.37]	[78.74]	[118.11]	[196.85]

Table 7-11-1

2. Method 1: Direct mounting on a plate

T3*L8(2X)
TORQUE:
4kg-cm
[3.5lb-in.]
[0.39Nm]


TORQUE:
8~9kg-cm
[6.94~7.81lb-in.]
[0.78~0.88NM]

Figure 7-11-2

3. **Method 2**: Mounting through a plate

Plate Thickness = 1.2 [0.05] or 2.0 [0.08]

Unit: mm [inch]






Figure 7-11-3

7-12 DIN-Rail Mounting

MKM-DRB (Applicable for Frame A and Frame B)

Screw	Torque	
	8–10 kg-cm	
M4*2PCS	[6.9–8.7 lb-in.]	
	[0.78–0.98 Nm]	




Figure 7-12-1

MKM-DRC (Applicable for Frame C)

Screw	Torque	
	10–12 kg-cm	
M5*4PCS	[8.7–10.4 lb-in.]	
	[0.98–1.18 Nm]	




Figure 7-12-2

Installation

Model	Screw	Torque
MKM-DRB	M4*P0.7*2PCS	8–10 kg-cm / [6.9–8.7 lb-in.] / [0.78–0.98 Nm]
MKM-DRC	M5*P0.8*4PCS	10–12 kg-cm / [8.7–10.4 lb-in.] / [0.98–1.18 Nm]




Figure 7-12-3

7-13 Mounting Adapter Plate


The mounting adapter plate is to change the wiring method for the ME300/MS300/MH300 series to provide you a flexible installation. It changes the wiring method from the "bottom-mains input/bottom-motor output" to the "top-mains input/bottom-motor output" for ME300/MS300/MH300. Therefore, you can use the mounting adapter plate to change the drive from VFD-E/VFD-EL series to ME300/MS300/MH300 series without changing the original wiring method and fixing hole. The following table shows the correspondences.

Series Models	ME/MS/MH300	VFD-E	VFD-EL
MKM-MAPB	Frame A–B	Frame A	Frame A
MKM-MAPC	Frame C	Frame B	Frame B

Table 7-13-1

MKM-MAPB:

Applicable for Frame A and B




Unit: mm [inch]

Figure 7-13-1

MKM-MAPC:

Applicable for Frame C



Unit: mm [inch]

Figure 7-13-2

Installation

Frame A and B

Screw	Torque	
M4	14–16 kg-cm / [12.4–13.9 lb-in.] / [1.37–1.57 Nm]	
M5	16–20 kg-cm / [13.9–17.4 lb-in.] / [1.57–1.96 Nm]	




Figure 7-13-3

Frame C

Screw	Torque
M4	14-16 kg-cm / [12.4-13.9 lb-in.] / [1.37-1.57 Nm]
M5	16–20 kg-cm / [13.9–17.4 lb-in.] / [1.57–1.96 Nm]




Figure 7-13-4

7-14 Digital Keypad - KPC-CC01

7-14-1 Digital Keypad KPC-CC01

The default communication protocol for MS300 is ASCII 9600, 7, N, 2, but the communication protocol for KPC-CC01 is RTU 19200, 8, N, 2. Therefore, you must set MS300 communication parameters so as to connect with the digital keypad KPC-CC01. The setting steps are as follows:

- 1. Set Pr.09-00 communication address = 1
- 2. Set Pr.09-01 COM1 transmission speed (Baud rate) = 19.2 Kbps
- 3. Set Pr.09-04 COM1 communication protocol = 13: 8N2 (RTU)

KPC-CC01



Communication Interface RJ45 (socket), RS-485 interface

Installation Method

- 1. The embedded type can be installed flat on the surface of the control box. The front cover is waterproof.
- 2. Buy a MKC-KPPK model for wall mounting or embedded mounting. Its protection level is IP66.
- 3. The maximum RJ45 extension lead is 5 m (16 ft)
- 4. This keypad can only be used on Delta's motor drive C2000 series, CH2000, CP2000, MS300, MH300 and ME300.


Keypad Function Descriptions

Key	Descriptions
RUN	Start Operation Key 1. Only valid when the source of operation command is the keypad. 2. Operates the AC motor drive by the function setting. The RUN LED will be ON. 3. Can be pressed repeatedly at the stop process.
STOP	 Stop Command Key. This key has the highest priority in any situation. 1. When it receives the STOP command, regardless of whether the AC motor drive is in operation or stop status, the AC motor drive executes the "STOP" command. 2. Use the RESET key to reset the drive after a fault occurs. 3. If you cannot reset after the error: a. The condition which triggers the fault is not cleared. After you clear the condition, you can then reset the fault. b. The drive is in fault status when powered on. After you clear the condition, restart and then you can reset the fault.
FWD REV	Operation Direction Key 1. Only controls the operation direction, NOT the drive activation. FWD: forward, REV: reverse. 2. Refer to the LED descriptions for more details.
ENTER	ENTER Key Goes to the next menu level. If at the last level, press ENTER to execute the command.
ESC	ESC Key Leaves the current menu and returns to the previous menu; also functions as a return key or cancel key in a sub-menu.


Key	Descriptions			
MENU	Returns to the main menu. Menu commands: 1. Parameter Setup 2. Quick Start 3. Application Selection List 4. Changed List 5. Copy Parameter 12. Display Setup 13. Start-up Menu 14. Main Page 15. PC Link 16. Start Wizard 17. Language Setup 18. Time Setup 19. Keypad Locked 19. Function 10. PLC Function 11. Copy PLC 12. Display Setup			
< > ^ V	Direction: Left / Right / Up / Down 1. In the numeric value setting mode, moves the cursor and changes the numeric value. 2. In the menu/text selection mode, selects an item.			
F1 F2 F3 F4	 Function Key The functions keys have defaults and can also be user-defined. The defaults for F1 and F4 work with the function list below. For example, F1 is the JOG function, and F4 is a speed setting key for adding/deleting user-defined parameters. Other functions must be defined using TPEditor. Download TPEditor software at Delta website at: 			

LED Function Descriptions

LED	Descriptions
STOP RESET	Steady ON: STOP indicator for the AC motor drive. Blinking: the drive is in standby. Steady OFF: the drive does not execute the STOP command.
FWD	Operation Direction LED 1. Green light: the drive is running forward. 2. Red light: the drive is running backward. 3. Flashing light: the drive is changing direction.
REV	Operation Direction LED under Torque Mode 1. Green light: when the torque command ≥ 0, and the motor is running forward. 2. Red light: when the torque command < 0, and the motor is running backward. 3. Twinkling light: when the torque command < 0, and the motor is running forward.




7-14-2 Function of Digital Keypad KPC-CC01






- 1. Start-up screen can only display pictures, not animation.
- 2. When powered ON, it displays the start-up screen then the main screen. The main screen displays Delta's default setting F/H/A/U. You can set the display order with Pr.00-03 (Start-up display). When you select the U screen, use the left/right keys to switch between the items, and set the display order for the U screen with Pr.00-04 (User display).

Display Icons





- : present setting
- ▼ : Scroll down the page for more options

Press for more options

► : show complete sentence


Press for complete information

Display items


MENU

1: Parameter Setup	6: Fault Record	11: Copy PLC
2: Quick Start	7: Language Setup	12: Display Setup
3: Application Selection List	8: Time Setup	13: Start-up Menu
4: Changed List	9: Keypad Locked	14: Main Page
5: Copy Parameter	10: PLC Function	15: PC Link
		16: Start Wizard

1. Parameter Setup



2. Quick Start



2. SVC Mode

\$VC Mode :P00-07 ♦01:Password De 02:Password Inp 03:Control Meth

01: Password Decoder



- 30. Torque compensation gain (Pr.07-26)
- 31. Slip Compensation Gain (Pr.07-27)

Items

- Parameter protection password input (Pr.00-07)
- 2. Parameter protection password setting (Pr.00-08)
- 3. Speed control mode (Pr.00-11)
- 4. Load selection (Pr.00-16)
- 5. Carrier frequency (Pr.00-17)
- 6. Master frequency command (AUTO) source (Pr.00-20)
- 7. Operation command (AUTO) source (Pr.00-21)
- 8. Stop method (Pr.00-22)
- 9. Digital keypad STOP function (Pr.00-32)
- 10. Max. operation frequency (Pr.01-00)
- 11. Output frequency of motor 1 (Pr.01-01)
- 12. Output voltage setting of motor 1 (Pr.01-02)
- 13. Min. output frequency of motor 1 (Pr.01-07)
- 14. Min. output voltage of motor 1 (Pr.01-08)
- 15. Output frequency upper limit (Pr.01-10)
- 16. Output frequency lower limit (Pr.01-11)
- 17. Acceleration time 1 (Pr.01-12)
- 18. Deceleration time 1 (Pr.01-13)
- 19. Full-load current for induction motor 1 (Pr.05-01)
- Rated power for induction motor 1 (Pr.05-02)
- 21. Rated speed for induction motor 1 (Pr.05-03)
- 22. Number of poles for induction motor 1 (Pr.05-04)
- No-load current for induction motor 1 (Pr.05-05)
- 24. Over-voltage stall prevention (Pr.06-01)
- 25. Over-current stall prevention during acceleration (Pr.06-03)
- 26. Derating protection (Pr.06-55)
- 27. Software brake level (Pr.07-00)
- 28. Emergency stop (EF) & Force to stop selection (Pr.07-20)
- 29. Torque command filter time (Pr.07-24)
- 30. Slip compensation filter time (Pr.07-25)
- 31. Slip compensation gain (Pr.07-27)
- 3. My Mode

Press F4 in parameter setting screen to save the parameter to My Mode. To delete or correct the parameter, select this parameter and press F4 for DEL in


Items

You can save 01-32 sets of parameters (Pr).


Setup process


 Go to Parameter Setup function. Press ENTER to select the parameter to use. There is an ADD in the bottom right corner of the screen. Press F4 to add this parameter to My Mode.






3. Application Selection List







4. Changed List



5. Copy Parameter



6.



Able to store 6 error codes (Keypad V1.02 and previous versions) Able to store 30 error codes (Keypad V1.20 and later version) The most recent error record shows as the first record. Choose an error record to see details such as date, time, frequency, current, voltage, and DC

bus voltage. Fault record ▼1:oL 2:ovd 3:GFF 1: oL **♦**Current: 79.57 Voltage: 189 2 BUS Voltage:409.5 1: oL Date: 01/20/2014 Time: 21:02:24 Outfreq: 32.61 Fault record 1:oL ♦ 2:ovd 3:GFF 2: ovd **♦**Current: 79.57 Voltage: 189.2

Press the Up / Down keys to select an error record. Press ENTER to see that error record's details.

Press the Up / Down keys to scroll through an error record's details such as date, time, frequency, current, voltage, and DC bus voltage.

Press ESC to return to the Fault record screen.

Press the Up / Down keys to select the next error

After selecting an error code, press ENTER to see that error record's details.

Press the Up / Down keys to see an error record's details such as date, time, frequency, current, voltage, and DC bus voltage.



Outfreq:

2: ovd

BUS Voltage:409.5

♦Date: 01/20/2014 Time: 21:02:24

32.61

The AC motor drive actions are recorded and saved to the KPC-CC01. When you remove the KPC-CC01 and connect it to another AC motor drive, the previous fault records are not deleted. The new fault records of the new AC motor drive continue to be added to the KPC-CC01.

7. Language Setup




Press the Up / Down keys to select the language, and then press ENTER.

The language setting option is displayed in the language of your choice. Language setting options:


- 1. English
- 2. 繁體中文
- 3. 简体中文
- 4. Türkçe

- 5. Русский
- Español
- Português
- 8. français


8. Time Setup



9. Keypad Locked




days. After 7 days, you must reset the time.



Press any key on the keypad; a message displays as shown on the left.

Press ESC for 3 seconds to unlock the keypad; the keypad returns to this screen. All keys on the keypad is functional. Turning the power off and on does not lock the keypad.

10. PLC Function



When activating and stopping the PLC function (choosing 2: PLC Run or 3: PLC Stop), the PLC status displays on main screen (Delta default setting).

Choose option 2: PLC Run to enable the PLC function.

The default on the main screen displays the PLC / RUN status message.


Choose option 3: PLC Stop to disable the PLC function.

The default on the main screen displays the PLC / STOP status message.

If the PLC program is not available in the control board, the PLFF warning displays when you choose option 2 or 3.

In this case, choose option 1: Disable to clear PLFF warning.


11. Copy PLC



Four groups of parameters are available to copy.

The steps are shown in the example below.

Example: PLC program saved in the motor drive.



ERR8

Type Mismatch

PLC/STOP AUTO

PLFF

Function defect


Warning

- 1. Go to Copy PLC
- 2. Select the PLC program to copy and press ENTER.
- 1. Select 1: keypad→VFD.
- 2. Press ENTER to go to the "keypad→VFD" screen.


Begin copying the PLC program until it is done.


After copying is done, the keypad automatically returns to this screen.

If you select "Option 1: keypad→VFD", check if the PLC program is built-in to the KPC-CC01 keypad. If the PLC program is not available in the keypad when you select "Option 1: keypad→VFD", an "ERR8 Warning: Type Mismatch" displays on the screen.




12. Display setup





The setting value changes to Blue Text.

13. Start-up



1. Default 1 **DELTA LOGO**



2. Default 2 **DELTA Text**



3. User Define: an optional accessory is required (TPEditor & USB / RS-485) Communication Interface-IFD6530) to design your own start-up screen. If the editor accessory is not installed, the User Define option displays a blank screen.



USB/RS-485 Communication Interface-IFD6530


Refer to Chapter 07 Optional Accessories for more details.

Download TPEditor software at Delta website at

http://www.deltaww.com/services/DownloadCenter2.aspx?secID=8&pid=2& tid=0&CID=06&itemID=060302&typeID=1&downloadID=,&title=-- Select Product Series --&dataType=8;&check=1&hl=en-US

Select TPEditor version 1.60 or above. Refer to the installation instruction for TPEditor in Section 7-14-3.

14. Main page



Default screen and editable screen are available.






to select.

Default page



F 60.00Hz >>> H >>> A >>> U (options rotate)

2. User Define: an optional accessory is required (TPEditor & USB / RS-485 Communication Interface-IFD6530) to design your own main screen. If the editor accessory is not installed, the User Define option displays a blank screen.



USB/RS-485 Communication Interface-IFD6530

Refer to Chapter 07 Optional Accessories for more details.


TPEditor


Download TPEditor software at Delta website at


http://www.deltaww.com/services/DownloadCenter2.aspx?secID=8&pid=2& tid=0&CID=06&itemID=060302&typeID=1&downloadID=,&title=-- Select Product Series --&dataType=8;&check=1&hl=en-US

Select TPEditor version 1.60 or above. Refer to the installation instruction for TPEditor in Section 7-14-3.


15. PC Link
















NOTE: The "16: Start Wizard" on the menu is to set whether the screen shows the start wizard when starting the drive.

Other displays

When a fault occurs, the screen display shows the fault or warning:





- 1. Press the STOP / RESET key to reset the fault code. If there is no response, contact your local distributor or return the unit to the factory. To view the fault DC bus voltage, output current and output voltage, press MENU and then choose 6: Fault Record.
- 2. After resetting, if the screen returns to the main page and shows no fault after your press ESC, the fault is cleared.
- 3. When the fault or warning message appears, the LED backlight blinks until you clear the fault or warning.

Optional accessory: RJ45 Extension Lead for Digital Keypad

Part No.	Description
CBC-K3FT	RJ45 extension lead, 3 feet (approximately 0.9 m)
CBC-K5FT	RJ45 extension lead, 5 feet (approximately 1.5 m)
CBC-K7FT	RJ45 extension lead, 7 feet (approximately 2.1 m)
CBC-K10FT	RJ45 extension lead, 10 feet (approximately 3 m)
CBC-K16FT	RJ45 extension lead, 16 feet (approximately 4.9 m)

Note: When you need communication cables, buy non-shielded, 24 AWG, four-wire twisted pair, 100 ohms communication cables.


7-14-3 TPEditor Installation Instruction

TPEditor can edit up to 256 HMI (Human-Machine Interface) pages with a total storage capacity of 256 KB. Each page can include 50 normal objects and 10 communication objects.


- 1) TPEditor: Setup & Basic Functions
 - 1. Run TPEditor version 1.60 or above by double-clicking the program icon.



 On the File menu, click New. In the New Project dialog box, for Set Device Type, select DELTA VFD-C Inverter. For TP Type, select VFD-C KeyPad. For File Name, enter TPE0 and then click OK.




3. The editor displays the Design window. On the **Edit** menu, click **Add a New Page**. You can also right-click on the TP page in the upper right corner of the Design window and click **Add** to add one more page(s) to edit.




4. Edit the start-up screen

5. Add static text. Open a blank page (step 3), then on the toolbar click . Double-click the blank page to display the **Static Text Setting** dialog box, and then enter the static text.



6. Add a static bitmap. Open a blank page (step 3), then on the toolbar, click . Double-click the blank page to display the **Static Bitmap Setting** dialog box where you can choose the bitmap.




You can only use images in the BMP format. Click the image and then click Open to show the image in the page.

- 7. Add a geometric bitmap. There are 11 kinds of geometric bitmaps to choose. Open a new blank page (step
 - 3), then on the toolbar click the geometric bitmap icon that you need

 In the page, drag the geometric bitmap and enlarge it to the size that you need.

Chapter 7 Optional Accessories | MS300


8. When you finish editing the start-up screen, on the Communication menu, click Input User Defined Keypad Starting Screen.




- 9. Download the new setting: On the **Tool** menu, click **Communication**. Set up the communication port and speed for the IFD6530. There are three speeds available: 9600 bps, 19200 bps, and 38400 bps.
- 10. On the Communication menu, click Input User Defined Keypad Starting Screen.



11. The Editor displays a message asking you to confirm the new setting. Before you click **OK**, on the keypad, go to MENU, select PC LINK, press ENTER and then wait for few seconds. Then click **YES** in the confirmation dialog box to start downloading.



- 2) Edit the Main Page and Download to the Keypad
 - In the Editor, add a page to edit. On the Edit menu, click Add a New Page. You can also right-click on the
 TP page in the upper right corner of the Design window and click Add to add one more pages to edit.
 This keypad currently supports up to 256 pages.



2. In the bottom right-hand corner of the Editor, click the page number to edit, or on the View menu, click HMI Page to start editing the main page. As shown in the picture above, the following objects are available. From left to right they are: Static Text, ASCII Display, Static Bitmap, Scale, Bar Graph, Button, Clock Display, Multi-state bit map, Units, Numeric Input, the 11 geometric bitmaps, and lines of different widths. Use the same steps to add Static Text, Static Bitmap, and geometric bitmaps as for the start-up page.



3. Add a numeric/ASCII display. On the toolbar, click the **Numeric/ASCII** button. In the page, double-click the object to specify the **Refer Device**, **Frame Setting**, **Font Setting** and **Alignment**.




Click [...]. In the **Refer Device** dialog box, choose the VFD communication port that you need. If you want to read the output frequency (H), set the **Absolute Addr.** to 2202. For other values, refer to the ACMD Modbus Comm Address List (see Pr.09-04 in Chapter 12 Group 09 Communication Parameters).

Chapter 7 Optional Accessories | MS300




4. Scale Setting. On the toolbar, click to add a scale. You can also edit the Scale Setting in the Property Window on the right-hand side of your computer screen.




- a. Scale Position: specifies where to place the scale.
- b. **Scale Side**: specifies whether the scale is numbered from smaller numbers to larger numbers or from larger to smaller.
- c. Font Setting: specifies the font.
- d. Value Length: specifies 16 bits or 32 bits.
- e. **Main Scale & Sub-Scale**: divides the whole scale into equal parts; enter the numbers for the main scale and sub-scale.
- f. Max Value & Min Value: specifies the numbers on the two ends of the scale. They can be negative numbers, but the maximum and minimum values are limited by the Value Length setting. For example, when Value Length is hexadecimal (16 bits), the maximum and the minimum value cannot be entered as -40000.


Clicking **OK** creates a scale as in the picture below.



5. Bar Graph setting. On the toolbar, click to add a bar graph.



- a. Refer Device: specifies the VFD communication port.
- b. **Direction Setting**: specifies the direction: **From Bottom to Top**, **From Top to Bottom**, **From Left to Right** or **From Right to Left**.
- c. **Max Value** and **Min Value**: specifies the maximum value and minimum value. A value smaller than or equal to the minimum value causes the bar graph to be blank (0). A value is bigger or equal to the maximum value causes the bar graph is full (100%). A value between the minimum and maximum values causes the bar graph to be filled proportionally.
- 6. Button: on the toolbar, click . Currently this function only allows the keypad to switch pages; other functions are not yet available (including text input and insert image). In the blank page, double-click to open the Button Setting dialog box.




Button Type: specifies the button's functions.

Page Jump and **Constant Setting** are the only functions currently supported.

A. Page Jump Setting


- Page Jump Setting: in the Button Type list, choose Page Jump to show the Page Jump Setting.
- Function Key: specifies the functions for the following keys on the KPC-CC01 keypad: F1, F2, F3, F4, Up, Down, Left and Right. Note that the Up and Down keys are locked by TPEditor. You cannot program these two keys. If you want to program Up and Down keys, on the Tool menu, click Function Key Setting, and then click Re-Define Up/Down Key.



Button Text: specifies the text that appears on a button. For example, when you enter Next Page
for the button text, that text appears on the button.

B. Constant Setting

This function specifies the memory address' values for the VFD or PLC. When you press the **Function Key**, it writes a value to the memory address specified by the value for **Constant Setting**. You can use this function to initialize a variable.




7. Clock Display Setting: on the toolbar, click . You can display the time, day, or date on the keypad.

Open a new page and click once in that window to add a clock display.


Choose to display **Time**, **Day**, or **Date** on the keypad. To adjust time, go to #8 on the keypad's menu. You can also specify the **Frame Setting**, **Font Setting**, and **Alignment**.




8. Multi-state bitmap: on the toolbar, click . Open a new page and click once in that window to add a Multi-state bitmap. This object reads a bit's property value from the PLC. It defines the image or text that appears when this bit is 0 or 1. Set the initial status (**Current State**) to be 0 or 1 to define the displayed image or text.



9. Unit Measurement: on the toolbar, click P. Open a new blank page, and double-click on that window to display the Units Setting dialog box. Choose the Metrology Type and the Unit Name. For Metrology, the choices are Length, Square Measure, Volume/Solid Measure, Weight, Speed, Time, and Temperature. The unit name changes automatically when you change metrology type.



Numeric Input Setting: on the toolbar, click ...
 This object enables you to provide parameters or communication ports (0x22xx) and to input numbers.
 Open a new file and double click on that window to display the Numeric Input Setting dialog box.



- a. Refer Device: specifies the Write and the Read values. Enter the numbers to display and the corresponding parameter and communication port numbers. For example, enter 012C to Read and Write Parameter Pr.01-44.
- b. OutLine Setting: specifies the Frame Setting, Font Setting, Hori. Alignment, and Vert. Alignment for the outline.
- c. **Function Key**: specifies the function key to program on the keypad in the **Function Key** box. The corresponding key on the keypad starts to blink. Press ENTER to confirm the setting.
- d. Value Type and Value Length: specify the range of the Min Value and Max Value for the Limit Setting. Note that the corresponding supporting values for MS300 must be 16 bits. 32-bit values are not supported.
- e. Value Setting: automatically set by the keypad itself.
- f. **Limit Setting**: specifies the range for the numeric input here.


For example, if you set **Function Key** to **F1**, **Min Value** to 0 and **Max Value** to 4, when you press F1 on the keypad, then you can press Up/Down on the keypad to increase or decrease the value. Press ENTER on the keypad to confirm your setting. You can also view the parameter table 01-44 to verify if you correctly entered the value.


Chapter 7 Optional Accessories | MS300


11. Download the TP page. Press Up/Down on the keypad to select #15 PC Link.


Then press ENTER on the keypad. The screen displays "Waiting". In TPEditor, choose a page that you have created, and then on the **Communication** menu click **Write to TP** to start downloading the page to the keypad

When you see "Completed" on the keypad screen, the download is finished. You can then press ESC on the keypad to go back to the menu screen.










7-14-4 Digital Keypad KPC-CC01 Fault Codes and Descriptions



Fault Codes

LCD Display *	Description	Corrective Actions
Fault FrEr kpd Flash Read Er	Keypad flash memory read error	 Error in the keypad's flash memory. Press RESET to clear the errors. Check for any problem on Flash IC. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your authorized local dealer for assistance.
Fault FsEr kpd Flash Save Er	Keypad flash memory save error	 Error in the keypad's flash memory. Press RESET to clear the errors. Check for any problem on Flash IC. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your authorized local dealer for assistance.
Fault FPEr kpd Flash Pr Er	Keypad flash memory parameter error	Error in the default parameters. It might be caused by a firmware update. 1. Press RESET to clear the errors. 2. Check for any problem on Flash IC. 3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.
Fault VFDr Read VFD Info Er	Keypad error when reading AC motor drive data	Keypad cannot read any data sent from the VFD. 1. Verify that the keypad is properly connected to the motor drive by a communication cable such as R M5.
Fault CPUEr CPU Error	Keypad CPU error	 A serious error in the keypad's CPU. 1. Check for any problem on CPU clock. 2. Check for any problem on Flash IC. 3. Check for any problem on RTC IC. 4. Verify that the communication quality of the RS-485 cable is good. 5. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.


Warning Codes

LCD Display *	Description	Corrective Actions
Warning CE1 Comm. Error 1	Modbus function code error	 Motor drive does not accept the communication command sent from the keypad. 1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45. 2. Press RESET to clear the errors. If none of the above solutions works, contact your local authorized dealer for assistance.
Warning CE2 Comm. Error 2	Modbus data address error	 Motor drive does not accept the keypad's communication address. 1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45. 2. Press RESET to clear the errors. If none of the above solutions works, contact your local authorized dealer for assistance.
Warning CE3 Comm. Error 3	Modbus data value error	 Motor drive does not accept the communication data sent from the keypad. 1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45. 2. Press RESET to clear the errors. If none of the above solution works, contact your local authorized dealer for assistance.
Warning CE4 Comm. Error 4	Modbus slave drive error	 Motor drive cannot process the communication command sent from the keypad. 1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45. 2. Press RESET to clear the errors. 3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.
Warning CE10 Comm. Error 10	Modbus transmission time-out	 Motor drive does not respond to the communication command sent from the keypad. 1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45. 2. Press RESET to clear the errors. 3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.
Warning TPNO TP No Object	Object not supported by TPEditor	If none of the above solution works, contact your local authorized dealer. Keypad's TPEditor uses an unsupported object. 1. Verify that the TPEditor is not using an unsupported object or setting. Delete unsupported objects and unsupported settings. 2. Re-edit the object in the TPEditor, and then download it to the keypad. If none of the above solutions works, contact your local authorized dealer for assistance.

The warning code CExx only occurs when the communication problem is between the drive and the keypad. It has nothing to do with the drive and other devices. Note the warning code description to find the cause of the error if CExx appears.

File Copy Setting Fault Description:

These faults occur when KPC-CC01 cannot perform the command after clicking the ENTER key in the copy function.



100.01			
LCD Display *	Description	Corrective Actions	
ERR1 Read Only	Parameter and file are read-only	The parameter/file is read-only and cannot be written to. 1. Verify the specification in the user manual. If this solution does not work, contact your local authorized dealer for assistance.	
P00-00 ERR2 Write Fail	Fail to write parameter and file	 An error occurred while writing to a parameter/file. 1. Check for any problem on Flash IC. 2. Shut down the system, wait for ten minutes, and then restart the system. If this solution does not work, contact your local authorized dealer for assistance. 	
P00-00 ERR3 VFD Running	AC motor drive is in operating status	A setting cannot be changed while the motor drive is in operation. 1. Verify that the drive is not in operation. If this solution does not work, contact your local authorized dealer for assistance.	
001> P00-00 ERR4 Pr Lock	AC motor drive parameter is locked	A setting cannot be changed because a parameter is locked. 1. Check if the parameter is locked. If it is locked, unlock it and try to set the parameter again. If this solution does not work, contact your local authorized dealer for assistance.	
P00-00 ERR5 Pr Changing	AC motor drive parameter is changing	 A setting cannot be changed because a parameter is being modified. 1. Check if the parameter is being modified. If it is not being modified, try to change that parameter again. If this solution does not work, contact your local authorized dealer for assistance. 	
P00-00 ERR6 Fault Code	Fault code is not cleared	 A setting cannot be changed because an error has occurred in the motor drive. 1. Check if an error occurred in the motor dive. If there is no error, try to change the setting again. If this solution does not work, contact your local authorized dealer for assistance. 	
P00-00 ERR7 Warning Code	Warning code is not cleared	A setting cannot be changed because of a warning message given to the motor drive. 1. Check if there is a warning message given to the motor drive. If this solution does not work, contact your local authorized dealer for assistance.	
P00-00 ERR8 Type Mismatch	File type mismatch	 Data to be copied are not the correct type, so the setting cannot be changed. 1. Check if the products' serial numbers to be copied are in the same category. If they are in the same category, try to copy the setting again. If this solution does not work, contact your authorized dealer for assistance. 	

Chapter 7 Optional Accessories | MS300

LCD Display *	Description	Corrective Actions	
P00-00 ERR9 Password Lock	File is locked with password	 A setting cannot be changed because some data are locked. 1. Check if the data are unlocked or able to be unlocked. If the data are unlocked, try to change the setting again. 2. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your authorized dealer for assistance. 	
P00-00 ERR10 Password Fail	File password mismatch	 A setting cannot be changed because the password is incorrect. 1. Check if the password is correct. If the password is correct, try to change the setting again. 2. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your authorized dealer for assistance. 	
001> P00-00 ERR11 Version Fail	File version mismatch	A setting cannot be changed because the version of the data is incorrect. 1. Check if the version of the data matches the motor drive. If it matches, try to change the setting again. If this solution does not work, contact your authorized dealer for assistance.	
001> P00-00 ERR12 VFD Time Out	AC motor drive copy function time-out	 A setting cannot be changed because the data copying time-out expired. 1. Try copying the data again. 2. Check if copying data is authorized. If it is authorized, try to copy the data again. 3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your authorized dealer for assistance. 	


[※] The content in this section only applies to the KPC-CC01 keypad V1.01 and later versions...

7-14-5 Unsupported Functions when Using TPEditor with the KPC-CC01


1. Local Page Setting and Global Setting functions are not supported.



2. In the Communication menu, Read from TP function is not supported.



3. In the RTC Display Setting, you cannot change the Refer Device.



Chapter 7 Optional Accessories | MS300

[This page intentionally left blank]

Chapter 8 Option Cards


8- I	Option Card Installation
8-2	CMM-PD02 Communication Extension Card, PROFIBUS DR
8-3	CMM-DN02 Communication Extension Card, DeviceNet
8-4	CMM-EIP02 Communication Extension Card, EtherNet/IP
8-5	CMM-COP02 Communication Extension Card, CANopen
8-6	CMM-EC02 Communication Extension Card, EtherCAT
8-7	EMM-BPS02 +24 V Power Card
8-8	Delta Standard Fieldbus Cables

Chapter 8 Option Cards | MS300

The option cards in this chapter are optional accessories. Select the applicable option cards for your motor drive, or contact your local distributor for suggestions. The option cards can significantly improve the efficiency of the motor drive. To prevent damage to the motor drive during installation, remove the digital keypad and the cover before wiring.

8-1 Option Card Installation


Mounting Position of Option Cards



Note: Frame E and F does not support a second option card installation, so there is no mounting position 2.

The Wiring of Option Cards

MS300 control board connector



Option card connector




Figure 8-4

Figure 8-3

Attention: Do NOT misuse the cables for the communication cards and the cables for the power card. You must read the descriptions on the cables before wiring.

Communication Card Cables

To correctly use the communication cards, you must purchase the communication card along with the connection cables. Check your communication card models first. Then, select your applicable connection cables according to the mounting positions by different frames. Two cable length are available for your choice. See the table below to select your applicable communication card cables.

Communication	CMM-DN02, CMM-EIP02,		CMM-EC02	
Card	CMM-PD02, CMM-COP02			
Frame	Mounting Position 1	Mounting Position 2	Mounting Position 1	Mounting Position 2
Frame	Cable Model#	Cable Model#	Cable Model#	Cable Model#
А	CBM-CL01A	CBM-CC01A	CBM-CL01A	CBM-CL01A
В	CDIVI-CLUTA	CBM-CC02A	CBIVI-CLUTA	CBM-CL02A
С			CBM-CL02A	
D	CBM-CL02A			
E	ODIVI-OLUZA	N/A		N/A
F				



An option card mounting box is included upon purchasing the communication card CMM-EC02, you need to purchase it with CBM-CL01A or CBM-CL02A




Figure 8-5




Figure 8-6

Power Card Cables

An option card mounting box and cables with two different length are included when you purchase the power card EMM-BPS02 (DC 24 V backup power supply card), so you do not need to purchase it with the connection cables. "BPS use only" and "# S" or "# L" are marked on the EMM-BPS02 power card cable. See the table below to select your applicable power card cables according to different mounting positions.

Power Card	EMM-BPS02		
F	Mounting Position 1	Mounting Position 2	
Frame —	Cable Model#	Cable Model#	
A	# S	# S	
В	#5		
С		# L	
D	# L		
E	# L	N/A	
F		IV/A	



Figure 8-7





Figure 8-8

Option Card Mounting Position 1

Installation method: Back-mount the option card by connecting flat cables to the control board.


- 1. Turn off the power of the motor drive, and then remove the front cover, as shown in Figure 8-9.
- 2. Assemble the connection cable: Connect the connector at one end of the connection cable to the control board connector. Refer to Section 8-1 **The Wiring of Option Cards** for more information on connection methods.
- 3. Assemble the supported frame of the option card: Aim the two clips at the two slots on the motor drive, and then press downward to have the two clips engage the slots, as shown in Figure 8-10.
- 4. Assemble the connection cable: Connect the connector at the other end of the connection cable to the connector of the option card.
- 5. Assemble the option card: Have the terminal block and connector of the option card face downward, aim the two holes of the option card to the position column and press downward so that the three clips engage the option card, as shown in Figure 8-11.
- 6. Make sure that three clips properly engage the option card and then tighten the screws (suggested torque value: 4–6 kg-cm [3.5–5.2 lb-in.] [0.39–0.59 Nm]), as shown in Figure 8-12.
- 7. Assembly is completed, as shown in Figure 8-13.



Option Card Mounting Position 2 (Frame A–D)


Installation method: Front-mount the option card by connecting flat cables to the control board.

- 1. Turn off the power of the motor drive and then remove the front cover, as shown in Figure 8-14.
- 2. Assemble the option card: Detach the upper cover of the mounting box for the option card by slipping and make the terminal block and connector of the option card face upward. Fix the front end of the option card to the slots, and then rotate it, as shown in the Figure 8-15.
- 3. Make sure that two clips properly engage the option card on the backside, and then tighten the screws (suggested torque value: 4–6 kg-cm [3.5–5.2 lb-in.] [0.39–0.59 Nm]), as shown in Figure 8-16.
- 4. Assemble the connection cable: Connect the connector at one end of the connection cable to the control board connector. Refer to Section 8-1 The Wiring of Option Cards for more information on connection methods.
- 5. Attach the front cover of the drive.
- Assemble the connection cable: Connect the connector at the other end of the connection cable to the connector of the option card.
- 7. Attach the upper cover to the mounting box for the option card, as shown in Figure 8-17.
- 8. Assemble the mounting box for the option card: Aim the four clips of the mounting box for the option card at the slots on the upper cover of the motor drive, and then press downward to have the four clips engage the slots, as shown in the Figure 8-18.



Grounded installation

You must ground the option cards as listed below when wiring. The ground terminal is included in the option card package, as shown in Figure 8-20.



Installation of the ground terminal:

The B end of the grounding wire connects to the ground terminal block of the option card, as the No.6 shows in Figure 8-21 (see Chapter 8 for the ground terminal block position of other option cards). The A end of the grounding wire connects to the drive's PE, as the circles show in Figure 8-22 and Figure 8-23.




Figure 8-21

Frame A-C




Figure 8-22

0
3

a	DC-	DC+/+1	+2461	B2	•	\checkmark

D, E

Frame D-F


Frame	ne Screw Spec. Torque (±10%)	
Α	M3.5	9 kg-cm [7.8 lb-in] [0.88 Nm]
В	M4	15 kg-cm [13.0 lb-in] [1.47 Nm]
С	M4	20 kg-cm [17.4 lb-in] [1.96 Nm]

Frame	Screw Spec.	Torque (±10%)
D	M4	20 kg-cm [17.4 lb-in] [1.96 Nm]
E	M5	25 kg-cm [21.7 lb-in] [2.45 Nm]
F	M4	20 kg-cm [17.4 lb-in] [1.96 Nm]

Figure 8-23

8-2 CMM-PD02

■ Product Profile



- 1. Screw fixing hole
- 2. Positioning hole
- 3. AC motor drive connection port
- 4. Communication port
- . Indicator
- NET1, NET2
- Ground terminal block

■ Features

- 1. Supports PZD control data exchange.
- 2. Supports PKW access AC motor drive parameters.
- 3. Supports user diagnosis function.
- 4. Auto-detects baud rates; supports a maximum of 12 Mbps.

Specifications

PROFIBUS DP Connector

Interface	DB9 connector	
Transmission method	High-speed RS-485	
Transmission cable Shielded twisted-pair cable		
Electrical isolation	500 V _{DC}	

Communication

Message type	Cyclic data exchange	
Module name	CMM-PD02	
GSD document	DELA08DB.GSD	
Product ID	08DB (HEX)	
Serial transmission speed	9.6 kbps; 19.2 kbps; 93.75 kbps; 187.5 kbps; 500 kbps; 1.5 Mbps; 3 Mbps;	
supported (auto-detection)	6 Mbps; 12 Mbps (bits per second)	

Electrical Specification

Power supply voltage	15 V _{DC} (supplied by the AC motor drive)	
Insulation voltage	500 V _{DC}	
Power consumption	1 W	
Weight	28 g	


Environment

	ESD (IEC 61800-5-1, IEC 6100-4-2)	
N1 - 1 1 16	EFT (IEC 61800-5-1, IEC 6100-4-4)	
Noise immunity	Surge Test (IEC 61800-5-1, IEC 6100-4-5)	
	Conducted Susceptibility Test (IEC 61800-5-1, IEC 6100-4-6)	
Operation / storage	Operation: -10–50°C (temperature), 90% (humidity)	
Operation / storage	Storage: -25–70°C (temperature), 95% (humidity)	
Shock / vibration International standards:		
resistance	IEC 61131-2, IEC 68-2-6 (TEST Fc) / IEC 61131-2 & IEC 68-2-27(TEST Ea)	

■ Installation

PROFIBUS DP Connector

PIN	Signal	Definition
1	-	Not defined
2	-	Not defined
3	Rxd / Txd-P	Sending / receiving data P(B)
4	-	Not defined
5	DGND	Data reference ground
6	VP	Power voltage – positive
7	-	Not defined
8	Rxd / Txd-N	Sending / receiving data N(A)
9	-	Not defined



■ LED Indicator & Troubleshooting

There are two LED indicators on the CMM-PD02: POWER LED and NET LED. POWER LED displays the status of the working power. NET LED displays the connection status of the communication.

POWER LED

LED status	Indication	Corrective Action
Green light on	Power supply in normal status.	No action is required.
Off	No power	Check if the connection between the CMM-PD02 and the AC motor drive is normal.

NET LED

LED status	Indication	Corrective Action
Green light on	Normal status	No action is required.
Red light on	The CMM-PD02 is not connected to PROFIBUS DP bus.	Connect the CMM-PD02 to the PROFIBUS DP bus.
Red light flashes	Invalid PROFIBUS communication address	Set the PROFIBUS address of the CMM-PD02 between 1–125 (decimal).
Orange light flashes	The CMM-PD02 fails to communicate with the AC motor drive.	Switch off the power and check whether the CMM-PD02 is correctly installed and normally connected to the AC motor drive.

Screw fixing

Positioning hole AC motor drive

connection port

Communication

terminal block

hole

Port

6.


Indicator NET1, NET2

Ground

8-3 CMM-DN02

Product Profile





99999 Wire gauge: 0.25-0.5 mm² [24-20 AWG]

Stripping length: 7-8 mm

Screw torque: 2 kg-cm / [1.7 lb-in.] / [0.2 Nm]

Features

- 1. Based on the high-speed communication interface of Delta's HSSP protocol, the AC motor drive can be controlled in real-time.
- 2. Supports Group 2 only connection and polling I/O data exchange.
- 3. For I/O mapping, supports a maximum of 32 words input and 32 words output.
- Supports EDS file configuration in DeviceNet configuration software.
- Supports all baud rates on DeviceNet bus: 125 kbps, 250 kbps, 500 kbps and extendable baud rate mode.
- Node address and baud rate can be set in the AC motor drive.
- Power is supplied from the AC motor drive. 7.

Specifications

DeviceNet Connector

Interface	5-PIN open pluggable connector. PIN interval: 5.08 mm	
Transmission method	CAN	
Transmission cable	Shielded twisted-pair cable (with 2 power cables)	
Transmission speed	125 kbps, 250 kbps, 500 kbps and extendable baud rate mode	
Network protocol	DeviceNet protocol	

AC Motor Drive Connection Port

Interface	24 PIN communication terminal	
Transmission method	SPI communication	
Terminal function	Communication module communicates with the AC motor drive through this port. The AC motor drive supplies power to communication module through this port.	
Communication protocol	Delta HSSP protocol	

Electrical Specification


Power supply voltage	15 V _{DC} (supplied by the AC motor drive)	
Insulation voltage	500 V _{DC}	
Communication cable power consumption	0.85 W	
Power consumption	1 W	
Weight	23 g	

Environment

	ESD (IEC 61800-5-1, IEC 6100-4-2)	
Noise immunity	EFT (IEC 61800-5-1, IEC 6100-4-4)	
	Surge Test (IEC 61800-5-1, IEC 6100-4-5)	
	Conducted Susceptibility Test (IEC 61800-5-1, IEC 6100-4-6)	
Operation / storage	Operation: -10–50°C (temperature), 90% (humidity)	
Operation / storage	Storage: -25–70°C (temperature), 95% (humidity)	
Shock / vibration International standards:		
resistance	IEC 61800-5-1, IEC 60068-2-6 / IEC 61800-5-1, IEC 60068-2-27	

DeviceNet Connector

De l'idente Commodici			
PIN	Signal	Color	Definition
1	V+	Red	24 V _{DC}
2	Н	White	Signal+
3	S	-	Ground
4	L	Blue	Signal-
5	V-	Black	0 V



■ LED Indicator & Troubleshooting

There are two LED indicators on the CMM-DN02: NS LED and MS LED. NS LED and MS LED are dual-color LEDs, displaying the connection status and error messages of the communication module.

NS LED

LED status	Indication	Corrective Action
Off	No power supply or the CMM-DN02 does not pass the MAC ID test.	 Check the power to the CMM-DN02 and see if the connection is normal. Make sure there is at least one node on the bus. Check if the baud rate of the CMM-DN02 is the same as that of the other nodes.
Green light flashes	The CMM-DN02 is on-line but does not connect to the master.	 Configure the CMM-DN02 to the scan list of the master. Re-download the configured data to the master.

Chapter 8 Option Cards | MS300

Green light on	The CMM-DN02 is on-line and normally connects to the master.	No action is required.
LED status	Indication	Corrective Action
Red light flashes	The CMM-DN02 is on-line, but I/O connection is timed-out.	 Check if the network connection is normal. Check if the master operates normally.
Red light on	 Broken communication MAC ID test failure No network power supply. CMM-DN02 is off-line. 	 Make sure all MAC IDs on the network are unique. Check if the network installation is normal. Check if the baud rate of the CMM-DN02 is the same as that of the other nodes. Check if the node address of the CMM-DN02 is illegal. Check if the network power supply is normal.


MS LED


LED status	Indication	Corrective Action
Off	No power supply or device is off-line	Check the power supply of the CMM-DN02 and see if the connection is normal.
Green light flashes	Waiting for I/O data	Switch the master PLC to RUN status.
Green light on	I/O data is normal	No action is required.
Red light flashes	Mapping error	 Reset the CMM-DN02. Re-power the AC motor drive.
Red light on	Hardware error	 See the fault codes displayed on the keypad and find the causes. Return the unit to the factory for repair if necessary.
Orange light flashes	The CMM-DN02 is connecting with the AC motor drive.	If the flashing lasts for a long period of time, turn off the power to check if the CMM-DN02 and the AC motor drive install correctly and are normally connected to each other.

8-4 CMM-EIP02

■ Product Profile







- Screw fixing hole
- 2. Positioning hole
- 3. AC motor drive connection port
 - Communication port

Indicator NET1, NET2

Ground terminal block

Wire gauge: 0.25-0.5 mm² [24-20 AWG]

Stripping length: 7–8 mm

Screw torque: 2 kg-cm / [1.7 lb-in.] / [0.2 Nm]

■ Features

- 1. Supports Modbus TCP and EtherNet/IP protocol
- 2. 32 / 32 words parameter reading / writing correspondence
- 3. User-defined corresponding parameters
- 4. MDI / MDI-X auto-detect
- 5. E-mail alarm
- 6. IP filter simple firewall function

■ Specifications

Network Interface

Interface	RJ45 with Auto MDI / MDIX
Number of ports	1 Port
Transmission method	IEEE 802.3, IEEE 802.3u
Transmission cable	Category 5e shielding 100 M
Transmission speed	10/100 Mbps Auto-Detect
Notwork protocol	ICMP, IP, TCP, UDP, DHCP, HTTP, SMTP, Modbus over TCP/IP, EtherNet/IP,
Network protocol	Delta Configuration

Electrical Specification

Power supply voltage	15 V _{DC}
Insulation voltage	500 V _{DC}
Power consumption	0.8 W
Weight	25 g


Environment

	TCD /ITC 64000 F 4 ITC 64000 4 0)
	ESD (IEC 61800-5-1, IEC 61000-4-2)
Noise immunity	EFT (IEC 61800-5-1, IEC 61000-4-4)
Noise initiality	Surge Test (IEC 61800-5-1, IEC 61000-4-5)
	Conducted Susceptibility Test (IEC 61800-5-1, IEC 61000-4-6)
Operation / storage	Operation: -10–50°C (temperature), 90% (humidity)
Operation / Storage	Storage: -25–70°C (temperature), 95% (humidity)
Shock / vibration resistance	International standards:
SHOCK / VIDIATION TESISTANCE	IEC 61800-5-1, IEC 60068-2-6 / IEC 61800-5-1, IEC 60068-2-27

■ Installation

Connecting the CMM-EIP02 to the Network

- 1. Turn off the power of the drive.
- 2. Open the front cover of the drive.
- Connect the CAT-5e network cable to the RJ45 port of the CMM-EIP02 (as shown in the right figure).



RJ45 PIN Definition

PIN	Signal	Definition
1	Tx+	Positive pole for data transmission
2	Tx-	Negative pole for data transmission
3	Rx+	Positive pole for data reception
4		N/C

PIN	Signal	Definition
5		N/C
6	Rx-	Negative pole for data reception
7		N/C
8		N/C



VFD-MS300 Communication Parameter Settings when Connecting to Ethernet

When you connect the VFD-MS300 to Ethernet, set up the communication parameters based on the table below. The Ethernet master reads and writes the frequency command words and operation command words after you set the communication parameters.

Parameters	Function	Current Setting Value	Description
00-20	Master frequency command source	8	The frequency command is controlled by the communication card.
00-21	Operation command source	5	The operation command is controlled by the communication card.
09-30	Communication decoding method	0	The decoding method for Delta AC motor drive.
09-75	IP configuration	0	0: Static IP 1: Dynamic IP (DHCP)
09-76	IP address 1	192	IP address <u>192</u> .168.1.5
09-77	IP address 2	168	IP address 192. <u>168</u> .1.5

Chapter 8 Option Cards | MS300

Parameters	Function	Current Setting Value	Description
09-78	IP address 3	1	IP address 192.168. <u>1</u> .5
09-79	IP address 4	5	IP address 192.168.1. <u>5</u>
09-80	Netmask 1	255	Netmask <u>255</u> .255.255.0
09-81	Netmask 2	255	Netmask 255. <u>255</u> .255.0
09-82	Netmask 3	255	Netmask 255.255. <u>255</u> .0
09-83	Netmask 4	0	Netmask 255.255.255. <u>0</u>
09-84	Default gateway 1	192	Default gateway <u>192</u> .168.1.1
09-85	Default gateway 2	168	Default gateway 192. <u>168</u> .1.1
09-86	Default gateway 3	1	Default gateway 192.168. <u>1</u> .1
09-87	Default gateway 4	1	Default gateway 192.168.1. <u>1</u>

■ LED Indicator & Troubleshooting

There are two LED indicators on the CMM-EIP02: POWER LED and LINK LED. POWER LED displays the status of the working power. LINK LED displays the connection status of the communication.

LED Indicators

LED	Status		Indication	Corrective Action
POWER	/ER Green On Off		Power supply in normal status	No action is required.
POWER			No power supply	Check the power supply.
LINK Green		On	Network connection in normal status	No action is required.
	Flashes	Network in operation	No action is required.	
		Off	Network not connected	Check if the network cable is connected.

Troubleshooting


Abnormality	Cause	Corrective Action
DOMED LED -#	The AC motor drive is not powered.	Check the power of the AC motor drive, and see if the power supply is normal.
POWER LED off	The CMM-EIP02 is not connected to the AC motor drive.	Ensure that the CMM-EIP02 is connected to the AC motor drive.
LINK LED off	The CMM-EIP02 is not connected to network.	Ensure that the network cable is correctly connected to network.
LINK LED off	Poor contact to the RJ45 connector	Ensure that the RJ45 connector is connected to the Ethernet port.
Connet find	The CMM-EIP02 is not connected to the network.	Ensure that the CMM-EIP02 is correctly connected to the network.
Cannot find communication card	The PC and the CMM-EIP02 are in different networks and blocked by network firewall.	Search by IP or set up relevant settings using the AC motor drive keypad.

Chapter 8 Option Cards | MS300

Abnormality	Cause	Corrective Action
	The CMM-EIP02 is not connected to the network.	Ensure that the CMM-EIP02 is correctly connected to the network.
Cannot open CMM-EIP02 setup page	Incorrect communication setting in DCISoft	Ensure that the communication setting in DCISoft is set to Ethernet.
page	The PC and the CMM-EIP02 are in different networks and blocked by network firewall.	Set up with the AC motor drive keypad.
The CMM-EIP02 setup page opens successfully but webpage monitoring is unavailable	Incorrect network setting in the CMM-EIP02	Check if the network setting for the CMM-EIP02 is correct. For the Intranet setting in your company, please consult your IT staff. For the Internet setting at home, please refer to the network setting instructions provided by your ISP.
	Incorrect network setting in the CMM-EIP02	Check if the network setting for the CMM-EIP02 is correct.
Cannot send e-mails	Incorrect mail server setting	Confirm the IP address for the SMTP-Server.

8-5 CMM-COP02

■ Product Profile



Screw torque: 2 kg-cm / [1.7 lb-in.] / [0.2 Nm]

- 1. Screw fixing hole
- 2. Positioning hole
- 3. AC motor drive connection port
- 4. Communication port
- Indicator NET1, NET2
- 6. Ground terminal block

■ RJ45 Pin Definition




PIN	Signal	Definition	
1	CAN_H	CAN_H bus line (dominant high)	
2	CAN_L	CAN_L bus line (dominant low)	
3	CAN_GND	Ground / 0 V / V-	
7	CAN_GND	Ground / 0 V / V-	

■ Specifications

Interface	RJ45	
Number of ports	2 Port	
Transmission method	CAN	
Transmission cable	CAN standard cable	
Transmission speed	1 Mbps; 500 kbps; 250 kbps; 125 kbps; 100 kbps; 50 kbps	
Communication protocol	CANopen protocol	
	CMM-COP02 contains terminal resistance accessories.	
Terminating resistance	Install the terminal resistance accessories to one of the network connectors	
	when using CMM-COP02.	

■ CANopen Communication Cable





Chapter 8 Option Cards | MS300


Title	Part No.	L	
		mm	inch
1	UC-CMC003-01A	300	11.8
2	UC-CMC005-01A	500	19.6
3	UC-CMC010-01A	1000	39
4	UC-CMC015-01A	1500	59
5	UC-CMC020-01A	2000	78.7
6	UC-CMC030-01A	3000	118.1
7	UC-CMC050-01A	5000	196.8
8	UC-CMC100-01A	10000	393.7
9	UC-CMC200-01A	20000	787.4

■ CANopen Dimension

Model: TAP-CN03 Unit: mm [inch]










For details on how to operate the CANopen communication card, refer to the CANopen operation manual or download the related manuals from Delta's website at http://www.delta.com.tw/industrialautomation/.

8-6 CMM-EC02

■ Product Profile



Screw torque: 2 kg-cm / [1.7 lb-in.] / [0.2 Nm]

- 1. Screw fixing hole
- 2. Positioning hole
- 3. AC motor drive connection port
- 4. Communication port
 - 5. Indicator
- 6. +24V terminal block

■ Features

- 1. Supports speed mode
- 2. Supports standard CANopen CiA 402 decoding (CoE)
- 3. Supports reading and writing parameters
- 4. Supports stop during disconnection


Specifications

Network Interface

Interface	RJ45	
Number of ports	2 ports	
Transmission method	IEEE 802.3, IEEE 802.3u	
Transmission cable	Category 5e shielding 100M	
Transmission speed	100 Mbps	

8-7 EMM-BPS02

■ Product Profile



Screw fixing hole
 Positioning hole

- 3. AC motor drive connection port
 - . +24 V terminal block

Wire gauge: 0.25-0.5 mm² [24-20 AWG]

Stripping length: 7-8 mm

Screw torque: 2 kg-cm / [1.7 lb-in.] / [0.2 Nm]

■ Features

- 1. Provides external power supply
- 2. Supports 24 V_{DC} input.
- 3. Supports parameter reading and writing and status monitoring of the drive.

Specifications

When the drive is only powered by the EMM-BPS02, the EMM-BPS02 ensures the communication works normally, and supports all communication cards and the following functions.

- Parameter reading and writing
- Keypad display
- Keys on the keyboard panel (except the RUN key)
- Analog input with +10 V terminal supply power
- Multi-function inputs (FWD, REV, MI1–MI7) with +24 V terminal or external power supply
- Relay output
- Pulse sequence frequency command

The following functions does not support:

- DFM digital frequency signal output
- AFM multi-function analog voltage output
- PLC functions

8-8 Delta Standard Fieldbus Cables

Delta Cables	Part Number	Description	Length
	UC-CMC003-01A	CANopen cable, RJ45 connector	0.3 m
	UC-CMC005-01A	CANopen cable, RJ45 connector	0.5 m
	UC-CMC010-01A	CANopen cable, RJ45 connector	1 m
CANopen Cable /	UC-CMC015-01A	CANopen cable, RJ45 connector	1.5 m
Digital Keypad RJ45	UC-CMC020-01A	CANopen cable, RJ45 connector	2 m
Extension Lead	UC-CMC030-01A	CANopen cable, RJ45 connector	3 m
	UC-CMC050-01A	CANopen cable, RJ45 connector	5 m
	UC-CMC100-01A	CANopen cable, RJ45 connector	10 m
	UC-CMC200-01A	CANopen cable, RJ45 connector	20 m
DeviceNet Cable	UC-DN01Z-01A	DeviceNet cable	305 m
Devicervet Cable	UC-DN01Z-02A	DeviceNet cable	305 m
	UC-EMC003-02A	Ethernet / EtherCAT cable, Shielding	0.3 m
	UC-EMC005-02A	Ethernet / EtherCAT cable, Shielding	0.5 m
	UC-EMC010-02A	Ethernet / EtherCAT cable, Shielding	1 m
Ethernet / EtherCAT Cable	UC-EMC020-02A	Ethernet / EtherCAT cable, Shielding	2 m
	UC-EMC050-02A	Ethernet / EtherCAT cable, Shielding	5 m
	UC-EMC100-02A	Ethernet / EtherCAT cable, Shielding	10 m
	UC-EMC200-02A	Ethernet / EtherCAT cable, Shielding	20 m
PROFIBUS Cable	UC-PF01Z-01A	PROFIBUS DP cable	305 m

Chapter 8 Option Cards | MS300

[This page intentionally left blank]

Chapter 9 Specifications

- 9-1 115V Models
- 9-2 230V Models
- 9-3 460V Models
- 9-4 575V Models
- 9-5 General Specifications
- 9-6 Environment for Operation, Storage and Transportation
- 9-7 Derating for Ambient Temperature, Altitude and Carrier Frequency

9-1 115V Models

115V models one-phase (without built-in filter)

		Fra	ame			A	С	
ı	Mode	I VFD		ANSAA ENSAA	1A6MS11	2A5MS11	4A8MS11	
	Apı	olicable Mo	tor Output [l	κW]	0.2 0.4		0.75	
	Applicable Motor Output [HP]			HP]	1/4	1/2	1	
	tuty	Rated Ou	tput Capacit	y [kVA]	0.6	1.0	1.8	
	Heavy duty	Rated Ou	tput Current	[A]	1.6	2.5	4.8	
Output	2	Carrier Fr	equency [k	lz]		2-15 (Default: 4)		
Out	duty	Rated Ou	tput Capacit	y [kVA]	0.7	1.0	2.1	
	Normal duty	Rated Ou	tput Current	[A]	1.8	1.8 2.7		
	Š	Carrier Fr	equency [k	lz]		2-15 (Default: 4)		
	Rat	ted Input	Heavy	Duty	6.0	9.4	18	
	Cu	rrent [A]	Norma	Duty	6.8	20.6		
Input	Rate	ed Voltage	/ Frequency		One-phase 100–120 V _{AC} (-15–10%), 50/60 Hz			
_	M	ains Input \	/oltage Ran	ge [V _{AC}]		85–132		
	ı	Mains Freq	uency Rang	e [Hz]		47–63		
		Weig	ht [kg]		0.65	0.74	1.24	
	Cooling Method				Convective cooling Fan cooling			
	EMC Filter				Optional			
	IP Rating				VFD A NSAA: IP20 VFD _E NSAA : IP40*			

Table 9-1

NOTE

- IP40*: The IP ratings of the wiring area (main circuit terminals and control terminals for frame A/B/C/D/E/F) and the vent near the capacitor (frame C/D/E/F) are both IP20.
- The value of the carrier frequency is a factory default. Decrease the current value if you need to increase the carrier frequency. Refer to Section 9-7 Derating for Ambient Temperature and Altitude for details.
- For shock or impact load applications, select a drive with a larger capacity model.

9-2 230V Models

230V models one-phase (without built-in filter)

		Fran	ne		,	A	В	(С	
M	odel	VFD		ANSAA ENSAA	1A6MS21	2A8MS21	4A8MS21	7A5MS21	11AMS21	
	Applicable Motor Output [kW]			[kW]	0.2	0.4	0.75	1.5	2.2	
	App	licable Moto	r Output	[HP]	1/4	1/2	1	2	3	
	tuty	Rated Out	tput Cap	acity [kVA]	0.6	1.1	1.8	2.9	4.2	
	Heavy duty	Rated O	utput Cu	ırrent [A]	1.6	2.8	4.8	7.5	11	
Output	완	Carrier	Frequen	cy [kHz]			2-15 (Default: 4)			
Out	duty	Rated Out	tput Cap	acity [kVA]	0.7	1.2	1.9	3.2	4.8	
	Normal	Rated O	utput Cu	ırrent [A]	1.8	1.8 3.2 5 8.5				
	Ž	Carrier	Frequen	cy [kHz]			2-15 (Default: 4)			
	Rat	ed Input	Heavy	/ Duty	5.1	7.3	10.8	16.5	24.2	
	Cu	rrent [A]	Norma	al Duty	5.8	8.3	11.3	18.5	27.5	
Input		Rated Volta	ige / Fre	quency	One-phase 200-240 V _{AC} (-15-10%), 50/60 Hz					
_	Ma	ains Input Vo	oltage Ra	ange [V _{AC}]	170–265					
	N	∕lains Frequ	ency Ra	nge [Hz]	47–63					
		Weight	[kg]		0.65	0.76	0.95	1.	24	
	Cooling Method				(Convective cooling	g	Fan c	ooling	
	EMC Filter				Optional					
	IP Rating			VFD A NSAA : IP20 VFD E NSAA : IP40*						

230V models one-phase (with built-in filter)

		Fra	ame			В		(С	
M	odel	VFD		AFSAA	1A6MS21	2A8MS21	4A8MS21	7A5MS21	11AMS21	
	Appl	icable Mo	tor Output	[kW]	0.2	0.4	0.75	1.5	2.2	
	Applicable Motor Output [HP]			[HP]	1/4	1/2	1	2	3	
	luty	Rated Output Capacity [kVA]			0.6	1.1	1.8	2.9	4.2	
	Heavyduty	Rated Output Current [A]			1.6	2.8	4.8	7.5	11	
Output	丑	Carrier Frequency [kHz]					2-15 (Default: 4)			
Out	duty	Rated C	utput Cap	acity [kVA]	0.7	1.2	1.9	3.2	4.8	
	Namal duty	Rated Output Current [A]			1.8 3.2 5 8.5				12.5	
	S	Carrier Frequency [kHz]					2-15 (Default: 4)			
	Rated Input Heavy Duty			y Duty	5.1	7.3	10.8	16.5	24.2	
.	Cur	rent [A]	Normal Duty		5.8 8.3 11.3 18.5			27.5		
Input		Rated Vo	Itage / Fre	quency	One-phase 200–240 V _{AC} (-15–10%), 50/60 Hz					
_	Ма	ins Input	Voltage Ra	ange [V _{AC}]	170–265					
	N	lains Fred	quency Ra	nge [Hz]	47–63					
		Weig	ht [kg]			1.32		1	.8	
	Cooling Method				Convective Fan cooling					
	EMC Filter				Built-in					
	IP Rating				IP20					

Table 9-2

NOTE

- IP40*: The IP ratings of the wiring area (main circuit terminals and control terminals for frame A/B/C/D/E/F) and the vent near the capacitor (frame C/D/E/F) are both IP20.
- The value of the carrier frequency is a factory default. Decrease the current value if you need to increase the carrier frequency. Refer to Section 9-7 Derating for Ambient Temperature and Altitude for details.
- For shock or impart load applications, select a drive with a higher capacity model.

230V models three-phase (without built-in filter)

		Fr	ame			Α		В	С	
M	odel	VFD		ANSAA ENSAA	1A6MS23	2A8MS23	4A8MS23	7A5MS23	11AMS23	
	Appl	licable Mo	otor Output	[kW]	0.2	0.4	0.75	1.5	2.2	
	Applicable Motor Output [HP]			t [HP]	1/4	1/2	1	2	3	
	tuty	Rated C	Output Cap	acity [kVA]	0.6	1.1	1.8	2.9	4.2	
	Heavy duty	Rated	Output Cu	urrent [A]	1.6	2.8	4.8	7.5	11	
Output	윈	Carrie	er Frequen	cy [kHz]			2-15 (Default: 4)			
Out	duty	Rated C	Output Cap	acity [kVA]	0.7	1.2	1.9	3.0	4.8	
	Normal	Rated Output Current [A]		1.8	3.2	5	8	12.5		
	Ž	Carrier Frequency [kHz]				2-15 (Default: 4)				
	Rat	ed Input	Heavy Duty		1.9	3.4	5.8	9.0	13.2	
-	Cui	rrent [A]	Norma	al Duty	2.2	3.8	6.0	9.6	15	
Input		Rated Vo	ltage / Fre	quency	Three-phase 200–240 V _{AC} (-15–10%), 50/60 Hz					
_	Ma	ains Input	Voltage Ra	ange [V _{AC}]	170–265					
	١	/lains Fre	quency Ra	nge [Hz]			47–63			
	Weight [kg]				0.65	0.68	0.81	1.05	1.24	
	Cooling Method				Convective cooling Fan cooling					
	EMC Filter				Optional					
	IP Rating				VFD A NSAA : IP20 VFD _E NSAA : IP40*					

230V models three-phase (without built-in filter)

		Fra	ame		С	D	E	Ē	F	
M	odel	VFD		ANSAA ENSAA	17AMS23	25AMS23	33AMS23	49AMS23	65AMS23	
	App	licable Mc	tor Output	[kW]	3.7 / 4	3.7 / 4 5.5 7.5 11				
	Applicable Motor Output [HP]				5	5 7.5 10 15				
	tuty	Rated C	utput Cap	acity [kVA]	6.5	9.5	12.6	18.7	24.8	
	Heavy duty	Rated Output Current [A]		urrent [A]	17	25	33	49	65	
Output	뫈	Carrie	r Frequen	cy [kHz]	2–15 (Default: 4)					
Ont	duty	Rated C	utput Cap	acity [kVA]	7.4	10.3	13.7	19.4	26.3	
	Normal duty	Rated	Output Cu	urrent [A]	19.5	27	36	51	69	
	No	Carrie	er Frequency [kHz]				2-15 (Default: 4)			
	Rat	ed Input	Heav	y Duty	20.4	30	39.6	58.8	78	
	Cu	rrent [A]	Norma	al Duty	23.4 32.4 43.2 61.2				82.8	
Input		Rated Vo	ltage / Fre	quency	Three-phase 200–240 V _{AC} (-15–10%), 50/60 Hz					
_	Ma	ains Input	Voltage Ra	ange [V _{AC}]	170–265					
	N	/lains Fred	quency Ra	nge [Hz]	47–63					
		Weig	ht [kg]		1.24	2.07	3.9	97	6.25	
	Cooling Method						Fan cooling			
	EMC Filter				Optional					
	IP Rating				VFD A NSAA : IP20 VFD E NSAA : IP40*					

Table 9-3



- IP40*: The IP ratings of the wiring area (main circuit terminals and control terminals for frame A/B/C/D/E/F) and the vent near the capacitor (frame C/D/E/F) are both IP20.
- The value of the carrier frequency is a factory default. Decrease the current value if you need to increase the carrier frequency. Refer to Section 9-7 Derating for Ambient Temperature and Altitude for details.
- For shock or impact load applications, select a drive with a larger capacity model.

9-3 460V Models

460V models three-phase (without built-in filter)

		Fra	me		A	A	В		С		
M	odel	VFD		ANSAA ENSAA	1A5MS43	2A7MS43	4A2MS43	5A5MS43	7A3MS43	9A0MS43	
	App	licable Mot	or Output	[kW]	0.4	0.75	1.5	2.2	3	3.7 / 4	
	App	licable Mot	or Output	[HP]	0.5	1	2	3	4	5	
	duty	Rated Ou	utput Cap	acity [kVA]	1.1	2.1	3.2	4.2	5.6	6.9	
	Heavyo	Rated (Output Cu	ırrent [A]	1.5	2.7	4.2	5.5	7.3	9	
Output	완	Carrier	Frequen	cy [kHz]			2–15 (De	efault: 4)			
Out	duty	Rated Ou	utput Cap	acity [kVA]	1.4	2.3	3.5	5.0	6.1	8.0	
	Normal	Rated (Output Cu	ırrent [A]	1.8	3	4.6	6.5	8	10.5	
	Ž	Carrier	Frequen	cy [kHz]	2–15 (Default: 4)						
	Rat	ed Input	Heavy	/ Duty	1.7	3.0	4.6	6.1	8.1	9.9	
	Cu	rrent [A]	Norma	al Duty	2.0	3.3	5.1	7.2	8.9	11.6	
Input		Rated Volt	age / Fre	quency	Three-phase 380-480 V _{AC} (-15-10%), 50/60 Hz						
-	Ma	ains Input \	/oltage Ra	ange [V _{AC}]	323–528						
	N	∕lains Freq	uency Ra	nge [Hz]	47–63						
	Weight [kg]				0.76	0.81	1.0		1.24		
	Cooling Method				Convective cooling Fan cooling						
	EMC Filter				Optional						
	IP Rating				VFD _A NSAA : IP20 VFD _E NSAA : IP40*						

460V models three-phase (with built-in filter)

		Fr	ame	_		В			С		
M	odel	VFD		AFSAA	1A5MS43	2A7MS43	4A2MS43	5A5MS43	7A3MS43	9A0MS43	
	App	icable Mo	otor Output	[kW]	0.4	0.75	1.5	2.2	3	3.7 / 4	
	Арр	licable Mo	otor Output	[HP]	0.5	1	2	3	4	5	
	luty	Rated C	Output Cap	acity [kVA]	1.1	2.1	3.2	4.2	5.6	6.9	
	Heavyduty	Rated	Output Cu	ırrent [A]	1.5	2.7	4.2	5.5	7.3	9	
Output	Ŧ	Carrie	er Frequen	cy [kHz]			2–15 (D	efault: 4)			
Ont	duty	Rated C	Output Cap	acity [kVA]	1.4	2.3	3.5	5.0	6.1	8.0	
	Namal	Rated Output Current [A]			1.8	3	4.6	6.5	8	10.5	
	Na	Carrier Frequency [kHz]					2–15 (D	efault: 4)			
	Rat	ed Input	Heavy Duty		1.7	3.0	4.6	6.1	8.1	9.9	
-	Cu	rrent [A]	Norma	al Duty	2.0	3.3	5.1	7.2	8.9	11.6	
Input		Rated Vo	ltage / Fre	quency	Three-phase 380–480 V _{AC} (-15–10%), 50/60 Hz						
-	Ma	ins Input	Voltage Ra	ange [V _{AC}]	323–528						
	N	/lains Fre	quency Ra	nge [Hz]	47–63						
		Wei	ght [kg]		1.32 1.80						
	Cooling Method				Fan cooling						
	EMC Filter				Built-in						
		IP F	Rating				IP	20			

Chapter 9 Specifications | MS300

460V models three-phase (without built-in filter)

		F	rame)	E		F		
M	Model VFD ANSAA ENSAA				13AMS43	17AMS43	25AMS43	32AMS43	38AMS43	45AMS43	
	Applicable Motor Output [kW]			[kW]	5.5	7.5	11	15	18.5	22	
	App	licable M	otor Output	[HP]	7.5	10	15	20	25	30	
	tuty	Rated	Output Cap	acity [kVA]	9.9	13	19.1	24.4	29	34.3	
	Heavy duty	Rate	d Output Cu	urrent [A]	13	17	25	32	38	45	
Output	윈	Carr	ier Frequen	cy [kHz]			2–15 (D	efault: 4)			
Ont	duty	Rated	Output Cap	acity [kVA]	12	15.6	21.3	27.4	31.6	37.3	
	Normal	Rate	Output Current [A]		15.7	20.5	28	36	41.5	49	
	Š	Carr	ier Frequen	cy [kHz]			2–15 (D	efault: 4)			
	Rat	ed Input	Heav	y Duty	14.3	18.7	27.5	35.2	41.8	49.5	
	Cu	rrent [A]	Norma	al Duty	17.3	22.6	30.8	39.6	45.7	53.9	
Input		Rated V	oltage / Fre	quency	Three-phase 380–480 V _{AC} (-15–10%), 50/60 Hz						
-	Ma	ains Inpu	t Voltage R	ange [V _{AC}]	323–528						
	N	/lains Fre	equency Ra	nge [Hz]			47-	-63			
	Weight [kg]				2.07 3.97 6.25					25	
	Cooling Method				Fan cooling						
	EMC Filter			Optional							
	IP Rating			VFD A NSAA : IP20 VFD E NSAA : IP40*							

460V models three-phase (with built-in filter)

	Frame				Γ)	E	=	F	
М	Model VFD AFSAA				13AMS43	17AMS43	25AMS43	32AMS43	38AMS43	45AMS43
	Appl	icable Mo	tor Output	[kW]	5.5	7.5	11	15	18.5	22
	Appl	licable Mo	tor Output	[HP]	7.5	10	15	20	25	30
	luty	Rated C	utput Cap	acity [kVA]	9.9	13	19.1	24.4	29	34.3
	Heavy duty	Rated	Output Cu	ırrent [A]	13	17	25	32	38	45
Output	뿐	Carrie	er Frequen	cy [kHz]			2–15 (D	efault: 4)		
Ont	duty	Rated C	utput Cap	acity [kVA]	12	15.6	21.3	27.4	31.6	37.3
	Normal duty	Rated	Output Current [A]		15.7	20.5	28	36	41.5	49
	Po	Carrier Frequency [kHz]					2–15 (D	efault: 4)		
	Rat	ed Input	Heavy Duty		14.3	18.7	27.5	35.2	41.8	49.5
۰,	Cui	rrent [A]	Norma	al Duty	17.3	22.6	30.8	39.6	45.7	53.9
Input		Rated Vo	Itage / Fre	quency	Three-phase 380-480 V _{AC} (-15-10%), 50/60 Hz					
-	Ma	ins Input	Voltage Ra	ange [V _{AC}]	323–528					
	١	/lains Fred	quency Ra	nge [Hz]			47-	-63		
	Weight [kg]				2.91 5.15 8.50					
	Cooling Method				Fan cooling					
	EMC Filter				Built-in					
		IP F	Rating		IP20					

Table 9-4

NOTE

- IP40*: The IP ratings of the wiring area (main circuit terminals and control terminals for frame A/B/C/D/E/F) and the vent near the capacitor (frame C/D/E/F) are both IP20.
- The value of the carrier frequency is a factory default. Decrease the current value if you need to increase the carrier frequency. Refer to Section 9-7 Derating for Ambient Temperature and Altitude for details.

 For shock or impact load applications, select a drive with a larger capacity model.

9-4 575V Models

575V models three-phase (without built-in filter)

		F	rame		Α	В	(D			
N	lodel	VFD		ANSAA	1A7MS53	3A0MS53	4A2MS53	6A6MS53	9A9MS53	12AMS53		
	App	olicable M	lotor Output	[kW]	0.75	1.5	2.2	3.7	5.5	7.5		
	App	olicable M	lotor Output	[HP]	1	2	3	5	7.5	10		
	tuty	Rated	Output Capa	acity [kVA]	1.7	3	4.2	6.6	9.9	12.2		
	Heavy duty	Rate	d Output Cu	rrent [A]	1.7	3	4.2	6.6	9.9	12.2		
put	포	Carr	ier Frequenc	cy [kHz]			2–15 (De	efault: 4)				
Output	ξ	Rated	Output Capa	acity [kVA]	2.1	3.6	5	8	11.5	15		
	Normal duty	Rate	d Output Cu	rrent [A]	2.1	3.6	5	8	11.5	15		
	2	Carr	ier Frequenc	cy [kHz]		2–15 (Default: 4)						
	Rate	d Input	Heavy	/ Duty	2	3.5	4.9	7.7	11.5	14.2		
	Curr	ent [A]	Norma	al Duty	2.4	4.2	5.8	9.3	13.4	17.5		
Input		Rated Vo	oltage / Freq	luency	Three-phase 500–600 V _{AC} (-15–10%), 50/60 Hz							
	Ma	ains Inpu	t Voltage Ra	nge [V _{AC}]	425–660							
	ı	Mains Fre	equency Ran	nge [Hz]			47-	-63				
	Weight [kg]				0.85	0.87	1.18	1.29	2.0	04		
	Cooling Method				Convective cooling Fan cooling							
	EMC Filter				Optional							
	IP Rating				IP20							

Table 9-5

9-5 General Specifications

	Control Method	V/F, SVC, FOC Sensorless				
	Applicable Motor	IM (Induction Motor), Simple PM mo	otor control (IPM and SPM)			
	Starting Torque	150% / 3 Hz	(V/F, SVC control for IM, heavy duty, rated)			
	Starting Torque	100% / (motor rated frequency/20)	(SVC control for PM, heavy duty, rated)			
	[Note 1]	200% / 0.5 Hz	(FOC control for IM, heavy duty, rated)			
	Speed Control	1: 50 (V/F, SVC control for IM, heav	y duty, rated)			
	Speed Control	1: 20 (SVC control for PM, heavy du	uty, rated)			
	Range [Note 1]	1: 100 (FOC control for IM, heavy de	uty, rated)			
	Max. Output	0.00–599.00 Hz				
	Frequency					
		Normal duty:				
		120% of rated current can endure for	<i>,</i>			
	Overload Capacity	150% of rated current can endure for 3 seconds during every 30 seconds.				
	. ,	Heavy duty:				
Control		150% of rated current can endure for 1 minute during every 5 minutes				
Characteristics		200% of rated current can endure for	or 3 seconds during every 30 seconds			
	Frequency Setting	0–10 V / -10–10 V				
	Signal	4–20 mA / 0–10 V				
		1 channel pulse input (33 kHz), 1 ch	nannel pulse output (33 kHz)			
		Multiple motor switching (a maximum of four independent motor parameter				
		settings), Fast start-up, Deceleration Energy Back (DEB) function, Wobble				
		frequency function, Fast deceleration function, Master and Auxiliary frequency				
		source selectable, Restart after momentary power loss, Speed tracking,				
	Main Functions	Over-torque detection, 16-step	speed (including the master speed),			
		Accel./decel. time switch, S-curve a	accel./decel., three-wire operation control,			
		JOG frequency, Frequency upper/l	ower limit settings, DC brake at start-up			
		and stop, PID control, Built-in PL	C (2000 steps), and Simple positioning			
		function.				
	Application Macro	Built-in application parameter group	s (selected by industry) and user-defined			
	Application Macro	application parameter groups.				
Protection	Motor Protection	Over-current, Over-voltage, Over-he	eating, Phase loss.			
Characteristics	Stall Prevention	,	n, deceleration and running (independent			
		settings).				
Accessory -	Communication	DeviceNet, EtherNet/IP, PROFIBUS	DP, Modbus TCP, CANopen, EtherCAT			
	Cards	DeviceNet, EtherNet/IP, PROFIBUS DP, Modbus TCP, CANopen, EtherCAT				
	External DC	EMM-BPS01 (24 V power backup supply card)				
	Power Supply	EIVIIVI-DE 30 I (24 V power packup suppry Card)				
Certi	fications	UL, CE, RCM, TÜV (SIL 2), RoHS, I	REACH			

Table 9-6

[Note 1] Control accuracy may vary depending on the environment, application conditions or different motors. For more information, contact Delta or your local distributors.

9-6 Environment for Operation, Storage and Transportation

DO NOT expose the AC motor drive to a poor environment, such as one with dust, direct sunlight, corrosive/inflammable gasses, humidity, liquids, or excessive vibration. The salt in the air must be less than 0.01 mg/cm² every year.

every year.	Installation Location	IEC 60364-1/ IEC	C 60664-1 Pollution degree 2	, Indoor use only.			
		Operation	IP20/UL Open Type	-20–50°C -20–60°C with derating			
	O l'a	Operation	IP40/NEMA 1/UL Type 1	-20–40°C			
	Surrounding		Side-by-side Installation	-20–50°C with derating			
	Temperature	Storage	-40-85°C	•			
		Transportation	tion -20-70°C				
		Non-condensing, non-freezing					
		Operation Maximum 90%					
Environment	Rated Humidity	Storage / Transportation	Maximum 95%				
		No water conder	lo water condensation				
		Operation	86–106 kPa				
	Air Pressure	Storage/ Transportation	70–106 kPa				
		IEC 60721-3	1				
		Operation	Class 3C2; Class 3S2				
	Pollution Level	Storage	Class 2C2; Class 2S2				
		Transportation	ransportation Class 1C2; Class 1S2				
		Concentrate pro	hibited				
	Altitude	<1000 m (For alt	titudes > 1000 m, derate to us	se it.)			
Package	Storage	1074	44./	20000 2 24			
Drop	Transportation	151A procedure	1A (according to weight) IEC	60068-2-31			
	Operating	· 0.7–2.0 G rang	to peak value range from 2–′ ge from 13.2–55 Hz;	13.2 Hz;			
Vibration	-	· 2.0 G range fro					
		Compliance with					
	Non-operating	2.5 G peak, 5 H					
		0.015" maximun	n displacement				
to t	Operating	15 G, 11 ms	JEO/EN00000 0 07				
Impact		Compliance with IEC/EN60068-2-27					
	Non-operating	30 G					

Table 9-7

9-7 Derating for Ambient Temperature, Altitude and Carrier Frequency

9-7-1 Derating Curve for Ambient Temperature and Altitude

Protection Level	Operating Environment
IP20 /	If the AC motor drive operates at the rated current, the ambient temperature needs to be
	between -20–50°C. If the temperature is above 50°C, decrease 2.5% of the rated current
UL Open Type	for every 1°C increase in temperature. The maximum allowable temperature is 60°C.
IP40 /	If the AC motor drive operates at the rated current, the ambient temperature needs to be
NEMA1 /	between -20–40°C. If the temperature is above 40°C, decrease 2.5% of the rated current
UL Type 1	for every 1°C increase in temperature. The maximum allowable temperature is 60°C.
	If the AC motor drive is installed at an altitude of 0-1000 m, follow normal operation
	restrictions. For altitudes of 1000-2000 m, decrease the drive's rated current by 1% or
High Altitude	lower the temperature by 0.5°C for every 100 m increase in altitude. The maximum
	altitude for corner grounded is 2000 m. If installing at an altitude higher than 2000 m is
	required, contact Delta for more information.

Table 9-8

Ambient Temperature Derating Curve




Figure 9-1




Figure 9-2

For IP20 / UL Open Type

	Current derating at ambient temperature									
Ambient to	emperature	40°C	45°C	50°C						
Operating altitude	0–1000									
above sea level	1001–1500	100	95%							
(m)	1501–2000	100%	95%	90%						

Table 9-9

For IP40 / NEMA1 / UL Type 1

	Current derating at ambient temperature										
Ambient to	emperature	30°C	35°C	40°C							
Operating altitude	0–1000										
above sea level	1001–1500	100	0%	95%							
(m)	1501–2000	100%	95%	90%							

Table 9-10

Altitude Derating Curve




Figure 9-3

9-7-2 Derating Curve for Carrier Frequency

Normal load (Pr.00-16=0)

Space Vector Modulation Mode (Pr.11-41=2)




Figure 9-4

The rated output current (%) of SVPWM in normal load for different carrier frequencies:

Carrier Freq. (kHz) Ambient Temp. (Ta), 100% Load	2	3	4	5	6	7	8	9	10	11	12	13	14	15
50°C	100	96	86	77	69	62	56	51	46	42	38	35	32	29
40°C	100	100	100	90	82	74	68	62	56	52	48	44	40	37
35°C	100	100	100	96.5	88.5	80	74	67.5	61	57	53	48.5	44	41

Table 9-11

Two-phase Modulation Mode (Pr.11-41=0)




Figure 9-5

The rated output current (%) of DPWM in normal load for different carrier frequencies:

Carrier Freq. (kHz) Ambient Temp. (Ta), 100% Load	2	3	4	5	6	7	8	9	10	11	12	13	14	15
50°C	100	100	100	88	80	72	66	60	55	51	47	44	41	38
40°C	100	100	100	100	100	93	87	82	77	72	68	64	60	56
35°C	100	100	100	100	100	100	97.5	93	88	82.5	78.5	74	69.5	65

Table 9-12

Heavy load (Pr.00-16=1)

• Space Vector Modulation Mode (Pr.11-41=2)




Figure 9-6

The rated output current (%) of SVPWM in heavy load for different carrier frequencies:

Carrier Freq. (kHz) Ambient Temp. (Ta), 100% Load	2	3	4	5	6	7	8	9	10	11	12	13	14	15
50°C	100	100	100	88	80	72	65	59	53	48	44	40	36	33
40°C	100	100	100	100	95	86	78	71	65	59	54	50	46	42
35°C	100	100	100	100	100	93	84.5	77	71	64.5	59	55	51	46.5

Table 9-13

Two-phase Modulation Mode (Pr.11-41=0)




Figure 9-7

The rated output current (%) of DPWM in heavy load for different carrier frequencies:

Carrier Freq. (kHz) Ambient Temp. (Ta), 100% Load	2	3	4	5	6	7	8	9	10	11	12	13	14	15
50°C	100	100	100	100	100	93	86	80	74	69	65	61	57	53
40°C	100	100	100	100	100	100	100	95	89	83	78	73	69	65
35°C	100	100	100	100	100	100	100	100	96.5	90	84.5	79	75	71

Table 9-14

Chapter 9 Specifications | MS300

[This page intentionally left blank]

Chapter 10 Digital Keypad

KPMS-LE01 keyboard panel



Descriptions of Keypad Functions

Displayed items	Descriptions
RUN STOP FWD PLC	Displays the present frequency setting for the drive.
RUN STOP FWD PLC	Displays the actual output frequency to the motor.
RUN STOP FWD PLC	Displays the user-defined output of a physical quantity. This example uses Pr.00-04=30 (user-defined output).
RUN STOP FWD PLC	Displays the load current.
RUN • STOP FWD • PLC	Forward command
RUN • STOP • PLC	Reverse command
RUN • STOP • PLC	Displays the count value.
RUN STOP FWD PLC	Displays a parameter item.
RUN • STOP • PLC	Displays a parameter value.
RUN • STOP • PLC	Displays an external fault.
RUN O STOP O PLC	Displays "End" for approximately one second if the data has been accepted and automatically stored in the register.
RUN STOP	Displays if the setting data is not accepted or data value exceeds the allowed range.

Keypad Operation Process

A. Main Page Selection



Note 1: In screen selection mode, press **ENTER** to set the parameters.

Note 2: App displays only when Pr.13-00≠0


Setting parameters




Note: In the parameter setting mode, you can press FITTEN to return to the selection mode.


To shift data

Setting direction (When the operation source is the digital keypad)



PLC setting





NOTE


MS300 digital keypad does not support parameter copy functions. You must use the MH300 digital keypad KPMH-LC01 to perform the parameter copy functions.

For details on how to use the digital keypad KPMH-LC01, see Chapter 10 in the MH300 user manual.

B. F Page (Frequency command setting page)


General Mode 1

(The maximum operation frequency Pr.01-00 is in two decimal places. The example uses Pr.01-00 = 60.00 Hz.)



General Mode 2

(The maximum operation frequency Pr.01-00 is in three decimal places. The example uses Pr.01-00 = 599.0 Hz.)



C. Application Macro Selection Page


Go to Parameter Group 13 to set the application macro functions. The application macro function is enabled when $Pr.13-00 \neq 0$.

Once enabled, the Application Marco Selection page displays "APP". If Pr.13-00 = 0, the APP page does not display.




Application Selection

When Pr.13-00≠0, you enter into the APP page. After you press ENTER, the screen displays a corresponding short name according to Pr.13-00 setting values. Follow the process below to set the industry-specific application macro parameters.



Example:


When Pr.13-00 = 2, you enter into the APP page. After you press ENTER, the screen displays "CoPr" and the compressor application macro parameters are enabled. Then, press ENTER again to check the industry-specific parameter sets. Press Up and Down keys to select the parameter to set. Finally, press ENTER to set the parameter values. For other industry application, follow the same process.




User-defined Application

Set Pr.13-00 = 1 to enable the user-defined applications. The "USEr" appears in the APP page after pressing ENTER.

(If Pr.13-00 = 1 and you do not set any parameters for Pr.13-01–Pr.13-50, you cannot enter the sub-layer of the USEr page.)




Follow the process below to set the user-defined application selection (Pr.13-00=1).



- 1. Use Pr.13-01–Pr.13-50 to set the user-defined parameters in sequence according to your requirement. The default setting 0.00 means there is no user-defined parameter. Press ENTER to set the corresponding parameters for Pr.13-01– Pr.13-50.
- 2. The setting method of user-defined parameters is the same as that for non-user-defined parameters. You can use Up and Down keys or left shift key to speed up the settings.

 Example:

Setting Pr.13-01 to the user-defined parameter 04-00. First, press ENTER at Pr.13-01 to enter the setting page. Then, long press MODE to enable the left shift key to start the setting. The setting process shows as follows.




NOTE You must set Pr.13-01, 02......50 in sequence, or the display shows "Err".

3. After finishing the setting, press MODE to return to the APP page, and then press ENTER. The keypad displays "USEr". After you press ENTER again, the corresponding parameter that you set appears.

Example:

If you set Pr.13-01 as the user-defined parameter Pr.04-00, and Pr.13-02 as Pr.04-01, the parameters you set appear when you press ENTER at the "USEr" page.



Note: In the mode of parameter settings, pressing returns to the main page selection.

4. To remove a set user-defined parameter, remove from the last defined parameter (set to 0.00) first, or the display shows "Err". For example, if there are five user-defined parameters (Pr.13-01, 13-02...13-05), to remove Pr.13-02, you must remove Pr.13-05 first, then 13-04, then 13-03, and then 13-02.

D. Parameter setting

D-1. Unsigned parameter

(Parameter setting range ≥ 0; for example, Pr.01-00)

- Without using the left shift key: Use Up and Left/Down key to select and adjust the parameters.
 Then, press ENTER to start the parameter settings.
- 2. Using the left shift key: Long press MODE for two seconds until the last digit of the parameter value starts to blink. Increase the value by pressing the Up key. The value goes back to 0 after 9.
- 3. Press left/down key to shift the blinking cursor one digit to the left, and increase the value by pressing the Up key.
- 4. After you finish setting the parameter, the left shift key function is not disabled automatically until you disable it manually by pressing MODE for two seconds.

Example:

The default setting for Pr.01-00 is 60.00. Long pressing MODE for two seconds enables the left shift function. The process for pressing the Left/Down key shows as follows:



The upper limit for Pr.01-00 is 599.00. If you set a value greater than 599.00, "Err" appears after you press ENTER, and then the keypad shows the upper limit (599.00) for a second to remind you of the incorrect setting. The setting value remains as the original set value and the cursor returns to the last digit.

D-2. Minus-signed parameter setting status 1

(Parameter setting range can be < 0; for example, Pr.03-03)

- 1. Without using the left shift key: Use Up and Left/Down key to select and adjust the parameters. Then, press ENTER to start the parameter settings.
- 2. Using the left shift key: Long press MODE for two seconds until the last digit of the parameter value starts to blink. Increase the value by pressing the Up key. The value goes back to 0 after 9.
- 3. Press left/down key to shift the blinking cursor one digit to the left, and increase the value by pressing the Up key. When you shift to the first digit and press the Up key, the digit "0" changes to "-" (minus).
- 4. After you finish setting the parameter, the left shift key function is not disabled automatically until you disable it manually by pressing MODE for two seconds.

Example:

The default setting for Pr.03-03 is 0.0. Long pressing MODE for two seconds enables the left shift function. The process for pressing the Left/Down key shows as follows:



The upper limit for Pr.03-03 is 100.0 and lower limit is -100.0. If you set a value greater than 100.0 or less than -100.0, "Err" appears after you press ENTER, and then the keypad shows the upper limit (100.0) or lower limit (-100.0) for a second to remind you of the incorrect setting. The setting value remains as the original set value, and the cursor returns to the last digit.

D-3. Minus-signed parameter setting status 2

(Parameter setting range can be < 0, and the lower limit is ≤ -100.00 with two decimal places; for example, Pr.03-74)

- Without using the left shift key: Use Up and Left/Down key to select and adjust the parameters.
 Then, press ENTER to start the parameter settings.
- 2. Using the left shift key: Long press MODE for two seconds until the last digit of the parameter value starts to blink. Increase the value by pressing the Up key. The value goes back to 0 after 9.
- 3. Press the left/down key to shift the blinking cursor one digit to the left, and increase the value by pressing the Up key. When you shift to the first digit and press the Up key, the digit "0" changes to "-" (minus).
- 4. For parameter values with three digits and two decimal places and a positive/negative setting range (Pr.03-74, -100.00–100.00%), the keypad only displays four digits (-100.0 or 100.0). Example:

The default setting for Pr.03-74 is -100.0. If you increase the parameter value by 0.01, the display shows -99.99, with four digits only. Long pressing MODE for two seconds enables the left shift function. The process for pressing the Left/Down key shows as follows:



The upper limit for Pr.03-74 is 100.00 and lower limit is -100.00. If you set a value greater than 100.0 or less than -100.0, "Err" appears after you press ENTER, and then the keypad shows the upper limit (100.0) or lower limit (-100.0) (only one decimal place is displayed) for a second to remind you of the incorrect setting. The setting value remains as the original set value, and the cursor returns to the last digit.

Reference Table for the Seven-segment Digital Keypad LED Display

Number	0	1	2	3	4	5	6	7	8	9
Display	Ū	- !	Ċ	3	4	5	8		8	9
Number	Α	а	В	b	С	С	D	d	Е	е
Display	R	-	-	Ь		C	-	ď	E	-
Number	F	f	G	g	Н	h	I	i	J	j
Display	F	-	[]	-	H	h	-	L		
Number	K	k	L	I	M	m	N	n	0	0
Display	r	-	L	-	-	-	-	n	-	O
Number	Р	р	Q	q	R	r	S	S	Т	t
Display	P	-	-	9	-	,-	5	-	-	E
Number	U	u	V	V	W	W	Χ	Х	Υ	у
Display	<u>u</u>	U	-	Ū	-	-	-	-	5	-
Number	Z	Z								
Display	-	-								

Chapter 10 Digital Keypad | MS300

[This page intentionally left blank]

This chapter provides a summary of parameter (Pr.) setting ranges and defaults. You can set, change, and reset parameters through the digital keypad.



★: You can set this parameter during operation.

The following are abbreviations for different types of motors:

- IM: Induction motor
- PM: Permanent magnet synchronous AC motor
- IPM: Interior permanent magnet synchronous AC motor
- SPM: Surface permanent magnet synchronous AC motor

00 Drive Parameters

Pr.	Explanation	Settings	Default	
		102: 115 V, 1 Phase, 0.25 HP		
		103: 115 V, 1 Phase, 0.5 HP		
		104: 115 V, 1 Phase, 1 HP		
		302: 230 V, 1 Phase, 0.25 HP		
		303: 230 V, 1 Phase, 0.5 HP		
		304: 230 V, 1 Phase, 1 HP		
		305: 230 V, 1 Phase, 2 HP		
		306: 230 V, 1 Phase, 3 HP		
		202: 230 V, 3 Phase, 0.25 HP		
		203: 230 V, 3 Phase, 0.5 HP		
		204: 230 V, 3 Phase, 1 HP		
	AC motor drive identity code 206: 230 V, 3 Phase 207: 230 V, 3 Phase		205: 230 V, 3 Phase, 2 HP	
00-00		206: 230 V, 3 Phase, 3 HP	Read only	
00-00		207: 230 V, 3 Phase, 5 HP		
		208: 230 V, 3 Phase, 7.5 HP		
		209: 230 V, 3 Phase, 10 HP		
		210: 230 V, 3 Phase, 15 HP		
		211: 230 V, 3 Phase, 20 HP		
		403: 460 V, 3 Phase, 0.5 HP		
		404: 460 V, 3 Phase, 1 HP		
		405: 460 V, 3 Phase, 2 HP		
		406: 460 V, 3 Phase, 3 HP		
		407: 460 V, 3 Phase, 5 HP		
		408: 460 V, 3 Phase, 7.5 HP		
		409: 460 V, 3 Phase, 10 HP		
		410: 460 V, 3 Phase, 15 HP		

	Pr.	Explanation	Settings	Default
Ī			411: 460 V, 3 Phase, 20 HP	
			412: 460 V, 3 Phase, 25 HP	
			413: 460 V, 3 Phase, 30 HP	
			482: 460 V, 3 Phase, 4 HP	
			504: 575 V, 3 Phase, 1 HP	
			505: 575 V, 3 Phase, 2 HP	
			506: 575 V, 3 Phase, 3 HP	
			507: 575 V, 3 Phase, 5 HP	
			508: 575 V, 3 Phase, 7.5 HP	
			509: 575 V, 3 Phase, 10 HP	
	00-01	AC motor drive rated current display	Display by models	Read only
-			0: No function	
			1: Write protection for parameters	
			5: Return kWh displays to 0	
			6: Reset PLC (including CANopen Master Index)	
			7: Reset CANopen Slave index	
			8: Keypad does not respond	
			9: Reset all parameters to defaults	
	00.00	D	(base frequency is 50 Hz)	0
	00-02	Parameter reset	10: Reset all parameters to defaults	0
			(base frequency is 60 Hz)	
			11: Reset all parameters to defaults with base frequency	
			at 50 Hz (keep the user-defined parameter values	
			Pr.13-01–Pr.13-50)	
			12: Reset all parameters to defaults with base frequency	
			at 60 Hz (keep the user-defined parameter values	
			Pr.13-01–Pr.13-50)	
Ī			0: F (frequency command)	
	00-03	Start up diaplay	1: H (output frequency)	0
	00-03	Start-up display	2: U (user-defined, see Pr.00-04)	0
			3: A (output current)	
			0: Display output current (A) (unit: Amp)	
			1: Display counter value (c) (unit: CNT)	
			2: Display the drive's actual output frequency (H.)	
	00-04	Content of multi-function	(unit: Hz)	2
	00-04	display (user-defined)	3: Display the drive's DC bus voltage (V) (unit: V _{DC})	3
			4: Display the drive's output voltage (E) (unit: V _{AC})	
			5: Display the drive's output power angle (n) (unit: deg)	
			6: Display the drive's output power (P) (unit: kW)	

Pr.	Explanation	Settings	Default
		7: Display the motor speed rpm (r) (unit: rpm)	
		8: Display the drive's estimated output torque, motor's	
		rated torque is 100% (t) (unit: %)	
		10: Display PID feedback (b) (unit: %)	
		11: Display AVI analog input terminal signal (1.) (unit: %)	
		12: Display ACI analog input terminal signal (2.) (unit: %)	
		14: Display the drive's IGBT temperature (i.) (unit: °C)	
		16: The digital input status (ON / OFF) (i)	
		17: The digital output status (ON / OFF) (o)	
		18: Display multi-step speed (S)	
		19: The corresponding CPU digital input pin status (d)	
		20: The corresponding CPU digital output pin status (0.)	
		22: Pulse input frequency (S.)	
		25: Overload count (0.00–100.00%) (o.) (unit: %)	
		26: Ground fault GFF (G.) (unit: %)	
		27: DC bus voltage ripple (r.) (unit: V _{DC})	
		28: Display PLC register D1043 data (C)	
		30: Display the output of User-defined (U)	
		31: Display Pr.00-05 user gain (K)	
		35: Control mode display:	
		0 = Speed control mode (SPD)	
		1 = Torque control mode (TQR) (t.)	
		36: Present operating carrier frequency of the drive (J.)	
		(Unit: Hz)	
		38: Display the drive status (6.)	
		39: Display the drive's estimated output torque, positive	
		and negative, using Nt-m as unit	
		(t 0.0: positive torque; -0.0: negative torque) (C.)	
		40: Torque command (L.) (unit: %)	
		41: kWh display (J) (unit: kWh)	
		42: PID target value (h.) (unit: %)	
		43: PID compensation (o.) (unit: %)	
		44: PID output frequency (b.) (unit: Hz)	
		46: Auxiliary frequency value (U.) (unit: Hz)	
		47: Master frequency value (A) (unit: Hz)	
		48: Frequency value after addition and subtraction of	
		master and auxiliary frequency (L.) (unit: Hz)	
		51: PMSVC torque offset	
		58: Pr.00-05 User gain display (K)	
		(Does not display decimal places.)	

	Pr.	Explanation	Settings	Default
			62: I2t (o.) (unit: %)	
			63: Error code (E.)	
			64: Warning code (n.)	
			65: Accumulated motor operation record (day) (r.)	
			(refer to Pr.05-32)	
*	00-05	Coefficient gain in actual output frequency	0.00–160.00	1.00
	00-06	Firmware version	Read only	Read only
	00.07	Parameter protection	0-65535	0
*	00-07	password input	0–4: the number of password attempts allowed	0
			0–65535	
	00.00	Parameter protection	0: No password protection or password entered correctly	0
*	80-00	password setting	(Pr.00-07)	0
			1: Parameter has been set	
			0: Speed Control mode	_
	00-10	Control mode	2: Torque mode	0
			0: IMVF (IM V/F control)	
			1: IMVFPG (IM V/F control + encoder)	
	00-11	Speed Control mode	2: IM/PM SVC (IM / PM space vector control)	0
			5: IMFOC Sensorless	
			(IM field-oriented sensorless vector control)	
			0: Normal load	
	00-16	Load selection	1: Heavy load	1
			Normal load: 2–15 kHz	4
	00-17	Carrier frequency	Heavy load: 2–15 kHz	4
		Carrier inequency	Note: When Pr.00-11=5 (IMFOC Sensorless), the maximum setting value for the carrier frequency is 10 kHz.	
			bit 0: Control command is forced by PLC control	
	00-19	PLC command mask	bit 1: Frequency command is forced by PLC control	Read only
			bit 3: Torque command is forced by PLC control	
			0: Digital keypad	
			1: RS-485 communication input	
			2: External analog input (Refer to Pr.03-00)	
			3: External UP / DOWN terminal	
		Master frequency	(multi-function input terminals)	
N	00-20	command source	4: Pulse input without direction command	0
		(AUTO, REMOTE)	(refer to Pr.10-16 without considering direction)	
			6: CANopen communication card	
			7: Digital keypad potentiometer knob	
			8: Communication card (does not include CANopen card)	
			9: PID controller	

	Pr.	Explanation	Settings	Default
			Note: HOA (Hand-Off-Auto) function is valid only when you use with MO function setting 42 and 56 or with KPC-CC01 (optional).	
			0: Digital keypad	
			1: External terminals	
		Operation command	2: RS-485 communication input	
×	00-21	•	3: CANopen communication card	0
		source (AUTO, REMOTE)	5: Communication card (does not include CANopen card)	
			Note: HOA (Hand-Off-Auto) function is valid only when you use with MO function setting 42 and 56 or with KPC-CC01 (optional)	
	00.00	Otan martha ad	0: Ramp to stop	0
*	00-22	Stop method	1: Coast to stop	0
			0: Enable forward / reverse	
×	00-23	Motor direction control	1: Disable reverse	0
			2: Disable forward	
		Digital operator (keypad)		
	00-24	frequency command	Read only	Read only
		memory		
		00-25 User-defined characteristics	bit 0–3: user-defined decimal places	
			0000h-0000b: no decimal place	
			0001h-0001b: one decimal place	
			0002h-0010b: two decimal places	
			0003h-0011b: three decimal places	
			bit 4–5: user-defined unit	
			000xh: Hz	
			001xh: rpm	
			002xh: %	
			003xh: kg	
			004xh: m/s	
*	00-25		005xh: kW	0
			006xh: HP	
			007xh: ppm	
			008xh: 1/m	
			009xh: kg/s	
			00Axh: kg/m 00Bxh: kg/h	
			00Cxh: lb/s	
			00Dxh: lb/m	
			00Exh: lb/h	
			00Exh: ft/s	
			010xh: ft/m	
			OTOMIL IVIII	

Pr.	Explanation	Settings	Default
		011xh: m	
		012xh: ft	
		013xh: degC	
		014xh: degF	
		015xh: mbar	
		016xh: bar	
		017xh: Pa	
		018xh: kPa	
		019xh: mWG	
		01Axh: inWG	
		01Bxh: ftWG	
		01Cxh: psi	
		01Dxh: atm	
		01Exh: L/s	
		01Fxh: L/m	
		020xh: L/h	
		021xh: m3/s	
		022xh: m3/h	
		023xh: GPM	
		024xh: CFM	
		xxxxh: Hz	
		0: Disable	
	Maximum user-defined value	0–65535 (when Pr.00-25 is set to no decimal place)	
00-26		0.0–6553.5 (when Pr.00-25 is set to one decimal place)	0
		0.00–655.35 (when Pr.00-25 is set to two decimal places)	
		0.000–65.535 (when Pr.00-25 is set to three decimal places)	
00-27	User-defined value	Read only	Read only
		0: Standard HOA function	
		1: When switching between local and remote, the drive	
		stops.	
		2: When switching between local and remote, the drive	
		runs with REMOTE settings for frequency and	
	LOCAL / REMOTE	operating status.	
00-29	selection	3: When switching between local and remote, the drive	0
	SOICOLOIT	runs with LOCAL settings for frequency and operating	
		status.	
		4: When switching between local and remote, the drive	
		runs with DCAL settings when switched to Local and	
		runs with REMOTE settings when switched to	
		Remote for frequency and operating status.	

	Pr.	Explanation	Settings	Default
			0: Digital keypad	
			1: RS-485 communication input	
			2: External analog input (refer to Pr.03-00)	
			3: External UP / DOWN terminal	
			(multi-function input terminals)	
		Master frequency	4: Pulse input without direction command	
×	00-30	command source	(refer to Pr.10-16 without considering direction)	0
		(HAND, LOCAL)	6: CANopen communication card	
			7: Digital keypad potentiometer knob	
			8: Communication card (does not include CANopen card)	
			9: PID controller	
			Note: HOA (Hand-Off-Auto) function is valid only when you use with MO function setting 41 and 56 or with KPC-CC01 (optional).	
			0: Digital keypad	
			1: External terminal	
		Operation command	2: RS-485 communication input	
×	00-31	source	3: CANopen communication card	0
		(HAND, LOCAL)	5: Communication card (does not include CANopen card)	
			Note: HOA (Hand-Off-Auto) function is valid only when you use with MO function setting 41 and 56 or with KPC-CC01 (optional).	
	00-32	Digital keypad STOP	0: STOP key disabled	0
^	00-32	function	1: STOP key enabled	U
			0: Master and auxiliary frequency function disabled	
			1: Digital keypad	
			2: RS-485 communication input	
			3: Analog input	
			4: External UP / DOWN key input	
	00-35	Auxiliary frequency source	(multi-function input terminals)	0
			5: Pulse input without direction command	
			(refer to Pr.10-16)	
			6: CANopen communication card	
			7: Digital keypad potentiometer knob	
		Master and auxiliary	8: Communication card 0: Master + curvillary fraguency	
	00-36	frequency command	O: Master + auxiliary frequency 1: Master - auxiliary frequency	0
		selection	2: Auxiliary - master frequency	
		Output phase order	0: Standard	
	00-47	selection	1: Exchange the rotation direction	0
×	00-48	Display filter time (current)	0.001–65.535 sec.	0.100
×	00-49	Display filter time (keypad)	0.001–65.535 sec.	0.100
	00-50	Software version (date)	Read only	Read only
		,	·	,

01 Basic Parameters

	Pr.	Explanation	Settings	Default
	01-00	Maximum operation	0.00-599.00 Hz	60.00 /
	01-00	frequency	0.00-399.00 HZ	50.00
		Output frequency of motor 1		60.00 /
	01-01	(Base frequency / Motor's	0.00–599.00 Hz	50.00
		rated frequency)		30.00
		Output voltage of motor 1	115V / 230V models: 0.0–255.0 V	220.0
	01-02	(Base voltage / Motor's	460V models: 0.0–510.0 V	440.0
		rated voltage)	575V models: 0.0–637.0 V	575.0
	01-03	Mid-point frequency 1 of motor 1	0.00–599.00 Hz	3.00
		Mid point voltage 1 of mater	115V / 230V models: 0.0–240.0 V	11.0
×	01-04	Mid-point voltage 1 of motor	460V models: 0.0–480.0 V	22.0
			575V models: 0.0–600.0 V	40.0
	01-05	Mid-point frequency 2 of motor 1	0.00–599.00 Hz	1.50
		Mid point valtage 2 of mater	115V / 230V models: 0.0–240.0 V	5.0
×	01-06	Mid-point voltage 2 of motor 1	460V models: 0.0–480.0 V	10.0
			575V models: 0.0–600.0 V	26.1
	01-07	Minimum output frequency of motor 1	0.00–599.00 Hz	0.50
	01-08	Minimum output voltage of	115V / 230V models: 0.0–240.0 V	1.0
×		Minimum output voltage of motor 1	460V models: 0.0–480.0 V	2.0
			575V models: 0.0–600.0 V	16.7
	01-09	Start-up frequency	0.00–599.00 Hz	0.50
*	01-10	Output frequency upper limit	0.00–599.00 Hz	599.00
×	01-11	Output frequency lower limit	0.00–599.00 Hz	0.00
	01-12	Acceleration time 1	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
×	01-12	Acceleration time 1	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
~	01-13	Deceleration time 1	Pr.01-45 = 0: 0.00-600.00 sec.	10.00
^	01-13	Deceleration time 1	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
.	01-14	Acceleration time 2	Pr.01-45 = 0: 0.00-600.00 sec.	10.00
×	01-14	Acceleration time 2	Pr.01-45 = 1: 0.0-6000.0 sec.	10.0
~	01-15	Deceleration time 2	Pr.01-45 = 0: 0.00-600.00 sec.	10.00
/*	01-10	DOGGICIANOTI NITIC Z	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
~	01-16	Acceleration time 3	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
,,	01 10	, tooloration time o	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0

	Pr.	Explanation	Settings	Default
,	01-17	Deceleration time 3	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
	01-17	Deceleration time 3	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
×	01-18	1-18 Acceleration time 4	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
	01-10	Acceleration time 4	Pr.01-45 = 1: 0.0-6000.0 sec.	10.0
N	01-19	Deceleration time 4	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
	01-19	Deceleration time 4	Pr.01-45 = 1: 0.0-6000.0 sec.	10.0
~	01-20	JOG acceleration time	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
	01-20	JOG acceleration time	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
[01-21	JOG deceleration time	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
×	01-21	JOG deceleration time	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
*	01-22	JOG frequency	0.00–599.00 Hz	6.00
*	01-23	Switch frequency between first and fourth Accel./Decel.	0.00–599.00 Hz	0.00
	04.04	S-curve for acceleration	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
*	01-24	begin time 1	Pr.01-45 = 1: 0.0–250.0 sec.	0.2
	04.05	S-curve for acceleration	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
*	01-25	arrival time 2	Pr.01-45 = 1: 0.0–250.0 sec.	0.2
.,	04.00	S-curve for deceleration	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
×	01-26	begin time 1	Pr.01-45 = 1: 0.0–250.0 sec.	0.2
.,	01-27	S-curve for deceleration	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
~		arrival time 2	Pr.01-45 = 1: 0.0–250.0 sec.	0.2
=	01-28	Skip frequency 1	0.00–599.00 Hz	0.00
	01-20	(upper limit)	0.00-599.00 HZ	0.00
	01-29	Skip frequency 1 (lower limit)	0.00-599.00 Hz	0.00
	01-30	Skip frequency 2 (upper limit)	0.00–599.00 Hz	0.00
	01-31	Skip frequency 2 (lower limit)	0.00–599.00 Hz	0.00
	01-32	Skip frequency 3 (upper limit)	0.00–599.00 Hz	0.00
	01-33	Skip frequency 3 (lower limit)	0.00–599.00 Hz	0.00
Ī			0: Output waiting	
	01-34	Zero-speed mode	1: Zero-speed operation	0
			2: Fmin (refer to Pr.01-07 and Pr.01-41)	
Ī		Output frequency of motor 2		60.00./
	01-35	(Base frequency / Motor's	0.00–599.00 Hz	60.00 /
		rated frequency)		50.00

	Pr.	Explanation	Settings	Default
		Output voltage of motor 2	115V / 230V models: 0.0–255.0 V	220.0
	01-36	(Base voltage / Motor's	460V models: 0.0–510.0 V	440.0
		rated voltage)	575V models: 0.0–637.0 V	575.0
	01-37	Mid-point frequency 1 of motor 2	0.00-599.00 Hz	3.00
		Mid point voltage 1 of motor	115V / 230V models: 0.0–240.0 V	11.0
×	01-38	Mid-point voltage 1 of motor 2	460V models: 0.0–480.0 V	22.0
		2	575V models: 0.0–600.0 V	40.0
	01-39	Mid-point frequency 2 of motor 2	0.00–599.00 Hz	1.50
		Mid point voltage 2 of mater	115V / 230V models: 0.0–240.0 V	5.0
×	01-40	Mid-point voltage 2 of motor	460V models:0.0–480.0 V	10.0
		2	575V models: 0.0–600.0 V	26.1
	01-41	Minimum output frequency of motor 2	0.00–599.00 Hz	0.50
		Minimum output voltage of motor 2	115V / 230V models: 0.0–240.0 V	1.0
×	01-42		460V models: 0.0–480.0 V	2.0
			575V models: 0.0–600.0 V	16.7
			0: V/F curve determined by Pr.01-00–Pr.01-08	
	01-43	V/F curve selection	1: V/F curve to the power of 1.5	0
			2: V/F curve to the power of 2	
			0: Linear acceleration and deceleration	
	04.44		1: Auto-acceleration and linear deceleration	
		Auto-acceleration and	2: Linear acceleration and auto-deceleration	0
*	01-44	auto-deceleration setting	3: Auto-acceleration and auto- deceleration	0
			4: Stall prevention by auto-acceleration and	
			auto-deceleration (limited by Pr.01-12–Pr.01-21)	
	04.45	Time unit for acceleration /	0: Unit 0.01 sec.	0
	01-45	deceleration and S-curve	1: Unit 0.1 sec.	0
	04.46	CAN an an avial atom time	Pr.01-45 = 0: 0.00-600.00 sec.	1.00
*	01-46	CANopen quick stop time	Pr.01-45 = 1: 0.0–6000.0 sec.	1.0
		Demonstruction and an arrange	0: Disable	
	01-49	Regenerative energy restriction control method	1: Over voltage energy restriction	0
		restriction control method	2: Traction energy control (TEC)	
	04.50	Maximum operation	0.00 500 00 U-	60.00 /
	01-52 frequency of motor 2	frequency of motor 2	0.00–599.00 Hz	50.00
	04 50	Maximum operation	0.00 500 00 Hz	60.00 /
	01-53	frequency of motor 3	0.00–599.00 Hz	50.00

	Pr.	Explanation	Settings	Default
Ī		Output frequency of motor 3		60.00 /
	01-54	(Base frequency / Motor's	0.00–599.00 Hz	50.00
		rated frequency)		30.00
		Output voltage of motor 3	115V / 230V models: 0.0–255.0 V	220.0
	01-55	(Base voltage / Motor's	460V models: 0.0–510.0 V	440.0
		rated voltage)	575V models: 0.0–637.0 V	575.0
	01-56	Mid-point frequency 1 of motor 3	0.00–599.00 Hz	3.00
		No. 1 and a state of the state	115V / 230V models: 0.0–240.0 V	11.0
×	01-57	Mid-point voltage 1 of motor	460V models: 0.0–480.0 V	22.0
		3	575V models: 0.0–600.0 V	40.0
-	01-58	Mid-point frequency 2 of motor 3	0.00–599.00 Hz	1.50
Ī		Mid point valtage O of mater	115V / 230V models: 0.0–240.0 V	5.0
×	01-59	Mid-point voltage 2 of motor 3	460V models: 0.0–480.0 V	10.0
		3	575V models: 0.0–600.0 V	26.1
	01-60	Minimum output frequency of motor 3	0.00–599.00 Hz	0.50
=			115V / 230V models: 0.0–240.0 V	1.0
×	01-61	Minimum output voltage of motor 3	460V models: 0.0–480.0 V	2.0
			575V models: 0.0–600.0 V	16.7
	01-62	Maximum operation	0.00-599.00 Hz	60.00 /
	01-62	frequency of motor 4	0.00-599.00 HZ	50.00
		Output frequency of motor 4		60.00 /
	01-63	(Base frequency / Motor's	0.00–599.00 Hz	50.00
		rated frequency)		30.00
		Output voltage of motor 4	115V / 230V models: 0.0–255.0 V	220.0
	01-64	(Base voltage / Motor's	460V models: 0.0–510.0 V	440.0
		rated voltage)	575V models: 0.0–637.0 V	575.0
	01-65	Mid-point frequency 1 of motor 4	0.00–599.00 Hz	3.00
		Mid-point voltage 1 of motor	115V / 230V models: 0.0–240.0 V	11.0
×	01-66	4	460V models: 0.0–480.0 V	22.0
		7	575V models: 0.0–600.0 V	40.0
	01-67	Mid-point frequency 2 of motor 4	0.00–599.00 Hz	1.50
		Mid-point voltage 2 of motor	115V / 230V models: 0.0–240.0 V	5.0
×	01-68	wiid-point voitage 2 of motor	460V models: 0.0–480.0 V	10.0
		T	575V models: 0.0–600.0 V	26.1

Pr.	Explanation	Settings	Default
01-69	Minimum output frequency	0.00–599.00 Hz	0.50
	of motor 4		
01-70	Minimum output voltage of motor 4	115V / 230V models: 0.0–240.0 V	1.0
		460V models: 0.0–480.0 V	2.0
		575V models: 0.0–600.0 V	16.7

02 Digital Input / Output Parameters

Pr.	Explanation	Settings	Default
		0: No function	
		1: Two-wire mode 1, power on for operation control	
		(M1: FWD / STOP, M2: REV / STOP)	
		2: Two-wire mode 2, power on for operation control	
		(M1: RUN / STOP, M2: REV / FWD)	
		3: Three-wire, power on for operation control	
		(M1: RUN, M2: REV / FWD, M3: STOP)	
		4: Two-wire mode 1, Quick Start	
		(M1: FWD / STOP, M2: REV / STOP)	
		5: Two-wire mode 2, Quick Start	
02-00	Two-wire / three-wire	(M1: RUN / STOP, M2: REV / FWD)	1
02-00	operation control	6: Three-wire, Quick Start	I
		(M1: RUN, M2: REV / FWD, M3: STOP)	
		<u>IMPORTANT</u>	
		1. In the fast start-up function, terminal output keeps in	
		the ready status, and the drive responses to the	
		command immediately.	
		2. When using Quick Start function, the output terminals	
		UVW are with driving voltages in order to output and	
		respond immediately if a Start command is given. Do	
		not touch the terminals or modify the motor wiring to	
		prevent electric shocks.	
02-01	Multi-function input	0: No function	0
02-01	command 1 (MI1)	1: Multi-step speed command 1 / multi-step	
02-02	Multi-function input	position command 1	0
02-02	command 2 (MI2)	2: Multi-step speed command 2 / multi-step	0
02-03	Multi-function input	position command 2	1
02-03	command 3 (MI3)	3: Multi-step speed command 3 / multi-step	ı
02-04	Multi-function input	position command 3	2
02-04	command 4 (MI4)	4: Multi-step speed command 4 / multi-step	2
02-05	Multi-function input	position command 4	3
02-05	command 5 (MI5)	5: Reset	3
02-06	Multi-function input	6: JOG operation	4
UZ-U0	command 6 (MI6)	[by external control or KPC-CC01 (optional)]	4
02-07	Multi-function input	7: Acceleration / deceleration speed inhibit	0
02-07	command 7 (MI7)	8: 1 st and 2 nd acceleration / deceleration time selection	U
		9: 3 rd and 4 th acceleration / deceleration time selection	
		10: External Fault (EF) Input (Pr.07-20)	
		11: Base Block (B.B.) input from external	

Pr.	Explanation	Settings	Default
		12: Output stop	
		13: Cancel the setting of auto-acceleration /	
		auto-deceleration time	
		15: Rotating speed command from AVI	
		16: Rotating speed command from ACI	
		18: Force to stop (Pr.07-20)	
		19: Digital up command	
		20: Digital down command	
		21: PID function disabled	
		22: Clear the counter	
		23: Input the counter value (MI6)	
		24: FWD JOG command	
		25: REV JOG command	
		26: TQC / FOC mode selection	
		27: ASR1 / ASR2 selection	
		28: Emergency stop (EF1)	
		29: Signal confirmation for Y-connection	
		30: Signal confirmation for Δ-connection	
		31: High torque bias (Pr.11-30)	
		32: Middle torque bias (Pr.11-31)	
		33: Low torque bias (Pr.11-32)	
		38: Disable writing EEPROM function	
		39: Torque command direction	
		40: Force coasting to stop	
		41: HAND switch	
		42: AUTO switch	
		48: Mechanical gear ratio switch	
		49: Enable drive	
		50: Slave dEb action to execute	
		51: Selection for PLC mode bit 0	
		52: Selection for PLC mode bit 1	
		53: Trigger CANopen quick stop	
		56: Local / Remote selection	
		58: Enable fire mode (with RUN command)	
		59: Enable fire mode (without RUN command)	
		70: Force auxiliary frequency return to 0	
		71: Disable PID function, force PID output return to 0	
		72: Disable PID function, retain the output value before	
		disabled	
		73: Force PID integral gain return to 0, disable integral	

	Pr.	Explanation	Settings	Default
			74: Reverse PID feedback	
			81: Simple positioning zero point position signal input	
			82: OOB loading balance detection	
			83: Multi-motor (IM) selection bit 0	
			84: Multi-motor (IM) selection bit 1	
			0: UP / DOWN by the acceleration / deceleration time	
			1: UP / DOWN constant speed (Pr.02-10)	
×	02-09	UP / DOWN key mode	2: Pulse signal (Pr.02-10)	0
			3: External terminals UP / DOWN mode	
			4: External terminals UP / DOWN mode (Pr.02-10)	
		Constant speed,		
	02-10	acceleration / deceleration	0.001–1.000 Hz/ms	0.004
~	02-10	speed of the UP/DOWN	0.001-1.000 H2/MS	0.001
		Key		
	02-11	Multi-function input	0.000-30.000 sec.	0.005
~	02-11	response time	0.000–30.000 Sec.	0.003
	02-12	Multi-function input mode	0000h–FFFFh (0: N.O.; 1: N.C.)	0000
~	02-12	selection	000011-FFF11 (0. N.O., 1. N.O.)	0000
	02-13	Multi-function output 1	0: No function	11
<i></i>	02-10	(RY1)	1: Indication during RUN	1.1
<i></i>	02-16	Multi-function output 2	2: Operation speed reached	0
	02-10	(MO1)	3: Desired frequency reached 1 (Pr.02-22)	0
~	02-17	Multi-function output 3	4: Desired frequency reached 2 (Pr.02-24)	0
	02-17	(MO2)	5: Zero speed (Frequency command)	U
			6: Zero speed including STOP (Frequency command)	
			7: Over-torque 1 (Pr.06-06-08)	
			8: Over-torque 2 (Pr.06-09-06-11)	
			9: Drive is ready	
			10: Low voltage warning (Lv) (Pr.06-00)	
			11: Malfunction indication	
			13: Overheat warning (Pr.06-15)	
			14: Software brake signal indicator (Pr.07-00)	
			15: PID feedback error (Pr.08-13, Pr.08-14)	
			16: Slip error (oSL)	
			17: Count value reached, does not return to 0 (Pr.02-20)	
			18: Count value reached, return to 0 (Pr.02-19)	
			19: External interrupt B.B. input (Base Block)	
			20: Warning output	
			21: Over-voltage	
			22: Over-current stall prevention	

Pr.	Explanation	Settings	Default
		23: Over-voltage stall prevention	
		24: Operation mode	
		25: Forward command	
		26: Reverse command	
		29: Output when frequency ≥ Pr.02-34	
		30: Output when frequency < Pr.02-34	
		31: Y-connection for the motor coil	
		32: Δ -connection for the motor coil	
		33: Zero speed (actual output frequency)	
		34: Zero speed including STOP (actual output frequency)	
		35: Error output selection 1 (Pr.06-23)	
		36: Error output selection 2 (Pr.06-24)	
		37: Error output selection 3 (Pr.06-25)	
		38: Error output selection 4 (Pr.06-26)	
		40: Speed reached (including STOP)	
		42: Crane function	
		43: Motor speed detection	
		44: Low current output (use with Pr.06-71-06-73)	
		45: UVW output electromagnetic valve switch	
		46: Master dEb output	
		50: Output control for CANopen	
		51: Analog output control for RS-485 interface	
		52: Output control for communication cards	
		53: Fire mode indication	
		66: SO output logic A	
		67: Analog input level reached	
		68: SO output logic B	
		73: Over-torque 3	
		74: Over-torque 4	
		75: Forward RUN status	
		76: Reverse RUN status	
02-18	Multi-function output direction	0000h–FFFFh (0: N.O.; 1: N.C.)	0000h
02-19	Terminal counting value reached (returns to 0)	0–65500	0
	Preliminary counting value		
02-20	reached	0–65500	0
- - -	(does not return to 0)		-
02-21	Digital output gain (DFM)	1–55	1
VL-∠ I	Digital Output gall (DI W)	1. 55	

	Pr.	Explanation	Settings	Default
~	02-22	Desired frequency reached	0.00-599.00 Hz	60.00 /
,	02 22	1	0.00 000.00112	50.00
N	02-23	The width of the desired	0.00–599.00 Hz	2.00
-		frequency reached 1		22.22.4
×	02-24	Desired frequency	0.00–599.00 Hz	60.00 /
-		reached 2 The width of the desired		50.00
*	02-25	frequency reached 2	0.00–599.00 Hz	2.00
		Output frequency setting	0.00-599.00 Hz	
×	02-34	for multi-function output	(Motor speed when using PG Card)	0.00
-		terminal		
.,	00.05	External operation control	Disable Drive runs if the RUN command remains after reset or	0
~	02-35	selection after reset and reboot	reboot	0
~	02-47	Motor zero-speed level	0–65535 rpm	0
		Display the status of multi-		
	02-50	function input terminal	Monitor the status of multi-function input terminals	Read only
-	00.54	Display the status of multi-	Manifest the state of model for ation and the state of	Deed and
	02-51	function output terminal	Monitor the status of multi-function output terminals	Read only
		Display the external multi-		
	02-52	function input terminals	Monitor the status of PLC input terminals	Read only
-		used by PLC		
		Display the external multi-		
	02-53	function output terminals	Monitor the status of PLC output terminals	Read only
-		used by PLC		
	02-54	Display the frequency command executed by	0.00-599.00 Hz (Read only)	Read only
	02 0 .	external terminal	olog good ne (right girly)	Trodu orny
-		Multi-function output		
	00.50	terminal (function 42):	0.00 500 00 11-	0.00
*	02-58	brake frequency check	0.00–599.00 Hz	0.00
-		point		
-	02-78	Motor deceleration ratio	4.0–1000.0	200.0
	02-79	Automatic positioning	0.0-6480.0	180.0
-		angle setting		
	02-80	Automatic positioning	0.00: Disable the function	0.00
-		deceleration time	0.01–100.00 sec.	
	NO 04	EF activates when the terminal count value	0: Terminal count value reached, no EF displays	
~	02-81	reached	(continues to operate) 1: Terminal count value reached, EF activates	0
		reached	i. ieiiiiilai count value reacheu, Er activates	

	Pr.	Explanation	Settings	Default
		Initial Frequency	0: Use current Frequency command	
×	02-82	command (F) mode after	1: Use zero Frequency Command	0
		stop	2: Refer to Pr.02-83 to set up	
		Initial Frequency		
×	02-83	command (F) setting after	0.00–599.00 Hz	60.00
		stop		

03 Analog Input / Output Parameters

	Pr.	Explanation	Settings	Default
*	03-00	Analog input selection (AVI)	0: No function 1: Frequency command 2: Torque command (torque limit under speed mode) 3: Torque compensation command 4: PID target value 5: PID feedback signal 6: Thermistor (PTC) input value	1
×	03-01	Analog input selection (ACI)	7: Positive torque limit 8: Negative torque limit 9: Regenerative torque limit 10: Positive / negative torque limit 11: PT100 thermistor input value 12: Auxiliary frequency input 13: PID compensation value	0
~	03-03	Analog input bias (AVI)	-100.0–100.0%	0
*	03-04	Analog input bias (ACI)	-100.0–100.0%	0
*	03-07	Positive / negative bias mode (AVI)	0: No bias1: Lower than or equal to bias2: Greater than or equal to bias3: The absolute value of the bias voltage while serving as	0
*	03-08	Positive / negative bias mode (ACI)	the center 4: Bias serves as the center	
*	03-10	Reverse setting when analog signal input is negative frequency	O: Negative frequency input is not allowed. The digital keypad or external terminal controls the forward and reverse direction. 1: Negative frequency input is allowed. Positive frequency = run in a forward direction; negative frequency = run in a reverse direction. The digital keypad or external terminal control cannot change the running direction.	0
*	03-11	Analog input gain (AVI)	-500.0–500.0%	100.0
*	03-12	Analog input gain (ACI)	-500.0–500.0%	100.0
*	03-15	Analog input filter time (AVI)	0.00–20.00 sec.	0.01
*	03-16	Analog input filter time (ACI)	0.00–20.00 sec.	0.01
*	03-18	Analog input addition function	0: Disable (AVI, ACI) 1: Enable (excludes analog extension card)	0

	Pr.	Explanation	Settings	Default
			0: Disable	
	00.40	Signal loss selection for	1: Continue operation at the last frequency	•
	03-19	analog input 4–20 mA	2: Decelerate to 0 Hz	0
			3: Stop immediately and display "ACE"	
			0: Output frequency (Hz)	
			1: Frequency command (Hz)	
			2: Motor speed (Hz)	
			3: Output current (rms)	
			4: Output voltage	
			5: DC bus voltage	
			6: Power factor	
			7: Power	
			8: Output torque	
			9: AVI	
	03-20		10: ACI	
N		Multi-function output	12: Iq current command	0
		(AFM)	13: Iq feedback value	
			14: Id current command	
			15: Id feedback value	
			16: Vq-axis voltage command	
			17: Vd-axis voltage command	
			18: Torque command	
			19: PG2 frequency command	
			20: CANopen analog output	
			21: RS-485 analog output	
			22: Communication card analog output	
			23: Constant voltage output	
N	03-21	Analog output gain (AFM)	0.0–500.0%	100.0
			0: Absolute value in output voltage	
N	03-22	Analog output in REV	1: Reverse output 0 V; forward output 0–10 V	0
		direction (AFM)	2: Reverse output 5–0 V; forward output 5–10 V	
N	03-27	AFM output bias	-100.00–100.00%	0.00
	00.00	AVI terminal input	0: 0–10 V (Pr.03-63–Pr.03-68 is valid)	
×	03-28	selection	3: -10–10 V (Pr.03-69–Pr.03-74 are valid)	0
		1011	0: 4–20 mA	
N	03-29	ACI terminal input	1: 0–10 V	0
		selection	2: 0–20 mA	
		PLC analog output	Monitor the status of the PLC analog output terminals	
	03-30	terminal status	bit 0: AFM	Read only

	Pr.	Explanation	Settings	Default
			0: 0–10 V output	
×	03-31	AFM output selection	1: 0–20 mA output	0
_			2: 4–20 mA output	
*	03-32	AFM DC output setting level	0.00-100.00%	0.00
×	03-35	AFM output filter time	0.00-20.00 sec.	0.01
	03-39	VD input coloation	0: Disable	1
~	03-39	VR input selection	1: Frequency command	1
×	03-40	VR input bias	-100.0–100.0%	0.0
-			0: No bias	
			1: Lower than or equal to bias	
	02.44	VD positive / posetive bios	2: Greater than or equal to bias	0
*	03-41	VR positive / negative bias	3: The absolute value of the bias voltage while serving as	0
			the center	
			4: Bias serves as the center	
×	03-42	VR gain	-500.0–500.0%	100.0
×	03-43	VR filter time	0.00–2.00 sec.	0.01
	00.44	Multi-function output (MO)	0: AVI	0
×	03-44	by Al level source	1: ACI	0
×	03-45	Al upper level	-100–100%	50
×	03-46	Al lower level	-100–100%	10
•			0: Normal curve	
	02.50	Analog input curve selection	1: Three-point curve of AVI	0
×	03-50		2: Three-point curve of ACI	0
			3: Three-point curve of AVI & ACI	
	00.57	A CALL	Pr.03-29 = 1, 0.00–10.00 V	4.00
~	03-57	ACI lowest point	Pr.03-29 ≠ 1, 0.00–20.00 mA	4.00
*	03-58	ACI proportional lowest point	0.00–100.00%	0.00
	03-59	ACI mid point	Pr.03-29 = 1, 0.00–10.00 V	12.00
~	03-59	ACI mid-point	Pr.03-29 ≠ 1, 0.00–20.00 mA	12.00
×	03-60	ACI proportional mid-point	0.00-100.00%	50.00
	02.64	ACI highest point	Pr.03-29 = 1, 0.00–10.00 V	20.00
~	03-61	ACI highest point	Pr.03-29 ≠ 1, 0.00–20.00 mA	20.00
*	03-62	ACI proportional highest point	0.00-100.00%	100.00
×	03-63	AVI voltage lowest point	0.00–10.00 V	0.00
*	03-64	AVI proportional lowest point	-100.00–100.00%	0.00
*	03-65	AVI voltage mid-point	0.00–10.00 V	5.00

	Pr.	Explanation	Settings	Default
×	03-66	AVI proportional mid-point	-100.00–100.00%	50.00
×	03-67	AVI voltage highest point	0.00–10.00 V	10.00
*	03-68	AVI proportional highest point	-100.00–100.00%	100.00
	03 60	Negative AVI voltage	-10.00–0.00 V	0.00
	03-69	lowest point	(valid when Pr.03-28 sets as -10–10 V)	0.00
~	03-70	Negative AVI proportional	-100.00–100.00%	0.00
^	03-70	lowest point	(valid when Pr.03-28 sets as -10–10 V)	0.00
~	03-71	Negative AVI voltage	-10.00–0.00 V	-5.00
^		mid-point	(valid when Pr.03-28 sets as -10–10 V)	
~	03-72	Negative AVI proportional	-100.00–100.00%	-50.00
^	00-72	mid-point	(valid when Pr.03-28 sets as -10–10 V)	-30.00
*	03-73	Negative AVI voltage	-10.00–0.00 V	-10.00
,	00-70	highest point	(valid when Pr.03-28 sets as -10–10 V)	-10.00
~	N3-7 <i>4</i>	Negative AVI proportional	-100.00–100.00%	-100.00
,	03-74	highest point	(valid when Pr.03-28 sets as -10–10 V)	-100.00

04 Multi-step Speed Parameters

	Pr.	Explanation	Settings	Default
×	04-00	1st step speed frequency	0.00-599.00 Hz	0.00
×	04-01	2 nd step speed frequency	0.00–599.00 Hz	0.00
×	04-02	3 rd step speed frequency	0.00–599.00 Hz	0.00
×	04-03	4 th step speed frequency	0.00-599.00 Hz	0.00
×	04-04	5 th step speed frequency	0.00-599.00 Hz	0.00
×	04-05	6 th step speed frequency	0.00-599.00 Hz	0.00
×	04-06	7 th step speed frequency	0.00-599.00 Hz	0.00
×	04-07	8 th step speed frequency	0.00-599.00 Hz	0.00
×	04-08	9 th step speed frequency	0.00-599.00 Hz	0.00
\mathcal{M}	04-09	10 th step speed frequency	0.00-599.00 Hz	0.00
×	04-10	11 th step speed frequency	0.00-599.00 Hz	0.00
×	04-11	12 th step speed frequency	0.00–599.00 Hz	0.00
×	04-12	13 th step speed frequency	0.00-599.00 Hz	0.00
×	04-13	14 th step speed frequency	0.00-599.00 Hz	0.00
×	04-14	15 th step speed frequency	0.00-599.00 Hz	0.00
×	04-50	PLC buffer 0	0–65535	0
×	04-51	PLC buffer 1	0–65535	0
×	04-52	PLC buffer 2	0–65535	0
×	04-53	PLC buffer 3	0–65535	0
×	04-54	PLC buffer 4	0–65535	0
*	04-55	PLC buffer 5	0–65535	0
×	04-56	PLC buffer 6	0–65535	0
×	04-57	PLC buffer 7	0–65535	0
×	04-58	PLC buffer 8	0–65535	0
×	04-59	PLC buffer 9	0–65535	0
×	04-60	PLC buffer 10	0–65535	0
×	04-61	PLC buffer 11	0–65535	0
×	04-62	PLC buffer 12	0–65535	0
×	04-63	PLC buffer 13	0–65535	0
×	04-64	PLC buffer 14	0–65535	0
×	04-65	PLC buffer 15	0–65535	0
×	04-66	PLC buffer 16	0–65535	0
*	04-67	PLC buffer 17	0–65535	0
*	04-68	PLC buffer 18	0–65535	0
×	04-69	PLC buffer 19	0–65535	0

05 Motor Parameters

	Pr.	Explanation	Settings	Default
			No function Dynamic test for induction motor (IM)	
	05.00	Motor parameter	2: Static test for induction motor (IM)	0
	05-00	auto-tuning	5: Rolling auto-tuning for PM (IPM / SPM)	0
			12: FOC sensorless inertia estimation	
			13: High frequency stall test for PM	
	05-01	Full-load current for induction motor 1 (A)	10–120% of the drive's rated current	Depending on the model power
*	05-02	Rated power for induction motor 1 (kW)	0.00-655.35 kW	Depending on the model power
*	05-03	Rated speed for induction motor 1 (rpm)	0–xxxxx rpm (Depending on the motor's number of poles) 1710 (60 Hz, 4 poles); 1410 (50 Hz, 4 poles)	Depending on the motor's number of poles
	05-04	Number of poles for induction motor 1	2–20	4
	05-05	No-load current for induction motor 1 (A)	0.00-Pr.05-01 default	Depending on the model power
•	05-06	Stator resistance (Rs) for induction motor 1	$0.000-65.535~\Omega$	Depending on the model power
	05-07	Rotor resistance (Rr) for induction motor 1	$0.000-65.535~\Omega$	0.000
	05-08	Magnetizing inductance (Lm) for induction motor 1	0.0–6553.5 mH	0.0
	05-09	Stator inductance (Lx) for induction motor 1	0.0–6553.5 mH	0.0
	05-13	Full-load current for induction motor 2 (A)	10–120% of the drive's rated current	Depending on the model power
*	05-14	Rated power for induction motor 2 (kW)	0.00–655.35 kW	Depending on the model power
*	05-15	Rated speed for induction motor 2 (rpm)	0-xxxxx rpm (Depending on the motor's number of poles) 1710 (60 Hz, 4 poles); 1410 (50 Hz, 4 poles)	Depending on the motor's number of poles
	05-16	Number of poles for induction motor 2	2–20	4
	05-17	No-load current for induction motor 2 (A)	0.00-Pr.05-13 default	Depending on the model power

	Pr.	Explanation	Settings	Default
	05-18	Stator resistance (Rs) for induction motor 2	$0.000-65.535~\Omega$	Depending on the model power
	05-19	Rotor resistance (Rr) for induction motor 2	$0.000-65.535~\Omega$	0.000
	05-20	Magnetizing inductance (Lm) for induction motor 2	0.0-6553.5 mH	0.0
	05-21	Stator inductance (Lx) for induction motor 2	0.0-6553.5 mH	0.0
	05-22	Multi-motor (induction) selection	1: Motor 1 2: Motor 2 3: Motor 3 (VF or SVC control mode only) 4: Motor 4 (VF or SVC control mode only)	1
*	05-23	Frequency for Y- connection / △-connection switch for an induction motor	0.00–599.00 Hz	60.00
	05-24	Y-connection /Δ-connection switch for an induction motor	0: Disable 1: Enable	0
*	05-25	Delay time for Y-connection /Δ-connection switch for an induction motor	0.000-60.000 sec.	0.200
	05-26	Accumulated Watt-second for a motor in low word (W-msec.)	Read only	0.0
	05-27	Accumulated Watt-second for a motor in high word (W-sec.)	Read only	0.0
•	05-28	Accumulated Watt-hour for a motor (W-hour)	Read only	0.0
	05-29	Accumulated Watt-hour for a motor in low word (kW-hour)	Read only	0.0
	05-30	Accumulated Watt-hour for a motor in high word (MW-hour)	Read only	0.0
	05-31	Accumulated motor operation time (minutes)	0–1439	0
	05-32	Accumulated motor operation time (days)	0–65535	0

Pr.	Explanation	Settings	Default
05-33	Induction motor (IM) or permanent magnet synchronous AC motor (PM) selection	0: IM (Induction motor) 1: SPM (Surface permanent magnet synchronous AC motor) 2: IPM (Interior permanent magnet synchronous AC motor)	0
05-34	Full-load current for a permanent magnet synchronous AC motor	0–120% of the drive's rated current	Depending on the model power
05-35	Rated power for a permanent magnet synchronous AC motor	0.00–655.35 kW	Depending on the motor power
05-36	Rated speed for a permanent magnet synchronous AC motor	0–65535 rpm	2000
05-37	Number of poles for a permanent magnet synchronous AC motor	0–65535	10
05-39	Stator resistance for a permanent magnet synchronous AC motor	0.000–65.535 Ω	0.000
05-40	Permanent magnet synchronous AC motor Ld	0.00–655.35 mH	0.00
05-41	Permanent magnet synchronous AC motor Lq	0.00–655.35 mH	0.00
05-43	Ke parameter of a permanent magnet synchronous AC motor	0–65535 (Unit: V / krpm)	0
05-64	Full-load current for induction motor 3 (A)	10–120% of the drive's rated current	Depending on the model power
05-65	Rated power for induction motor 3 (kW)	0.00–655.35 kW	Depending on the model power
05-66	Rated speed for induction motor 3 (rpm)	0–xxxxx rpm (Depending on the motor's number of poles) 1710 (60 Hz, 4 poles); 1410 (50 Hz, 4 poles)	Depending
05-67	Number of poles for induction motor 3	2–20	4
05-68	No-load current for induction motor 3 (A)	0.00-Pr.05-64 default	Depending on the model power

	Pr.	Explanation	Settings	Default
	05-69	Stator resistance (Rs) for induction motor 3	0.000–65.535 Ω	Depending on the model power
	05-70	Full-load current for induction motor 4 (A)	10–120% of the drive's rated current	Depending on the model power
*	05-71	Rated power for induction motor 4 (kW)	0.00–655.35 kW	Depending on the model power
*	05-72	Rated speed for induction motor 4 (rpm)	0–xxxxx rpm (Depending on the motor's number of poles) 1710 (60 Hz, 4 poles); 1410 (50 Hz, 4 poles)	Depending on the motor's number of poles
	05-73	Number of poles for induction motor 4	2–20	4
	05-74	No-load current for induction motor 4 (A)	0.00–Pr.05-70 default	Depending on the model power
	05-75	Stator resistance (Rs) for induction motor 4	0.000–65.535 Ω	Depending on the model power

06 Protection Parameters (1)

	Pr.	Explanation	Settings	Default
			115V / 230V models: 150.0–220.0 V _{DC}	180.0
×	06-00	Low voltage level	460V models: 300.0–440.0 V _{DC}	360.0
			575V models: 375.0–550.0 V _{DC}	450.0
			0: Disable	
.	06-01	Over-voltage stall	115V / 230V models: 0.0–390.0 V _{DC}	380.0
	06-01	prevention	460V models: 0.0–780.0 V _{DC}	760.0
			575V models: 0.0–1000.0 V _{DC}	975.0
	06.00	Selection for over-voltage	0: Traditional over-voltage stall prevention	0
	06-02	stall prevention	1: Smart over-voltage stall prevention	0
•		Over everent stell	Normal load: 0–150%	120
	06.02	Over-current stall	(100% corresponds to the rated current of the drive)	
*	06-03	prevention during	Heavy load: 0–200%	180
		acceleration	(100% corresponds to the rated current of the drive)	
•		Over everent stell	Normal load: 0–150%	120
	06-04 prevent	Over-current stall prevention during operation	(100% corresponds to the rated current of the drive)	
*			Heavy load: 0–200%	180
			(100% corresponds to the rated current of the drive)	
			0: By current acceleration / deceleration time	
		Acceleration / deceleration	1: By the first acceleration / deceleration time	
	06-05	time selection for stall	2: By the second acceleration / deceleration time	0
	06-05	prevention at constant	3: By the third acceleration / deceleration time	0
		speed	4: By the fourth acceleration / deceleration time	
			5: By Auto-acceleration / auto-deceleration	
			0: No function	
			1: Continue operation after over-torque detection during	
			constant speed operation	
~	06-06	Over-torque detection	2: Stop after over-torque detection during constant	0
_	00-00	selection (motor 1)	speed operation	U
			3: Continue operation after over-torque detection during	
			RUN	
_			4: Stop after over-torque detection during RUN	
~	06-07	Over-torque detection	10–250%	120
/*	00-01	level (motor 1)	(100% corresponds to the rated current of the drive)	120
~	06-08	Over-torque detection	0.1–60.0 sec.	0.1
	00-00	time (motor 1)	0.1 00.0 300.	0.1

	Pr.	Explanation	Settings	Default
			0: No function	
			1: Continue operation after over-torque detection during	
			constant speed operation	
N	06-09	Over-torque detection	2: Stop after over-torque detection during constant speed	0
,	00-03	selection (motor 2)	operation	
			3: Continue operation after over-torque detection during	
			RUN	
			4: Stop after over-torque detection during RUN	
×	06-10	Over-torque detection	10–250%	120
		level (motor 2)	(100% corresponds to the rated current of the drive)	
×	06-11	Over-torque detection	0.1–60.0 sec.	0.1
		time (motor 2)		
×	06-12	Current limit	0–250%	150
			(100% corresponds to the rated current of the drive)	
	00.40	Electronic thermal relay	O: Inverter motor (with external forced cooling) O: Inverter motor (with external forced cooling)	
*	06-13	06-13 selection 1 (motor 1)	1: Standard motor (motor with fan on the shaft)	2
			2: Disabled	
×	06-14	Electronic thermal relay action time 1 (motor 1)	30.0–600.0 sec.	60.0
		` · · · · · · · · · · · · · · · · · · ·		Depending
×	06-15	Temperature level	0.0-110.0°C	on the model
		overheat (OH) warning		power
		Stall prevention limit level	0–100% (refer to Pr.06-03–Pr.06-04)	
×	06-16	(Weak magnetic field		100
		current stall prevention		
	00.47	level)		
	06-17	Fault record 1	0: No fault record	0
	06-18	Fault record 2	1: Over-current during acceleration (ocA)	0
	06-19	Fault record 3	2: Over-current during deceleration (ocd)	0
	06-20	Fault record 4 Fault record 5	3: Over-current during steady operation (ocn)	0
	06-21 06-22	Fault record 5	4: Ground fault (GFF)	0
	00-22	Fault record 6	6: Over-current at stop (ocS)	0
		Fault record 8 (Pr.14-71)	7: Over-voltage during acceleration (ovA)	0
		Fault record 9 (Pr.14-71)	8: Over-voltage during deceleration (ovd) 9: Over-voltage during constant speed (ovn)	0
		Fault record 9 (Pr.14-72)	10: Over-voltage at stop (ovS)	0
		1 auit 160010 10 (P1.14-73)	11: Low-voltage during acceleration (LvA)	U
			12: Low-voltage during deceleration (Lvd)	
			13: Low-voltage during constant speed (Lvn)	
			14: Low-voltage at stop (LvS)	
			15: Phase loss protection (orP)	

Pr.	Explanation	Settings	Default
		16: IGBT overheating (oH1)	
		18: IGBT temperature detection failure (tH1o)	
		21: Over load (oL)	
		22: Electronic thermal relay 1 protection (EoL1)	
		23: Electronic thermal relay 2 protection (EoL2)	
		24: Motor overheating PTC/ PT100 (oH3)	
		26: Over torque 1 (ot1)	
		27: Over torque 2 (ot2)	
		28: Under current (uC)	
		31: EEPROM read error (cF2)	
		33: U-phase error (cd1)	
		34: V-phase error (cd2)	
		35: W-phase error (cd3)	
		36: cc (current clamp) hardware error (Hd0)	
		37: oc (over-current) hardware error (Hd1)	
		40: Auto-tuning error (AUE)	
		41: PID loss ACI (AFE)	
		43: PG feedback loss (PGF2)	
		44: PG feedback stall (PGF3)	
		45: PG slip error (PGF4)	
		48: ACI loss (ACE)	
		49: External fault (EF)	
		50: Emergency stop (EF1)	
		51: External Base Block (bb)	
		52: Password is locked (Pcod)	
		54: Illegal command (CE1)	
		55: Illegal data address (CE2)	
		56: Illegal data value (CE3)	
		57: Data is written to read-only address (CE4)	
		58: Modbus transmission time-out (CE10)	
		61: Y-connection / △-connection switch error (ydc)	
		62: Deceleration energy backup error (dEb)	
		63: Over slip error (oSL)	
		72: STO Loss (STL1)	
		76: STO (STo)	
		77: STO Loss 2 (STL2)	
		78: STO Loss 3 (STL3)	
		79: U-phase Over-current before run (Aoc)	
		80: V-phase Over-current before run (boc)	
		81: W-phase Over-current before run (coc)	

	Pr.	Explanation	Settings	Default
			82: Output phase loss U phase (oPL1)	
			83: Output phase loss V phase (oPL2)	
			84: Output phase loss W phase (oPL3)	
			87: Low frequency overload protection (oL3)	
			89: Rotor position detection error (roPd)	
			101: CANopen guarding error (CGdE)	
			102: CANopen heartbeat error (CHbE)	
			104: CANopen bus off error (CbFE)	
			105: CANopen index error (CidE)	
			106: CANopen station address error (CAdE)	
			107: CANopen index setting exceed limit (CFrE)	
			111: InrCOM time-out error (ictE)	
			121: Internal communication error (CP20)	
			123: Internal communication error (CP22)	
			124: Internal communication error (CP30)	
			126: Internal communication error (CP32)	
			127: Internal communication error (CP33)	
			128: Over-torque 3 (ot3)	
			129: Over-torque 4 (ot4)	
			134: Internal communication error (EoL3)	
			135: Internal communication error (EoL4)	
			140: oc hardware error (Hd6)	
			141: GFF occurs before run (b4GFF)	
			142: Auto-tune error 1 (AuE1)	
			143: Auto-tune error 2 (AuE2)	
			144: Auto-tune error 3 (AuE3)	
~	06-23	Fault output option 1	0–65535 (refer to bit table for fault code)	0
×	06-24	Fault output option 2	0–65535 (refer to bit table for fault code)	0
×	06-25	Fault output option 3	0–65535 (refer to bit table for fault code)	0
×	06-26	Fault output option 4	0–65535 (refer to bit table for fault code)	0
			0: Inverter motor (with external forced cooling)	
×	06-27	Electronic thermal relay	1: Standard motor (motor with fan on the shaft)	2
		selection 2 (motor 2)	2: Disabled	
		Electronic thermal relay		
×	06-28	action time 2 (motor 2)	30.0-600.0 sec.	60.0
		,	0: Warn and continue operation	
			1: Fault and ramp to stop	
×	06-29	PTC detection selection	2: Fault and coast to stop	0
			3: No warning	
×	06-30	PTC level	0.0–100.0%	50.0
′		<u> </u>		30.0

Pr.	Explanation	Settings	Default
06-31	Frequency command at malfunction	0.00–599.00 Hz	Read only
06-32	Output frequency at malfunction	0.00–599.00 Hz	Read only
06-33	Output voltage at malfunction	0.0–6553.5 V	Read only
06-34	DC bus voltage at malfunction	0.0–6553.5 V	Read only
06-35	Output current at malfunction	0.00–655.35 Amp	Read only
06-36	IGBT temperature at malfunction	-3276.7–3276.7°C	Read only
06-38	Motor speed at malfunction	-32767–32767 rpm	Read only
06-39	Torque command at malfunction	-32767–32767%	Read only
06-40	Status of the multi-function input terminal at malfunction	0000h-FFFFh	Read only
06-41	Status of the multi-function output terminal at malfunction	0000h-FFFFh	Read only
06-42	Drive status at malfunction	0000h-FFFFh	Read only
06-44	STO latch selection	0: STO latch 1: STO no latch	0
06-45	Output phase loss detection action (OPHL)	O: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning	3
06-46	Detection time for output phase loss	0.000–65.535 sec.	0.500
06-47	Current detection level for output phase loss	0.00-100.00%	1.00
06-48	DC brake time for output phase loss	0.000-65.535 sec.	0.000
06-49	LvX auto-reset	0: Disable 1: Enable	0
06-53	Input phase loss detection action (OrP)	0: Fault and ramp to stop 1: Fault and coast to stop	0

	Pr.	Explanation	Settings	Default
			0: Constant rated current and limit carrier frequency by	
		5 Derating protection	load current and temperature	
~	06-55		1: Constant carrier frequency and limit load current by	0
,	00-00	Derating protection	setting carrier frequency	
			2: Constant rated current (same as setting 0), but close	
			current limit	
×	06-56	PT100 voltage level 1	0.000-10.000 V	5.000
×	06-57	PT100 voltage level 2	0.000-10.000 V	7.000
~	06-58	PT100 level 1 frequency	0.00–599.00 Hz	0.00
		protection		
		PT100 activation level 1		
×	06-59	protection frequency	0–6000 sec.	60
		delay time		
*	06-60	Software detection GFF current level	0.0–6553.5%	60.0
	00.04	Software detection GFF	0.00 055 05	0.40
×	06-61	filter time	0.00-655.35 sec.	0.10
	06-63	Operation time of fault record 1 (Days)	0–65535 days	Read only
		Operation time of fault	0.4400	Decite
	06-64	record 1 (Minutes)	0–1439 min.	Read only
	00.05	Operation time of fault	0.05505 4	Decelorate
	06-65	record 2 (Days)	0–65535 days	Read only
	06-66	Operation time of fault	0–1439 min.	Read only
	00-00	record 2 (Minutes)	0-1439 Hilli.	rtead only
	06-67	Operation time of fault	0–65535 days	Read only
	00 07	record 3 (Days)	o oooo aayo	rtodd orny
	06-68	Operation time of fault	0–1439 min.	Read only
		record 3 (Minutes)		
	06-69	Operation time of fault record 4 (Days)	0–65535 days	Read only
	06-70	Operation time of fault	0–1439 min.	Read only
		record 4 (Minutes)		. todd offly
×	06-71	Low current setting level	0.0–100.0%	0.0
×	06-72	Low current detection time	0.00–360.00 sec.	0.00
			0: No function	
<i>N</i>	06-73	Low current action	1: Fault and coast to stop	0
,			2: Fault and ramp to stop by the second deceleration time	
			3: Warn and continue operation	

Pr.	Explanation	Settings	Default
		0: Disable	
06-80	Fire mode	1: Forward (counterclockwise) operation	0
		2: Reverse (clockwise) operation	
06-81	Operating frequency in fire	0.00–599.00 Hz	60.00
00-61	mode	0.00–399.00 HZ	00.00
06-88	Operation times in fire	0–65535 times	Dood only
00-00	mode	0-03333 times	Read only
06.00	Operation time of fault	0–65535 days	Read only
06-90	record 5 (days)		
06.04	Operation time of fault		Read only
06-91	record 5 (minutes)	0–1439 min.	
06.00	Operation time of fault	0.05525 days	Dood only
06-92	record 6 (days)	0–65535 days	Read only
06-93	Operation time of fault	0–1439 min.	Dood only
00-93	record 6 (minutes)	U— 1438 IIIIII.	Read only

07 Special Parameters

	Pr.	Explanation	Settings	Default
		Software brake chopper	115V / 230V models: 350.0–450.0 V _{DC}	370.0
×	07-00	action level	460V models: 700.0–900.0 V _{DC}	740.0
		action level	575V models: 875.0–1000.0 V _{DC}	950.0
*	07-01	DC brake current level	0–100%	0
*	07-02	DC brake time at start-up	0.0-60.0 sec.	0.0
*	07-03	DC brake time at STOP	0.0-60.0 sec.	0.0
*	07-04	DC brake frequency at STOP	0.00–599.00 Hz	0.00
*	07-05	Voltage increasing gain	1–200%	100
*	07-06	Restart after momentary power loss	Stop operation Speed tracking by the speed before the power loss Speed tracking by the minimum output frequency	0
*	07-07	Allowed power loss duration	0.0–20.0 sec.	2.0
×	07-08	Base Block time	0.0–60.0 sec.	0.5
*	07-09	Current limit of speed tracking	20–200%	100
*	07-10	Restart after fault action	Stop operation Speed tracking by current speed Speed tracking by minimum output frequency	0
*	07-11	Number of times of restart after fault	0–10	0
*	07-12	Speed tracking during start-up	Disable Speed tracking by the maximum output frequency Speed tracking by the motor frequency at start-up Speed tracking by the minimum output frequency	0
*	07-13	dEb function selection	 Disable dEb with auto-acceleration / auto-deceleration, the drive does not output the frequency after the power is restored. dEb with auto-acceleration / auto-deceleration, the drive outputs the frequency after the power is restored. dEb low-voltage control, then the drive's voltage increases to 350 V_{DC} / 700 V_{DC} and ramps to stop after low frequency dEb high-voltage control of 350 V_{DC} / 700 V_{DC}, and the drive ramps to stop 	0
×	07-15	Dwell time at acceleration	0.00-600.00 sec.	0.00

	Pr.	Explanation	Settings	Default
*	07-16	Dwell frequency at acceleration	0.00–599.00 Hz	0.00
×	07-17	Dwell time at deceleration	0.00-600.00 sec.	0.00
*	07-18	Dwell frequency at deceleration	0.00–599.00 Hz	0.00
*	07-19	Fan cooling control	 0: Fan is always ON 1: Fan is OFF after the AC motor drive stops for one minute. 2: Fan is ON when the AC motor drive runs, fan is OFF when the AC motor drive stops. 3: Fan turns ON when temperature (IGBT) reaches around 60°C. 	3
*	07-20	Emergency stop (EF) & force to stop selection	0: Coast to stop 1: Stop by the first deceleration time 2: Stop by the second deceleration time 3: Stop by the third deceleration time 4: Stop by the fourth deceleration time 5: System deceleration 6: Automatic deceleration	0
~	07-21	Automatic energy-saving	0: Disable	0
	07.00	setting	1: Enable	400
*	07-22	Energy-saving gain	10–1000%	100
*	07-23	Automatic voltage regulation (AVR) function	0: Enable AVR1: Disable AVR2: Disable AVR during deceleration	0
*	07-24	Torque command filter time (V/F and SVC control mode)	0.001-10.000 sec.	0.050
*	07-25	Slip compensation filter time (V/F and SVC control mode)	0.001-10.000 sec.	0.100
×	07-26	Torque compensation gain (V/F and SVC control mode)	IM: 0–10 (when Pr.05-33 = 0) PM: 0–5000 (when Pr.05-33 = 1 or 2)	1
*	07-27	Slip compensation gain (V/F and SVC control mode)	0.00–10.00	0.00 (Default value is 1.00 in SVC mode)
*	07-29	Slip deviation level	0.0–100.0% 0: No detection	0
*	07-30	Over-slip deviation detection time	0.0-10.0 sec.	1.0

	Pr.	Explanation	Settings	Default
			0: Warn and continue operation	
.	07-31	Over-slip deviation	1: Fault and ramp to stop	0
^	07-31	treatment	2: Fault and coast to stop	0
			3: No warning	
~	07-32	Motor oscillation compensation factor	0–10000	1000
*	07-33	Auto-restart interval of fault	0.0-6000.0 sec.	60.0
	07-38	PMSVC voltage feed forward gain	0.50-2.00	1.00
	07-46	OOB sampling time	0.1–120.0 sec.	1.0
	07-47	Number of OOB sampling times	00–32	20
	07-48	OOB average sampling	Read only	Read
	07-40	angle	read only	only
×	07-62	dEb gain (Kp)	0–65535	8000
×	07-63	dEb gain (Ki)	0–65535	150
×	07-71	Torque compensation gain	IM: 0–10 (when Pr.05-33 = 0)	1
,		(motor 2)	PM: 0-5000 (when Pr.05-33 = 1 or 2)	
*	07-72	Slip compensation gain (motor 2)	0.00–10.00	0.00 (Default value is 1.00 in SVC mode)
	07.70	Torque compensation gain	IM: 0–10 (when Pr.05-33 = 0)	
~	07-73	(motor 3)	PM: 0–5000 (when Pr.05-33 = 1 or 2)	1
*	07-74	Slip compensation gain (motor 3)	0.00-10.00	0.00 (Default value is 1.00 in SVC mode)
	07.75	Torque compensation gain	IM: 0–10 (when Pr.05-33 = 0)	1
×	07-75	(motor 4)	PM: 0–5000 (when Pr.05-33 = 1 or 2)	1
*	07-76	Slip compensation gain (motor 4)	0.00-10.00	0.00 (Default value is 1.00 in SVC mode)

08 High-function PID Parameters

	Pr.	Explanation	Settings	Default
*	08-00	Terminal selection of PID feedback	O: No function 1: Negative PID feedback: by analog input (Pr.03-00, Pr.03-01) 2: Negative PID feedback: by single-phase input (MI7), without direction (Pr.10-16=5) 4: Positive PID feedback: by analog input (Pr.03-00, Pr.03-01) 5: Positive PID feedback: by single-phase input (MI7), without direction (Pr.10-16=5) 7: Negative PID feedback: by communication protocols 8: Positive PID feedback: by communication protocols	0
*	08-01	Proportional gain (P)	0.0–1000.0 (When Pr.08-23 bit 1=0) 0.00–100.00 (When Pr.08-23 bit 1=1)	1.00
×	08-02	Integral time (I)	0.00-100.00 sec.	1.00
×	08-03	Differential time (D)	0.00-1.00 sec.	0.00
*	08-04	Upper limit of integral control	0.0–100.0%	100.0
*	08-05	PID output command limit (positive limit)	0.0–110.0%	100.0
*	08-06	PID feedback value by communication protocol	-200.00–200.00%	0.00
×	08-07	PID delay time	0.0–2.5 sec.	0.0
*	08-08	Feedback signal detection time	0.0-3600.0 sec.	0.0
*	08-09	Feedback signal fault treatment	O: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: Warn and operate at last frequency	0
×	08-10	Sleep frequency	0.00-599.00 Hz	0.00
×	08-11	Wake-up frequency	0.00-599.00 Hz	0.00
×	08-12	Sleep time	0.0-6000.0 sec.	0.0
*	08-13	PID feedback signal error deviation level	1.0–50.0%	10.0
*	08-14	PID feedback signal error deviation detection time	0.1–300.0 sec.	5.0
*	08-15	PID feedback signal filter time	0.1–300.0 sec.	5.0
*	08-16	PID compensation selection	0: Parameter setting 1: Analog input	0

	Pr.	Explanation	Settings	Default
×	08-17	PID compensation	-100.0–100.0%	0
	00.40	Sleep mode function	0: Refer to PID output command	0
	08-18	setting	1: Refer to PID feedback signal	0
×	08-19	Wake-up integral limit	0.0–200.0%	50.0
-	00.00	PID mode selection	0: Serial connection	0
	08-20	70-20 PID Mode selection	1: Parallel connection	0
	00.01	Enable PID to change the	0: Operation direction cannot be changed	0
	08-21	operation direction	1: Operation direction can be changed	0
×	08-22	Wake-up delay time	0.00-600.00 sec.	0.00
•			bit 0 = 1: PID running in reverse follows the setting for	
			Pr.00-23.	
	00.00	DID southed flow	bit 0 = 0: PID running in reverse refers to PID's	0
*	08-23	PID control flag	calculated value.	2
			bit 1 = 1: two decimal places for PID Kp	
			bit 1 = 0: one decimal place for PID Kp	
.,	00.00	PID output command limit	0.0.100.00/	100.0
*	08-26	(reverse limit)	0.0–100.0%	100.0
.,	00.07	Acceleration / deceleration	0.00 055 05	0.00
*	08-27	time for PID command	0.00-655.35 sec.	0.00
-		_	0: PID control output 100.00% corresponding to maximum	
	00.00	Frequency base	operation frequency (Pr.01-00)	0
*	08-29	corresponding to	1: PID control output 100.00% corresponding to the input	0
		100.00% PID	value of the auxiliary frequency	
	00.04	Down and the state of	0.0–1000.0 (when Pr.08-23 setting bit1=0)	4.00
*	08-31	Proportional gain 2	0.00–100.00 (when Pr.08-23 setting bit1=1)	1.00
×	08-32	Integral time 2	0.00-100.00 sec.	1.00
×	08-33	Differential time 2	0.00–1.00 sec.	0.00
•			0: Frequency command (Pr.00-20, Pr.00-30)	
			1: Pr.08-66 setting	
			2: RS-485 communication input	
×	08-65	PID target value source	3: External analog input (refer to Pr.03-00, Pr.03-01)	0
			4: CANopen communication card	
			6: Communication card (does not include CANopen card)	
			7: Digital keypad potentiometer knob	
×	08-66	PID target value setting	-100.00–100.00%	50.00
		Master and auxiliary		
×	08-67	reverse running cutoff	0.0–100.0%	10.0
		frequency		
×	08-68	PID deviation limit	0.00-100.00%	0.00
×	08-69	Integral separation level	0.00-100.00%	0.00

	Pr.	Explanation	Settings	Default
	08-70	Smart start-up level	0.00-100.00%	5.00
*	08-71	Smart start-up frequency command	0.00–599.00 Hz	0.00
*	08-72	Smart start-up acceleration time	0.00-600.00 sec.	3.00
*	08-75	PID2 parameter switch condition	O: No switching (refer to Pr.08-01–Pr.08-03) 1: Auto-switch based on the output frequency 2: Auto-switch based on the deviation	0
*	08-76	PID2 parameter switch deviation 1	0.00-Pr.08-77%	10.00
*	08-77	PID2 parameter switch deviation 2	Pr.08-76-100.00%	40.00
*	08-78	Allowed reverse running time after start-up	0.0-6553.5 sec.	0.0

09 Communication Parameters

	Pr.	Explanation	Settings	Default
×	09-00	Communication address	1–254	1
×	09-01	COM1 transmission speed	4.8–115.2 Kbps	9.6
*	09-02	COM1 transmission fault treatment	O: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning, no fault, and continue operation	3
×	09-03	COM1 time-out detection	0.0-100.0 sec.	0.0
*	09-04	COM1 communication protocol	1: 7, N, 2 (ASCII) 2: 7, E, 1 (ASCII) 3: 7, O, 1 (ASCII) 4: 7, E, 2 (ASCII) 5: 7, O, 2 (ASCII) 6: 8, N, 1 (ASCII) 7: 8, N, 2 (ASCII) 8: 8, E, 1 (ASCII) 9: 8, O, 1 (ASCII) 10: 8, E, 2 (ASCII) 11: 8, O, 2 (ASCII) 12: 8, N, 1 (RTU) 13: 8, N, 2 (RTU) 14: 8, E, 1 (RTU) 15: 8, O, 1 (RTU) 16: 8, E, 2 (RTU) 17: 8, O, 2 (RTU)	1
*	09-09	Communication response delay time	0.0–200.0 ms	2.0
	09-10	Communication main frequency	0.00–599.00 Hz	60.00
×	09-11	Block transfer 1	0–65535	0
×	09-12	Block transfer 2	0–65535	0
×	09-13	Block transfer 3	0–65535	0
×	09-14	Block transfer 4	0–65535	0
×	09-15	Block transfer 5	0–65535	0
×	09-16	Block transfer 6	0–65535	0
×	09-17	Block transfer 7	0–65535	0
×	09-18	Block transfer 8	0–65535	0
×	09-19	Block transfer 9	0–65535	0
×	09-20	Block transfer 10	0–65535	0

	Pr.	Explanation	Settings	Default
×	09-21	Block transfer 11	0–65535	0
N	09-22	Block transfer 12	0–65535	0
~	09-23	Block transfer 13	0–65535	0
N	09-24	Block transfer 14	0–65535	0
N	09-25	Block transfer 15	0–65535	0
N	09-26	Block transfer 16	0–65535	0
	00.00	Communication decoding	0: Decoding method 1	4
	09-30	method	1: Decoding method 2	1
~	09-33	PLC command force to 0	0–65535	0
	09-35	PLC address	1–254	2
	00.00	CANLORDE	0: Disable	
	09-36	CANopen slave address	1–127	0
			0: 1 Mbps	
		7 CANopen speed	1: 500 Kbps	
	00.07		2: 250 Kbps	
	09-37 CANopen speed		3: 125 Kbps	0
		4: 100 Kbps (Delta only)		
		5: 50 Kbps		
			bit 0: CANopen software disconnection 1	
			(CANopen guarding time-out)	
			bit 1: CANopen software disconnection 2	
			(CANopen heartbeat time-out)	
	09-39		bit 3: CANopen SDO time-out	0
	09-39	CANopen warning record	bit 4: CANopen SDO buffer overflow	0
			bit 5: CANopen hardware disconnection warning	
			(CANopen bus off)	
			bit 6: CANopen format error warning	
			(Error protocol for CANopen)	
	09-40	CANopen decoding	0: Use Delta-defined decoding method	1
	00-40	method	1: Use CANopen standard DS402 protocol	'
			0: Node reset state	
			1: Com reset state	
	09-41	CANopen communication	2: Boot up state	Read only
	00-41	status	3: Pre-operation state	Tread only
			4: Operation state	
			5: Stop state	

	Pr.	Explanation	Settings	Default
			0: Not ready for use state	
			1: Inhibit start state	
			2: Ready to switch on state	
	09-42	CANopen control status	3: Switched on state	Read only
	03-42	CANOPER CORROL Status	4: Enable operation state	ixeau only
			7: Quick stop active state	
			13: Error reaction activation state	
			14: Error state	
			bit 0: CANopen reset, the internal address 20XX is 0	
	09-43	CANopen reset index	bit 1: CANopen reset, the internal address 264X is 0	65535
	09-43	CANopen reset index	bit 2: CANopen reset, the internal address 26AX is 0	00000
			bit 3: CANopen reset, the internal address 60XX is 0	
			0: No communication card	
			1: DeviceNet slave	
			2: PROFIBUS-DP slave	
	09-60	Communication card	3: CANopen slave	Dood only
	09-60	identification	4: Modbus-TCP slave	Read only
			5: EtherNet/IP slave	
			6: EtherCAT	
			10: Backup power supply	
	09-61	Firmware version of	Pood only	Pood only
	09-01	communication card	Read only	Read Only
	09-62	Product code	Read only	Read only
	09-63	Error code	Read only	Read only
		Communication card	DeviceNet: 0–63	
✓	09-70	address	PROFIBUS-DP: 1–125	1
		(for DeviceNet or PROFIBUS)	1 NOT 1003-01 . 1-123	
			Standard DeviceNet:	
			0: 125 Kbps	
			1: 250 Kbps	
			2: 500 Kbps	
			3: 1 Mbps (Delta only)	
		Communication card	Non-standard DeviceNet (Delta only):	
~	09-71	speed setting	0: 10 Kbps	2
		(for DeviceNet)	1: 20 Kbps	
			2: 50 Kbps	
			3: 100 Kbps	Read only
			4: 125 Kbps	
			5: 250 Kbps	
			6: 500 Kbps	

	Pr.	Explanation	Settings	Default
			7: 800 Kbps	
			8: 1 Mbps	
			0: Disable	
			In this mode, the baud rate can only be 125 Kbps,	
		Additional settings for	250 Kbps, 500 Kbps, or 1 Mbps in standard	
×	09-72	communication card speed	DeviceNet speed.	0
		(for DeviceNet)	1: Enable	
			In this mode, DeviceNet baud rate can be same as	
			that for CANopen (0–8).	
		Communication card IP	0: Static IP	
×	09-75	configuration	1: Dynamic IP (DHCP)	0
		(for Modbus TCP)	1. Dynamic ir (Dilor)	
		Communication card IP		
×	09-76	address 1	0–255	0
		(for Modbus TCP)		
		Communication card IP		
×	09-77	address 2	0–255	0
		(for Modbus TCP)		
		Communication card IP		
×	09-78	address 3	0–255	0
		(for Modbus TCP)		
		Communication card IP		
×	09-79	address 4	0–255	0
		(for Modbus TCP)		
		Communication card		
×	09-80	address mask 1	0–255	0
		(for Modbus TCP)		
		Communication card		
×	09-81	address mask 2	0–255	0
		(for Modbus TCP)		
		Communication card		
×	09-82	address mask 3	0–255	0
		(for Modbus TCP)		
		Communication card		
×	09-83	address mask 4	0–255	0
		(for Modbus TCP)		
	_	Communication card		
×	09-84	gateway address 1	0–255	0
		(for Modbus TCP)		

	Pr.	Explanation	Settings	Default
		Communication card		
×	09-85	gateway address 2	0–255	0
		(for Modbus TCP)		
		Communication card		
×	09-86	gateway address 3	0–255	0
		(for Modbus TCP)		
		Communication card		
×	09-87	gateway address 4	0–255	0
		(for Modbus TCP)		
		Communication card		
×	09-88	password (low word)	0–99	0
		(for Modbus TCP)		
		Communication card		
×	09-89	password (high word)	0–99	0
		(for Modbus TCP)		
	09-90	Reset communication card	0: Disable	0
^	09-90	(for Modbus TCP)	1: Reset to defaults	0
			bit 0: Enable IP filter	
			bit 1: Enable internet parameters (1 bit)	
			When the IP address is set, this bit is enabled. After	
		Additional settings for the	updating the parameters for the communication	
×	09-91	communication card	card, this bit changes to disabled.	0
		(for Modbus TCP)	bit 2: Enable login password (1 bit)	
			When you enter the login password, this bit is	
			enabled. After updating the communication card	
			parameters, this bit changes to disabled.	
			bit 0: Enable password	
	09-92	Communication card status	When the communication card is set with a	0
	55 52	(for Modbus TCP)	password, this bit is enabled. When the password	
			is cleared, this bit is disabled.	

10 Speed Feedback Control Parameters

	Pr.	Explanation	Settings	Default
	10-00	Encoder type selection	0: Disabled 5: Pulse input (MI7)	0
	10-01	Encoder pulses per revolution	1–20000	600
	10-02	Encoder input type setting	0: Disable 5: Single-phase input (MI7)	0
*	10-04	Electrical gear at load side A1	1–65535	100
*	10-05	Electrical gear at motor side B1	1–65535	100
*	10-06	Electrical gear at load side A2	1–65535	100
*	10-07	Electrical gear at motor side B2	1–65535	100
*	10-10	Encoder stall level	0: No function 0–120%	115
*	10-11	Detection time of encoder stall	0.0–2.0 sec.	0.1
*	10-12	Encoder stall action	O: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop	2
*	10-13	Encoder slip range	0: Disable 0–50%	50
*	10-14	Detection time of encoder slip	0.0-10.0 sec.	0.5
*	10-15	Encoder stall and slip error action	O: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop	2
*	10-16	Pulse input type setting	0: Disabled 5: Single-phase input (MI7)	0
~	10-17	Electrical gear A	1–65535	100
×	10-18	Electrical gear B	1–65535	100
*	10-21	PG2 pulse input speed command low pass filter time	0.000–65.535 sec.	0.100
*	10-24	FOC & TQC function control	0–65535	0

	Pr.	Explanation	Settings	Default
*	10-25	FOC bandwidth for speed observer	20.0–100.0 Hz	40.0
*	10-26	FOC minimum stator frequency	0.0-10.0% fN	2.0
*	10-27	FOC low pass filter time constant	1–1000 ms	50
*	10-28	FOC gain for excitation current rise time	33–100% Tr	100
*	10-29	Upper limit of frequency deviation	0.00–200.00 Hz	20.00
*	10-31	I/F mode, current command	0–150% rated current of the motor	40
*	10-32	PM FOC sensorless speed estimator bandwidth	0.00–600.00 Hz	5.00
*	10-34	PM sensorless speed estimator low-pass filter gain	0.00-655.35	1.00
×	10-35	AMR (Kp) gain	0.00-3.00	1.00
×	10-36	AMR (Ki) gain	0.00-3.00	0.20
*	10-39	Frequency point to switch from I/F mode to PM sensorless mode	0.00–599.00 Hz	20.00
*	10-40	Frequency point to switch from PM sensorless mode to I/F mode	0.00–599.00 Hz	20.00
*	10-42	Initial angle detection pulse value	0.0–3.0	1.0
*	10-49	Zero voltage time during start-up	0.000-60.000 sec.	0.000
~	10-51	Injection frequency	0–1200 Hz	500
*	10-52	Injection magnitude	115V / 230V models: 100.0 V 460V models: 200.0 V 575V models: 200.0 V Note: The setting range varies depending on the voltage.	15.0 30.0 37.5
*	10-53	Angle detection method	0: Disabled 1: Force attracting the rotor to zero degrees 2: High frequency injection 3: Pulse injection	0

11 Advanced Parameters

	Pr.	Explanation	Settings	Default
			bit 0: Auto-tuning for ASR and APR	
	11-00	System control	bit 3: Dead time compensation closed	0
			bit 7: Save or do not save the frequency	
	11-01	Per-unit of system inertia	1–65535 (256 = 1 PU)	256
*	11-02	ASR1 / ASR2 switch frequency	5.00–599.00 Hz	7.00
*	11-03	ASR1 low-speed bandwidth	1–40 Hz	Read only
*	11-04	ASR2 high-speed bandwidth	1–40 Hz	Read only
×	11-05	Zero-speed bandwidth	1–40 Hz	Read only
×	11-06	ASR1 gain	0–40 Hz	10
×	11-07	ASR1 integral time	0.000-10.000 sec.	0.100
*	11-08	ASR2 gain	0–40 Hz	10
×	11-09	ASR2 integral time	0.000-10.000 sec.	0.100
×	11-10	ASR gain of zero speed	0–40 Hz	10
*	11-11	ASR integral time of zero speed	0.000-10.000 sec.	0.100
*	11-12	Gain for ASR speed feed forward	0–200%	0
×	11-13	PDFF gain value	0–200%	30
*	11-14	ASR output low pass filter time	0.000-0.350 sec.	0.008
×	11-15	Notch filter depth	0-20 db	0
×	11-16	Notch filter frequency	0.00–200.00 Hz	0.00
×	11-17	Forward motor torque limit	0–500%	500
*	11-18	Forward regenerative torque limit	0–500%	500
×	11-19	Reverse motor torque limit	0–500%	500
*	11-20	Reverse regenerative torque limit	0–500%	500
*	11-21	Flux weakening curve for motor 1 gain value	0–200%	90
*	11-22	Flux weakening curve for motor 2 gain value	0–200%	90
*	11-23	Flux weakening area speed response	0–150%	65

	Pr.	Explanation	Settings	Default
×	11-27	Maximum torque command	0–500%	100
			0: Disable	
			1: Analog signal input	
×	11-28	Torque offset source	2: RS-485 communication (Pr.11-29)	0
			3: Controlled through external terminals (Pr.11-30–11-	
			32)	
×	11-29	Torque offset setting	-100.0–100.0%	0.0
×	11-30	High torque offset	-100.0–100.0%	30.0
×	11-31	Middle torque offset	-100.0–100.0%	20.0
×	11-32	Low torque offset	-100.0–100.0%	10.0
			0: Digital keypad	
			1: RS-485 communication (Pr.11-34)	
×	11-33	Torque command source	2: Analog signal input (Pr.03-00)	0
			3: CANopen	
			5: Communication Card	
×	11-34	Torque command	-100.0–100.0%	0.0
×	11-35	Torque command filter time	0.000–1.000 sec.	0.000
			0: Set by Pr.11-37 (forward speed limit) and Pr.11-38	
			(reverse speed limit)	
	11-36	11-36 Speed limit selection	1: Set by Pr.00-20 (Master frequency command (AUTO,	0
	11 00	opoda iiiiii oolodaan	REMOTE) source) and Pr.11-37, Pr.11-38	· ·
			2: Set by Pr.00-20 (master frequency command (AUTO,	
			REMOTE) source)	
×	11-37	Forward speed limit	0–120%	10
		(Torque mode)		
N	11-38	Reverse speed limit	0–120%	10
		(Torque mode)		
	11-41	PWM mode selection	0: Two-phase modulation mode	2
			2: Space vector modulation mode	
×	11-42	System control flag	0000-FFFFh	0000

13 Industry Application Parameters

Pr.	Explanation	Settings	Default
		00: Disabled	
		01: User-defined parameter	
		02: Compressor	
		03: Fan	
		04: Pump	
12.00	Industry-specific	05: Conveyor	00
13-00	parameter application	06: Machine tool	00
		07: Packing	
		08: Textiles	
		10: Logistics	
		11: Tension PID	
		12: Tension PID + master / auxiliary frequency	
13-01	Application parameters		
13-50	(user-defined)		

14 Protection Parameters (2)

Pr.	Explanation	Settings	Default
14-50	Output frequency at malfunction 2	0.00–599.00 Hz	Read only
14-51	DC bus voltage at malfunction 2	0.0–6553.5 V	Read only
14-52	Output current at malfunction 2	0.00–655.35 Amp	Read only
14-53	IGBT temperature at malfunction 2	-3276.7–3276.7°C	Read only
14-54	Output frequency at malfunction 3	0.00–599.00 Hz	Read only
14-55	DC bus voltage at malfunction 3	0.0–6553.5 V	Read only
14-56	Output current at malfunction 3	0.00–655.35 Amp	Read only
14-57	IGBT temperature at malfunction 3	-3276.7–3276.7°C	Read only
14-58	Output frequency at malfunction 4	0.00–599.00 Hz	Read only
14-59	DC bus voltage at malfunction 4	0.0–6553.5 V	Read only
14-60	Output current at malfunction 4	0.00–655.35 Amp	Read only
14-61	IGBT temperature at malfunction 4	-3276.7–3276.7°C	Read only
14-62	Output frequency at malfunction 5	0.00–599.00 Hz	Read only
14-63	DC bus voltage at malfunction 5	0.0–6553.5 V	Read only
14-64	Output current at malfunction 5	0.00–655.35 Amp	Read only
14-65	IGBT temperature at malfunction 5	-3276.7–3276.7°C	Read only
14-66	Output frequency at malfunction 6	0.00–599.00 Hz	Read only
14-67	DC bus voltage at malfunction 6	0.0–6553.5 V	Read only
14-68	Output current at malfunction 6	0.00–655.35 Amp	Read only

Chapter 11 Summary of Parameter Settings | MS300

	Pr.	Explanation	Settings	Default	
	14-69	IGBT temperature at malfunction 6	-3276.7–3276.7°C	Read only	
	14-70	Fault record 7	Refer to fault record Pr.06-17-Pr.06-22	0	
-	14-71	Fault record 8	Refer to fault record Pr.06-17-Pr.06-22	0	
	14-72	Fault record 9	Refer to fault record Pr.06-17-Pr.06-22	0	
	14-73	Fault record 10	Refer to fault record Pr.06-17-Pr.06-22	0	
			0: No function		
			1: Continue operation after over-torque detection during		
			constant speed operation		
	44.74	Over-torque detection	2: Stop after over-torque detection during constant	0	
/	14-74	selection (motor 3)	speed operation	0	
			3: Continue operation after over-torque detection during		
			RUN		
			4: Stop after over-torque detection during RUN		
	44.75	Over-torque detection	10–250%	400	
"	14-75	level (motor 3)	(100% corresponds to the rated current of the drive)	120	
*	14-76	Over-torque detection time (motor 3)	0.1–60.0 sec.	0.1	
		,	0: No function		
			Continue operation after over-torque detection during		
			constant speed operation		
		Over-torque detection	2: Stop after over-torque detection during constant speed		
*	14-77	selection (motor 4)	operation	0	
		, ,	3: Continue operation after over-torque detection during		
			RUN		
			4: Stop after over-torque detection during RUN		
		Over-torque detection	10–250%		
*	14-78	level (motor 4)	(100% corresponds the rated current of the drive)	120	
إ	4	Over-torque detection time			
~	14-79	(motor 4)	0.1–60.0 sec.	0.1	
			0: Inverter motor (with external forced cooling)		
×	14-80	Electronic thermal relay	1: Standard motor (motor with the fan on the shaft)	2	
		selection 3 (motor 3)	2: Disable	_	
<u>ا</u> ر	14-81	Electronic thermal relay	30.0-600.0 sec.	60.0	
	14-01	action time 3 (motor 3)	30.0-000.0 Sec.	00.0	
Ī		Electronic thermal relati	0: Inverter motor (with external forced cooling)		
×	14-82	Electronic thermal relay	1: Standard motor (motor with the fan on the shaft)	2	
		selection 4 (motor 4)	2: Disable		
.	14.00	Electronic thermal relay	20.0.600.0.000	60.0	
*	14-83	action time 4 (motor 4)	30.0–600.0 sec.	60.0	

Chapter 12 Descriptions of Parameter Settings

12-1 Descriptions of Parameter Settings

00 Drive Parameters

✓ You can set this parameter during operation.

AC Motor Drive Identity Code

Default: #.#

Settings Read only

Default: #.#

Settings Read only

- Pr.00-00 displays the AC motor drive identity code. Use the following specification table to check if Pr.00-01 setting is the rated current of the AC motor drive. Pr.00-01 corresponds to the identity code of Pr.00-00.
- The default is the rated current for heavy duty. Set Pr.00-16=0 to display the rated current for normal duty.

Models	115V Models: One-phase				230V Models: One-phase			
Frame	Α	В	С	Α/	В	В	C	;
Power (kW)	0.2	0.4	0.75	0.2	0.4	0.75	1.5	2.2
Power (HP)	0.25	0.5	1	0.25	0.5	1	2	3
Identity Code	102	103	104	302	303	304	305	306
Rated Current for Heavy Duty	1.6	2.5	4.8	1.6	2.8	4.8	7.5	11
Rated Current for Normal Duty	1.8	2.7	5.5	1.8	3.2	5	8.5	12.5

Models		230V Models: Three-phase								
Frame		Α		В)	D	E		F
Power (kW)	0.2	0.4	0.75	1.5	2.2	3.7/4	5.5	7.5	11	15
Power (HP)	0.25	0.5	1	2	3	5	7.5	10	15	20
Identity Code	202	203	204	205	206	207	208	209	210	211
Rated Current for Heavy Duty	1.6	2.8	4.8	7.5	11	17	25	33	49	65
Rated Current for Normal Duty	1.8	3.2	5	8	12.5	19.5	27	36	51	69

Models		460V Models: Three-phase										
Frame	A	/B	В		С)	E	Ξ	F	=
Power (kW)	0.4	0.75	1.5	2.2	3	3.7/4	5.5	7.5	11	15	18.5	22
Power (HP)	0.5	1	2	3	4	5	7.5	10	15	20	25	30
Identity Code	403	404	405	406	482	407	408	409	410	411	412	413
Rated Current for Heavy Duty	1.5	2.7	4.2	5.5	7.3	9	13	17	25	32	38	45
Rated Current for Normal Duty	1.8	3	4.6	6.5	8	10.5	15.7	20.5	28	36	41.5	49

Models	575V Models: Three-phase					
Frame	Α	В	С		D	
Power (kW)	0.75	1.5	2.2	3.7	5.5	7.5
Power (HP)	1	2	3	5	7.5	10
Identity Code	504	505	506	507	508	509
Rated Current for Heavy Duty	1.7	3	4.2	6.6	9.9	12.2
Rated Current for Normal Duty	2.1	3.6	5	8	11.5	15

Parameter Reset

Default: 0

Settings 0: No Function

- 1: Write protection for parameters
- 5: Return kWh displays to 0
- 6: Reset PLC (including CANopen Master index)
- 7: Reset CANopen Slave index
- 8: Keypad does not respond
- 9: Reset all parameters to defaults (base frequency is 50 Hz)
- 10: Reset all parameters to defaults (base frequency is 60 Hz)
- 11: Reset all parameters to defaults with base frequency at 50 Hz (keep the user-defined parameter values Pr.13-01–Pr.13-50)
- 12: Reset all parameters to defaults with base frequency at 60 Hz (keep the user-defined parameter values Pr.13-01–Pr.13-50)
- 1: All parameters are read only except Pr.00-02, Pr.00-07, and Pr.00-08. Set Pr.00-02 to 0 before changing other parameter settings.
- 🚇 5: You can return the kWh displayed value to 0 even during drive operation. For example, you can set Pr.05-26-Pr.05-30 to 0.
- 6: Clear the internal PLC program (includes the related settings of PLC internal CANopen master).
- 2: Reset the related settings of CANopen slave.
- 8: RUN key on the keypad is invalid; the rest of the keys work normally.
- 9 or 10: Reset all parameters to defaults. If you have set a password (Pr.00-08), unlock the password (Pr.00-07) to clear the password you have set before you reset all parameters.
- For settings of 6, 7, 9, 10, 11 and 12, you must reboot the motor drive after you finish the setting.

✓ ☐☐ ☐☐ Start-up Display

Default: 0

Settings 0: F (frequency command)

1: H (output frequency)

2: U (user-defined) see Pr.00-04

3: A (output current)

Determines the start-up display page after power is applied to the drive. The user-defined contents display according to the Pr.00-04 settings.

Default: 3

Content of Multi-function Display (User-Defined)

- Settings 0: Display output current (A) (Unit: Amp)
 - 1: Display counter value (c) (Unit: CNT)
 - 2: Display the drive's actual output frequency (H.) (Unit: Hz)
 - 3: Display the drive's DC bus voltage (v) (Unit: V_{DC})
 - 4: Display the drive's output voltage (E) (Unit: V_{AC})
 - 5: Display the drive's output power angle (n) (Unit: deg)
 - 6: Display the drive's output power (P) (Unit: kW)
 - 7: Display the motor speed (r) (Unit: rpm)
 - 8: Display the drive's estimated output torque, motor's rated torque is 100% (t) (Unit: %)
 - 10: Display PID feedback (b) (Unit: %)
 - 11: Display AVI analog input terminal signal (1.) (Unit: %)
 - 12: Display ACI analog input terminal signal (2.) (Unit: %)
 - 14: Display the drive's IGBT temperature (i.) (Unit: °C)
 - 16: The digital input status (ON / OFF) (i)
 - 17: The digital output status (ON / OFF) (o)
 - 18: Display multi-step speed (S)
 - 19: The corresponding CPU digital input pin status (d)
 - 20: The corresponding CPU digital output pin status (0.)
 - 22: Pulse input frequency (S.)
 - 25: Overload count (0.00-100.00%) (o.) (Unit: %)
 - 26: Ground Fault GFF (G.) (Unit: %)
 - 27: DC bus voltage ripple (r.) (Unit: V_{DC})
 - 28: Display PLC register D1043 data (C)
 - 30: Display the output of User-defined (U)
 - 31: Display Pr.00-05 user gain (K)
 - 35: Control mode display:
 - 0= Speed control mode (SPD)
 - 1 = Torque control mode (TQR) (t.)
 - 36: Present operating carrier frequency of the drive (J.) (Unit: Hz)
 - 38: Display the drive status (6.) (Refer to Explanation 6 below)
 - 39: Display the drive's estimated output torque, positive and negative, using Nt-m as unit (t 0.0: positive torque; -0.0: negative torque) (C.)
 - 40: Torque command (L.) (Unit: %)
 - 41: kWh display (J) (Unit: kWh)
 - 42: PID target value (h.) (Unit: %)
 - 43: PID compensation (o.) (Unit: %)
 - 44: PID output frequency (b.) (Unit: Hz)
 - 46: Auxiliary frequency value (U.) (Unit: Hz)

47: Master frequency value (A.) (Unit: Hz)

48: Frequency value after addition and subtraction of master and auxiliary frequency (L.) (Unit: Hz)

51: PMSVC torque offset

58: Pr.00-05 User gain display (K) (Does not display decimal places.)

62: I2t (o.) (Unit: %)

63: Error code (E.)

64: Warning code (n.)

65: Accumulated motor operation record (day) (r.) (Refer to Pr.05-32)

Explanation 1

It can also display negative values when setting analog input bias (Pr.03-03-03-10).
 Example: Assume that AVI input voltage is 0 V, Pr.03-03 is 10.0%, Pr.03-07 is 4 (Bias serves as the center).

Explanation 2

Example: If MI1 and MI6 are ON, the following table shows the status of the terminals.

Normally opened contact (N.O.): (0: OFF, 1: ON)

Terminal	MI7	MI6	MI5	MI4	MI3	MI2	MI1
Status	0	1	0	0	0	0	1

- The value is 0000 0000 0010 0001 in binary and 0021H in HEX. When Pr.00-04 is set to 16 or 19, the u page on the keypad displays 0021h.
- The setting 16 is the ON / OFF status of digital input according to Pr.02-12 setting and the setting 19 is the corresponding CPU pin ON / OFF status of the digital input.
- When MI1 / MI2 default setting is two-wire / three-wire operation control (Pr.02-00 ≠ 0), and MI3 is set to three-wire, it is not affected by Pr.02-12.
- You can set 16 to monitor the digital input ON / OFF status, and then set 19 to check if the circuit is normal.

Explanation 3

Example: Assume that RY: Pr.02-13 is set to 9 (Drive is ready). After the drive is powered on, if there is no other abnormal status, the contact is ON. The display status is shown below.

Normally opened contact (N.O.):

Terminal	MO2	MO1	RY1
Status	0	0	1

- If Pr.00-04 is set to 17 or 20, it displays in hexadecimal "0001h" with LED u page is ON in the keypad.
- The setting 17 is the ON / OFF status of digital output according to Pr.02-18 setting and the setting
 20 is the corresponding CPU pin ON / OFF status of the digital output.
- You can set 17 to monitor the digital output ON / OFF status, and then set 20 to check if the circuit
 is normal.

Explanation 4

Setting value 8: 100% means the motor rated torque.

Motor rated torque = (motor rated power x $60 / 2\pi$) / motor rated speed

Explanation 5

 Setting value 25: when displayed value reaches 100.00%, the drive shows "oL" as an overload warning.

Explanation 6

- Setting value 38:
 - bit 0: The drive is running forward.
 - bit 1: The drive is running backward.
 - bit 2: The drive is ready.
 - bit 3: Errors occurred on the drive.
 - bit 4: The drive is running.
 - bit 5: Warnings occurred on the drive.

★ Graph Coefficient Gain in Actual Output Frequency

Default: 1.00

Settings 0.00-160.00

Sets the user-defined unit coefficient gain. Set Pr.00-04 = 31 to display the calculation result on the screen (calculation = output frequency * Pr.00-05).

GG-GG Firmware Version

Default: Read only

Settings Read only

✓ ☐☐ - ☐☐ Parameter Protection Password Input

Default: 0

Settings 0-65535

Display 0–4 (the number of password attempts)

- This parameter allows you to enter your password (which is set in Pr.00-08) to unlock the parameter protection and to make changes to the parameter.
- To avoid problems in the future, be sure to write down the password after you set this parameter.
- Pr.00-07 and Pr.00-08 are used to prevent personnel from setting other parameters by accident.
- If you forget the password, clear the password setting by entering 9999 and pressing the ENTER key, then enter 9999 again and press ENTER within 10 seconds. After decoding, all the settings return to default.
- When setting is under password protection, all the parameters read 0, except Pr.00-08.

✓ ☐☐ - ☐☐ Parameter Protection Password Setting

Default: 0

Settings 0-65535


0: No password protection or password is entered correctly (Pr.00-07)

1: Password has been set

This parameter is for setting the password protection. Password can be set directly the first time. After you set the password, the value of Pr.00-08 is 1, which means password protection is activated. At this time, if you want to change any of the parameter settings, you must enter the

correct password in Pr.00-07 to deactivate the password temporarily, and this would make Pr.00-08 become 0. After you finish setting the parameters, reboot the motor drive and the password is activated again.

- Entering the correct password in Pr.00-07 only temporarily deactivates the password. To permanently deactivate password protection, set Pr.00-08 to 0 manually. Otherwise, password protection is always reactivated after you reboot the motor drive.
- The keypad copy function works only when the password protection is deactivated (temporarily or permanently), and the password set in Pr.00-08 cannot be copied to the keypad. So when copying parameters from the keypad to the motor drive, set the password manually again in the motor drive to activate password protection.



Control Mode

Default: 0

Settings 0: Speed Control mode

2: Torque mode

- Determines the control mode of the AC motor drive.
- When Pr.00-10=2: Torque mode, control mode is IM TQC Sensorless.

☐☐ - ! ! Speed Control Mode

Default: 0


Settings 0: IMVF (IM V/F control)

1: IMVFPG (IM V/F control + encoder)


2: IM/PM SVC (IM / PM Space Vector Control)

5: IMFOC Sensorless (IM Field-Oriented sensorless vector Control)


- Determines the control mode of the AC motor drive:
 - 0: IM V/F control: you can set the proportion of V/F as required and control multiple motors simultaneously.
 - 1: IM V/F control + Encoder pulse input: you can use the encoder for closed-loop speed control.
 - 2: IM/PM space vector control: gets the optimal control by auto-tuning the motor parameters.
 - 5: IM FOC sensorless: IM field-oriented sensorless vector control.
- ☐ If you use MI7 single-phase pulse input as speed feedback, apply it for VFPG closed-loop control.
- ☐ If you use 1: IMVFPG control mode along with MI7 as speed feedback, you also need to set Pr.10-00=5 and Pr.10-02=5.
- \square When Pr.00-10 = 0 and you set Pr.00-11 to 0, the V/F control diagram is as follows:




When Pr.00-10 = 0 and you set Pr.00-11 to 1, the V/F control + encoder diagram is as follows:




When Pr.00-10 = 0 and you set Pr.00-11 to 2, the sensorless vector control diagram is as follows: IM Space Vector Control (IMSVC):



PM Space Vector Control (PMSVC):



When Pr.00-10=0 and you set Pr. 00-11 to 5, IMFOC Sensorless control diagram is as follows:



Load Selection

Default: 1

Settings 0: Normal load 1: Heavy load

- Normal duty: overload rated output current 150% in 3 seconds. (120%, 1 minute). Refer to Pr.00-17 for the setting for the carrier frequency. Refer to Chapter 9 Specifications or Pr.00-01 for the rated current.
- Heavy duty: overload rated output current 200% in 3 seconds. (150%,1 minute) Refer to Pr.00-17 for the setting for the carrier frequency. Refer to Chapter 9 Specifications or Pr. 00-01 for the rated current.
- Pr.00-01 varies with the setting value of Pr.00-16. The default value and maximum of Pr.06-03 and Pr.06-04 also vary with the setting value of Pr.00-16.
- In normal duty, the default setting of Pr.06-03 and Pr.06-04 is 120%, and the maximum is 150%.
- In heavy duty, the default setting of Pr.06-03 and Pr.06-04 is 180%, and the maximum is 200%.

Carrier Frequency

Default: 4 / 4

Settings Normal load: 2–15 kHz

Heavy load: 2-15 kHz

Note:

When Pr.00-11=5 (IMFOC Sensorless), the maximum setting value for the


carrier frequency is 10 kHz.

Determines the PWM carrier frequency for the AC motor drive.

	23	OV	46	0V	575V
Models	1–15 HP [0.75–11 kW]	20–30 HP [15–37 kW]	1–20 HP [0.75–15 kW]	25–40 HP [18.5–55 kW]	1–10 HP [0.75–7.5 kW]
Settings Range	02–15 kHz	02–10 kHz	02–15 kHz	02–10 kHz	02–15 kHz
Normal Duty Default			4 kHz		
Heavy Duty Default			4 kHz		

Carrier Frequency	Acoustic Noise	Electromagnetic Noise or Leakage Current	Heat Dissipation	Current Wave
2 kHz	Significant	Minimal	Minimal	
8 kHz				
15 kHz	Minimal	Significant	↓ Significant	│


- From the table, you see that the PWM carrier frequency has significant influences on the electromagnetic noise, the AC motor drive heat dissipation, and the motor acoustic noise. Therefore, if the surrounding noise is greater than the motor noise, lower the carrier frequency to reduce the temperature rise. Although the motor has quiet operation in the higher carrier frequency, consider the entire wiring and interference.
- When the carrier frequency is higher than the default, decrease the carrier frequency to protect the drive. Refer to Pr.06-55 for the related setting and details.



In the HOA mode, if the multi-function input terminal (MI) function setting 41 and 42 are OFF, the drive does not receive any operation command and JOG is invalid.



Determines how the motor is stopped when the drive receives the Stop command.



Ramp to Stop and Coast to Stop

- **1. Ramp to stop:** According to the set deceleration time, the AC motor drive decelerates to 0 Hz or the minimum output frequency (Pr.01-07), and then stop.
- Coast to stop: According to the load inertia, the AC motor drive stops output immediately, and the motor coasts to stop.
 - ☑ Use "ramp to stop" for the safety of personnel or to prevent material from being wasted in applications where the motor must stop immediately after the drive stops. You must set the deceleration time accordingly.
 - ☑ If idling is allowed or the load inertia is large, use "coast to stop". For example, blowers, punching machines and pumps.

★ ## Motor Direction Control

Default: 0

Settings 0: Enable forward / reverse

1: Disable reverse

2: Disable forward

Enables the motor to run in the forward and reverse direction. You can use it to prevent a motor from running in a direction that would cause injury or damage to the equipment, especially when only one running direction is allowed for the motor load.

요즘 - 근목 Digital Operator (Keypad) Frequency Command Memory

Default: Read only

Settings Read only

If the keypad is the frequency command source, when Lv or fault occurs, this parameter stores the current frequency command.

Default: 0

Settings bit 0-3: user-defined decimal places

0000h-0000b: no decimal place

0001h-0001b: one decimal place

0002h-0010b: two decimal places

0003h-0011b: three decimal places

bit 4-15: user-defined unit

000xh: Hz

001xh: rpm

002xh: %

003xh: kg

004xh: m/s

005xh: kW

006xh: HP

007xh: ppm

008xh: 1/m

009xh: kg/s

00Axh: kg/m

00Bxh: kg/h

00Cxh: lb/s

00Dxh: lb/m

00DXII. 10/111

00Exh: lb/h

00Fxh: ft/s

010xh: ft/m

011xh: m

012xh: ft

013xh: degC

014xh: degF

015xh: mbar

016xh: bar

017xh: Pa

018xh: kPa

019xh: mWG

01Axh: inWG

01Bxh: ftWG

01Cxh: psi

01Dxh: atm

01Exh: L/s

01Fxh: L/m

020xh: L/h


021xh: m3/s 022xh: m3/h 023xh: GPM 024xh: CFM xxxxh: Hz

□ bit 0–3:

The displayed units for the control frequency F page and user-defined (Pr.00-04 = d10, PID feedback), and the displayed number of decimal places for Pr.00-26 (support up to three decimal places).

□ bit 4–15:

The displayed units for the control frequency F page, user-defined (Pr.00-04 = d10, PID feedback) and Pr.00-26.



You must convert the setting value to decimal when using the keypad to set parameters.

Example: Assume that the user-defined unit is inWG and user-defined decimal place is the third decimal point. According to the information above, the corresponding unit to inWG is 01Axh (x is the set decimal point), and the corresponding unit to the third decimal place is 0003h, then inWG and the third decimal point displayed in hexadecimal is 01A3h, that is 419 in decimal value. Thus, set Pr.00-25 = 419 to complete the setting.

Maximum User-Defined Value

Default: 0

Settings 0: Disable

0-65535 (when Pr.00-25 is set to no decimal place)

0.0–6553.5 (when Pr.00-25 is set to one decimal place)

0.00-655.35 (when Pr.00-25 is set to two decimal places)

0.000-65.535 (when Pr.00-25 is set to three decimal places)

When Pr.00-26 is NOT set to 0, the user-defined value is enabled. After selecting the displayed unit and number of decimal places with Pr.00-25, the setting value of Pr.00-26 corresponds to Pr.01-00 (drive's maximum operating frequency).

Example: When the frequency set in Pr.01-00 = 60.00 Hz, the maximum user-defined value for Pr.00-26 is 100.0%. This also means that Pr.00-25 is set at 33 (0021h) to select % as the unit.

Note: Set Pr.00-25 before using Pr.00-26. After you finish setting, when Pr.00-26 is not 0, the displayed unit on the keypad shows correctly according to Pr.00-25 settings.

∷ - 2 ↑ User-De	efined Value
	Default: Read only
Settings	Read only
Pr.00-27 displays	the user-defined value when Pr.00-26 is not set to 0.
The user-defined	value is valid only when Pr.00-20 (frequency source) is set to the digital keypad
or to RS-485 com	nmunication.
88-23 LOCAL	/ REMOTE Selection
	Default: 0
Settings	0: Standard HOA function
	1: When switching between local and remote, the drive stops.
	2: When switching between local and remote, the drive runs with REMOTE
	settings for frequency and operating status.
	3: When switching between local and remote, the drive runs with LOCAL
	settings for frequency and operating status.
	4: When switching between local and remote, the drive runs with LOCAL
	settings when switched to Local and runs with REMOTE settings when

The default for Pr.00-29 is 0, that is, the standard HOA (Hand-Off-Auto) function. Set the AUTO and HAND frequency and operation source with Pr.00-20, 00-21 and Pr.00-30, 00-31. The external terminal function (MI) = 56 for LOC / REM mode selection is disabled when Pr.00-29=0.

switched to Remote for frequency and operating status.

- If Pr.00-29 is not set to 0, the top right corner of digital keypad KPC-CC01 (optional) displays LOC or REM. Set the REMOTE and LOCAL frequency and operation source with Pr.00-20, 00-21 and Pr.00-30, 00-31. Set the multi-function input terminal (MI) = 56 to set the LOC / REM selection. The AUTO key on the KPC-CC01 (optional) is the REMOTE function; the HAND key is the LOCAL function.
- If Pr.00-29 is not set to 0, the AUTO / HAND keys are disabled. In this case, the external terminal (MI) setting = 56 (local / remote selection) has the highest command priority.

✓ ☐☐ - ☐☐ Master Frequency Command Source (HAND, LOCAL)

Default: 0

Settings (

- 0: Digital keypad
- 1: RS-485 communication input
- 2: External analog input (Refer to Pr.03-00)
- 3: External UP / DOWN terminal (multi-function input terminals)
- 4: Pulse input without direction command (Refer to Pr.10-16 without considering direction)
- 6: CANopen communication card
- 7: Digital keypad potentiometer knob
- 8: Communication card (does not include CANopen card)
- 9: PID controller

		Note:	
		HOA (Hand-Off-Auto) function is valid only when you use with MO function	
setting 41 and 56 or with KPC-CC01 (optional).			
	Determines the master frequency source in the "HAND, LOCAL" mode.		
	You can switch	the HAND, LOCAL mode with the keypad KPC-CC01 (optional) or the	
	multi-function inp	ut terminal (MI) to set the master frequency source.	
It returns to AUTO or REMOTE mode whenever you cycle the power. If you use a multi-fund			
	input terminal to switch between HAND (LOCAL) and AUTO (REMOTE) mode, the higher		
	priority is the multi-function input terminal.		
	The pulse of Pr.00	0-20=4 (Pulse input without direction command) is input by PG or MI7.	
~	Operation	on Command Source (HAND, LOCAL)	
		Default: 0	
	Settings	0: Digital keypad	
		1: External terminals	
		2: RS-485 communication input	
		3: CANopen communication card	
		5: Communication card (does not include CANopen card)	
		Note:	
		HOA (Hand-Off-Auto) function is valid only when you use with MO function	
		setting 41 and 56 or with KPC-CC01 (optional).	
	Determines the o	peration frequency source in the "HAND, LOCAL" mode.	
	In the HOA mode	, if the multi-function input terminal (MI) function setting 41 and 42 are OFF, the	
	drive does not red	ceive any operation command and JOG is invalid.	
1	☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	eypad STOP Function	
		Default: 0	
	Settings	0: STOP key disabled	
		1: STOP key enabled	
	Valid when the	operation command source is not the digital keypad (Pr.00-21≠ 0). When	
	Pr.00-21=0, the S	TOP key on the digital keypad is not affected by this parameter.	
	## Auxiliary	r Frequency Source	
		Default: 0	
	Settings	0: Master and auxiliary frequency function disabled	
		1: Digital keypad	
		2: RS-485 communication input	
		3: Analog input	
		4: External UP/DOWN key input (multi-function input terminals)	
		5: Pulse input without direction command (Refer to Pr.10-16)	
		6: CANopen communication card	
		7: Digital keypad potentiometer knob	

8: Communication card

U	☐ - ☐ Master and Auxiliary Frequency Command Selection	
	Default: 0	
	Settings 0: Master + auxiliary frequency	
	1: Master - auxiliary frequency	
	2: Auxiliary - master frequency	
	Master and auxiliary frequency command sets the master frequency source according to Pr.00-20, and sets the auxiliary frequency source according to Pr.00-35. This parameter determines the addition and subtraction of the master and auxiliary frequency.	
	When $Pr.00-36 = 0$, 1, 2, the control command comes after adding or subtracting the master /	
	auxiliary frequency and the acceleration and deceleration (including S-curve).	
	If the value is negative after adding or subtracting the master / auxiliary frequency, Pr.03-10 determines whether to change the running direction.	
	If you set the master frequency source (Pr.00-20 = 0) or the auxiliary frequency source (Pr.00-35 = 1) using the keypad, the F page of the keypad displays the setting frequency that you can use to set the master frequency or the auxiliary frequency. If the master frequency source or the auxiliary frequency source is NOT set by the keypad (Pr.00-20 \neq 0 and Pr.00-35 \neq 1), the F page of the keypad displays the value after adding or subtracting the master / auxiliary frequency.	
0] - 4 7 Output Phase Order Selection	
	Default: 0	
	Default: 0 Settings 0: Standard	
1	Settings 0: Standard	
Ш	Settings 0: Standard 1: Exchange the rotation direction	
	Settings 0: Standard 1: Exchange the rotation direction Without changing the wiring and light indicator, this parameter can be used to change the rotation	
	Settings 0: Standard 1: Exchange the rotation direction Without changing the wiring and light indicator, this parameter can be used to change the rotation direction from forward to reverse or from reverse to forward. When using this parameter with Pr.00-23 (Motor Direction Control), Pr.00-23 has priority over	
	Settings 0: Standard 1: Exchange the rotation direction Without changing the wiring and light indicator, this parameter can be used to change the rotation direction from forward to reverse or from reverse to forward. When using this parameter with Pr.00-23 (Motor Direction Control), Pr.00-23 has priority over Pr.00-47. Display Filter Time (Current) Default: 0.100	
	Settings 0: Standard 1: Exchange the rotation direction Without changing the wiring and light indicator, this parameter can be used to change the rotation direction from forward to reverse or from reverse to forward. When using this parameter with Pr.00-23 (Motor Direction Control), Pr.00-23 has priority over Pr.00-47. Display Filter Time (Current) Default: 0.100 Settings 0.001–65.535 sec.	
	Settings 0: Standard 1: Exchange the rotation direction Without changing the wiring and light indicator, this parameter can be used to change the rotation direction from forward to reverse or from reverse to forward. When using this parameter with Pr.00-23 (Motor Direction Control), Pr.00-23 has priority over Pr.00-47. Display Filter Time (Current) Default: 0.100 Settings 0.001–65.535 sec. Minimizes the current fluctuation displayed by the digital keypad.	
	Settings 0: Standard 1: Exchange the rotation direction Without changing the wiring and light indicator, this parameter can be used to change the rotation direction from forward to reverse or from reverse to forward. When using this parameter with Pr.00-23 (Motor Direction Control), Pr.00-23 has priority over Pr.00-47. Display Filter Time (Current) Default: 0.100 Settings 0.001–65.535 sec.	
	Settings 0: Standard 1: Exchange the rotation direction Without changing the wiring and light indicator, this parameter can be used to change the rotation direction from forward to reverse or from reverse to forward. When using this parameter with Pr.00-23 (Motor Direction Control), Pr.00-23 has priority over Pr.00-47. Display Filter Time (Current) Default: 0.100 Settings 0.001–65.535 sec. Minimizes the current fluctuation displayed by the digital keypad. Display Filter Time (Keypad) Default: 0.100	
	Settings 0: Standard 1: Exchange the rotation direction Without changing the wiring and light indicator, this parameter can be used to change the rotation direction from forward to reverse or from reverse to forward. When using this parameter with Pr.00-23 (Motor Direction Control), Pr.00-23 has priority over Pr.00-47. Display Filter Time (Current) Default: 0.100 Settings 0.001–65.535 sec. Minimizes the current fluctuation displayed by the digital keypad. Default: 0.100 Settings 0.001–65.535 sec.	
	Settings 0: Standard 1: Exchange the rotation direction Without changing the wiring and light indicator, this parameter can be used to change the rotation direction from forward to reverse or from reverse to forward. When using this parameter with Pr.00-23 (Motor Direction Control), Pr.00-23 has priority over Pr.00-47. Display Filter Time (Current) Default: 0.100 Settings 0.001–65.535 sec. Minimizes the current fluctuation displayed by the digital keypad. Default: 0.100 Settings 0.001–65.535 sec. Minimizes the value fluctuation displayed by the digital keypad.	
	Settings 0: Standard 1: Exchange the rotation direction Without changing the wiring and light indicator, this parameter can be used to change the rotation direction from forward to reverse or from reverse to forward. When using this parameter with Pr.00-23 (Motor Direction Control), Pr.00-23 has priority over Pr.00-47. Display Filter Time (Current) Default: 0.100 Settings 0.001–65.535 sec. Minimizes the current fluctuation displayed by the digital keypad. Default: 0.100 Settings 0.001–65.535 sec.	
	Settings 0: Standard 1: Exchange the rotation direction Without changing the wiring and light indicator, this parameter can be used to change the rotation direction from forward to reverse or from reverse to forward. When using this parameter with Pr.00-23 (Motor Direction Control), Pr.00-23 has priority over Pr.00-47. Display Filter Time (Current) Default: 0.100 Settings 0.001–65.535 sec. Minimizes the current fluctuation displayed by the digital keypad. Default: 0.100 Settings 0.001–65.535 sec. Minimizes the value fluctuation displayed by the digital keypad. Settings 0.001–65.535 sec. Minimizes the value fluctuation displayed by the digital keypad.	

Chapter 12 Descriptions of Parameter Settings | MS300

[This page intentionally left blank]

01 Basic Parameters

✓ You can set this parameter during operation.

☐ I - ☐ ☐ Maximum Operation Frequency
☐ 1 - 5 ≥ Maximum Operation Frequency of Motor 2
☐ 1 - 5 3 Maximum Operation Frequency of Motor 3
☐ 1 - 5 ≥ Maximum Operation Frequency of Motor 4

Default: 60.00 / 50.00

Settings 0.00-599.00 Hz

Determines the AC motor drive's maximum operation frequency. All the AC motor drive frequency command sources (analog inputs 0–10 V, 4–20 mA, 0–20 mA, ±10 V) are scaled to correspond to the output frequency range.

Output Frequency of Motor 1 (Base frequency / Motor's rated frequency)	
0 Utput Frequency of Motor 2 (Base frequency / Motor's rated frequency)	
G: 1-54 Output Frequency of Motor 3 (Base frequency / Motor's rated frequency)	
Counter 1 - 6 3 Output Frequency of Motor 4 (Base frequency / Motor's rated frequency)	

Default: 60.00 / 50.00

Settings 0.00-599.00 Hz

Set this parameter according to the motor's rated frequency on the motor nameplate. If the motor's rated frequency is 60 Hz, set this parameter to 60. If the motor's rated frequency is 50 Hz, set this parameter to 50.

☐ I - ☐ ☐ Output Voltage of Motor 1 (Base voltage / Motor's rated voltage)
0 1-38 Output Voltage of Motor 2 (Base voltage / Motor's rated voltage)
0 1-55 Output Voltage of Motor 3 (Base voltage / Motor's rated voltage)
I - E Y Output Voltage of Motor 4 (Base voltage / Motor's rated voltage)

Default: 220.0 / 440.0 / 575.0

Settings 115V / 230V models: 0.0–255.0 V

460V models: 0.0–510.0 V 575V models: 0.0–637.0 V

- Set this parameter according to the rated voltage on the motor nameplate. If the motor's rated voltage is 220 V, set this parameter to 220.0. If the motor's rated voltage is 200 V, set this parameter to 200.0.
- There are many motor types in the market and the power system for each country is also different. The economical and convenient solution is to install an AC motor drive. Then there is no problem using the motor with different voltage and frequency inputs, and the motor drive can improve the original motor characteristics and useful life.

Default: 3.00

✓ ☐ ! - ☐ Y Mid-point Voltage 1 of Motor 1

Default: 11.0 / 22.0 / 40.0

Settings 115V / 230V models: 0.0-240.0 V

460V models: 0.0–480.0 V 575V models: 0.0–600.0 V

Default: 3.00

Settings 0.00-599.00 Hz

★ ☐ ! - 3 ☐ Mid-point Voltage 1 of Motor 2

Default: 11.0 / 22.0 / 40.0

Settings 115V / 230V models: 0.0–240.0 V

460V models: 0.0–480.0 V 575V models: 0.0–600.0 V

1 - 58 Mid-point Frequency 1 of Motor 3

Default: 3.00

Settings 0.00–599.00 Hz

★ ☐ ! - 5 ↑ Mid-point Voltage 1 of Motor 3

Default: 11.0 / 22.0 / 40.0

Settings 115V / 230V models: 0.0–240.0 V

460V models: 0.0–480.0 V 575V models: 0.0–600.0 V

1 - 55 Mid-point Frequency 1 of Motor 4

Default: 3.00

Settings 0.00–599.00 Hz

★ B ! - 55 Mid-point Voltage 1 of Motor 4

Default: 11.0 / 22.0 / 40.0

Settings 115V / 230V models: 0.0-240.0 V

460V models: 0.0–480.0 V 575V models: 0.0–600.0 V

1 - ## Mid-point Frequency 2 of Motor 1

Default: 1.50

Settings 0.00-599.00 Hz

✓
☐ I - ☐ ☐ Mid-point Voltage 2 of Motor 1

Default: 5.0 / 10.0 / 26.1

Settings 115V / 230V models: 0.0–240.0 V

460V models: 0.0–480.0 V 575V models: 0.0–600.0 V

B ! - 39 Mid-point Frequency 2 of Motor 2

Default: 1.50

Settings 0.00–599.00 Hz

✓ ☐ ! - Ч☐ Mid-point Voltage 2 of Motor 2

Default: 5.0 / 10.0 / 26.1

Settings 115V / 230V models: 0.0–240.0 V

460V models: 0.0–480.0 V 575V models: 0.0–600.0 V

1 - 5 # Mid-point Frequency 2 of Motor 3

Default: 1.50

Settings 0.00-599.00 Hz

✓ ☐ 1 - 5 ☐ Mid-point Voltage 2 of Motor 3

Default: 5.0 / 10.0 / 26.1

Settings 115V / 230V models: 0.0–240.0 V

460V models: 0.0–480.0 V 575V models: 0.0–600.0 V

1 - # 7 Mid-point Frequency 2 of Motor 4

Default: 1.50

Settings 0.00-599.00 Hz

★ B: -58 Mid-point Voltage 2 of Motor 4

Default: 5.0 / 10.0 / 26.1

Settings 115V / 230V models: 0.0-240.0 V

460V models: 0.0–480.0 V 575V models: 0.0–600.0 V

I - # T Minimum Output Frequency of Motor 1

Default: 0.50

Settings 0.00-599.00 Hz

★ ☐ ☐ ☐ ☐ ☐ ☐ ☐ Minimum Output Voltage of Motor 1

Default: 1.0 / 2.0 / 16.7

Settings 115V / 230V models: 0.0–240.0 V

460V models: 0.0–480.0 V 575V models: 0.0–600.0 V

Default: 0.50

×	01-42	Minimum Output Voltage of Motor	2
---	-------	---------------------------------	---

Default: 1.0 / 2.0 / 16.7

Settings 115V / 230V models: 0.0-240.0 V

460V models: 0.0–480.0 V 575V models: 0.0–600.0 V

1 - 5 # Minimum Output Frequency of Motor 3

Default: 0.50

Settings 0.00-599.00 Hz

✓ ☐ ! - ☐ ! Minimum Output Voltage of Motor 3

Default: 1.0 / 2.0 / 16.7

Settings 115V / 230V models: 0.0-240.0 V

460V models: 0.0–480.0 V 575V models: 0.0–600.0 V

1 - # B Minimum Output Frequency of Motor 4

Default: 0.50

Settings 0.00-599.00 Hz


✓ ☐ ! - ☐ Minimum Output Voltage of Motor 4

Default: 1.0 / 2.0 / 16.7

Settings 115V / 230V models: 0.0–240.0 V

460V models: 0.0–480.0 V 575V models: 0.0–600.0 V


- You usually set the V/F curve according to the motor's allowable loading characteristics. Pay special attention to the motor's heat dissipation, dynamic balance, and bearing lubrication when the loading characteristics exceed the loading limit of the motor.
- There is no limit for the voltage setting, but a high voltage at a low frequency may cause motor damage, overheating, and trigger the stall prevention or the over-current protection; therefore, use low voltage at low frequency to prevent motor damage or drive error.
- The diagram below shows the V/F curve for motor 1. You can use the same V/F curve for motor 2, motor 3, and motor 4. For multi-motor selections, refer to the multi-function input terminal (Pr.02-01–Pr.02-07) settings 83 and 84.




V/F Curve

Common settings for the V/F curve:

(1) General purpose



Setting
60.0
60.0
220.0
1.50
10.0
1.50
10.0




Pr.	Setting
01-00	50.0
01-01	50.0
01-02	220.0
01-03	1.30
01-05	1.30
01-04	10.0
01-06	10.0
01-07	1.30
01-08	10.0

(2) For fan and hydraulic machinery


Motor spec. 60Hz 220 10 1.5 30 60.0 F

Pr.	Setting
01-00	60.0
01-01	60.0
01-02	220.0
01-03	30.0
01-05	30.0
01-04	50.0
01-06	50.0
01-07	1.50
01-08	10.0
	•



Pr.	Setting
01-00	50.0
01-01	50.0
01-02	220.0
01-03 01-05	25.0
01-04 01-06	50.0
01-07	1.30
01-08	10.0

(3) High starting torque



	Pr.	Setting
	01-00	60.0
	01-01	60.0
	01-02	220.0
	01-03 01-05	3.00
	01-04 01-06	23.0
-	01-07	1.50
	01-08	18.0
		·


	Motors	pec. 50HZ
V ⁴ 220		
23		
23 14		
	1.3 2.2	50.0► F

Setting
50.0
50.0
220.0
2 20
2.20
23.0
14.0

☐ : - ☐ ☐ Start-up Frequency

Default: 0.50

- When the starting frequency (Pr.01-09) is larger than the Minimum Output Frequency of Motor 1 (Pr.01-07), the drive's frequency output starts when the starting frequency (Pr.01-09) reaches the F command. Refer to the following diagram for details.
- ☐ Fcmd = frequency command;
 - Fstart = start-up frequency (Pr.01-09);
 - fstart = actual start-up frequency of the drive;
 - Fmin = 4th output frequency setting (Pr.01-07 / Pr.01-41);
 - Flow = output frequency lower limit (Pr.01-11)
- When Fcmd > Fmin and Fcmd < Fstart:
 - If Flow < Fcmd, the drive runs directly with Fcmd.
 - If Flow ≥ Fcmd, the drive runs with Fcmd, and then rises to Flow according to acceleration time.
- The drive's output frequency goes directly to 0 when decelerating to Fmin.






Default: 599.00

Settings 0.00-599.00 Hz

✓ ☐ ! - ! : Output Frequency Lower Limit

Default: 0.00


- Use the upper and lower limit output frequency settings to limit the actual output frequency. If the output frequency setting is higher than the upper limit (Pr.01-10), the drive runs with the upper limit frequency. If the output frequency setting is lower than the lower limit (Pr.01-11) but higher than the minimum output frequency (Pr.01-07), the drive runs with the lower limit frequency. Set the upper limit frequency > the lower limit frequency (Pr.01-10 setting value must be > Pr.01-11 setting value).
- The upper output frequency limits the drive's maximum output frequency. If the frequency setting for the Frequency command is higher than Pr.01-10, the drive runs with the Pr.01-10 setting.
- If the PID feedback control is enabled for the drive, the drive's output frequency may exceed the Frequency command but is still limited by this setting.
- Related parameters: Pr.01-00 Maximum Operation Frequency, Pr.01-11 Output Frequency Lower Limit.



- The lower output frequency limits the drive's minimum output frequency. If the frequency setting for the Frequency command is lower than Pr.01-11, the drive runs with the Pr.01-11 setting.
- When the drive starts, it operates according to the V/F curve and accelerates from the minimum output frequency (Pr.01-07) to the setting frequency. It is not limited by the lower output frequency settings.

		Use the output frequency upper and lower limit settings to prevent operator misuse, overheating caused by the motor's operating at a too low frequency, or mechanical wear due to a too high
		speed.
		If the output frequency upper limit setting is 50 Hz and the frequency setting is 60 Hz, the maximum output frequency is 50 Hz.
	Ш	If the output frequency lower limit setting is 10 Hz and the minimum output frequency setting
		(Pr.01-07) is 1.5 Hz, then the drive operates at 10 Hz when the Frequency command is higher
		than Pr.01-07 but lower than 10 Hz. If the Frequency command is lower than Pr.01-07, the drive
	~~	is in ready status without output.
		If the frequency output upper limit is 60 Hz and the frequency setting is also 60 Hz, only the
		Frequency command is limited at 60 Hz. The actual output frequency may be higher than 60 Hz if
		used for slip compensation.
N	Ü	!- !? Acceleration Time 1
N	8	! - ! 3 Deceleration Time 1
N	0	
N	8	! - !5 Deceleration Time 2
N	8	:- : Acceleration Time 3
N	8	! - ! 7 Deceleration Time 3
N	8	:- : Acceleration Time 4
N	8	! - ! B Deceleration Time 4
N	_	! - 2 B JOG Acceleration Time
N	8	! - 2 ! JOG Deceleration Time
		Default: 10.00 / 10.0
		Settings Pr.01-45 = 0: 0.00–600.00 sec.
		Pr.01-45 = 1: 0.0-6000.0 sec.
		The acceleration time determines the time required for the AC motor drive to ramp from 0.00 Hz
		to the maximum operation frequency (Pr.01-00). The deceleration time determines the time
		required for the AC motor drive to decelerate from the maximum operation frequency (Pr.01-00)
		down to 0.00 Hz.
		The acceleration and deceleration time are invalid when using Pr.01-44 Auto-acceleration and
		Auto-deceleration Setting.
		$Select\ the\ Acceleration/Deceleration\ Time\ 1,\ 2,\ 3,\ 4\ with\ the\ multi-function\ input\ terminal\ settings.$
		The defaults are Acceleration Time 1 and Deceleration Time 1.
		With the enabled torque limits and stall prevention functions, the actual acceleration and
		deceleration time are longer than the above action time.
		Note that setting the acceleration and deceleration time too short may trigger the drive's
		protection function (Pr.06-03 Over-current Stall Prevention during Acceleration or Pr.06-01
		Over-voltage Stall Prevention), and the actual acceleration and deceleration time are longer than
		this setting.
		Note that setting the acceleration time too short may cause motor damage or trigger drive
		protection due to over-current during the drive's acceleration.

- Note that setting the deceleration time too short may cause motor damage or trigger drive protection due to over-current during the drive's deceleration or over-voltage.
- Use suitable brake resistors (refer to Chapter 07 Optional Accessories) to decelerate in a short time and prevent over-voltage.
- When you enable Pr.01-24–Pr.01-27 (S-curve acceleration and deceleration begin and arrival time), the actual acceleration and deceleration time are longer than the setting.



✓ ☐ ! - 2 2 JOG Frequency

Default: 6.00


Settings 0.00-599.00 Hz

You can use both the external terminal JOG and F1 key on the optional keypad KPC-CC01 (optional) to set the JOG function. When the JOG command is ON, the AC motor drive accelerates from 0 Hz to the JOG frequency (Pr.01-22). When the JOG command is OFF, the AC motor drive decelerates from the JOG frequency to stop. The JOG acceleration and deceleration time (Pr.01-20, Pr.01-21) are the time to accelerate from 0.00 Hz to the JOG frequency (Pr.01-22). You cannot execute the JOG command when the AC motor drive is running. When the JOG command is executing, other operation commands are invalid.

★ ☐ ! - 2 3 Switch Frequency between First and Fourth Accel./Decel.

Default: 0.00

- This function does not require the external terminal switching function; it switches the acceleration and deceleration time automatically according to the Pr.01-23 setting. If you set the external terminal, the external terminal has priority over Pr.01.23.
- When using this function, set the S-curve acceleration time to 0 if the fourth acceleration time is short.
 - a. If Pr.01-02=10 s, Pr. 01-18=6 s, then the acceleration time is 3 s for 0–40 Hz and 5 s for 40-80 Hz.
 - b. If Pr.01-13=8 s, Pr. 01-19=2 s, then the deceleration time is 4 s for 80–40 Hz and 1 s for 40–0 Hz.




1st/4thAcceleration/Deceleration Frequency Switching

×	01-24	S-curve for Acceleration Begin Time 1
×	0:-25	S-curve for Acceleration Arrival Time 2
×	85-10	S-curve for Deceleration Begin Time 1
×	0:1-27	S-curve for Deceleration Arrival Time 2

Default: 0.20 / 0.2

Settings Pr.01-45 = 0: 0.00–25.00 sec. Pr.01-45 = 1: 0.0–250.0 sec.

- Using an S-curve gives the smoothest transition between speed changes. The acceleration and deceleration curve adjusts the acceleration and deceleration S-curve. When enabled, the drive produces a different acceleration and deceleration curve according to the acceleration and deceleration time.
- ☐ The S-curve function is invalid when you set the acceleration and deceleration time to 0.
- When Pr.01-12, 01-14, 01-16, 01-18 \geq Pr.01-24 and Pr.01-25, the actual acceleration time = Pr.01-12, 01-14, 01-16, 01-18 + (Pr.01-24 + Pr.01-25) / 2.
- When Pr.01-13, 01-15, 01-17, 01-19 \geq Pr.01-26 and Pr.01-27, the actual deceleration time = Pr.01-13, 01-15, 01-17, 01-19 + (Pr.01-26 + Pr.01-27) / 2.




<pre>G ! - 28 Skip Frequency 1 (Upper Limit)</pre>
☐ ! - 2 Skip Frequency 1 (Lower Limit)
☐ ! - 3☐ Skip Frequency 2 (Upper Limit)
<pre>G: !- 3 Skip Frequency 2 (Lower Limit)</pre>
☐ ! - 3 ≥ Skip Frequency 3 (Upper Limit)
<pre>Skip Frequency 3 (Lower Limit)</pre>

Default: 0.00

Settings 0.00-599.00 Hz

- Sets the AC motor drive's skip frequency. The drive's frequency setting skips these frequency ranges. However, the frequency output is continuous. There are no limits for these six parameters and you can combine them. Pr.01-28 does not need to be greater than Pr.01-29; Pr.01-30 does not need to be greater than Pr.01-31; Pr.01-32 does not need to be greater than Pr.01-33. You can set Pr.01-28-01-33 as you required. There is no size distinction among these six parameters.
- These parameters set the skip frequency ranges for the AC motor drive. You can use this function to avoid frequencies that cause mechanical resonance. The skip frequencies are useful when a motor has resonance vibration at a specific frequency bandwidth. Skipping this frequency avoids the vibration. There are three frequency skip zones available.
- You can set the Frequency command (F) within the range of skip frequencies. Then the output frequency (H) is limited to the lower limit of skip frequency ranges.
- During acceleration and deceleration, the output frequency still passes through the skip frequency ranges.



☐ ! -] ' Zero-speed Mode

Default: 0


Settings 0: Output waiting

1: Zero-speed operation


2: Fmin (refer to Pr.01-07, Pr.01-41)

- When the drive's Frequency command is lower than Fmin (Pr.01-07 and Pr.01-41), the drive operates according to this parameter.
- © the AC motor drive is in waiting mode without voltage output from terminals U, V, W.
- 1: the drive executes the DC brake by Vmin (Pr.01-08 and Pr.01-42) in V/F, FOC sensorless, and SVC modes. And it executes zero-speed operation in VFPG and FOCPG modes.
- 2: the AC motor drive runs using Fmin (Pr.01-07 and Pr.01-41) and Vmin (Pr.01-08 and Pr.01-42) in V/F, VFPG, SVC, FOC sensorless and FOCPG modes.

In V/F, VFPG, SVC and FOC sensorless modes:



In FOCPG mode, when Pr.01-34 is set to 2, the AC motor drive operates according to this setting.



☐ I - Y → V/F Curve Selection


Default: 0

Settings 0: V/F curve determined by Pr.01-00–01-08

1: V/F curve to the power of 1.5

2: V/F curve to the power of 2

- When setting to 0, refer to Pr.01-01–01-08 for the motor 1 V/F curve. For motor 2, refer to Pr.01-35–01-42.
- When setting to 1 or 2, the second and third voltage frequency settings (as shown in the V/F Curve diagram for Pr.01-70) are invalid.
- If the load of the motor is a variable torque load (torque is in direct proportion to the rotating speed, such as the load of a fan or a pump), the load torque is low at low rotating speed. You can decrease the input voltage appropriately to make the magnetic field of the input current smaller and reduce flux loss and iron loss for the motor to increase efficiency.
- When you set the V/F curve to high power, it has lower torque at low frequency, and the drive is not suitable for rapid acceleration and deceleration. Do NOT use this parameter for rapid acceleration and deceleration.




★ # Auto-acceleration and Auto-deceleration Setting

Default: 0

Settings 0: Linear acceleration and deceleration

- 1: Auto-acceleration and linear deceleration
- 2: Linear acceleration and auto-deceleration
- 3: Auto-acceleration and auto-deceleration
- 4: Stall prevention by auto-acceleration and auto-deceleration (limited by Pr.01-12–01-21)
- 0 (linear acceleration and deceleration): the drive accelerates and decelerates according to the setting for Pr.01-12–01-19.
- 1 or 2 (auto/linear acceleration and auto/linear deceleration): the drive auto-tunes the acceleration and deceleration to effectively reduce the mechanical vibration during the load start-up and stop and make the auto-tuning process more easier. It does not stall during acceleration and does not need a brake resistor during deceleration to stop. It can also improve operation efficiency and save energy.
- 3 (auto-acceleration and auto-deceleration—decelerating by the actual load): the drive auto-detects the load torque and automatically accelerates from the fastest acceleration time and smoothest start-up current to the setting frequency. During deceleration, the drive automatically determines the loaded regenerative energy to steadily and smoothly stop the motor in the fastest deceleration time.
- 4 (stall prevention by auto-acceleration and deceleration—reference to the acceleration and deceleration time settings): if the acceleration and deceleration time are within a reasonable range, the actual acceleration and deceleration time refer to the Pr.01-12–01-19 settings. If the acceleration and deceleration time are too short, the actual acceleration and deceleration time are greater than the acceleration and deceleration time settings.



When Pr.01-44 is set to 0.

When Pr.01-44 is set to 3.

deceleration time.

Time Unit for Acceleration and Deceleration and S-Curve Default: 0 Settings 0: Unit 0.01 sec. 1: Unit 0.1 sec. ✓ ☐ I - Y ☐ CANopen Quick Stop Time Default: 1.00/1.0 Settings Pr.01-45 = 0: 0.00-600.00 sec.Pr.01-45 = 1: 0.0-6000.0 sec.Sets the time required to decelerate from the maximum operation frequency (Pr.01-00) to 0.00 Hz through the CANopen control. Regenerative Energy Restriction Control Method Default: 0 Settings 0: Normal deceleration 1: Over voltage energy restriction 2: Traction energy control (TEC) 0: decelerate or stop in accordance with the original deceleration setting. The actual deceleration time of the motor is longer than the deceleration time setting because of the over-voltage stall prevention. 🕮 1: during deceleration, the drive controls the motor according to the setting for Pr.06-01 and the recovery voltage of the DC bus. The controller starts when the DC bus voltage reaches 95% of Pr.06-01. When Pr.06-01 is set to 0, the drive controls the motor according to the operating voltage and the recovery voltage of the DC bus. This method decelerates according to the setting for the deceleration time. The fastest actual deceleration time is not less than the deceleration time setting. 2: during deceleration, the drive controls the motor according to the setting for Pr.06-01 and the DC bus voltage. The controller starts when the DC bus voltage reaches 95% of Pr.06-01, auto-tunes the output frequency and the output voltage to accelerate the consumption of the

regenerative energy according to the drive's capability, and the deceleration time is the result of the drive's auto-tuning. Use this setting when over-voltage occurs due to unexpected

02 Digital Input / Output Parameters

✓ You can set this parameter during operation.

R2 - RB Two-wire / Three-wire Operation Control

Default: 1

Settings 0: No function

1: Two-wire mode 1, power on for operation control

(M1: FWD / STOP, M2: REV / STOP)

2: Two-wire mode 2, power on for operation control

(M1: RUN / STOP, M2: REV / FWD)

3: Three-wire, power on for operation control

(M1: RUN, M2: REV / FWD, M3: STOP)

4: Two-wire mode 1, Quick Start

(M1: FWD / STOP, M2: REV / STOP)


5: Two-wire mode 2, Quick Start


(M1: RUN / STOP, M2: REV / FWD)

6: Three-wire, Quick Start

(M1: RUN, M2: REV / FWD, M3: STOP)

- In the Quick Start function, the output remains ready for operation. The drive responds to the Start command immediately.
- When using Quick Start function, the output terminals UVW are with driving voltages in order to output and respond immediately if a Start command is given. Do NOT touch the terminals or modify the motor wiring to prevent electric shocks.
- This parameter sets the configuration of the external drive operation control and the Quick Start function. There are six different control modes listed in the following table.





\$\mathcal{G} \rightarrow G \rightarrow \limits \text{Multi-function Input Command 1 (MI1)}	
□ 2 - □ 2 Multi-function Input Command 2 (MI2)	
	Default: 0
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	
	Default: 1
□ - □ + Multi-function Input Command 4 (MI4)	
	Default: 2
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	
	Default: 3
□ 2 - □ 5 Multi-function Input Command 6 (MI6)	
	Default: 4

Settings 0: No function

- 1: Multi-step speed command 1 / multi-step position command 1
- 2: Multi-step speed command 2 / multi-step position command 2
- 3: Multi-step speed command 3 / multi-step position command 3
- 4: Multi-step speed command 4 / multi-step position command 4
- 5: Reset
- 6: JOG operation [by external control or KPC-CC01 (optional)]
- 7: Acceleration / deceleration speed inhibit
- 8: 1st and 2nd acceleration / deceleration time selection
- 9: 3rd and 4th acceleration / deceleration time selection
- 10: External Fault (EF) input (Pr.07-20)
- 11: Base Block (B.B.) input from external
- 12: Output stop

- 13: Cancel the setting of auto-acceleration / auto-deceleration time
- 15: Rotating speed command from AVI
- 16: Rotating speed command from ACI
- 18: Force to stop (Pr.07-20)
- 19: Digital up command
- 20: Digital down command
- 21: PID function disabled
- 22: Clear the counter
- 23: Input the counter value (MI6)
- 24: FWD JOG command
- 25: REV JOG command
- 26: TQC / FOC mode selection
- 27: ASR1 / ASR2 selection
- 28: Emergency stop (EF1)
- 29: Signal confirmation for Y-connection
- 30: Signal confirmation for Δ -connection
- 31: High torque bias (Pr.11-30)
- 32: Middle torque bias (Pr.11-31)
- 33: Low torque bias (Pr.11-32)
- 38: Disable writing EEPROM function
- 39: Torque command direction
- 40: Force coasting to stop
- 41: HAND switch
- 42: AUTO switch
- 48: Mechanical gear ratio switch
- 49: Enable drive
- 50: Slave dEb action to execute
- 51: Selection for PLC mode bit 0
- 52: Selection for PLC mode bit 1
- 53: Trigger CANopen quick stop
- 56: Local / Remote selection
- 58: Enable fire mode (with RUN command)
- 59: Enable fire mode (without RUN command)
- 70: Force auxiliary frequency return to 0
- 71: Disable PID function, force PID output return to 0
- 72: Disable PID function, retain the output value before disabled
- 73: Force PID integral gain return to 0, disable integral
- 74: Reverse PID feedback
- 81: Simple positioning zero point position signal input
- 82: OOB loading balance detection
- 83: Multi-motor (IM) selection bit 0
- 84: Multi-motor (IM) selection bit 1

This parameter selects the functions for each multi-function terminal.
When Pr.02-00 = 0, you can set multi-function options with multi-function input terminals MI1, MI2.
When $Pr.02-00 \neq 0$, the multi-function input terminals MI1, MI2 work in accordance with the
setting values for Pr.02-00.
Example:
If Pr.02-00 = 1: multi-function input terminal MI1 = FWD / STOP, MI2 = REV / STOP.
If Pr.02-00 = 2: multi-function input terminal MI1 = RUN / STOP, MI2 = FWD / REV.
When multi-function input terminal MI7 = 0, MI7 is designated as a pulse input terminal.
If Pr.02-00 is set to three-wire operation control, terminal MI3 is for the STOP contact.
The function set previously for this terminal is automatically invalid.

Summary of Function Settings

Take the normally open contact (N.O.) for example, ON: contact is closed, OFF: contact is open.

Settings	Functions	Descriptions
0	No function	
	Multi-step speed	
1	command 1 / multi-step	
	position command 1	
	Multi-step speed	
2	command 2 / multi-step	You can set 15 steps of speed or 15 positions with the digital
	position command 2	status of these four terminals. You can use 16-steps of speed if
	Multi-step speed	you include the master speed when setting as 15 steps of speed
3	command 3 / multi-step	(refer to Parameter Group 04 Multi-step Speed Parameters).
	position command 3	
	Multi-step speed	
4	command 4 / multi-step	
	position command 4	
5	Reset	Use this terminal to reset the drive after clearing a drive fault.
		This function is valid when the source of the operation command
		is the external terminals.
		The JOG operation executes when the drive stops completely.
	JOG operation	While running, you can still change the operation direction, and
6	[by external control or	the STOP key on the keypad* and the STOP command from
	KPC-CC01 (optional)]	communications are valid. Once the external terminal receives
		the OFF command, the motor stops in the JOG deceleration
		time. Refer to Pr.01-20–01-22 for details.
		*: This function is valid when Pr.00-32 is set to 1.

Settings	Functions	Descriptions		
		Pr.01-22 JOG Pr.01-07 Min. output frequency JOG accel. time Pr.01-20 MIx-GND ON OFF MIx: external terminal		
7	Acceleration / deceleration speed inhibit	When you enable this function, the drive stops acceleration or deceleration immediately. After you disable this function, the AC motor drive starts to accelerate or decelerate from the inhibit point. Frequency Setting frequency Accel. inhibit area Actual operation frequency Decel. inhibit area Actual operation frequency Decel. inhibit area Actual operation frequency Decel. inhibit area ON Operation ON Operation ON OFF		
8	1 st and 2 nd acceleration / deceleration time selection	You can select the acceleration and deceleration time of the drive with this function, or from the digital status of the terminals;		
9	3 rd and 4 th acceleration / deceleration time selection	there are four acceleration and deceleration selections.		
10	External Fault (EF) input (Pr.07-20)	For external fault input. The drive decelerates according to the Pr.07-20 setting, and the keypad shows "EF" (it shows the fault record when an external fault occurs). The drive keeps running until the fault is cleared (terminal status restored) after RESET.		
11	Base Block (B.B.) input from external	ON: the output of the drive stops immediately. The motor is in free run and the keypad displays the B.B. signal. Refer to Pr.07-08 for details.		

Settings	Functions	Descriptions			
		ON: the output of the drive stops immediately and the motor is in			
		free run status. The drive is in output waiting status until the			
		switch is turned to OFF, and then the drive restarts and runs to			
		the current setting frequency.			
		Frequency			
12	Output stop	Setting			
12	Output stop	frequency			
		Time			
		MIx-GND ON OFF ON			
		Operation ON			
	Cancel the setting of	Set Pr.01-44 to one of the 01–04 setting modes before using this			
13	auto-acceleration /	function. When this function is enabled, OFF is for auto mode			
10	auto-deceleration time	and ON is for linear acceleration / deceleration.			
	auto-deceleration time	ON: force the source of the drive's frequency to be AVI. If the			
15	Rotating speed command from AVI	rotating speed commands are set to AVI and ACI at the same			
		time, the priority is AVI > ACI.			
	Rotating speed command from ACI	ON: force the source of the drive's frequency to be ACI. If the			
16		rotating speed commands are set to AVI and ACI at the same			
		time, the priority is AVI > ACI.			
18	Force to stop (Pr.07-20)	ON: the drive ramps to a stop according to the Pr.07-20 setting			
		ON: the frequency of the drive increases or decreases by one			
19	Digital up command	unit. If this function remains ON continuously, the frequency			
		increases or decreases according to Pr.02-09 / Pr.02-10.			
		The Frequency command returns to zero when the drive stops			
20	Digital down command	and the displayed frequency is 0.00 Hz. If you select Pr.11-00,			
		bit 7 = 1, the frequency is not saved.			
21	PID function disabled	ON: the PID function is disabled.			
22	Clear the counter	ON: the current counter value is cleared and displays 0. The			
		drive counts up when this function is disabled.			
23	Input the counter value	ON: the counter value increases by one. Use the function with			
	(MI6)	Pr.02-19.			
		This function is valid when the source of the operation command			
0.4	EMD 100	is the external terminal. ON: the drive executes forward JOG.			
24	FWD JOG command	When executing the JOG command in torque mode, the drive			
		automatically switches to speed mode. The drive returns to			
		torque mode after the JOG command is complete.			

Settings	Functions	Descriptions				
		This function is valid when the source of the operation command				
		is the external terminal. ON: the drive executes reverse JOG.				
25	REV JOG command	When executing the JOG command in torque mode, the drive				
		automatically switches to speed mode. The drive returns to				
		torque mode after the JOG command is complete.				
		ON: TQC mode, OFF: FOC mode.				
		RUN/STOP RUN STOP				
		Multi-function input terminal is set to 26 OFF ON OFF ON				
		(torque/speed mode switch) speed speed limit speed speed limit				
26	TQC / FOC mode	Pr.03-00-01=1 com mand com mand				
20	selection	command) torque torque				
		(AVI/ACI is torque command command)				
		speed speed speed Control control torque control torque control				
		mode control control (decel. to stop) Switch timing for torque/speed control				
		(Pr.00-10=0 or 2, Multi-function input terminal is set to 26				
27	ASR1 / ASR2 selection	ON: the speed is adjusted by the ASR 2 setting. OFF: the speed				
	/ tortr//tortz derestion	is adjusted by the ASR 1 setting. Refer to Pr.11-02 for details.				
	Emergency stop (EF1)	ON: the output of the drive stops immediately, displays "EF1" on				
		the keypad, and the motor is in free run status. The drive keeps				
		running until the external fault is cleared after you press RESET				
		on the keypad (EF: External Fault).				
		Voltage — Frequency				
		Setting				
28		frequency				
		MIX CND ON OFF ON				
		Reset ON OFF				
		Operation ON				
	Signal confirmation for	When the control mode is V/F, ON: the drive operates by the first				
29	Y-connection	V/F.				
	Signal confirmation for	When the control mode is V/F, ON: the drive operates by the				
30	Δ-connection	second V/F.				
31	High torque bias					
32	Middle torque bias	Refer to Pr.11-30–11-32 for details.				
33	Low torque bias	_				
	Disable writing					
	EEPROM function	ON: writing to EEPROM is disabled. Changed parameters are				
38	(parameters memory	not saved after power off.				
	disable)					
	· · · · · · · · · · · · · · · · · · ·	1				

Settings	Functions	Descriptions				
20	Torque command	For torque control (Pr.00-10=2), when the torque command is				
39	direction	AVI or ACI, ON: negative torque.				
40	Force coasting to stop	ON: during operation, the motor coasts to stop.				
41	HAND switch	 When the MI terminal switches to OFF, it executes a STOP command. Therefore, if the MI terminal switches to OFF during operation, the drive stops. Use the optional keypad KPC-CC01 to switch between HAND and AUTO. The drive stops first, and then switches to HAND or AUTO status. 				
42	AUTO switch	3. The optional digital keypad KPC-CC01 displays the current status of the drive (HAND / OFF / AUTO).				
40	Mechanical gear ratio	ON: the mechanical gear ratio switches to the second group.				
48	switch	Refer to Pr.10-04–Pr.10-07 for details.				
49	Enable drive	When the drive is enabled, the RUN command is valid. When the drive is disabled, the RUN command is invalid. When the drive is operating, the motor coasts to stop. This function varies with MO = 45.				
50	Slave dEb action to execute	Enter the message setting in this parameter when the master triggers dEb. This ensures that the slave also triggers dEb, then the master and slave stop simultaneously.				
	Selection for PLC mode	PLC status bit 1 bit 0				
51	(bit 0)	Disable PLC function (PLC 0) 0 0				
		Trigger PLC to operate (PLC 1) 0 1				
52	Selection for PLC mode	Trigger PLC to stop (PLC 2) 1 0				
52	(bit 1)	No function 1 1				
53	Trigger CANopen quick stop	When this function is enabled under CANopen control, it changes to Quick Stop. Refer to Chapter 15 CANopen Overview for more details.				
56	Local / Remote selection	Use Pr.00-29 to select LOCAL / REMOTE mode. When Pr.00-29 is not set to 0, the optional digital keypad KPC-CC01 displays LOC / REM status. (Refer to Pr.00-29 for details)				

Settings	Functions	Descriptions
58	Enable fire mode (with RUN command)	When fire occurs, enable this terminal to make the drive enter the fire mode to force the drive to run. If the drive is in stop status, enable this terminal to make the drive enter the fire mode to force the drive to run according to Pr.06-80 settings. (Refer to Pr.06-80, 06-81, 06-88 for details)
59	Enable fire mode (without RUN command)	When fire occurs, enable this terminal to make the drive enter the fire mode. If the drive is in stop status, enable this terminal to make the drive enter the fire mode, but the drive does not run. If the drive is in running status, enable this terminal to run the drive according to Pr.06-80 settings. (Refer to Pr.06-80, 06-81, 06-88 for details)
70	Force auxiliary frequency return to 0	Forces the auxiliary frequency return to 0 when using this function. PID keeps operating if PID is the master frequency. When $Pr.00-35 \neq 0$, the master and auxiliary frequencies are enabled, and then selecting this function with the terminal effectively forces the auxiliary frequency return to 0.
71	Disable PID function, force PID output return to 0	When the master and auxiliary frequencies are enabled and when using the PID function, ON: PID does not operate, returns the integral value to 0, and forces the PID output return to 0.
72	Disable PID function, retain the output value before disabled	When the master and auxiliary frequencies are enabled, and the PID function is enabled, ON: PID does not operate, and its output value remains the same as the value before it was disabled.
73	Force PID integral gain return to 0, disable integral	ON: PID continues to operate, disables the integral control, and returns the integral value to 0.
74	Reverse PID feedback	ON: PID negative feedback becomes positive feedback, or PID positive feedback becomes negative feedback.
81	Simple positioning zero point position signal input	Use this function as the trigger terminal for simple positioning with Pr.02-78–Pr.02-80. This function is just a simple positioning, so you must verify the positioning accuracy. Refer to Pr.02-80 for details.
82	OOB loading balance detection	You can use the OOB (Out Of Balance Detection) function with the PLC program in the washing machine system. ON: it receives the $\Delta\theta$ value according to Pr.07-46 (OOB Sampling Time) and Pr.07-47 (Number of OOB Sampling Times). The PLC or the host controller determines the motor's speed according to this $\Delta\theta$ value (Pr.07-48).

Settings	Functions	Descriptions					
		ON: parameters can be changed Example: MI1 = 83, MI2 = 84					
83	Multi-motor (IM) selection bit 0			Motor Selection	Related Motor Parameter		
		MI1	MI2		Max. Operation Frequency	V/F Curve Parameters	
84	Multi-motor (IM) selection bit 1	OFF	OFF	Motor 1	Pr.01-00	Pr.01-01-08	
		ON	OFF	Motor 2	Pr.01-52	Pr.01-35-01-42	
		OFF	ON	Motor 3	Pr.01-53	Pr.01-54-01-61	
		ON	ON	Motor 4	Pr.01-62	Pr.01-63-01-70	

Default: 0

Settings 0: UP / DOWN by the acceleration / deceleration time

1: UP / DOWN constant speed (Pr.02-10)

2: Pulse signal (Pr.02-10)

3: External terminals UP / DOWN key mode

4: External terminals UP / DOWN key mode (Pr.02-10)


✓ ☐ Constant Speed, Acceleration / Deceleration Speed of the UP / DOWN Key

Default: 0.001

Settings 0.001-1.000 Hz / ms

- Use when the multi-function input terminals are set to 19, 20 (Digital UP / DOWN command). The frequency increases or decreases according to Pr.02-09 and Pr.02-10.
- When Pr.11-00 bit 7 = 1, the frequency is not saved. The Frequency command returns to zero when the drive stops, and the displayed frequency is 0.00 Hz. At this time, increasing or decreasing the Frequency command (F) by using the UP or DOWN key is valid only when the drive is running.
- When Pr.02-09 is set to 0:


The increasing or decreasing Frequency command (F) operates according to the setting for acceleration or deceleration time (refer to Pr.01-12–01-19).



12.1-02-10


When Pr.02-09 is set to 1:

The increasing or decreasing Frequency command (F) operates according to the setting of Pr.02-10 (0.001–1.000 Hz/ms).



When Pr.02-09 is set to 4:

The tiered increasing or decreasing Frequency command (F) operates according to the setting of Pr.02-10 (0.001–1.000 Hz/100ms).



★ ☐ 2 - ! ! Multi-function Input Response Time

Default: 0.005

Settings 0.000-30.000 sec.

- Use this parameter to set the response time of the digital input terminals MI1–MI7.
- This function is to delay and confirm the digital input terminal signal. The time for delay is also the time for confirmation. The confirmation prevents interference that could cause error in the input to the digital terminals. But in the meanwhile, it delays the response time though confirmation improves accuracy.

Multi-function Input Mode Selection

Default: 0000

Settings 0000h–FFFFh (0: N.O.; 1: N.C.)

- The parameter setting is in hexadecimal.
- This parameter sets the status of the multi-function input signal (0: normally open; 1: normally closed) and it is not affected by the status of SINK / SOURCE.
- □ bit 0-bit 6 correspond to MI1-MI7.
- The default for bit 0 (MI1) is FWD terminal, and the default for bit 1 (MI2) is REV terminal. You cannot use this parameter to change the input mode when Pr.02-00 ≠ 0.

Default: 0

university You can change the terminal ON / OFF status through communications.

For example: MI3 is set to 1 (multi-step speed command 1) and MI4 is set to 2 (multi-step speed command 2). Then the forward + second step speed command = $1001_2 = 9_{10}$.

As long as Pr.02-12 = 9 is set through communications, there is no need to wire any multifunction terminal to run forward with the second step speed.

bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
MI7	MI6	MI5	MI4	MI3	MI2	MI1

Use Pr.11-42 bit 1 to select whether FWD / REV terminal is controlled by Pr.02-12 bit 0 and bit 1.

×	Multi-function Output 1 (RY1)	
		Default: 11
×	## G C C C M O I E O O O O O O O O O O	
×	## 3 Multi-function Output 3 (MO2)	

Settings 0: No function

1: Indication during RUN

2: Operation speed reached

3: Desired frequency reached 1 (Pr.02-22)

4: Desired frequency reached 2 (Pr.02-24)

5: Zero speed (Frequency command)

6: Zero speed including STOP (Frequency command)

7: Over-torque 1 (Pr.06-06-08)

8: Over-torque 2 (Pr.06-09-06-11)

9: Drive is ready

10: Low voltage warning (Lv) (Pr.06-00)

11: Malfunction indication

13: Overheat warning (Pr.06-15)

14: Software brake signal indication (Pr.07-00)

15: PID feedback error (Pr.08-13, 08-14)

16: Slip error (oSL)

17: Count value reached, does not return to 0 (Pr.02-20)

18: Count value reached, return to 0 (Pr.02-19)

19: External interrupt B.B. input (Base Block)

20: Warning output

21: Over-voltage

22: Over-current stall prevention

23: Over-voltage stall prevention

24: Operation mode

25: Forward command

26: Reverse command

29: Output when frequency ≥ Pr.02-34

30: Output when frequency < Pr.02-34

12.1-02-12

- 31: Y-connection for the motor coil
- 32: Δ-connection for the motor coil
- 33: Zero speed (actual output frequency)
- 34: Zero speed including STOP (actual output frequency)
- 35: Error output selection 1 (Pr.06-23)
- 36: Error output selection 2 (Pr.06-24)
- 37: Error output selection 3 (Pr.06-25)
- 38: Error output selection 4 (Pr.06-26)
- 40: Speed reached (including STOP)
- 42: Crane function
- 43: Actual motor speed detection
- 44: Low current output (use with Pr.06-71-Pr.06-73)
- 45: UVW output electromagnetic valve switch
- 46: Master dEb output
- 50: Output control for CANopen
- 51: Analog output control for RS-485 interface
- 52: Output control for communication cards
- 53: Fire mode indication
- 66: SO output logic A
- 67: Analog input level reached
- 68: SO output logic B
- 73: Over-torque 3
- 74: Over-torque 4
- 75: Forward RUN status
- 76: Reverse RUN status

Use this parameter to set the function of multi-function terminals.

Summary of Function Settings

(Take the normally open contact (N.O.) for example, ON: contact is closed, OFF: contact is open)

Settings	Functions	Descriptions
0	No Function	Output terminal with no function
1	Indication during RUN	Activates when the drive is not in STOP.
2	Operation speed	Activates when output frequency of drive reaches to the setting
	reached	frequency.
3	Desired frequency	Activates when the desired frequency (Pr.02-22) is reached.
3	reached 1 (Pr.02-22)	Activates when the desired frequency (F1.02-22) is reached.
4	Desired frequency	Activates when the desired frequency (Pr.02-24) is reached.
4	reached 2 (Pr.02-24)	Activates when the desired frequency (F1.02-24) is reached.
5	Zero speed	Activates when Frequency command = 0. (the drive must be in
	(Frequency command)	RUN status)
	Zero speed including	
	STOP	Activates when Frequency command = 0 or stopped.
	(Frequency command)	

Settings	Functions	Descriptions		
7		Activates when the drive detects over-torque. Pr.06-07 sets the		
	Over-torque 1	over-torque detection level (motor 1), and Pr.06-08 sets the		
		over-torque detection time (motor 1). Refer to Pr.06-06-08.		
	Over-torque 2	Activates when the drive detects over-torque. Pr.06-10 sets the		
8		over-torque detection level (motor 2), and Pr.06-11 sets the		
		over-torque detection time (motor 2). Refer to Pr.06-09-06-11.		
9	Drive is ready	Activates when the drive is ON with no error detected.		
10	Low voltage werning (Lv)	Activates when the DC bus voltage is too low.		
10	Low voltage warning (Lv)	(refer to Pr.06-00 Low Voltage Level)		
11	Malfunction indication	Activates when fault occurs (except Lv stop).		
13	Overheat werning	Activates when IGBT or heat sink overheats to prevent the drive		
13	Overheat warning	from shutting down due to overheating. (refer to Pr.06-15)		
14	Software brake signal indication	Activates when the soft brake function is ON. (refer to Pr.07-00).		
15	PID feedback error (Pr.08-13, 08-14)	Activates when the PID feedback signal error is detected.		
16	Slip error (oSL)	Activates when the slip error is detected.		
	Count value reached, does not return to 0 (Pr.02-20)	When the drive executes external counter, this contact activates		
17		if the count value is equal to the setting value for Pr.02-20.		
17		This contact deactivates when the setting value for Pr.02-20 >		
		Pr.02-19.		
	Count value reached, returns to 0 (Pr.02-19)	When the drive executes the external counter, this contact		
18		activates if the count value is equal to the setting value for		
	10.01.02 10)	Pr.02-19.		
19	External interrupt B.B.	Activates when external interrupt (B.B.) stop output occurs in the		
	input (Base Block)	drive.		
20	Warning output	Activates when a warning is detected.		
21	Over-voltage	Activates when over-voltage is detected.		
22	Over-current stall	Activates when the over-current stall prevention is detected.		
	prevention	Activates when the over-current stall prevention is detected.		
23	Over-voltage stall	Activates when over-voltage stall prevention is detected.		
	prevention	Activates when over-voltage stall prevention is detected.		
24	Operation mode	Activates when the source of operation command is not controlled		
27		by the digital keypad (Pr.00-21 ≠ 0).		
25	Forward command	Activates when the operation direction is forward.		
26	Reverse command	Activates when the operation direction is reverse.		
29	Output when frequency	Activates when frequency is ≥ Pr.02-34		
	≥ Pr.02-34	(actual output H ≥ Pr.02-34).		
30	Output when frequency	Activates when frequency is < Pr.02-34		
	< Pr.02-34	(actual output H < Pr.02-34).		

Functions	Descriptions			
Y-connection for the	Activates when Pr.05-24 = 1, the frequency output is lower than			
motor coil	Pr.05-23 minus 2 Hz and the time is longer than Pr.05-25.			
Δ -connection for the	Activates when Pr.05-24 = 1, the frequency output is higher than			
motor coil	Pr.05-23 plus 2 Hz and the time is longer than Pr.05-25.			
Zero speed	Activates when the actual output frequency is 0			
(actual output frequency)	(the drive is in RUN mode).			
Zero speed including				
stop	Activates when the actual output frequency is 0 or stopped.			
(actual output frequency)				
Error output selection 1 (Pr.06-23)	Activates when Pr.06-23 is ON.			
Error output selection 2 (Pr.06-24)	Activates when Pr.06-24 is ON.			
Error output selection 3 (Pr.06-25)	Activates when Pr.06-25 is ON.			
Error output selection 4 (Pr.06-26)	Activates when Pr.06-26 is ON.			
Speed reached	Activates when the drive's output frequency reaches the setting			
(including Stop)	frequency or stopped.			
Crane function	Use this function with Pr.02-34 and Pr.02-58.			
	Refer to Pr.02-34 and 02-58 for details and application examples.			
Actual motor speed detection	Activates when the motor actual speed is less than Pr.02-47.			
Low current output	Use this function with Pr.06-71–Pr.06-73.			
	Use this function with external terminal input = 49 (drive enabled)			
	and external terminal output = 45 (electromagnetic valve enabled),			
	and then the electromagnetic valve is ON or OFF according to the			
	status of the drive.			
	Enable ON			
	Contactor			
	MC MC			
	AC Drive			
	I I I I I I I I I I I I I I I I I I I			
	V(T2) W(T3) W(T3)			
	MOx=45			
	◆ MIx=49			
	Y-connection for the motor coil \(\Delta\)-connection for the motor coil \(\Zero\) speed (actual output frequency) \(\Zero\) speed including stop (actual output frequency) \(\Zero\) coutput selection 1 (\(\Pr.06-23\)) \(\Zero\) coutput selection 2 (\(\Pr.06-24\)) \(\Zero\) coutput selection 3 (\(\Pr.06-25\)) \(\Zero\) coutput selection 4 (\(\Pr.06-26\)) \(\Zero\) speed reached (\(\zero\) including Stop) \(\Zero\) crane function \(\Zero\) coutput selection 4 (\(\zero\) coutput selection \(\zero\) coutput selection			

Settings	Functions	Descriptions					
		When dEb rises at the master, MO sends a dEb signal to the					
46		slave. Output the message when the master triggers dEb. This					
	Master dEb output	ensures th	nat the	slave also t	riggers d	Eb. The	en the slave follows
		the decele	eration	time of the	master t	o stop	simultaneously with
		the maste	r.				
		Control the multi-function output terminals through CANopen.					
		The mapp	ing tal	ole of the CAI	Nopen D	O is sho	own in the following
	Output control for	table:					
50		Physical terminal		ng for related arameters	Attribute	Corr	responding index
30	CANopen	RY1	Pr.	.02-13=50	RW	bit 0 c	of initial value 0x01
		MO1	Pr.	.02-16=50	RW	bit 3 c	2026-41 of initial value 0x01
		MO2	Dr 02 17-50 DW 202		2026-41 of initial value 0x01		
		Refer to Section 15-3-5 for more information.					·
51	Analog output control for RS-485 interface	For RS-485 communication control output.					
		Control th	e outp	ut through the	e commu	nication	cards
		(CMM-PD	02, CM	IM-DN02, CM	M-EIP02,	CMM-C	COP02, CMM-EC02)
52	Output control for communication cards	Physical Se		etting of related Attr		ribute	Corresponding Address
		RY I		Pr.02-13 = 51 R		RW.	bit 0 of 2640
				Pr.02-16 = 51 Pr.02-17 = 51		RW RW	bit 3 of 2640 bit 4 of 2640
53	Fire mode indication	Activates	when I	MI setting 58	or 59 is 6	enabled	
		Status of the Status of the safety output					
66	SO output logic A	drive		Status A (MO = 66)		Status B (MO = 68)	
		Norm	nal	Broken circuit (open) Short circuit (close		,	
	SO output logic B	STO		Short circuit (closed)			Broken circuit (open)
68		STL1-STL3		Short circuit (closed)			Broken circuit (open)
	Analog input level reached	The multi-function output terminals operate when the analog					
		input level is between the high level and the low level.					
		Pr.03-44: Select one of the analog input channels (AVI, ACI) to be					
67		compared.					
		Pr.03-45: The high level for the analog input, default is 50 %.					
		Pr.03-46: The low level for the analog input, default is 10 %.					
		If analog input > Pr.03-45, the multi-function output terminal					
		operates. If analog input < Pr.03-46, the multi-function output					
		terminal stops output.					
		Activates when over-torque is detected. Pr.14-75 sets the over-					
73	Over-torque 3	torque detection level. Pr.14-76 sets the over-torque detection					
		time (refer to Pr.14-74-14-76).					

Settings	Functions	Descriptions			
		Activates when over-torque is detected. Pr.14-78 sets the over-			
74	Over-torque 4	torque detection level. Pr.14-79 sets the over-torque detection			
		time (refer to Pr.14-77–14-79).			
		When the drive runs FWD, the output terminal for forward running			
75	Forward RUN status	is closed; when the drive stops, the output terminal for forward			
		running is open.			
		When the drive runs REV, the output terminal for reverse runnir			
76	Reverse RUN status	is closed; when the drive stops, the output terminal for reverse			
		running is open.			

Default: 0000h

Settings 0000h-FFFFh (0:N.O.; 1:N.C.)

- This parameter is in hexadecimal.
- This parameter is set by a bit. If the bit is 1, the corresponding multi-function output acts in an opposite way.

Example:

Assume Pr.02-13 = 1 (indication when the drive is operating). If the output is positive, and the bit is set to 0, then Relay is ON when the drive runs and is OFF when the drive stops. On the contrary, if the output is negative, and the bit is set to 1, then the Relay is OFF when the drive runs and is ON when the drive stops.

bit 4	bit 3	bit 2	bit 1	bit 0
MO2	MO1	Reserved	Reserved	RY


★ 32 - 13 Terminal Counting Value Reached (returns to 0)

Default: 0


Settings 0-65500


- \square The counting function is enabled when Pr.02-19 \neq 0.
- You can set the input point for the counter using the multi-function terminal MI6 as a trigger terminal (set Pr.02-06 to 23). When counting is completed, the specified multi-function output terminal is activated (Pr.02-13, Pr.02-16, or Pr.02-17 is set to 18).

The timing diagram below shows that when counting to 5, RY1 activates and displays 0.



The timing diagram of the external counting terminals and the counting value reached





✓ ☐ 2 - 3 Y Output Frequency Setting for Multi-function Output Terminal

Default: 0.00

Settings 0.00-599.00 Hz


★ 32 - 58 Multi-function Output Terminal (Function 42): Brake Frequency Check Point

Default: 0.00


Settings

0.00-599.00 Hz

- Use Pr.02-34 with Pr.02-58 for the crane function and select the crane function MO #42 to set the multi-function outputs Pr.02-13, Pr.02-16, and Pr.02-17.
- When the output frequency (H) is lower than the setting for Pr.02-58, multi-function output terminal setting 42 stops after the command breaks off.
- Pr.02-58 must be lower than Pr.02-34 when using MO=42.
- Crane application example:



It is recommended that you use this with the Dwell acceleration/deceleration function as shown in the following diagram.



12.1-02-19

Default: 0

Settings 0: Disable

1: Drive runs if the RUN command remains after reset or reboot.

Setting value 1:


- Situation 1: After the drive is powered on and the external terminal for RUN stays ON, the drive runs.
- Situation 2: After clearing a fault once a fault is detected and the external terminal for RUN stays ON, you can run the drive by pressing the RESET key.

Motor Zero-speed Level

Default: 0

Settings 0-65535 rpm


- Use this parameter with MO=43 and set Pr.10-00=5.
- Use this parameter to set the motor's speed level at zero-speed. When the actual speed is lower than this setting, the corresponding multi-function output terminal setting 43 is ON, as shown in the diagram below.



Display the Status of Multi-function Input Terminal


Default: Read only

Settings Monitor the status of the Multi-function Input Terminal



Example:


When Pr.02-50 displays 0034h (hex) (that is, the value is 52 (decimal) and 0110100 (binary)), it means that MI3, MI5 and MI6 are ON.



🔐 🖁 - 🧲 🚶 Display the Status of Multi-function Output Terminal


Default: Read only

Settings Monitor the status of the Multi-function Output Terminal



Example:


When Pr.02-51 displays 0009h (hex) (that is, the value is 9 (decimal) and 01001 (binary)), it means that Relay and MO1 are ON.



Display the External Multi-function Input Terminals Used by PLC


Default: Read only

Settings Monitor the status of PLC input terminals




Example:

When Pr.02-52 displays 0034h (hex) (that is, the value is 52 (decimal) and 0110100 (binary)), it means that MI3, MI5 and MI6 are used by PLC.




📆 🖁 - 💲 🖁 Display the External Multi-function Output Terminals Used by PLC

Default: Read only



Example:

When Pr.02-53 displays 0009h (hex) (that is, the value is 9 (decimal) and 01001 (binary)), it means that Relay and MO1 are used by PLC.



Display the Frequency Command Executed by External Terminal

Default: Read only

Settings 0.00-599.00 Hz (Read only)

When you set the source of the Frequency command as the external terminal, if LV or Fault occurs, the external terminal Frequency command is saved in this parameter.

Motor Deceleration Ratio

Default: 200.0

Settings 4.0-1000.0

03 Analog Input / Output Parameters

✓ You can set this parameter during operation.

N	₿ 3 - ₿ 8 Analog I	nput Selection (AVI)				
			Default: 1			
N	## Analog Analog	nput Selection (ACI)				
			Default: 0			
	Settings	0: No function				
		1: Frequency command				
		2: Torque command (torque limit under speed mode)				
		3: Torque compensation command				
		4: PID target value				
		5: PID feedback signal				
		6: Thermistor (PTC) input value				
		7: Positive torque limit				
		8: Negative torque limit				
		9: Regenerative torque limit				
		10: Positive / negative torque limit				
		11: PT100 thermistor input value				
		12: Auxiliary frequency input				
		13: PID compensation value				
	When you use analog input as the PID reference target input, you must set Pr.00-20 to 2					
	(external analog input).					
	Setting method 1: Pr.03-00–03-01 set 1 as PID reference target input.					
	Setting method 2:	Pr.03-00-03-01 set 4 as PID reference target input.				
	If the setting value	e 1 and setting value 4 exist at the same time, the AVI inp	ut has highest priority			
	to become the PII	reference target input value.				
	When you use and	alog input as the PID compensation value, you must set P	r.08-16 to 1 (source of			
	PID compensation	n value is analog input). You can see the compensation va	alue with Pr.08-17.			
	When using the	Frequency command, the corresponding value for 0-	-10 V / 4-20 mA is			
	0-maximum oper	ation frequency (Pr.01-00).				
	When using the to	orque command, the corresponding value for 0–10 V / 4–	20 mA is 0–maximum			
	output torque (Pr.	11-27).				
	When using torqu	e compensation, the corresponding value for 0–10 V / 4–2 $$	0 mA is 0-the motor's			
	rated torque.					
	If the settings for	Pr.03-00–Pr.03-01 are the same, the AVI input has priority	over the ACI input.			
N	## Analog I	nput Bias (AVI)				
			Default: 0			
	Settings	-100.0–100.0 %				
	Sets the correspo	nding AVI voltage for the external analog input 0.				

Analog Input Bias (ACI)			
	Default: 0		
Settings	-100.0–100.0 %		
Sets the correspond	ding ACI current for the external analog input 0.		
✓ ☐ 3 - ☐ 7 Positive /	Positive / Negative Bias Mode (AVI)		
Positive /	Negative Bias Mode (ACI)		
	Default: 0		
Settings	0: No bias		
	1: Lower than or equal to bias		
	2: Greater than or equal to bias		
	3: The absolute value of the bias voltage while serving as the center		
	4: Bias serves as the center		

Using negative bias to set the frequency greatly reduces the noise interference. In a noisy

Reverse Setting when Analog Signal Input is Negative Frequency


environment, do NOT use signals less than 1 V to set the drive's operation frequency.

Default: 0

Settings

- 0: Negative frequency input is not allowed. The digital keypad or external terminal controls the forward and reverse direction.
- 1: Negative frequency input is allowed. Positive frequency = run in a forward direction; negative frequency = run in a reverse direction. The digital keypad or external terminal control cannot change the running direction.
- Use this parameter only for AVI or ACI analog input.
- Requirements for negative frequency (reverse running)
 - 1. Pr.03-10 = 1
 - 2. Bias mode = Bias serves as the center
 - 3. Corresponded analog input gain < 0 (negative); this makes the input frequency negative. In using the analog input addition function (Pr.03-18=1), when the analog signal is negative after the addition, you can set this parameter to allow or not allow the reverse running. The result after adding depends on the "Requirements for negative frequency (reverse running)".

In the diagram below: Black line: Curve with no bias. Gray line: curve with bias Diagram 01



Pr.03-03=10% Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- 0: Negative frequency is not valid.
 Forward and reverse run is controlled
 by digital keyboard or external terminals.
- 1: Negative frequency is valid.

 Positive frequency = forward run;
 negative frequency = reverse run.

 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%

Diagram 02



Pr.03-03=10% Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- Negative frequency is not valid.
 Forward and reverse run is controlled by digital keyboard or external terminals.
- 1: Negative frequency is valid.

 Positive frequency = forward run;
 negative frequency = reverse run.

 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%

Diagram 03



Pr.03-03=10% Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.

 Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%



Pr.03-03=10%

Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
 Forward and reverse run is controlled by digital keyboard or external terminals.
- 1: Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad
 or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%

Diagram 05



Pr.03-03=10%

Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.
 Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%

Diagram 06



Pr.03-03=10%

Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- O: Negative frequency is not valid.

 Forward and reverse run is controlled by digital keyboard or external terminals.
- 1: Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad
 or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%



Pr.03-03=10%

Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center


Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.

 Forward and reverse run is controlled
 by digital keyboard or external terminals.
- 1: Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad
 or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%

Diagram 08



Pr.03-03=10%

Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.
 Forward and reverse run is controlled
 by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%

Diagram 09



Pr.03-03=-10%


Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
 Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%



Pr.03-03=-10% Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.
 Forward and reverse run is controlled
 by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%

Diagram 11



Pr.03-03=-10% Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
 Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%

Diagram 12



Pr.03-03=-10% Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- O: Negative frequency is not valid.

 Forward and reverse run is controlled by digital keyboard or external terminals.
- 1: Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad
 or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%



Pr.03-03=-10% Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.
 Forward and reverse run is controlled
 by digital keyboard or external terminals.
- 1: Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad
 or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%

Diagram 14



Pr.03-03=-10% Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.
 Forward and reverse run is controlled
 by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%

Diagram 15



Pr.03-03=-10%


Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
 Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%



Pr.03-03=-10% Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.
 Forward and reverse run is controlled
 by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 100%

Diagram 17



Pr.03-03=10% Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
 Forward and reverse run is controlled by digital keyboard or external terminals.
- 1: Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad
 or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 111.1% 10/9 = 111.1%

Diagram 18




Pr.03-03=10% Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
 Forward and reverse run is controlled by digital keyboard or external terminals.
- 1: Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad
 or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 111.1% 10/9 = 111.1%



Pr.03-03=10% Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
 Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 111.1% 10/9 = 111.1%

Diagram 20



Pr.03-03=10% Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.
 Forward and reverse run is controlled
 by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 111.1% 10/9 = 111.1%

Diagram 21




Pr.03-03=10% Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- O: Negative frequency is not valid.
 Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 111.1% 10/9 = 111.1%



Pr.03-03=10% Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center


Pr.03-10 (Analog Frequency Command for Reverse Run)

- O: Negative frequency is not valid.

 Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 111.1% 10/9 = 111.1%

Diagram 23



Pr.03-03=10% Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
 Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 111.1% 10/9 = 111.1%

Diagram 24




Pr.03-03=10% Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.
 Forward and reverse run is controlled by digital keyboard or external terminals.
- 1: Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad
 or external terminal control.

Pr.03-11 Analog input Gain (AVI) = 111.1% 10/9 = 111.1%



Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

0: Negative frequency is not valid.

Forward and reverse run is controlled

by digital keyboard or external terminals.

Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.


Calculate the bias:

$$\frac{60-6\text{Hz}}{10\text{V}} = \frac{6-0\text{Hz}}{(0-\text{X})} \quad \text{XV} = \frac{100}{-9} = -1.11\text{V} \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

Calculate the gain:

$$Pr.03-11 = \frac{10V}{11.1V} \times 100\% = 90.0\%$$

Diagram 26



Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- O: Negative frequency is not valid.

 Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Diagram 27



Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.


 Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Calculate the bias:

$$\frac{60-6Hz}{10V} = \frac{6-0Hz}{(0-X)} \quad XV = \frac{100}{-9} = -1.11V \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

Calculate the gain:

$$Pr.03-11 = \frac{10V}{11.1V} \times 100\% = 90.0\%$$



Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.
 Forward and reverse run is controlled
 by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.


Calculate the bias:

$$\frac{60-6Hz}{10V} = \frac{6-0Hz}{(0-XV)} \quad XV = \frac{100}{-9} = -1.11V \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$
$$= -11.1\%$$

Calculate the gain:

$$Pr.03-11 = \frac{10V}{11.1V} \times 100\% = 90.0\%$$

Diagram 29



Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Calculate the bias:

$$\frac{60-6Hz}{10V} = \frac{6-0Hz}{(0-XV)} \times V = \frac{100}{-9} = -1.11V \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

Calculate the gain:

$$Pr.03-11 = \frac{10V}{11.1V} \times 100\% = 90.0\%$$



Pr.03-07-03-08 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- O: Negative frequency is not valid.

 Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.

Diagram 31



Pr.03-07-03-08 (Positive/Negative Bias Mode)

-): No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- O: Negative frequency is not valid.

 Forward and reverse run is controlled by digital keyboard or external terminals.
- Negative frequency is valid.
 Positive frequency = forward run;
 negative frequency = reverse run.
 Direction can not be switched by digital keypad or external terminal control.


Calculate the bias:

$$\frac{60-6Hz}{10V} = \frac{6-0Hz}{(0-XV)} \quad XV = \frac{100}{-9} = -1.11V \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

Calculate the gain:

$$Pr.03-11 = \frac{10V}{11.1V} \times 100\% = 90.0\%$$

Diagram 32



Pr.03-07-03-08 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal bias
- 2: Greater than or equal to bias
- The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
 Forward and reverse run is controlled
 by digital keyboard or external terminal.
- by digital keyboard or external terminals.

 1: Negative frequency is valid.

 Positive frequency = forward run;

negative frequency = reverse run.

Direction can not be switched by digital keypad or external terminal control.

Calculate the bias

$$\frac{60-6\text{Hz}}{10\text{V}} = \frac{6-0\text{Hz}}{(0-\text{XV})} \quad \text{XV} = \frac{100}{-9} = -1.11\text{V} \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

= -11.1 %

Calculate the gain:

Pr.03-11 =
$$\frac{10V}{11.1V} \times 100\% = 90.0\%$$

✓ ☐ 3 - ☐ Analog Input Gain (AVI)	
✓ ☐ 3 - ↑ 2 Analog Input Gain (ACI)	
	Default: 100.0

Settings -500.0-500.0 %

Pr.03-03-03-12 are used when the Frequency command source is the analog voltage or current signal.

×	Analog Input Filter Time (AVI)	
×	Analog Input Filter Time (ACI)	

Settings 0.00-20.00 sec.

Analog signals, such as those entering AVI and ACI, are commonly affected by interference that affects the stability of the analog control. Use the Input Noise Filter to create a more stable system.

When the time constant setting is too large, the control is stable but the control response is slow. When the time constant setting is too small, the control response is faster but the control may be unstable. For optimal setting, adjust the setting based on the control stability or the control response.

Default: 0

Default: 0.01


Settings 0: Disable (AVI, ACI)

1: Enable (excludes analog extension card)

When Pr.03-18=1:

Example: Pr.03-00 = Pr.03-01 = 1, Frequency command = AVI + ACI

When Pr.03-18=0 and the analog input selection settings (Pr.03-00 and Pr.03-01) are the same, AVI has priority over ACI. In other words, when Pr.03-00 and Pr.03-01 are both set to 1 (Frequency command), the drive ignores the setting value from ACI but execute the Frequency command according to the setting value from AVI.



F command=[(ay±bias)*gain]*
$$\frac{\text{Fmax (Pr.01-00)}}{10 \text{ V or } 16 \text{ mA or } 20 \text{ mA}}$$

F command: the corresponding frequency for 10V or 20mA

ay: 0–10V, 4–20mA, 0–20mA bias: Pr.03-03, Pr.03-04

gain: Pr.03-11, Pr.03-12

Signal Loss Selection for the Analog Input 4–20 mA

Default: 0

Settings 0: Disable

- 1: Continue operation at the last frequency
- 2: Decelerate to 0 Hz
- 3: Stop immediately and display "ACE"
- Determines the treatment when the 4–20 mA signal is lost (ACIc (Pr.03-29 = 0)).
- When Pr.03-29 ≠ 0, the voltage input to ACI terminal is 0–10 V or 0–20 mA, and Pr.03-19 is invalid.
- When the setting is 1 or 2, the keypad displays the warning code "ANL". It keeps blinking until the ACI signal is recovered.
- When the drive stops, the condition that causes the warning does not exist, so the warning automatically disappears.

★ B 3 - 2 B Multi-function Output (AFM)

Default: 0

Settings 0-23

Summary of Function Settings

Settings	Functions	Descriptions		
0	Output frequency (Hz)	Maximum frequency Pr.01-00 is processed as 100 %.		
1	Frequency command (Hz)	Maximum frequency Pr.01-00 is processed as 100 %.		
2	Motor speed (Hz)	Maximum frequency Pr.01-00 is processed as 100 %.		
3	Output current (rms)	(2.5 X drive rated current) is processed as 100 %.		
4	Output voltage	(2 X motor rated voltage) is processed as 100 %.		
		230 V series: 450 V = 100 %		
5	DC bus voltage	460 V series: 900 V = 100 %		
		575 V series: 1125 V = 100 %		
6	Power factor	-1.000–1.000 = 100 %		
7	Power	(2 X drive rated power) is processed as 100 %.		
8	Output torque	Full-load torque = 100 %		
9	AVI	0-10 V = 0-100 %		
10	ACI	4–20 mA = 0–100 %		
12	Iq current command (2.5 X drive rated current) is processed as 100 %.			
13	lq feedback value	(2.5 X drive rated current) is processed as 100 %.		
14	ld current command	(2.5 X drive rated current) is processed as 100 %.		
15	ld feedback value	(2.5 X rated current) is processed as 100 %.		
		230 V series: 250 V = 100 %		
16	Vq-axis voltage command	460 V series: 500 V = 100 %		
		575 V series: 625 V = 100 %		
		230 V series: 250 V = 100 %		
17	Vd-axis voltage command	460 V series: 500 V = 100 %		
		575 V series: 625 V = 100 %		

Settings	Functions	Descriptions
18	Torque command	Motor rated torque = 100%
19	PG2 frequency command	Maximum operation frequency (Pr.01-00) is processed as 100 %.
20	CANopen analog output	For CANopen communication analog output Terminal Address AFM 2026-A1
21	RS-485 analog output	For RS-485 (Modbus) control analog output Terminal Address AFM 26A0H
22	Communication card analog output	For communication analog output (CMM-EIP01, CMM-PN01, CMM-DN01) Terminal Address AFM 26A0H
23	Constant voltage output	Pr.03-32 controls the voltage output level. 0–100 % of Pr.03-32 corresponds to 0–10 V for AFM.

★ 3 - 2 ↑ Analog Output Gain (AFM)

Default: 100.0

Settings 0.0–500.0 %

Adjusts the voltage level outputted to the analog meter from the analog signal (Pr.03-20) output terminal AFM of the drive.


★ 3 - 2 2 Analog Output in REV Direction (AFM)

Default: 0

Settings 0: Absolute value in output voltage

1: Reverse output 0 V; forward output 0-10 V

2: Reverse output 5-0 V; forward output 5-10 V



Analog output direction selection

✓ ☐ 3 - 2 7 AFM Output Bias

Default: 0.00

Settings -100.00-100.00 %

Example 1: AFM 0–10 V is set to the output frequency, the output equation is

Example 2: AFM 0-20 mA is set to the output frequency, the output equation is

20 mA x (
$$\frac{\text{Output Frequency}}{\text{Pr.01-00}}$$
) x Pr.03-21 + 20 mA x Pr.03-27

Example 3: AFM 4–20 mA is set to the output frequency, the output equation is

This parameter sets the corresponding voltage of the analog output 0.

Default: 0

Settings 0: 0–10 V (Pr.03-63–Pr.03-68 is valid) 3: -10–10 V (Pr.03-69–Pr.03-74 are valid)

★ 3 - 23 ACI Terminal Input Selection

Default: 0

Settings 0: 4–20 mA 1: 0–10 V 2: 0–20 mA


- When you change the input mode, verify that the external terminal switch (ACI) position is correct.
- When you change the setting, proportion to the corresponding AVI and ACI will change to default.

PLC Analog Output Terminal Status

Default: Read only


Settings Monitor the status of the PLC analog output terminals

bit 0: AFM



Example:

When Pr.03-30 displays 0001 (hex) (that is, the value is 1 (decimal) and 1 (binary)), it means that AFM is used by PLC..



Default: 0.01

× 83	AFM Out	tput Selection
, <u>o</u>	5	Default: 0
	Settings	0: 0–10 V output
	eetii ige	1: 0–20 mA output
		2: 4–20 mA output
		2. 1 20 HW Couput
~ <u>83</u>	- <u>3 2</u> AFM DC	Output Setting Level
		Default: 0.00
	Settings	0.00–100.00 %
/ 03	- 35 AFM Out	tput Filter Time
0.0	JJ 74 W Ca	Default: 0.01
	Settings	0.00–20.00 sec.
₩ 83	- 33 VR Input	t Selection
		Default: 1
	Settings	0: Disable
		1: Frequency command
	VR is the abbre KPMS-LE01.	eviation for Variable Resistor; it is the potentiometer of the keyboard pane
× 83	- ¥₿ VR Input	t Bias
		Default: 0.0
	Settings	-100–100 %
w 00	- U I VR Posi	itive / Negative Bias
<u> </u>	VIXI USI	Default: 0
	Settings	0: No bias
	Settings	1: Lower than or equal to bias
		2: Greater than or equal to bias
		3: The absolute value of the bias voltage while serving as the center
		4: Bias serves as the center
		4. Dias serves as the center
× 83	- Ч⋛ VR Gain	
		Default: 100.0
	Settings	-500.0–500.0 %
Ω3	- Ӌ ∄ VR Filter	Time
_ ~ ~		

Settings 0.00-2.00 sec.

★ ## Multi-fur nction Output (MO) by AI Level Source		
		Default: 0
Settings	0: AVI	
	1: ACI	
	r Level	
		Default: 50
Settings	-100–100 %	
	r Level	
		Default: 10
Settings	-100–100 %	
Use this function v	with the multi-function output setting 67 (analog input level	reached). The MO is
active when the A	I input level is higher than the Pr.03-45. The MO is disable	d when the AI input is
lower than the Pr.	03-46.	
When setting leve	els, Pr.03-45 Al upper level must be higher than Pr.03-46 A	I lower level.
Malog I	nput Curve Selection	
		Default: 0
Settings	0: Normal curve	
	1: Three-point curve of AVI	
	2: Three-point curve of ACI	
	3: Three-point curve of AVI & ACI	
	est Point	
		Default: 4.00
Settings	Pr.03-29 = 1, 0.00–10.00 V	
	Pr.03-29 ≠ 1, 0.00–20.00 mA	
	portional Lowest Point	
		Default: 0.00
Settings	0.00–100.00 %	
	-point	
		Default: 12.00
Settings	Pr.03-29 = 1, 0.00–10.00 V	
	Pr.03-29 ≠ 1, 0.00–20.00 mA	
	portional Mid-point	
		Default: 50.00

Settings

0.00-100.00 %

×	03-61	ACI High	est Point	
				Default: 20.00
		Settings	Pr.03-29 = 1, 0.00–10.00 V	
			Pr.03-29 ≠ 1, 0.00–20.00 mA	
×	03-62	ACI Prop	oortional Highest Point	
				Default: 100.00
		Settings	0.00-100.00 %	
	When P	r.03-29 = 1	1, the ACI setting is 0–10 V and the unit is voltage (V).	
	When P	r.03-29 ≠ ′	1, the ACI setting is 0–20 mA or 4–20 mA and the unit is σ	urrent (mA).
	When y	ou set the	e analog input ACI to the Frequency command, 100% o	corresponds to Fmax
	(Pr.01-0	0 Maximu	m Operation Frequency).	
	The req	uirement	for these three parameters (Pr.03-57, Pr.03-59 and Pr.	03-61) is Pr.03-57 <
	Pr.03-59) < Pr.03-6	61. The values for three proportional points (Pr.03-58, Pr	:03-60 and Pr.03-62)
	have no	limits. The	ere is a linear calculation between two points.	
	The out	put percer	ntage becomes 0 % when the ACI input value is lower t	than the lowest point
	setting.			
	Example	e:		
	If Pr.03-	57 = 2 mA	$_{\rm c}$; Pr.03-58 = 10%, then the output becomes 0 % when the	e ACI input is ≤ 2 mA.
	If the A	.CI input	swings between 2 mA and 2.1 mA, the drive's output	frequency oscillates
	betweer	n 0 % and	10 %.	
×	03-83	AVI Volta	ige Lowest Point	
				Default: 0.00
		Settings	0.00–10.00 V	
/	00 60	A) / Duan	oution all assest Daint	
/	03-07	AVI Prop	ortional Lowest Point	Default: 0.00
		Cottingo	100.00.100.00.9/	Default: 0.00
		Settings	-100.00–100.00 %	
×	03-65	AVI Volta	ge Mid-point	
				Default: 5.00
		Settings	0.00–10.00 V	
N	03-88	AVI Prop	ortional Mid-point	
				Default: 50.00
		Settings	-100.00–100.00 %	
,	03 63			
N	03-6 P	AVI Volta	ige Highest Point	
				Default: 10.00

Settings 0.00–10.00 V

N	83-88 AVI Prop	portional Highest Point	
		Defau	ılt: 100.00
	Settings	-100.00–100.00 %	
	(Pr.01-00 Maximu	e positive voltage AVI to the Frequency command, 100 % corresponding Operation Frequency) and the motor runs in the forward direction for the second state of the seco	on.
	Pr.03-65 < Pr.03-	for these three parameters (Pr.03-63, Pr.03-65 and Pr.03-67) is -67. The values for three proportional points (Pr.03-64, Pr.03-66 and Pr.03-66 and Pr.03-66 and Pr.03-64, Pr.03-66 and Pr.03-65.	
	The output percer lowest point settin Example:	ntage becomes 0 % when the positive voltage AVI input value is long.	ower than the
		Pr.03-64 = 10 %, then the output becomes 0 % when the AVI inpurwings between 1 V and 1.1 V, the drive's output frequency oscillate	
×	BB-83 Negative	e AVI Voltage Lowest Point	
	Settings	-10.00-0.00 V	ılt: 0.00
		(valid when Pr.03-28 sets as -10–10 V)	
N		e AVI Proportional Lowest Point	
	Settings	Defa -100.00–100.00 % (valid when Pr.03-28 sets as -10–10 V)	ault: 0.00
N	R3-7; Negative	e AVI Voltage Mid-point	
	Settings	Defa -10.00–0.00 V (valid when Pr.03-28 sets as -10–10 V)	ault: -5.00
N	#3 - 7.2 Negative	e AVI Proportional Mid-point	
		Defa	ault: -50.00
	Settings	-100.00–100.00 % (valid when Pr.03-28 sets as -10–10 V)	
N	## Negative	e AVI Voltage Highest Point	
	Settings	-10.00–0.00 V	ault: -10.00
	Journal	(valid when Pr 03 28 sets as 10 10 V)	

Default: -100.00

Settings -100.00-100.00 %

(valid when Pr.03-28 sets as -10-10 V)

- When you set the negative voltage AVI to the Frequency command, -100% corresponds to Fmax (Pr.01-00 Maximum Operation Frequency) and the motor runs in the reverse direction.
- The requirement for these three parameters (Pr.03-69, Pr.03-71 and Pr.03-73) is Pr.03-69 < Pr.03-71 < Pr.03-73, the values for three proportional points (Pr.03-70, Pr.03-72 and Pr.03-74) have no limits. There is a linear calculation between two points.
- The output percentage becomes 0 % when the negative voltage AVI input value is lower than the lowest point setting.

Example:

If Pr.03-69 = -1 V; Pr.03-70 = 10%, then the output becomes 0 % when the AVI input is $\ge -1 V$. If the AVI input swings between -1 V and -1.1 V, drive's output frequency oscillates between 0 % and 10 %.

04 Multi-Step Speed Parameters

✓ You can set this parameter during operation.


1st Step Speed Frequency	N
2 nd Step Speed Frequency	N
	N
4 th Step Speed Frequency	N
5 th Step Speed Frequency	N
6 th Step Speed Frequency	N
7 th Step Speed Frequency	N
8 th Step Speed Frequency	N
9 th Step Speed Frequency	N
10 th Step Speed Frequency	N
11 th Step Speed Frequency	N
12 th Step Speed Frequency	N
13 th Step Speed Frequency	N
14 th Step Speed Frequency	N
15 th Step Speed Frequency	×

Default: 0.00

Settings 0.00–599.00 Hz

- Use the multi-function input terminals (refer to settings 1–4 of Pr.02-01–02-07 Multi-function Input Command) to select the multi-step speed command (the maximum is 15th step speed). Pr.04-00 to Pr.04-14 sets the multi-step speed (frequency) as shown in the following diagram.
- The external terminal/digital keypad/communication controls the RUN and STOP commands with Pr.00-21.
- ☐ You can set each multi-step speed between 0.00–599.00 Hz during operation.
- Explanation for the timing diagram of the multi-step speed and external terminals

 The related parameter settings are:
 - 1. Pr.04-00–Pr.04-14: sets the 1st–15th multi-step speed (to set the frequency of each step speed).
 - 2. Pr.02-01–Pr.02-07: sets the multi-function input terminals (multi-step speed command 1–4).
- Related parameters:
 - Pr.01-22 JOG frequency setting
 - Pr.02-01 multi-function input command 1 (MI1)
 - Pr.02-02 multi-function input command 2 (MI2)
 - Pr.02-03 multi-function input command 3 (MI3)
 - Pr.02-04 multi-function input command 4 (MI4)



Speed Selection through External Terminals

PLC Buffer 0	
PLC Buffer 1	
PLC Buffer 2	
PLC Buffer 3	
PLC Buffer 4	
PLC Buffer 5	
PLC Buffer 6	
PLC Buffer 7	
PLC Buffer 8	
PLC Buffer 9	
₩ 🔐 - 👸 PLC Buffer 10	
PLC Buffer 11	
₩ <mark>34-82</mark> PLC Buffer 12	
PLC Buffer 13	
PLC Buffer 14	
PLC Buffer 15	
₩ <mark>34 - 88</mark> PLC Buffer 16	
PLC Buffer 17	
PLC Buffer 18	-
PLC Buffer 19	

Default: 0

Settings 0-65535

In You can combine the PLC buffer with the built-in PLC function for a variety of applications.

05 Motor Parameters

✓ You can set this parameter during operation.

In this parameter group, the following are abbreviations for different types of motors:

- IM: Induction motor
- PM: Permanent magnet synchronous AC motor
- IPM: Interior permanent magnet synchronous AC motor
- SPM: Surface permanent magnet synchronous AC motor

☐ 5 - ☐ ☐ Motor Parameter Auto-tuning

Default: 0

Settings 0: No function

1: Dynamic test for induction motor (IM)

2: Static test for induction motor (IM)

5: Rolling auto-tuning for PM (IPM / SPM)

12: FOC sensorless inertia estimation

13: High frequency stall test for PM synchronous motor

Full-load Current for Induction Motor 1 (A)

Default: Depending on

the model power

Settings 10–120 % of the drive's rated current

Sets this value according to the rated current of the motor as indicated on the motor nameplate.

The default is 90% of the drive's rated current.

Example: The rated current for a 7.5 HP (5.5 kW) motor is 25 A. The default is 22.5 A.

The setting range is $2.5-30 \text{ A} (25 \times 10 \% = 2.5 \text{ A} \text{ and } 25 \times 120 \% = 30 \text{ A}).$

Default: Depending on

the model power

Settings 0.00-655.35 kW

Sets the rated power for motor 1. The default is the drive's power value.

Rated Speed for Induction Motor 1 (rpm)

Default: Depending on

the motor's number of

poles

Settings 0-xxxxx rpm (Depending on the motor's number of poles)

1710 (60 Hz 4 poles); 1410 (50 Hz 4 poles)

Sets the rated speed for the motor as indicated on the motor nameplate.

☐ 5 - ☐ 4 Number of Poles for Induction Motor 1

Default: 4

Settings 2–20

- Sets the number of poles for the motor (must be an even number).
- Set up Pr.01-01 and Pr.05-03 before setting up Pr.05-04 to ensure that the motor operates normally.

85-85 No	-load C	Current for Induction Motor 1 (A)	
			Default: Depending on
			the model power
Se	ttings	0.00-Pr.05-01 default	
The default	is 40%	of the motor's rated current.	
05-05 Sta	ator Re	sistance (Rs) for Induction Motor 1	
			Default: Depending on
			the model power
Se	ttings	0.000–65.535 Ω	
05-07 Ro	tor Res	sistance (Rr) for Induction Motor 1	
			Default: 0.000
Se	ttings	0.000–65.535 Ω	
05 - 08 Ma	agnetizi	ng Inductance (Lm) for Induction Motor 1	
		uctance (Lx) for Induction Motor 1	
00 00			Default: 0.0
Se	ttings	0.0–6553.5 mH	2 0.0.0 0.0
<u>85-43</u> Fu	III-load (Current for Induction Motor 2 (A)	
			Default: Depending on
•		40, 400 % 611 11 11 11	the model power
		10–120 % of the drive's rated current	
		rding to the rated current of the motor as indicated o	n the motor nameplate.
		of the drive's rated current.	
•		I current for a 7.5 HP (5.5 kW) motor is 25 A. The defa	
	ne seur	ng range is 2.5–30 A (25 × 10 % = 2.5 A and 25 × 120	% = 30 A).
₩ <u>85-14</u> Ra	ited Po	wer for Induction Motor 2 (kW)	
			Default: Depending on
			the model power
Se	ttings	0.00–655.35 kW	
Sets the rate	ed powe	er for motor 2. The default is the drive's power value.	
05-15 Ra	ited Spe	eed for Induction Motor 2 (rpm)	
			Default: Depending on
			the motor's number of
			poles
Se	ttings	0-xxxxx rpm (Depending on the motor's number of po	oles)
		1710 (60 Hz 4 poles); 1410 (50 Hz 4 poles)	
☐ Sets the rate	ed spee	ed for the motor as indicated on the motor nameplate.	


05-18	Number	of Poles for Induction Motor 2	
	0 11:	0.00	Default: 4
	Settings	2–20	
		f poles for the motor (must be an even number).	
•		and Pr.05-15 before setting up Pr.05-16 to ensure	that the motor operates
normally			
85-17	No-load	Current for Induction Motor 2 (A)	
			Default: Depending on
			the model power
	Settings	0.00–Pr.05-13 default	
The defa	ult is 40%	of the motor's rated current.	
05-18	Stator Re	esistance (Rs) for Induction Motor 2	
			Default: Depending on
			the model power
	Settings	0.000 – $65.535~\Omega$	
85-18	Rotor Re	esistance (Rr) for Induction Motor 2	
			Default: 0.000
	Settings	$0.000-65.535~\Omega$	
85-28	Magnetiz	ring Inductance (Lm) for Induction Motor 2	
05-21	Stator In	ductance (Lx) for Induction Motor 2	
			Default: 0.0
	Settings	0.0–6553.5 mH	
85-22	Multi-mo	tor (Induction) Selection	
			Default: 1
	Settings	1: Motor 1	
		2: Motor 2	
		3: Motor 3 (VF or SVC control mode only)	
		4: Motor 4 (VF or SVC control mode only)	
Sets the	motor ope	erated by the AC motor drive. Multi-motor selection onl	y supports single control
mode. Fo	or exampl	e, when you set motor 1 as SVC control mode, the cor	ntrol mode of motors 2–4
are also	set as SV	C.	
05-23	Frequen	cy for Y-connection / Δ -connection Switch for an In	duction Motor
			Default: 60.00
	Settings	0.00–599.00 Hz	
05-24	Y-connec	ction /∆-connection Switch for an Induction Motor	
			Default: 0
	Settings	0: Disable	
		1: Enable	

✓ 😘 - 🤰 Delay Time for Y-connection/∆-connection Switch for an Induction Motor


Default: 0.200


Settings 0.000-60.000 sec.

- You can apply Pr.05-23–Pr.05-25 in wide range motors, and the motor coil executes the Y-connection/Δ-connection switch as required. The wide range motors are related to the motor design. In general, the motor has higher torque with low speed Y-connection and has higher speed with high speed Δ-connection.
- \square Pr.05-24 enables and disables the switch of Y-connection/ \triangle -connection.
- When you set Pr.05-24 to 1, the drive uses the Pr.05-23 setting and current motor frequency, and switches the current motor to Y-connection or Δ-connection. You can switch the relevant motor parameter settings simultaneously.
- \square Pr.05-25 sets the switch delay time of Y-connection/ \triangle -connection.
- When the output frequency reaches the Y-connection/∆-connection switch frequency, the drive delays according to Pr.05-25 before activating the multi-function output terminals.



- Y- △ connection switch: can be used for wide range motor
- Y -connection for low speed: higher torque can be used for rigid tapping
- \triangle -connection for high speed: higher speed can be used for high-speed drilling





Accumulated Watt-second for a Motor in Low Word (W-msec.)
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐
☐ 5 - 2 B Accumulated Watt-hour for a Motor (W-hour)
Accumulated Watt-hour for a Motor in Low Word (kW-hour)
☐ 5 - 3 ☐ Accumulated Watt-hour for a Motor in High Word (MW-hour)
Default: 0.0

Settings Read only

- Pr.05-26–05-30 records the amount of power the motors consume. The accumulation begins when the drive is activated and the record is saved when the drive stops or turns OFF. The amount of consumed watts continues to accumulate when the drive is activated again. To clear the accumulation, set Pr.00-02 to 5 to return the accumulation record to 0.
- The accumulated total watts of the motor per second = Pr.05-27 x 65536 + Pr.05-26 Example: when Pr.05-26 = 2548.1 and Pr.05-27 = 15.2, the accumulated total watts of the motor per second = 15.2 x 65536 + 2548.1 = 996147.2 + 2548.1 = 998695.3
- The accumulated total kilowatts of the motor per hour = $Pr.05-30 \times 65536 + Pr.05-29$ Example: when Pr.05-29 = 3361.4 and Pr.05-30 = 11.2, the accumulated total kilowatts of the motor per hour = $11.2 \times 65536 + 3361.4 = 734003.2 + 3361.4 = 737364.6$

GS-3: Accumulated Motor Operation Time (minutes)

Default: 0

Settings 0–1439

#5 - 32 Accumulated Motor Operation Time (days)

Default: 0

Settings 0-65535

Use Pr.05-31 and Pr.05-32 to record the motor operation time. To clear the operation time, set Pr.05-31 and Pr.05-32 to 0. An operation time shorter than 60 seconds is not recorded.

Induction Motor (IM) or Permanent Magnet Synchronous AC Motor Selection Default: 0

Settings 0: IM (Induction motor)

1: SPM (Surface permanent magnet synchronous AC motor)

2: IPM (Interior permanent magnet synchronous AC motor)

☐ 5 - 3 4 Full-load Current for a Permanent Magnet Synchronous AC Motor

Default: Depending on

the model power

Settings 0–120% of the drive's rated current

8 - 35 Rated Power for a Permanent Magnet Synchronous AC Motor

Default: Depending on

the motor power

Settings 0.00–655.35 kW

Sets the rated power for the permanent magnet synchronous AC motor. The default is the drive's power value.

35 - **35** Rated Speed for a Permanent Magnet Synchronous AC Motor

Default: 2000

Settings 0-65535 rpm

Default: 10

Settings 0-65535

Default: 0.000

Settings $0.000-65.535 \Omega$

Permanent Magnet Synchronous AC Motor Ld

Default: 0.00

Settings 0.00-655.35 mH

Permanent Magnet Synchronous AC Motor Lq

Default: 0.00

Settings 0.00-655.35 mH

Unit: V / krpm

Default: 0

Settings 0-65535

## Full-load Current for Induction Motor 3 (A)	
	Default: Depending on
	the model power
Settings 10–120% of the drive's rated current	
Set this value according to the rated current of the motor as indicated The default is 90% of the drive's rated current.	on the motor nameplate.
Example: The rated current for a 7.5 HP (5.5 kW) motor is 25 A. The def	ault is 22.5 A.
The setting range is 2.5–30 A (25 × 10 % = 2.5 A and 25 × 120	
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	
	Default: Depending on
	the model power
Settings 0.00–655.35 kW	
Sets the rated power for motor 3. The default is the drive's power value.	
## Rated Speed for Induction Motor 3 (rpm)	
	Default: Depending on
	the motor's number of
	poles
Settings 0-xxxxx rpm (Depending on the motor's number of p	ooles)
1710 (60 Hz 4 poles); 1410 (50 Hz 4 poles)	
Sets the rated speed for the motor as indicated on the motor nameplate.	
05-67 Number of Poles for Induction Motor 3	
	Default: 4
Settings 2–20	
Sets the number of poles for the motor (must be an even number).	
Set up Pr.01-54 and Pr.05-66 before setting up Pr.05-67 to ensure normally.	that the motor operates
## B - 88 No-load Current for Induction Motor 3 (A)	
	Default: Depending on
	the model power
Settings 0.00-Pr.05-64 default	
The default is 40% of the motor's rated current.	
## Stator Resistance (Rs) for Induction Motor 3	
	Default: Depending on
	the model power
Settings $0.000-65.535 \Omega$	

☐ 5 - ☐ Full-load Current for Induction Motor 4	(A)
	Default: Depending on
	the model power
Settings 10–120% of the drive's rated cu	urrent
$\begin{tabular}{l} egin{tabular}{l} egin{tabular} egin{tabular}{l} egin{tabular}{l} egin{tabular}{l} egin{tabular}{l} egin{tabular}{l} egin{tabular}{l} egin{tabula$	e motor as indicated on the motor nameplate
The default is 90% of the drive's rated current.	
Example: The rated current for a 7.5 HP (5.5 kW) n	notor is 25 A. The default is 22.5 A.
The setting range is 2.5–30 A (25 × 10 %	= 2.5 A and 25 × 120 % = 30 A).
☐5 - ↑ ↑ Rated Power for Induction Motor 4 (kW)	<i>I</i>)
	Default: Depending on
	the model power
Settings 0.00–655.35 kW	
Sets the rated power for motor 4. The default is the	drive's power value.
Rated Speed for Induction Motor 4 (rpr	m)
	Default: Depending on
	the motor's number of
	poles
Settings 0-xxxxx rpm (Depending on the	e motor's number of poles)
1710 (60 Hz 4 poles); 1410 (50	Hz 4 poles)
Sets the rated speed for the motor as indicated on	the motor nameplate.
	Default: 4
Settings 2–20	
\square Sets the number of poles for the motor (must be an	even number).
☐ Set up Pr.01-63 and Pr.05-72 before setting up	Pr.05-73 to make sure the motor operates
normally.	
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	(A)
	Default: Depending on
	the model power
Settings 0.00-Pr.05-70 default	
The default is 40% of the motor's rated current.	
☐ 5 - 7.5 Stator Resistance (Rs) for Induction M	otor 4
	Default: Depending on
	the model power
Settings $0.000-65.535 \Omega$	

06 Protection Parameters (1)

✓ You can set this parameter during operation.


Default: 180.0 / 360.0 / 450.0

Default: 380.0 / 760.0 / 975.0

Settings 115V / 230V series: 150.0–220.0 V_{DC}

460V series:: 300.0–440.0 V_{DC} 575V series:: 375.0–550.0 V_{DC}

- Sets the Low Voltage (LV) level. When the DC bus voltage is lower than Pr.06-00, a LV fault is triggered, and the drive stops output then the motor coasts to a stop.
- If the LV fault is triggered during operation, the drive stops output and the motor coasts to a stop. There are three LV faults, LvA (LV during acceleration), Lvd (LV during deceleration), and Lvn (LV in constant speed) that are triggered according to the status of acceleration or deceleration. You must press RESET to clear the LV fault. The drive automatically restarts if set to restart after momentary power loss (refer to Pr.07-06 Restart after Momentary Power Loss and Pr.07-07 Allowed Power Loss Duration for details).
- If the LV fault is triggered when the drive is in STOP status, the drive displays LvS (LV during stop), which is not recorded, and the drive restarts automatically when the input voltage is higher than the LV level of 30 V (230V series), 60 V (460V series) or 75V (575 series).



Settings 0: Disabled

115V / 230V: 0.0-390.0 V_{DC}

460V: 0.0-780.0 V_{DC} 575V: 0.0-1000.0 V_{DC}

- Setting Pr.06-01 to 0.0 disables the over-voltage stall prevention function (connected with braking unit or brake resistor). Use this setting when braking units or brake resistors are connected to the drive.
- Setting Pr.06-01 to a value > 0.0 enables the over-voltage stall prevention. This setting refers to the power supply system and loading. If the setting is too low, then over-voltage stall prevention is easily activated, which may increase deceleration time.
- Related parameters:

Pr.01-13, Pr.01-15, Pr.01-17, Pr.01-19 Deceleration Time 1–4, Pr.02-13 Multi-function Output 1 (Relay 1), Pr.02-16–Pr.02-17 Multi-function Output 2–3 (MO1, MO2), and Pr.06-02 Selection for Over-voltage Stall Prevention.


★ ## Selection for Over-voltage Stall Prevention

Default: 0


Settings 0: Traditional over-voltage stall prevention

1: Smart over-voltage stall prevention

- Use this function when you are unsure about the load inertia. When stopping under normal load, the over-voltage does not occur during deceleration and meet the deceleration time setting. Sometimes it may not stop due to over-voltage during decelerating to STOP when the load regenerative inertia increases. In this case, the AC motor drive extends the deceleration time automatically until the drive stops.
- When you set Pr.06-02 to 0, during deceleration the motor exceeds the synchronous speed due to load inertia. In this case, the motor becomes an electrical generator. The DC bus voltage may exceed its maximum allowable value due to motor regeneration in some situations, such as motor's loading inertia being too high or drive's deceleration time being set too short. When you enable traditional over-voltage stall prevention and the DC bus voltage detected is too high, the drive stops decelerating (output frequency remains unchanged) until the DC bus voltage drops below the setting value.



When you set Pr.06-02 to 1 to use smart over-voltage stall prevention during deceleration, the drive maintains the DC bus voltage when decelerating and prevents the drive from OV.



- When you enable the over-voltage stall prevention, the drive's deceleration time is longer than the setting. If you encounter any problem with the deceleration time, refer to the following guides for troubleshooting.
 - 1. Increase the deceleration time to a proper value.
 - 2. Install a brake resistor (refer to Section 7-1 Brake Resistors and Brake Units Used in AC Motor Drives for details) to dissipate the electrical energy that is generated from the motor.
- Related parameters:

Pr.01-13, Pr.01-15, Pr.01-17, Pr.01-19 Deceleration Time 1–4, Pr.02-13 Multi-function Output 1 (Relay 1), Pr.02-16–Pr.02-17 Multi-function Output 2–3 (MO1, MO2), and Pr.06-01 Over-voltage Stall Prevention.

Default: 120 / 180


Settings Normal load: 0–150%

(100% corresponds to the rated current of the drive)

Heavy load: 0-200%

(100% corresponds to the rated current of the drive)

- In heavy load (Pr.00-16=1), if the DC voltage is higher than the 875 V_{DC} (575V series), 700 V_{DC} (460V series) or 350 V_{DC} (230 series), the maximum value for Pr.06-03 is 185%.
- If the motor load is too large or the drive's acceleration time is too short, the output current of the drive may be too high during acceleration, and it may cause motor damage or trigger the drive's protection functions (OL or OC). Use this parameter to prevent these situations.
- During acceleration, the output current of the drive may increase abruptly and exceed the setting value of Pr.06-03. In this case, the drive stops accelerating and keeps the output frequency constant, and then continues to accelerate until the output current decreases.
- When you enable the over-current stall prevention, the drive's acceleration time is longer than the setting.
- When the over-current stall prevention occurs because the motor capacity is too small or operates in the default, decrease the Pr.06-03 setting value.
- If you encounter any problem with the acceleration time, refer to the following guides for troubleshooting.
 - 1. Increase the deceleration time to a proper value.
 - 2. Set Pr.01-44 Auto-Acceleration and Auto-Deceleration Setting to 1, 3 or 4. (auto-acceleration)
 - 3. Related parameters: Pr.01-12, 01-14, 01-16, 01-18 (Acceleration Time 1–4), Pr.01-44 Auto-Acceleration and Auto-Deceleration Setting, Pr.02-13 Multi-function Output 1 (Relay 1), Pr.02-16–02-17 Multi-function Output 2–3 (MO1, MO2)



Over-current Stall Prevention during Operation

Default: 120 / 180


Settings Normal load: 0–150%


(100% corresponds to the rated current of the drive)

Heavy load: 0-200%

(100% corresponds to the rated current of the drive)

- In heavy load (Pr.00-16=1), if the DC voltage is higher than the 875 V_{DC} (575V series), 700 V_{DC} (460V series) or 350 V_{DC} (230 series), the maximum value for Pr.06-04 is 185%.
- This is a protection for the drive to decrease output frequency automatically when the motor overloads abruptly during constant motor operation.
- If the output current exceeds the setting value for Pr.06-04 when the drive is operating, the drive decelerates according to the Pr.06-05 setting to prevent the motor from stalling. If the output current is lower than the setting value for Pr.06-04, the drive accelerates (according to Pr.06-05) again to the setting frequency.





✓ ## Over-torque Detection Level (Motor 1)

record.

Default: 120

Settings 10–250% (100% corresponds to the rated current of the drive)

Default: 0.1

Settings 0.1-60.0 sec.


Default: 120

Settings 10–250% (100% corresponds to the rated current of the drive)


Default: 0.1


Settings 0.1-60.0 sec.

- When the output current exceeds the over-torque detection level (Pr.06-07 or Pr.06-10) and also exceeds the over-torque detection time (Pr.06-08 or Pr.06-11), the over-torque detection follows the setting of Pr.06-06 and Pr.06-09.
- When you set Pr.06-06 or Pr.06-09 to 1 or 3, an ot1 / ot2 warning displays while the drive keeps running after over-torque detection. The warning remains on until the output current is smaller than 5% of the over-torque detection level.



When you set Pr.06-06 or Pr.06-09 to 2 or 4, an ot1 / ot2 warning displays and the drive stops running after over-torque detection. The drive does not run until you manually reset it.





to ensure the load capability of the motor in low speed.

Setting the parameter to 1 is suitable for standard motor (motor fan is fixed on the rotor shaft). For this kind of motor, the cooling capacity is lower in low speed; therefore, the action of an electronic

power supply). For this kind of motor, there is no significant correlation between cooling capacity and motor speed. Therefore, the action of electronic thermal relays remains stable in low speed


When the power is cycled frequently, if the power is switched OFF, the electronic thermal relay protection is reset; therefore, even setting the parameter to 0 or 1 may not protect the motor well. If there are several motors connected to one drive, install an electronic thermal relay in each motor.

thermal relay reduces the action time to ensure the life of motor.


№ 85 - 14 Electronic Thermal Relay Action Time 1 (Motor 1)
 № 85 - 28 Electronic Thermal Relay Action Time 2 (Motor 2)

Settings 30.0-600.0 sec.

- Set the parameter to 150% of motor rated current and use with the setting of Pr.06-14 and Pr.06-28 to prevent motor damage due to overheating. When it reaches the setting, the drive displays "EoL1 / EoL2", and the motor coasts to stop.
- Use this parameter to set the action time of the electronic thermal relay. It works based on the I2t characteristic curve of electronic thermal relay, the output frequency and current of the drive, and the operation time to prevent the motor from overheating.



Motor cooling curve with shaft-fixed fan



Default: 60.0

Motor cooling curve with independent fan


- The action of the electronic thermal relay depends on the settings for Pr.06-13 and Pr.06-27.
 - 1. Pr.06-13 or Pr.06-27 is set to 0 (using inverter motor):

When the output current of the drive is higher than 150% of the motor rated current (refer to the motor rated current % corresponded to the motor rated frequency in the motor cooling curve with independent fan), the drive starts to count the time. The electronic thermal relay acts when the accumulated time exceeds Pr.06-14 or Pr.06-28.

2. Pr.06-13 or Pr.06-27 is set to 1 (using standard motor):

When the output current of the drive is higher than 150% of the motor rated current (refer to the motor rated current % corresponded to the motor rated frequency in the motor cooling curve with shaft-fixed fan), the drive starts to count the time. The electronic thermal relay acts when the accumulated time exceeds Pr.06-14 or Pr.06-28.

The actual electronic thermal relay action time adjusts according to the drive output current (shown as the motor loading rate %). The action time is short when the current is high, and the action time is long when the current is low. Refer to the following diagram.



★ 35 - 15 Temperature Level Overheat (OH) Warning

Default: Depending on the model power

Settings 0.0-110.0°C

- Sets the drive's internal IGBT overheat warning level. When the temperature is higher than Pr.06-15 setting, the oH1 fault displays and the warning remains but it does not affect the drive operation.
- Use this parameter to check the motor overheat in advance in order to take precautionary measures to decrease the temperature and maintain the motor's normal operation.
- If you set the temperature 5°C higher than the maximum setting value for Pr.06-15, IGBT overheating occurs and the drive stops. Refer to Chapter 14 oH1 fault descriptions for details.

Default: 100

★ 36 - 18 Stall Prevention Limit Level (Weak Magnetic Field Current Stall Prevention Level)

Settings 0–100% (Refer to Pr.06-03–Pr.06-04)

This parameter only works in VF, VFPG, and SVC control mode.

- Sets the over-current stall prevention level when the motor's operation frequency is larger than Pr.01-01 (base frequency).
- Example: When Pr.06-03 = 150 %, Pr.06-04 = 100 % and Pr.06-16 = 80 %.

The over-current stall prevention level during acceleration:

 $Pr.06-03 * Pr.06-16 = 150 \times 80 \% = 120 \%.$

The over-current stall prevention level during operation:

 $Pr.06-04 * Pr.06-16 = 100 \times 80 \% = 80 \%.$

☐6 - 17 Fault Record 1
₩ Fault Record 2
Fault Record 3
₩ Fault Record 4
₽8 - 2 ∤ Fault Record 5
Fault Record 6

Default: 0

Settings 0: No fault record

- 1: Over-current during acceleration (ocA)
- 2: Over-current during deceleration (ocd)
- 3: Over-current during steady operation (ocn)
- 4: Ground fault (GFF)
- 6: Over-current at stop (ocS)
- 7: Over-voltage during acceleration (ovA)
- 8: Over-voltage during deceleration (ovd)
- 9: Over-voltage during constant speed (ovn)
- 10: Over-voltage at stop (ovS)
- 11: Low-voltage during acceleration (LvA)
- 12: Low-voltage during deceleration (Lvd)
- 13: Low-voltage during constant speed (Lvn)
- 14: Low-voltage at stop (LvS)
- 15: Phase loss protection (orP)
- 16: IGBT overheating (oH1)
- 18: IGBT temperature detection failure (tH1o)
- 21: Over load (oL)
- 22: Electronic thermal relay 1 protection (EoL1)
- 23: Electronic thermal relay 2 protection (EoL2)
- 24: Motor overheating PTC/ PT100 (oH3)
- 26: Over torque 1 (ot1)

- 27: Over torque 2 (ot2)
- 28: Under current (uC)
- 31: EEPROM read error (cF2)
- 33: U-phase error (cd1)
- 34: V-phase error (cd2)
- 35: W-phase error (cd3)
- 36: cc (current clamp) hardware error (Hd0)
- 37: oc (over-current) hardware error (Hd1)
- 40: Auto-tuning error (AUE)
- 41: PID loss ACI (AFE)
- 43: PG feedback loss (PGF2)
- 44: PG feedback stall (PGF3)
- 45: PG slip error (PGF4)
- 48: ACI loss (ACE)
- 49: External fault (EF)
- 50: Emergency stop (EF1)
- 51: External Base Block (bb)
- 52: Password is locked (Pcod)
- 54: Illegal command (CE1)
- 55: Illegal data address (CE2)
- 56: Illegal data value (CE3)
- 57: Data is written to read-only address (CE4)
- 58: Modbus transmission time-out (CE10)
- 61: Y-connection / △-connection switch error (ydc)
- 62: Deceleration energy backup error (dEb)
- 63: Over slip error (oSL)
- 72: STO Loss (STL1)
- 76: STO (STo)
- 77: STO Loss 2 (STL2)
- 78: STO Loss 3 (STL3)
- 79: U-phase Over-current before run (Aoc)
- 80: V-phase Over-current before run (boc)
- 81: W-phase Over-current before run (coc)
- 82: Output phase loss U phase (oPL1)
- 83: Output phase loss V phase (oPL2)
- 84: Output phase loss W phase (oPL3)
- 87: Low frequency overload protection (oL3)
- 89: Rotor position detection error (roPd)
- 101: CANopen guarding error (CGdE)
- 102: CANopen heartbeat error (CHbE)
- 104: CANopen bus off error (CbFE)
- 105: CANopen index error (CidE)

- 106: CANopen station address error (CAdE)
- 107: CANopen index setting exceed limit (CFrE)
- 111: InrCOM time-out error (ictE)
- 121: Internal communication error (CP20)
- 123: Internal communication error (CP22)
- 124: Internal communication error (CP30)
- 126: Internal communication error (CP32)
- 127: Internal communication error (CP33)
- 128: Over-torque 3 (ot3)
- 129: Over-torque 4 (ot4)
- 134: Internal communication error (EoL3)
- 135: Internal communication error (EoL4)
- 140: oc hardware error (Hd6)
- 141: GFF occurs before run (b4GFF)
- 142: Auto-tune error 1 (AuE1)
- 143: Auto-tune error 2 (AuE2)
- 144: Auto-tune error 3 (AuE3)
- The parameters record when the fault occurs and forces a stop.
- When low-voltage at stop fault (LvS) occurs, the fault is not recorded. When low-voltage during operation faults (LvA, Lvd, Lvn) occur, the faults are recorded.
- When dEb function is valid and enabled, the drive executes dEb and records fault code 62 to Pr.06-17–Pr.06-22 and Pr.14-70–Pr.14-73 simultaneously.
- ★ 36 23 Fault Output Option 1
- ★ \$\frac{1}{2}\frac{1}{2} \text{ Fault Output Option 2}
- ✓

 ☐ Fault Output Option 4

Default: 0

Settings 0–65535 (refer to bit table for fault code)

Use these parameters with multi-function output terminal (set Pr.06-23–Pr.06-26 to 35–38) for the specific requirement. When a fault occurs, the corresponding terminals are activated. Convert the binary value to a decimal value before you enter the value for Pr.06-23–Pr.06-26.

Fault Code	bit 0	bit 1	bit 2	bit 3	bit 4	bit 5	bit 6
Fault Code	current	Volt.	OL	SYS	FBK	EXI	CE
0: No fault record							
1: Over-current during acceleration (ocA)	•						
2: Over-current during deceleration (ocd)	•						
3: Over-current during steady operation (ocn)	•						
4: Ground fault (GFF)	•						
6: Over-current at stop (ocS)	•						
7: Over-voltage during acceleration (ovA)		•					

Fault Code	bit 0	bit 1	bit 2	bit 3	bit 4	bit 5	bit 6
rault Code	current	Volt.	OL	SYS	FBK	EXI	CE
8: Over-voltage during deceleration (ovd)		•					
9: Over-voltage during constant speed (ovn)		•					
10: Over-voltage at stop (ovS)		•					
11: Low-voltage during acceleration (LvA)		•					
12: Low-voltage during deceleration (Lvd)		•					
13: Low-voltage during constant speed (Lvn)		•					
14: Low-voltage at stop (LvS)		•					
15: Phase loss protection (orP)		•					
16: IGBT over-heat (oH1)			•				
18: IGBT temperature detection failure (tH1o)			•				
21: Drive over-load (oL)			•				
22: Electronics thermal relay 1 protection							
(EoL1)			•				
23: Electronics thermal relay 2 protection							
(EoL2)			•				
24: Motor overheating PTC/ PT100 (oH3)			•				
26: Over torque 1 (ot1)			•				
27: Over torque 2 (ot2)			•				
28: Under current (uC)	•						
31: EEPROM read error (cF2)				•			
33: U-phase error (cd1)				•			
34: V-phase error (cd2)				•			
35: W-phase error (cd3)				•			
36: cc (current clamp) hardware error (Hd0)				•			
37: oc (over-current) hardware error (Hd1)				•			
40: Auto-tuning error (AUE)				•			
41: PID loss ACI (AFE)					•		
43: PG feedback loss (PGF2)					•		
44: PG feedback stall (PGF3)					•		
45: PG slip error (PGF4)					•		
48: ACI loss (ACE)					•		
49: External fault (EF)						•	
50: Emergency stop (EF1)						•	
51: External base block (bb)						•	
52: Password is locked (Pcod)				•			
54: Illegal command (CE1)							•
55: Illegal data address (CE2)							•
56: Illegal data value (CE3)							•

Fault Cada	bit 0	bit 1	bit 2	bit 3	bit 4	bit 5	bit 6
Fault Code	current	Volt.	OL	SYS	FBK	EXI	CE
57: Data is written to read-only address (CE4)							•
58: Modbus transmission time-out (CE10)							•
61: Y-connection / △-connection switch error							
(ydc)							
62: Deceleration energy backup error (dEb)		•					
63: Over slip error (oSL)						•	
72: STO Loss (STL1)				•			
76: STO (STo)				•			
77: STO Loss 2 (STL2)				•			
78: STO Loss 3 (STL3)				•			
79: U-phase over-current before run (Aoc)	•						
80: V-phase over-current before run (boc)	•						
81: W-phase over-current before run (coc)	•						
82: U-phase output phase loss (oPL1)	•						
83: V-phase output phase loss (oPL2)	•						
84: W-phase output phase loss (oPL3)	•						
87: Low frequency overload protection (oL3)			•				
89: Rotor position detection error (roPd)					•		
101: CANopen guarding error (CGdE)							•
102: CANopen heartbeat error (CHbE)							•
104: CANopen bus off error (CbFE)							•
105: CANopen index error (CidE)							•
106: CANopen slave station setting error							
(CAdE)							•
107: CANopen index setting exceed limit							
(CFrE)							•
111: InrCOM time-out error (ictE)							•
121: Internal communication error (CP20)							•
123: Internal communication error (CP22)							•
124: Internal communication error (CP30)							•
126: Internal communication error (CP32)							•
127: Internal communication error (CP33)				•			
128: Over-torque 3 (ot3)			•				
129: Over-torque 4 (ot4)			•				
134: Electronics thermal relay 3 protection							
(EoL3)			•				
135: Electronics thermal relay 4 protection							
(EoL4)			•				
140: oc hardware error (Hd6)				•			

Fault Code	bit 0	bit 1	bit 2	bit 3	bit 4	bit 5	bit 6
Fault Code	current	Volt.	OL	SYS	FBK	EXI	CE
141: GFF occurs before run (b4GFF)				•			
142: Auto-tuning error 1							
(no feedback current error) (AUE1)							
143: Auto-tuning error 2							
(motor phase loss error) (AUE2)				•			
144: Auto-tuning error 3							
(no-load current I ₀ measuring error) (AUE3)							

Default: 0

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop


3: No warning

Sets the operation mode of a drive after detecting PTC.


Default: 50.0

Settings 0.0-100.0 %

- Sets AVI / ACI analog input function Pr.03-00-03-01 to 6 [thermistor (PTC) input value)].
- Use this parameter to set the PTC level; 100% PTC level corresponds to the maximum analog input value.
- When using the AVI terminal, you must set Pr.03-28 to 0 and switch AVI voltage to 0–10 V. At this time, the AVI input impedance is 20 K Ω .
- When the temperature reaches to the set protection level, the motor acts according to the settings for Pr.06-29 and displays warning "oH3" (if Pr.06-29 = 1-3). When the temperature is lower than the set protection level, you can press RESET key to clear the fault.
- The PTC uses the AVI-input and is connected through divider resistance as shown below:
 - The voltage between +10V to ACM: lies within 10–11V.
 - 2. The impedance for AVI is around 20K Ω . Recommended value for divider resistance is 1K-10K Ω.
 - 3. Please contact your motor dealer for the curve of temperature and resistance value for PTC. Protection level (Pr.06-30) = V+10 * (RPTC//20K) / [R1+(RPTC//20K)]
 - V+10: voltage between +10V-ACM actual value, Range 10.4~11.2V_{DC};
 - RPTC: motor PTC overheat protection level;
 - 20K Ω : the AVI input impedance;
 - R1: divider resistance (recommended value: 1–10k Ω)



Take the standard PTC thermistor as an example: if the protection level is 1330 Ω , the actual voltage between +10V-ACM is 10.5 V and divider resistance R1 is 4.4k Ω .



Refer to the following calculation when Pr.06-30 is set to 23% and motor temperature overheating protection level is 1330 Ω :

1330/20000 = (1330*20000) / (1330+20000) = 1247.07

10.5 * 1247.07 / (4400+1247.07) = 2.32 (V) = 2.3 (V)

Pr.06-30 = 2.3 / 10 V * % = 23%

Default: Read only

Settings 0.00-599.00 Hz

When a malfunction occurs, check the current Frequency command. If it happens again, it overwrites the previous record.

☐ 6 - 3 Output Frequency at Malfunction

Default: Read only

Settings 0.00-599.00 Hz

When a malfunction occurs, check the current output frequency. If it happens again, it overwrites the previous record.

Default: Read only

Settings 0.0-6553.5 V

When a malfunction occurs, check the current output voltage. If it happens again, it overwrites the previous record.

## DC bus Voltage at Malfunction	
	Default: Read only
Settings 0.0-6553.5 V	
When a malfunction occurs, check the current DC bus voltage. If it he previous record.	nappens again, it overwrites
⊕5 - 35 Output Current at Malfunction	
	Default: Read only
Settings 0.00–655.35 Amp	
When a malfunction occurs, check the current output current. If it hap previous record.	pens again, it overwrites the
### GBT Temperature at Malfunction	
	Default: Read only
Settings -3276.7-3276.7 °C	
When a malfunction occurs, check the current IGBT temperatu overwrites the previous record.	re. If it happens again,
	Default: Read only
Settings -32767–32767 rpm	
When a malfunction occurs, check the current motor speed in rooverwrites the previous record.	pm. If it happens again,
Torque Command at Malfunction	
	Default: Read only
Settings -32767-32767%	
When a malfunction occurs, check the current torque command. If it the previous record.	happens again, it overwrite
## Status of the Multi-function Input Terminal at Malfunctio	n
	Default: Read only
Settings 0000h–FFFFh	
\$\frac{1}{15}\$ - \$\frac{1}{3}\$ Status of the Multi-function Output Terminal at Malfunct	ion
	Default: Read only
Settings 0000h-FFFFh	
When a malfunction occurs, check the current status of the multi-fun	ection input/output terminals
If it happens again, it overwrites the previous record.	
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	
	Default: Read only
Settings 0000h–FFFFh	
When a malfunction occurs, check the current drive status (commun	ication address 2101H). If
happens again, it overwrites the previous record.	



Default: 0

Settings 0: STO Latch

1: STO No Latch

- Pr.06-44 = 0: STO Alarm Latch. After you clear the cause of the STO Alarm, use a Reset command to clear the STO Alarm.
- Pr.06-44 = 1: STO Alarm no Latch. After you clear the cause of the STO Alarm, the STO Alarm clears automatically.
- All of the STL1-STL3 errors are "Alarm Latch" mode (in STL1-STL3 mode, the Pr.06-44 function is not available).

✓ ☐ 6 - 45 Output Phase Loss Detection Action (OPHL)

Default: 3

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop

3: No warning

The OPHL protection is enabled when Pr.06-45 is not set to 3.

✓ ☐ 6 - 46 Detection Time for Output Phase Loss

Default: 0.500

Settings 0.000–65.535 sec.

Current Detection Level for Output Phase Loss

Default: 1.00

Settings 0.00-100.00%


Default: 0.000

Settings 0.000–65.535 sec.

- Setting Pr.06-48 to 0 disables the OPHL detection function before operation.
- Status 1:

The drive is in operation


When any phase is less than the Pr.06-47 setting, and exceeds the Pr.06-46 setting time, the drive executes according to the Pr.06-45 setting.



Status 2:

The drive is in STOP; Pr.06-48 = 0; $Pr.07-02 \neq 0$

After the drive starts, the DC brake operates according to Pr.07-01 and Pr.07-02. During this period, OPHL detection is not active. After the DC brake action is completed, the drive starts to run, and enables the OPHL protection as mentioned above for status 1.




Status 3:


The drive is in STOP; Pr.06-48 \neq 0; Pr.07-02 \neq 0

When the drive starts, it executes Pr.06-48 first, and then executes Pr.07-02 (DC brake). The DC brake current level in this state includes two parts: one is 20 times the Pr.06-47 setting value in Pr.06-48 setting time; the other is the Pr.07-01 setting value in Pr.07-02 setting time. The total DC brake time T = Pr.06-48 + Pr.07-02. In this period, if an OPHL occurs within the time for Pr.06-48, the drive executes the Pr.06-45 setting after the drive starts counting for half the time of Pr.06-48.

Status 3-1: Pr.06-48≠0, Pr.07-02≠0 (No OPHL detected before operation)



Status 3-2: Pr.06-48≠0, Pr.07-02≠0 (OPHL detected before operation)




Status 4:


The drive is in STOP; $Pr.06-48 \neq 0$; Pr.07-02=0

When the drive starts, it executes Pr.06-48 as the DC brake. The DC brake current level is 20 times the Pr.06-47 setting value. In this period, if an OPHL occurs within the time for Pr.06-48, the drive executes the Pr.06-45 setting after the drive starts counting for half the time of Pr.06-48.

Status 4-1: Pr.06-48≠0, Pr.07-02=0 (No OPHL detected before operation)



Status 4-2: Pr.06-48≠0, Pr.07-02=0 (OPHL detected before operation)



LvX Auto-reset

Default: 0

Settings 0: Disable

1: Enable

★ 36 - 53 Input Phase Loss Detection Action (OrP)

Default: 0

Settings 0: Fault and ramp to stop

1: Fault and coast to stop

The drive executes the input phase loss protection according to Pr.06-53.

Default: 0

Settings 0: Constant rated current and limit carrier frequency by load current and temperature

 Constant carrier frequency and limit load current by setting carrier frequency

2: Constant rated current (same as setting 0), but close current limit

Allowable maximum output frequency and the minimum carrier frequency limit in control mode: For VF, SVC, VFPG modes:

When the maximum output frequency is 599 Hz, the minimum carrier frequency is 6 k.

Setting 0:

When the operating point is greater than the derating curve (when the operating carrier frequency is greater than the rated carrier frequency), the rated current is constant, and carrier frequency (Fc) output by the drive decreases automatically according to the ambient temperature, overload output current and overload time. If overloads are not frequent, and the concern is only about the carrier frequency operating with the rated current for a long time, and changes to the carrier frequency due to short overload are acceptable, set to 0.

Refer to the Section 9-7 Derating for Ambient Temperature, Altitude and Carrier Frequency for the carrier frequency derating level.

Take VFD9A0MS43ANSAA in normal load as an example: ambient temperature 50°C, UL open-type, and independent installation. When the carrier frequency is set to 10 kHz, it corresponds to 55% of the rated output current. In the same condition for ambient temperature 40°C, it corresponds to 75% of rated output current. When the output current is higher than this value, it automatically decreases the carrier frequency according to the ambient temperature, output current and overload time. At this time, the overload capacity of the drive is 150% of the rated current.

Setting 1:

When the operating point exceeds the derating curve 1, the carrier frequency is the setting value. Select this mode if the change of carrier frequency and motor noise caused by ambient temperature and frequent overload are not allowed. (Refer to Pr.00-17.)

Refer to Section 9-7 Derating for Ambient Temperature, Altitude and Carrier Frequency for the rated current derating level. Take VFD9A0MS43ANSAA in normal load as an example. If you need to maintain the carrier frequency at 10 kHz, decrease the rated current to 55%. The OL protection executes when the current is 120% * 55% = 66% for one minute; therefore, you must operate using the values within the derating curve to keep the carrier frequency constant.

Setting 2:

The protection method and action are the same as setting value 0, but it disables the current limit when output current is the derating ratio ×120% (default value) in normal load and when the output current is the derating ratio ×180% (default value) in heavy load. The advantage is that it provides a higher starting output current when the carrier frequency setting is higher than the default. However, the carrier frequency derates easily when it overloads.

Example: when Pr.06-55 = 0 or 1, over-current stall prevention level = Ratio * Pr.06-03. When Pr.06-55 = 2, the over-current stall prevention level = Pr.06-03.

- Use this parameter with Pr.00-16 and Pr.00-17.
- The ambient temperature also affects the derating. Refer to Section 9-7-1 Derating Curve for Ambient Temperature and Altitude.

Take VFD9A0MS43ANSAA in normal load as an example: ambient temperature 50° C, UL open-type, and independent installation. When the carrier frequency is set to 10 kHz, it corresponds to 55% of the rated output current. If used for ambient temperature 60° C, it corresponds to 55% * 75% of the rated output current.

№ \$\mathref{0}8 - \mathref{5}8\$ PT100 Voltage Level 1 Default: 5.000 Settings 0.000–10.000 V № \$\mathref{0}8 - \mathref{5}\$? PT100 Voltage Level 2 Default: 7.000

Settings 0.000–10.000 V

Condition settings: PT100 voltage level Pr.06-57 > Pr.06-56.

★ 38 - 58 PT100 Level 1 Frequency Protection

Default: 0.00

Settings 0.00-599.00 Hz


PT100 Activation Level 1 Protection Frequency Delay Time

Default: 60

Settings 0-6000 sec.

PT100 operation instructions

- 1. Use voltage type analog input (AVI, ACI voltage 0–10 V) and select PT100 mode.
- Select one of the voltage type analog inputs below:
 (a) Pr.03-00 =11, (b) Pr.03-01 = 11 and Pr.03-29 = 1
- 3. When selecting Pr.03-01 = 11 and Pr.03-29 = 1, you must switch AFM to 0–10 V.
- 4. The AFM outputs constant voltage or current, then Pr.03-20 = 23. You must switch ACM to 0–20 mA, and set AFM output level to 45% (Pr.03-32 = 45%) of 20 mA = 9 mA.
- 5. Use Pr.03-32 to adjust the constant voltage or constant current of the AFM output; the setting range is 0.00–100.00%.
- 6. There are two types of action levels for PT100. The diagram below shows the PT100 protection action.



When Pr.06-58 = 0.00 Hz, PT100 function is disabled.

Case:

When using PT100, if the motor temperature is higher than 135°C (275°F), the drive starts to count the delay time for auto-deceleration (Pr.06-59). The drive decreases the motor frequency to the setting for Pr.06-58 when it reaches the delay time count value. The drive operates at the frequency set for Pr.06-58 until the motor temperature is lower than 135°C (275°F). If the motor temperature is higher than 150°C (302°F), the drive automatically decelerates to STOP and displays the warning "oH3".

Set up process:

- 1. Switch AFM to 0–20 mA on the control board.
- 2.

Connect external terminal AFM to "+"

Connect external terminal ACM to "-"

Connect AFM and AVI to "short circuit"

- Pr.03-00 = 11, Pr.03-20 = 23, Pr.03-32 = 45% (9 mA) 3.
- 4. Refer to the RTD temperature and resistance comparison table

Temperature = 135°C, resistance = 151.71 Ω , input current: 9 mA, voltage: about 1.37 V_{DC} Temperature = 150°C, resistance = 157.33 Ω , input current: 9 mA, voltage: about 1.42 V_{DC}

- When the RTD temperature > 135°C, the drive decelerates to the specified operation 5. frequency automatically. Then, Pr.06-56 = 1.37 V and Pr.06-58 = 10 Hz. (When Pr.06-58 = 0, it disables the specified operation frequency.)
- 6. When RTD temperature > 150°C, the drive outputs a fault, decelerates to STOP, and displays the warning "oH3". Then, Pr.06-57 = 1.42 V and Pr.06-29 = 1 (fault and ramp to stop).

Software Detection GFF Current Level

Default: 60.0

Settings 0.0-6553.5%

Software Detection GFF Filter Time

Default: 0.10

Settings 0.00-655.35 sec.

When the drive detects that the unbalanced three-phase output current is higher than the setting for Pr.06-60, GFF protection activates. The drive then stops output.

□ 6 - 6 3 Operation Time of Fault Record 1 (Day)
☐ 6 - 6 5 Operation Time of Fault Record 2 (Day)
☐ Grant Operation Time of Fault Record 3 (Day)
☐ 6 - 6 9 Operation Time of Fault Record 4 (Day)
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐
☐ 6 - 9 → Operation Time of Fault Record 6 (Day)

Default: Read only

	Settings 0–65535 days
08-64	Operation Time of Fault Record 1 (Min.)
08-88	Operation Time of Fault Record 2 (Min.)
88-88	Operation Time of Fault Record 3 (Min.)
88-78	Operation Time of Fault Record 4 (Min.)
88-9:	Operation Time of Fault Record 5 (Min.)
08-93	Operation Time of Fault Record 6 (Min.)

Default: Read only

Settings 0-1439 min. If there is any malfunction when the drive operates, Pr.06-17–06-22 records the malfunctions, and Pr.06-63–06-70 records the operation time for four sequential malfunctions. Check if there is any problem with the drive according to the interval of the recorded fault.

Example:

The first error: ocA occurs after motor drive operates for 1000 minutes.

The second error: ocd occurs after another 1000 minutes. The third error: ocn occurs after another 1000 minutes. The fourth error: ocA occurs after another 1000 minutes.

The fifth error: ocd occurs after another 1000 minutes. The sixth error: ocn occurs after another 1000 minutes.

Then, Pr.06-17-06-22 and Pr.06-63-06-70 are recorded as follows:

,	1					
	1 st fault	2 nd fault	3 rd fault	4 th fault	5 th fault	6 th fault
Pr.06-17	ocA	ocd	ocn	ocA	ocd	ocn
Pr.06-18	0	ocA	ocd	ocn	ocA	ocd
Pr.06-19	0	0	ocA	ocd	ocn	ocA
Pr.06-20	0	0	0	ocA	ocd	ocn
Pr.06-21	0	0	0	0	ocA	ocd
Pr.06-22	0	0	0	0	0	осА
Pr.06-63	1000	560	120	1120	680	240
Pr.06-64	0	1	2	2	3	4
Pr.06-65	0	1000	560	120	1120	680
Pr.06-66	0	0	1	2	2	3
Pr.06-67	0	0	1000	560	120	1120
Pr.06-68	0	0	0	1	2	2
Pr.06-69	0	0	0	1000	560	120
Pr.06-70	0	0	0	0	1	2

By examining the time record, you can see that the last fault (Pr.06-17) happened after the
 drive ran for four days and 240 minutes.


Default: 0.0

Settings 0.0–100.0%

Low Current Detection Time

Default: 0.00

Settings 0.00-360.00 sec.



- 1: The motor operates in a counterclockwise direction (U, V, W).
- 2: The motor operates in a clockwise direction (U, W, V).

7 35 - 811 Operating Frequency in Fire Mode

Default: 60.00

Settings 0.00-599.00 Hz

36-88 Operation Times in Fire Mode

Default: Read only

Settings 0–65535 times

Chapter 12 Descriptions of Parameter Settings | MS300

[This page intentionally left blank]

Chapter 12 Descriptions of Parameter Settings | MS300

07 Special Parameters

✓ You can set this parameter during operation.

★ 3 - 33 Software Brake Chopper Action Level

Default: 370.0 / 740.0 / 950.0

Settings 115V / 230V models: 350.0–450.0 V_{DC}

460V models: 700.0–900.0 V_{DC} 575V models: 875.0–1000.0 V_{DC}

Sets the DC bus voltage at which the brake chopper is activated. Choose a suitable brake resistor to achieve the optimal deceleration performance. Refer to Chapter 7 Optional Accessories for information about brake resistors.

Default: 0

Settings 0-100%

Sets the level of the DC brake current output to the motor at start-up and stop. When setting the DC brake current, the rated current (Pr.00-01) is 100%. It is recommended that you start with a low DC brake current level and then increase until you reach the proper holding torque. However, the DC brake current cannot exceed the motor's rated current to prevent the motor from burnout. Therefore, DO NOT use the DC brake for mechanical retention, otherwise injury or accident may occur.

✓ ☐ 7 - ☐ 2 DC Brake Time at Start-up

Default: 0.0

Settings 0.0–60.0 sec.

The motor may continue rotating due to external forces or the inertia of the motor itself. If you use the drive with the motor rotating, it may cause motor damage or trigger drive protection due to over-current. This parameter outputs DC current, generating torque to force the motor stop to get a stable start before motor operation. This parameter determines the duration of the DC brake current output to the motor when the drive starts up. Set this parameter to 0.0 to disable the DC brake at start-up.

Default: 0.0

Settings 0.0-60.0 sec.


- The motor may continue rotating after the drive stops output due to external forces or the inertia of the motor itself. This parameter outputs DC current, generating torque to force the motor stop after the drive stops output to make sure that the motor stops.
- This parameter determines the duration of the DC Brake current output to the motor when braking. To enable the DC brake at STOP, you must set Pr.00-22 (Stop Method) to 0 (ramp to stop). Set this parameter to 0.0 to disable the DC brake at stop.
- Related parameters: Pr.00-22 Stop Method, Pr.07-04 DC Brake Frequency at STOP.

Default: 0.00

DC Brake Frequency at STOP

Settings 0.00-599.00 0 Hz

Determines the start frequency of the DC brake before the drive ramps to stop. When this setting is less than Pr.01-09 (Start-up Frequency), the start frequency for the DC brake begins at the minimum frequency.



DC Brake Output Timing Diagram

- Use the DC brake before running the motor when the load is movable at stop, such as with fans and pumps. The motor is in free running status and in unknown rotation direction before the drive starts up. Execute the DC brake before you start the motor.
- Use the DC Brake at STOP when you need to brake the motor quickly or to control the positioning, such as with cranes or cutting machines.

✓ ② ? - ② 5 Voltage Increasing Gain

Default: 100

Settings 1–200%

When using speed tracking, adjust Pr.07-05 to slow down the increasing voltage gain if there are errors such as oL or oc; however, the speed tracking time will be longer.

★ 37-35 Restart after Momentary Power Loss

Default: 0

Settings 0: Stop operation

- 1: Speed tracking by the speed before the power loss
- 2: Speed tracking by the minimum output frequency
- Determines the operation mode when the drive restarts from a momentary power loss.
- The power system connected to the drive may power off momentarily for many reasons. This function allows the drive to keep outputting voltages after the drive is repowered and does not cause the drive to stop.
- 1: Frequency tracking begins before momentary power loss and accelerates to the master Frequency command after the drive output frequency and motor rotator speed are synchronous. Use this setting when there is a lot of inertia with little resistance on the motor load. For example, in equipment with a large inertia flywheel, there is NO need to wait until the flywheel stops completely after a restart to execute the operation command; therefore, it saves time.

- 2: Frequency tracking starts from the minimum output frequency and accelerates to the master Frequency command after the drive output frequency and motor rotator speed are synchronous. Use this setting when there is little inertia and large resistance.
- In PG control mode, the AC motor drive executes the speed tracking function automatically according to the PG speed when this setting is NOT set to 0.

Default: 2.0

Settings 0.0–20.0 sec.


- Determines the maximum time of allowable power loss. If the duration of a power loss exceeds this parameter setting, the AC motor drive stops output after the power recovers.
- Pr.07-06 is valid when the maximum allowable power loss time is ≤ 20 seconds and the AC motor drive displays "LU". If the AC motor drive is powered off due to overload, even if the maximum allowable power loss time is ≤ 20 seconds, Pr.07-06 is invalid after the power recovers.

✓ ☐ 7 - ☐ ☐ Base Block Time


Default: 0.5

Settings 0.0–60.0 sec.


When momentary power loss is detected, the AC motor drive blocks its output and then waits for a specified period of time (determined by Pr.07-08, called Base Block Time) before resuming operation. Set this parameter to the time that allows the residual voltage at the output side to decrease to 0 V before activating the drive again.



B.B. Speed tracking: from last output frequency



B.B. Speed tracking: from minimum output frequency





Current Limit of Speed Tracking

Default: 100

Settings 20-200%

- The AC motor drive executes speed tracking only when the output current is greater than the value set in Pr.07-09.
- The maximum current for speed tracking affects the synchronous time. The larger the parameter setting, the faster the synchronization occurs. However, if the parameter setting is too large, the overload protection function may be activated.






 Situation 1: Momentary power loss, or too low and unstable power voltage, or power supply sliding down because of sudden heavy load

start relay remains closed), and the drive executes auto-deceleration.

Pr.07-13 = 1 and power recovers

When the power recovers and DC bus voltage exceeds the dEb return level, the drive linearly decelerates to 0 Hz and stops. The keypad displays the "dEb" warning until you manually reset it, so you can see the reason for the stop.


When the DC bus voltage drops below the dEb setting level, the dEb function starts to work (soft



 Situation 2: Momentary power loss, or too low and unstable power voltage, or power supply sliding down because of sudden heavy load

Pr.07-13 = 2 and power recovers


During the dEb deceleration (includes 0 Hz run), if the power recovers to a voltage higher than dEb return level, the drive maintains the frequency for three seconds and then accelerates again. The "dEb" warning on the keypad is automatically cleared.



• Situation 3: Unexpected power shut down or power loss

Pr.07-13 = 1 and power does not recover

The keypad displays the "dEb" warning and the drive stops after decelerating to the lowest operating frequency. When the DC bus voltage is lower than the Lv level, the drive disconnects the soft start relay until the power completely runs out.




• Situation 4: Unexpected power shut down or power loss

Pr.07-13 = 2 and power does not recover

The drive decelerates to 0 Hz. The DC bus voltage continues to decrease until the voltage is lower than the Lv level, and then the drive disconnects the soft start relay. The keypad displays "dEb" warning until the drive completely runs out of power.

• Situation 5: Pr.07-13 = 2 and power recovers after the DC bus voltage is lower than the Lv level.

The drive decelerates to 0 Hz. The DC bus voltage continues to decrease until the voltage is lower than the Lv level, and then the drive disconnects the soft start relay. The soft start relay closes again after the power recovers and the DC bus voltage is higher than the Lv return level. When the DC bus voltage is higher than the dEb return level, the drive maintains the frequency for three seconds and starts to accelerate linearly. The "dEb" warning on the keypad is automatically cleared.



Dwell Time at Acceleration

Default: 0.00

Settings 0.00-600.00 sec.

Default: 0.00

Settings 0.00-600.00 sec.

Dwell Frequency at Acceleration

Default: 0.00


Settings 0.00-599.00 Hz



Default: 0.00

Settings 0.00-599.00 Hz

- In heavy load situations, the Dwell temporarily maintains stable output frequency. Use this parameter for cranes, elevators, and so on.
- For heavy load applications, use Pr.07-15–Pr.07-18 to avoid OV or OC protection.



Dwell at accel./decel.

Fan Cooling Control

Default: 3

Settings 0: Fan is always ON

- 1: Fan is OFF after the AC motor drive stops for one minute.
- 2: Fan is ON when the AC motor drive runs; fan is OFF when the AC motor drive stops
- 3: Fan turns ON when the temperature (IGBT) reaches around 60°C.
- Use this parameter to control the fan.
- © 0: Fan runs immediately when the drive power is turned ON.
- 1: Fan runs when the AC motor drive runs. One minute after the AC motor drive stops, the fan is OFF.
- 2: Fan runs when the AC motor drive runs and stops immediately when the AC motor drive stops.
- 3: When temperature of the IGBT or capacitance is higher than 60°C, the fan runs.

 When both the temperature of the IGBT and capacitance are lower than 40°C, the fan stops.

Emergency Stop (EF) & Force to Stop Selection

Default: 0

Settings 0: Coast to stop

- 1: Stop by the first deceleration time
- 2: Stop by the second deceleration time
- 3: Stop by the third deceleration time
- 4: Stop by the fourth deceleration time
- 5: System deceleration
- 6: Automatic deceleration
- When the multi-function input terminal setting is set to 10 (EF input) or 18 (force to stop) and the terminal contact is ON, the drive stops according to the setting of this parameter.

N	8	7 - 2 Automatic Energy-saving Setting
		Default: 0
		Settings 0: Disable
		1: Enable
		When energy-saving is enabled, the motor acceleration/deceleration operates with full voltage.
		During constant speed operation, it automatically calculates the best voltage value according to
		the load power. This function is not suitable for fluctuating loads or loads which are nearly full during operation.
	m	When the output frequency is constant (that is, constant operation), the output voltage decreases
		automatically as the load decreases. Therefore, the drive operates with minimum multiplication of
		voltage and current (electric power) to reach the energy-saving.
		voltage and current (electric power) to reach the energy-saving.
N	B	? - 2 2 Energy-saving Gain
		Default: 100
		Settings 10–1000%
		When Pr.07-21 is set to 1, use this parameter to adjust the energy-saving gain. The default is
		100%. If the result is not satisfactory, adjust it by decreasing the setting value. If the motor
		oscillates, then increase the setting value.
		In certain applications such as high speed spindles, the temperature rise in the motor is a major
		concern. When the motor is not in working state, reduce the motor current to a lower level.
		Reduce this parameter setting to meet this requirement.
N	8	7 - 2 3 Automatic Voltage Regulation (AVR) Function
		Default: 0
		Settings 0: Enable AVR
		1: Disable AVR
		2: Disable AVR during deceleration
		The rated voltage of a 220V motor is usually 200 V_{AC} , 60 Hz / 50 Hz, and the input voltage of the
		AC motor drive may vary from 180–264 V_{AC} , 50 Hz / 60 Hz. Therefore, when the AC motor drive
		is used without the AVR function, the output voltage is the same as the input voltage. When the
		motor runs at the voltage exceeding 12–20% of the rated voltage, it causes higher temperatures,
		damaged insulation, and unstable torque output, which result in losses due to shorter motor
		lifetime.
		The AVR function automatically regulates the output voltage of the AC motor drive to the motor's
		rated voltage when the input voltage exceeds the motor's rated voltage. For example, if the V/F
		curve is set at 200 $V_{\text{AC}},\ 50$ Hz and the input voltage is at 200–264 $V_{\text{AC}},\ \text{then}$ the drive
		automatically reduces the output voltage to the motor to a maximum of 200 $\ensuremath{V_{\text{AC}}}\xspace,~50$ Hz. If the
		input voltage is at 180–200 V_{AC} , the output voltage to motor is in direct proportion to the input
		voltage.
		0: When the AVR function is enabled, the drive calculates the output voltage according to the

actual DC bus voltage. The output voltage does NOT change when the DC bus voltage changes.

Chapter 12 Descriptions of Parameter Settings | MS300

		1: When the AVR function is disabled, the drive calculates the output voltage according to the actual DC bus voltage. The output voltage changes with the DC bus voltage, and may cause
		insufficient current, over-current or oscillation.
		2: The drive disables the AVR function only during deceleration to stop, and at this time, you can
		accelerate the braking to achieve the same result.
		When the motor ramps to stop, disable the AVR function to shorten the deceleration time. Then,
		use with the auto-acceleration and auto-deceleration functions to make the motor's deceleration
		more stable and quicker.
×	8	7 - 2 Ч Torque Command Filter Time (V/F and SVC Control Mode)
		Default: 0.050
		Settings 0.001–10.000 sec.
		When the time constant setting is too large, the control is stable but the control response is slow.
		When the time constant setting is too small, the control response is faster but the control may be
		unstable. For optimal setting, adjust the setting based on the control stability or the control
		response.
×	Ü	? - 2 5 Slip Compensation Filter Time (V/F and SVC Control Mode)
•		Default: 0.100
		Settings 0.001-10.000 sec.
		Change the compensation response time with Pr.07-24 and Pr.07-25.
		If you set Pr.07-24 and Pr.07-25 to 10 seconds, the compensation response time is the slowest;
		however, the system may be unstable if you set the time too short.
×	Ü	7 - 25 Torque Compensation Gain (V/F and SVC Control Mode)
×	$ \Omega $	7 - 7 / Torque Compensation Gain (Motor 2)
×	0	7 - 7 3 Torque Compensation Gain (Motor 3)
×	0	7 - 75 Torque Compensation Gain (Motor 4)
		Default: 1
		Settings IM: 0–10 (when Pr.05-33=0)
		PM: 0–5000 (when Pr.05-33=1 or 2)
		With a large motor load, a part of the drive output voltage is absorbed by the stator winding
		resistor; therefore, the air gap magnetic field is insufficient. This causes insufficient voltage at
		motor induction and results in excessive output current but insufficient output torque. Auto-torque
		compensation can automatically adjust the output voltage according to the load and keep the air
		gap magnetic fields stable to get the optimal operation.
		In the V/F control, the voltage decreases in direct proportion with decreasing frequency. The
		torque decreases at low speed because of a decreasing AC resistor and an unchanged DC
		resistor. The auto-torque compensation function increases the output voltage at low frequency to


output current of the drive, motor overheating or trigger the drive's protection function.

When the compensation gain is set too high, it may cause motor over-flux and result in a too large

get a higher starting torque.

/ III I I Olin (Compensation Gain (V/F a	nd SVC Control Mode)
V III Slib C	Compensation Gain (Motor	- 2)
	Compensation Gain (Motor	- 3)
	Compensation Gain (Motor	- 4)
		Default: 0.00
Settin	gs 0.00–10.00	(Default value is 1 in SVC mode)
	motor needs constant slip to peeds, such as rated speed	produce electromagnetic torque. It can be ignored at or 2–3% of slip.
proportion to pr	roduce the same electromage frequency. Moreover, the real specific value. Therefore, the ation, when you use an industrial also affects the motor specific to set the compensation peed when the motor runs are the drive output current is the drive compensates the free reset to 1.00 automatically	slip and the synchronous frequency are in reverse netic torque. The slip is larger with the reduction of the motor may stop when the synchronous frequency he slip seriously affects the motor speed accuracy at ction motor with the drive, the slip increases when the eed accuracy. tion frequency, and reduce the slip to maintain the t the rated current in order to improve the accuracy of a higher than Pr.05-05 (No-load Current for Induction equency according to this parameter. when Pr.00-11 (Speed Control Mode) is changed from automatically set to 0.00. Apply the slip compensation
		ompensation value from small to large gradually; add
motor is at th		slip x Pr.07-27 (Slip Compensation Gain)] when the speed ratio is slower than expected, increase the setting value.
motor is at th	ing value; otherwise, decrea	speed ratio is slower than expected, increase the
motor is at th	ing value; otherwise, decrea	speed ratio is slower than expected, increase the se the setting value.
motor is at th	ing value; otherwise, decrea	speed ratio is slower than expected, increase the
motor is at the parameter sett Mark the parameter sett Settin	ing value; otherwise, decreased Deviation Level gs 0.0–100.0% 0: No detection	speed ratio is slower than expected, increase the se the setting value. Default: 0
motor is at the parameter sett	ing value; otherwise, decreased Deviation Level gs 0.0–100.0%	speed ratio is slower than expected, increase the se the setting value. Default: 0
motor is at the parameter sett Mark Solip Control Settin	ing value; otherwise, decrear Deviation Level gs 0.0–100.0% 0: No detection -slip Deviation Detection T	speed ratio is slower than expected, increase the se the setting value. Default: 0
motor is at the parameter setted. Market Setting Sett	ing value; otherwise, decrear Deviation Level gs 0.0–100.0% 0: No detection -slip Deviation Detection T	speed ratio is slower than expected, increase the se the setting value. Default: 0
motor is at the parameter setted. Market Setting Sett	ing value; otherwise, decreased Deviation Level gs 0.0–100.0% 0: No detection -slip Deviation Detection T gs 0.0–10.0 sec.	speed ratio is slower than expected, increase the se the setting value. Default: 0
motor is at the parameter setted. Market Setting Sett	ing value; otherwise, decreased Deviation Level gs 0.0–100.0% 0: No detection -slip Deviation Detection T gs 0.0–10.0 secslip Deviation Treatment	speed ratio is slower than expected, increase the se the setting value. Default: 0 Default: 1.0 Default: 0
motor is at the parameter setted. ### Comparison of the parameter setted. ### Setting of the parameter setted. ### Setting of the parameter setted. ### Setting of the parameter setted. #### Setting of the parameter setted. #### Setting of the parameter setted. #### Setting of the parameter setted. ###################################	ing value; otherwise, decreased Deviation Level gs 0.0–100.0% 0: No detection -slip Deviation Detection T gs 0.0–10.0 secslip Deviation Treatment	speed ratio is slower than expected, increase the se the setting value. Default: 0 Default: 1.0 Default: 0 peration
motor is at the parameter setted. ### Comparison of the parameter setted. ### Setting of the parameter setted. ### Setting of the parameter setted. ### Setting of the parameter setted. #### Setting of the parameter setted. #### Setting of the parameter setted. #### Setting of the parameter setted. ###################################	ing value; otherwise, decreased Deviation Level gs 0.0–100.0% 0: No detection -slip Deviation Detection T gs 0.0–10.0 secslip Deviation Treatment gs 0: Warn and continue of	speed ratio is slower than expected, increase the se the setting value. Default: 0 Default: 1.0 Default: 0 peration pp
motor is at the parameter sett. M	ing value; otherwise, decreased Deviation Level gs 0.0–100.0% 0: No detection -slip Deviation Detection T gs 0.0–10.0 sec. -slip Deviation Treatment gs 0: Warn and continue of 1: Fault and ramp to sto	speed ratio is slower than expected, increase the se the setting value. Default: 0 Default: 1.0 Default: 0 peration pp

N		1-32	Motor Os	cillation Comp	ensation Factor		
							Default: 1000
			Settings	0–10000			
		If there	are curren	t wave motions	which cause seve	re motor oscillation i	n some specific area,
		setting t	his parame	ter can effective	ly improve this situa	ation. (When running	with high frequency or
		PG, set	this paran	neter to 0. Whe	n the current wave	motion occurs in lov	w frequency and high
		power, i	ncrease th	e value for Pr.07	-32.)		
	n ·	7_ 22	Auto roo	art Interval of F	- Coult		
~	U	1-22	Auto-res	art interval of r	-auit		Default: 60.0
			Sottings	0.0.6000.0.00			Delault. 60.0
	m	When a	Settings	0.0–6000.0 sec		oo Dr 07 22 oo o tim	er and starts counting
							•
					•	•	ber of faults does not
		exceed	me seumg	101 P1.07-11, the	counting clears an	d starts from 0 when	the next fault occurs.
	8	7-38	PMSVC	Voltage Feed F	orward Gain		
							Default: 1.00
			Settings	0.50-2.00			
	0) nc	00D C=				
	Ü	1-70	OOB Sai	mpling Time			Defectly 4.0
			0 - 44:	0.4.400.0			Default: 1.0
			Settings	0.1–120.0 sec.			
	8	7-47	Number	of OOB Sampli	ng Times		
							Default: 20
			Settings	00–32			
	П	7_00	OOR AV	erage Sampliı	na Analo		
	U	1-70	OOB AV	erage Sampin	ig Aligie		Default: Read only
			Settings	Read only			Delault. Read Offly
	\Box	Vou con			ance Detection) fun	otion with the DLC n	rogram in the washing
	العطا			•	•	•	7 is set to 82 (OOB
			•		•		•
		•		,	`		gle) $\Delta\theta$ value is set
	\Box		•	•	,	7-47 (Number of OOE	. • ,
					-	•	.07-48 (OOB Average
		•	. ,		•		e is large, the load is
							Frequency command.
				e the Frequency	y command to exec	cute nigh speed oper	rations when Pr.07-48
	₽		e is small.	D00 04 D 0	0.07/\\	Immed Occurrence 1.3	
		Kelated	parameter	s: Pr.U2-U1-Pr.U	2-07 (Wuiti-function	Input Commands).	



- Sets the PI gain of DC bus voltage controller when the dEb function activates.
- If the DC bus voltage drops too fast, or the speed oscillation occurs during deceleration after the dEb function activates, adjust Pr.07-62 and Pr.07-63. Increase the Kp setting to quicken the control response, but the oscillation may occur if the setting is too large. Use Ki parameter to decrease the steady-state error to zero, and increase the setting to quicken the response speed.

08 High-function PID Parameters

✓ You can set this parameter during operation.

★ \$\ \frac{1}{12} \frac{1}{12} \] Terminal Selection of PID Feedback

Default: 0

Settings 0: No function

- 1: Negative PID feedback: by analog input (Pr.03-00, 03-01)
- 2: Negative PID feedback: by single-phase input (MI7), without direction (Pr.10-16=5)
- 4: Positive PID feedback: by analog input (Pr.03-00, 03-01)
- 5: Positive PID feedback: by single-phase input (MI7), without direction (Pr.10-16=5)
- 7: Negative PID feedback: by communication protocols
- 8: Positive PID feedback: by communication protocols

Negative feedback:

Error = + Target value (set point) – Feedback. Use negative feedback when the detection value increases if the output frequency increases.


Positive feedback:

- Error = Target value (set point)+ Feedback. Use positive feedback when the detection value decreases if the output frequency increases.
- When Pr.08-00 \neq 7 or \neq 8, the input value is disabled. The setting value does not remain when the drive is powered off.

1. Common applications for PID control:

- ☑ Flow control: Use a flow sensor to feedback the flow data and perform accurate flow control.
- ☑ Pressure control: Use a pressure sensor to feedback the pressure data and perform precise pressure control.
- Air volume control: Use an air volume sensor to feedback the air volume data to achieve excellent air volume regulation.
- ☑ Temperature control: Use a thermocouple or thermistor to feedback temperature data for comfortable temperature control.
- ☑ Speed control: Use a speed sensor–to feedback motor shaft speed or input another machine speed as a target value for synchronous control.

2. PID control loop:



K_P Proportional Gain (P), T_i Integral Time (I), T_d Differential Time (D), S Calculation

3. Concept of PID control:

Proportional gain (P):

The output is proportional to input. With only a proportional gain control, there is always a steady-state error.

Integral time (I):


The controller output is proportional to the integral of the controller input. When an automatic control system is in a steady state and a steady-state error occurs, the system is called a System with Steady-state Error. To eliminate the steady-state error, add an "integral part" to the controller. The integral time controls the relation between the integral part and the error. The integral part increases over time even if the error is small. It gradually increases the controller output to eliminate the error until it is zero. This stabilizes the system without a steady-state error by using proportional gain control and integral time control.

Differential control (D):

The controller output is proportional to the differential of the controller input. During elimination of the error, oscillation or instability may occur. Use the differential control to suppress these effects by acting before the error. That is, when the error is near 0, the differential control should be 0. Use proportional gain (P) and differential control (D) to improve the system state during PID adjustment.

4. Using PID control in a constant pressure pump feedback application:

Set the application's constant pressure value (bar) to be the set point of PID control. The pressure sensor sends the actual value as the PID feedback value. After comparing the PID set point and PID feedback, an error displays. The PID controller calculates the output by using proportional gain (P), integral time (I) and differential time (D) to control the pump. It controls the drive to use a different pump speed and achieves constant pressure control by using a 4–20 mA signal corresponding to 0–10 bar as feedback to the drive.



12.1-08-2

Chapter 12 Descriptions of Parameter Settings | MS300

- Pr.00-04 = 10 (display PID feedback (b) (%))
- Pr.01-12 Acceleration Time is set according to actual conditions.
- Pr.01-13 Deceleration Time is set according to actual conditions.
- Pr.00-21 = 0, operate through the digital keypad
- Pr.00-20 = 0, the digital keypad controls the set point.
- Pr.08-00 = 1 (negative PID feedback from analog input)
- ACI analog input Pr.03-01 = 5, PID feedback signal.
- Pr.08-01-08-03 is set according to actual conditions.
 If there is no oscillation in the system, increase Pr.08-01 (Proportional Gain (P))
 If there is no oscillation in the system, decrease Pr.08-02 (Integral Time (I))
 If there is no oscillation in the system, increase Pr.08-03 (Differential Time (D))
- Refer to Pr.08-00–08-21 for PID parameter settings.

Proportional Gain (P)

Default: 1.00

Settings 0.0–1000.0 (When Pr.08-23 bit 1 = 0) 0.00–100.00 (When Pr.08-23 bit 1 = 1)

- 1.0: Kp gain is 100%; if the setting is 0.5, Kp gain is 50%.
- Sets the proportional gain to determine the deviation response speed. The higher the proportional gain, the faster the response speed. Eliminates the system deviation; usually used to decrease the deviation and get faster response speed. If you set the value too high, overshoot occurs and it may cause system oscillation and instability.
- If you set the other two gains (I and D) to zero, proportional control is the only effective parameter.

Default: 1.00

Settings 0.00–100.00 sec.

- Use the integral controller to eliminate the deviation during stable system operation. The integral control does not stop working until the deviation is zero. The integral is affected by the integral time. The smaller the integral time, the stronger the integral action. It is helpful to reduce overshoot and oscillation for a stable system. Accordingly, the speed to lower the steady-state deviation decreases. The integral control is often used with the other two controls for the PI controller or PID controller.
- Sets the integral time of the I controller. When the integral time is long, there is a small I controller gain, with slower response and slow external control. When the integral time is short, there is a large I controller gain, with faster response and rapid external control.
- When the integral time is too short, it may cause overshoot or oscillation for the output frequency and system.
- Set Integral Time to 0.00 to disable the I controller.


~	38-83 Differential Time	(D)
_	Jo 65 Smerenaar riine	Default: 0.00
	Settings 0.00–1.0	
	Use the differential controll change in the deviation. You to improve the system state adjustment time; however, the large differential causes may and the differential output is	er to show the system deviation change, as well as to preview the a can use the differential controller to eliminate the deviation in order. Using a suitable differential time can reduce overshoot and shorten the differential operation increases noise interference. Note that a too ore noise interference. In addition, the differential shows the change 0 when there is no change. Note that you cannot use the differential must use it with the other two controllers for the PD controller or PID
	Sets the D controller gair differential time reduces the system. A differential time the	to determine the deviation change response. Using a suitable P and I controllers overshoot to decrease the oscillation for a stable nat is too long may cause system oscillation. Its on the change in the deviation and cannot reduce the interference.
	Do not use this function who	en there is significant interference.
/	명 - 유명 Upper Limit of Inte	egral Control
, <u> </u>		Default: 100.0
	Settings 0.0–100.	0%
	The formula is: Integral upp	the integral gain (I) and therefore limits the master frequency. er bound = Maximum Operation Frequency (Pr.01-00) x (Pr.08-04%). e causes a slow response due to sudden load changes and may e damage. If so, decrease it to a proper value.
/	8-85 PID Output Comm	nand Limit (Positive Limit)
	Settings 0.0–110.	Default: 100.0
	Defines the percentage of	the output frequency limit during the PID control. The formula is
_	Output Frequency Limit = N	laximum Operation Frequency (Pr.01-00) × Pr.08-05%.
×	₿-₿₽ PID Feedback Va	ue by Communication Protocol
_	Settings -200.00-	Default: 0.00
		et the PID feedback value when the PID feedback input is set to
	communications (Pr.08-00 =	·
*	₿ - ₿ ॏ PID Delay Time	
		Default: 0.0

Settings 0.0-2.5 sec.


Chapter 12 Descriptions of Parameter Settings | MS300

88	PID Mode Selection
	Default: 0
	Settings 0: Serial connection
	1: Parallel connection
	0: Use conventional PID control structure.
	1: The proportional gain, integral gain and differential gain are independent. You can customize
	the P, I and D value to fit your application.
	Pr.08-07 determines the primary low pass filter time when in PID control. Setting a large time
	constant may slow down the drive's response speed.
	PID control output frequency is filtered with a primary low pass function. This function can filter a
	mix of frequencies. A long primary low pass time means the filter degree is high and a short
	primary low pass time means the filter degree is low.
	Inappropriate delay time setting may cause system oscillation.
	PI Control:
	Controlled only by the P action, so the deviation cannot be entirely eliminated. In general, to
	eliminate residual deviations, use the P + I controls. When you use the PI control, it eliminates
	the deviation caused by the targeted value changes and the constant external interferences.
	However, if the I action is too powerful, it delays the response when there is rapid variation. You
	can use the P action by itself to control the loading system with the integral components.
	PD Control:
	When deviation occurs, the system immediately generates an operation load that is greater than
	the load generated only by the D action to restrain the deviation increment. If the deviation is
	small, the effectiveness of the P action decreases as well. The control objects include
	applications with integral component loads, which are controlled by the P action only. Sometimes
	if the integral component is functioning, the whole system may oscillate. In this case, use the PD
	control to reduce the P action's oscillation and stabilize the system. In other words, this control is
	useful with no brake function's loading over the processes.
	PID Control:
	Use the I action to eliminate the deviation and the D action to reduce oscillation; then combine
	this with the P action for the PID control. Use the PID method for a control process with no
	deviations, high accuracy, and a stable system.

Serial connection



Parallel connection



Default: 0.0

Settings 0.0-3600.0 sec.

- □ Valid only when the feedback signal is ACI (4–20 mA).
- This parameter sets the detection time for abnormal PID signal feedback. You can also use it when the system feedback signal response is extremely slow. (Setting the detection time to 0.0 disables the detection function.)

08-09	Feedback Signal Fault Treatment	
	Default:	0
	Settings 0: Warn and continue operation	
	1: Fault and ramp to stop	
	2: Fault and coast to stop	
	3: Warn and operate at last frequency	
Valid o	only when the feedback signal is ACI (4–20 mA).	
Sets th	ne treatments when the PID feedback signal is abnormal.	
08-10	Sleep Frequency	
	Default: 0	0.00
	Settings 0.00-599.00 Hz	
Determ	nines the sleep frequency, and if the sleep time and the wake-up frequency are enab	led o
disable	ed.	
Pr.08-1	10 = 0: Disabled; Pr.08-10 ≠ 0: Enabled	
08-11	Wake-up Frequency	
00 11	Default: 0	00
	Settings 0.00–599.00 Hz	
₩ When	Pr.08-18=0, the unit for Pr.08-10 and that for Pr.08-11 switch to frequency. The se	ttinas
	tween 0.00–599.00 Hz.	3-
₩ When	Pr.08-18=1, the unit for Pr.08-10 and that for Pr.08-11 switch to percentage. The se	ettings
	tween 0.00–200.00%.	J
The pe	ercentage is based on the current command value, not the maximum value. For exa	mple
if the n	maximum value is 100 kg, and the current command value is 30 kg, then if Pr.08-11=	-40%
the val	lue is 12 kg.	
Pr.08-1	10 uses the same logic for calculation.	
08 - 12	Sleep Time	
00 .0	Default:	0.0
	Settings 0.0–6000.0 sec.	
When to a contract of the contract of	the Frequency command is smaller than the sleep frequency and less than the sleep	time
	equency command is equal to the sleep frequency. However, the Frequency com	
	ns at 0.00 Hz until the Frequency command becomes equal to or larger than the wal	
freque	·	
08- :3	PID Feedback Signal Error Deviation Level	
00 13	Default: 1	10.0
	Settings 1.0–50.0%	
	U t tt t	

₩ 📆 🖁 - 👯 PID Feedback Signal Error Deviation Detection Time

Default: 5.0

Settings 0.1-300.0 sec.

✓ ☐8 - 15 PID Feedback Signal Filter Time

Default: 5.0

Settings 0.1-300.0 sec.

When the PID control function is normal, it should calculate the value within a period of time that is close to the target value.

Refer to the PID control diagram for details. When executing PID feedback control, if |PID reference target value - detection value| > Pr.08-13 PID Feedback Signal Error Deviation Level and time exceeds Pr.08-14 setting, it is regarded as a PID control fault, and the multi-function output terminal setting 15 (PID feedback error) activates.

✓ ☐8 - ☐6 PID Compensation Selection

Default: 0

Settings 0: Parameter setting

1: Analog input

①: The setting for Pr.08-17 gives the PID compensation value.

✓ ☐8 - ! ? PID Compensation

Default: 0

Settings -100.0–100.0%

The PID compensation value = maximum PID target value × Pr.08-17. For example, if the maximum operation frequency Pr.01-00 = 60 Hz, and Pr.08-17 = 10.0%, the PID compensation value increases the output frequency 6.00 Hz (60.00 Hz × 100.00% × 10.0% = 6.00 Hz).

Sleep Mode Function Setting

Default: 0

Settings 0: Refer to PID output command

1: Refer to PID feedback signal

- 0: The unit for Pr.08-10 and that for Pr.08-11 switch to frequency. The settings are between 0.00–599.00 Hz.
- 1: The unit for Pr.08-10 and that for Pr.08-11 switch to percentage. The settings are between 0.00–200.00%.

Default: 50.0

Settings 0.0–200.0%

Reduces the reaction time from sleep to wake-up.

Defines the wake-up integral frequency limit = (Pr.01-00 × Pr.08-19%)

☐8 - ☐ ☐ Enable PID to Change the Operation Direction

Default: 0

Settings 0: Operation direction cannot be changed

1: Operation direction can be changed

✓ Ø8 - 22 Wake-up Delay Time

Default: 0.00

Settings 0.00-600.00 sec.

Refer to Pr.08-18 for more information.

✓ ☐8 - 2 3 PID Control Flag

Default: 2

Settings bit 0 = 1, PID running in reverse follows the setting for Pr.00-23.

bit 0 = 0, PID running in reverse refers to PID's calculated value.


bit 1 = 1, two decimal places for PID Kp

bit 1 = 0, one decimal place for PID Kp

- bit 0 = 1: PID running in reverse function is valid only when Pr.08-21=1.
- bit 0 = 0: If the PID calculated value is positive, the direction is forward. If the PID calculated value is negative, the direction is reverse.
- When the bit1 setting changes, the Kp gain does not change. For example: Kp = 6. When Pr.08-23 bit1 = 0, Kp = 6.0; when Pr.08-23 bit1 = 1, Kp = 6.00.
- There are three scenarios for the sleep and wake-up frequency.

1) Frequency Command (PID is not in use, Pr.08-00 = 0. Works only in VF mode)


When the output frequency ≤ the sleep frequency and the drive reaches the preset sleep time, then the drive is in sleep mode (0 Hz). When the Frequency command reaches the wake-up frequency, the drive starts to count the wake-up delay time. When the drive reaches the wake-up delay time, it starts to catch up to reach the Frequency command value by the acceleration time.



2) Internal PID Calculation Frequency Command (PID is in use, Pr.08-00 ≠ 0 and Pr.08-18=0.)

When the PID calculation Frequency command reaches the sleep frequency, the drive starts to count the sleep time and the output frequency starts to decrease. If the drive exceeds the preset sleep time, then the drive is in sleep mode (0 Hz). If the drive does not reach the preset sleep time, it remains at the lower frequency limit (if there is a preset lower limit.), or it remains at the minimum output frequency set for Pr.01-07 and waits until it reaches the sleep time before going into sleep mode (0 Hz). When the PID calculated Frequency command reaches the wake-up frequency, the drive starts to count the wake-up delay time. Once it reaches the wake-up delay time, the drive starts to catch up to reach the PID Frequency command value by the acceleration time.


Internal PID Calculation Frequency Command



3) PID Feedback Value Percentage (PID is in use, Pr.08-00 ≠ 0 and Pr.08-18 = 1)

When the PID feedback value reaches the sleep level percentage, the drive starts to count the sleep time and the output frequency starts to decrease. If the drive exceeds the preset sleep time, then the drive is in sleep mode (0 Hz). If the drive does not reach preset the sleep time, it remains at the lower frequency limit (if there is a preset of lower limit.), or it remains at the minimum output frequency set for Pr.01-07 and waits until it reaches the sleep time before going into sleep mode (0 Hz).

When the PID feedback value reaches the wake-up percentage, the drive starts to count the wake-up delay time. Once it reaches the wake-up delay time, the drive starts to catch up to reach the PID Frequency command value by the acceleration time.





Default: 100.0

Settings 0.0-100.0%

When PID enables the reverse direction, the PID output is a negative value, and the PID output value is limited by the setting for Pr.08-26. Use this function with Pr.08-21.

Acceleration / Deceleration Time for PID Command

Default: 0.00

Settings 0.00-655.35 sec.

- © 0.00 seconds: Disables the PID acceleration/deceleration command, and the target value is equal to the PID command.
- When this parameter is not set to 0.00 seconds: Enables the PID acceleration/deceleration command. For PID acceleration and deceleration, when the PID target value changes, the command value increment/decrement is executed according to this parameter.

For example, if we set this parameter to 10.00 seconds, when PID target value changes from 0% to 100%, it takes 10 seconds for the PID command to change from 0% to 100%. In a similar way, when PID target value changes from 100% to 0%, it takes 10 seconds for the PID command to change from 100% to 0%.

Frequency Base Corresponding to 100.00% PID

Default: 0

Settings 0: PID control output 100.00% corresponding to maximum operation frequency (Pr.01-00)

1: PID control output 100.00% corresponding to the input value of the auxiliary frequency

☐ Valid only when you enable the master and auxiliary frequency functions.

When Pr.08-29 = 0, PID control outputs 100.00% corresponding to the maximum operation frequency. When Pr.08-29 = 1, PID control outputs 100.00% corresponding to the auxiliary frequency. (The PID output frequency changes when the auxiliary frequency command changes.)

★ B - 3 | Proportional gain 2

Default: 1.00

Settings 0.0–1000.0 (when Pr.08-23 setting bit 1=0) 0.00–100.00 (when Pr.08-23 setting bit 1=1)

🗸 🖁 🖁 - 🖁 🗗 Integral time 2

Default: 1.00

Settings 0.00-100.00 sec.

✓ ☐ B - ☐ B Differential time 2

Default: 0.00

Settings 0.00-1.00 sec.

✓ ☐ 8 - 6 5 PID Target Value Source

Default: 0

Settings 0: Frequency command (Pr.00-20, Pr.00-30)

- 1: Pr.08-66 setting
- 2: RS-485 communication input
- 3: External analog input (refer to Pr.03-00, Pr.03-01)
- 4: CANopen communication card
- 6: Communication card (does not include CANopen card)
- 7: Digital keypad potentiometer knob
- Selects the target value source for the PID controller.
- When Pr.08-65=0, the maximum operating frequency Pr.01-00 is 60 Hz, the error is 100%, and Pr.08-01=1.00, then the output frequency is "1" times the Pr.01-00 maximum operating frequency. Therefore, the output frequency = 60 * 100% * 1=60 Hz.

Calculation formula:


Output frequency=Fmax (Pr.01-00) * error% ((PID reference value (Pr.00-20 / Pr.00-30) – PID feedback (Pr.08-00)) * Pr.08-01.

When Pr.08-65≠0, the internal calculation of the proportional gain reduces by 100 times, that is, when Pr.01-00 Fmax=60 Hz, error=100%, Pr.08-01=1.00, then the output frequency is "0.01" times the Pr.01-00 Fmax. Therefore, the output frequency=60 * 100% * 0.01=0.6 Hz.


Calculation formula:

Output frequency=Fmax (Pr.01-00) * error% ((PID reference value (Pr.08-66) – PID feedback value (Pr.08-00)) * Pr.08-01 * 0.01.

When Pr.08-65=0, the PID controller architecture shows as the diagram below:



When Pr.08-65≠0, the PID controller architecture shows as the diagram below:



- When Pr.08-65 is not set to 0, Pr.00-20 is automatically set to 9.
- When Pr.08-65 is set to 1, set the PID command through Pr.08-66; when Pr.08-65 is not set to 1, Pr.08-66 displays the PID command.
- When Pr.08-65 is set to 2, 4, and 6, the corresponding communication address is C2003H.

✓ ☐ 8 - 5 5 PID Target Value Setting

Default: 50.00

Settings -100.00-100.00%

The target value setting of the PID controller (Pr.08-66) is a relative value.

★ ## Master and Auxiliary Reverse Running Cutoff Frequency

Default: 10.0

Settings 0.0–100.0%

- 100% corresponds to Pr.01-00 the maximum operation frequency
- In some cases, it is only possible for the PID to control the set point and the feedback to the same status when the PID output frequency is negative (the motor runs in reverse). However, an excessively high reverse frequency is not allowed in some cases, and Pr.08-67 is used to determine the upper limit of the reverse frequency

✓ ☐8 - 58 PID Deviation Limit

Default: 0.00

Settings 0.00-100.00%

- When Pr.08-68 is not set to 0, the PID deviation limit function is enabled.
- When PID deviation ≤ PID deviation limit, PID stops adjusting, which means the PID output frequency maintains the value at last status. This function is effective for some closed-loop control applications.

✓ ☐ B - ☐ ☐ Integral Separation Level

Default: 0.00

Settings 0.00-100.00%

- Reduces overshoot when overshoot occurs in the PID feedback at start-up.
- When Pr.08-69 is not set to 0, the integral separation function is enabled.
- The benchmark for the integral separation level is the PID error%.
- The integral separation function activates only once at start-up.
- When PID deviation ≥ Pr.08-69, the integral effect is cancelled to avoid the increasing system overshoot due to the integral effect. When PID deviation is smaller than Pr.08-69, the integral effect is activated to eliminate the steady-state error.

Default: 5.00

Settings 0.00-100.00%

Smart Start-up Frequency Command

Default: 0.00


Settings 0.00-599.00 Hz

Smart Start-up Acceleration Time

Default: 3.00

Settings 0.00-600.00 sec.

- When Pr.08-71 is not set to 0, the smart start-up function is enabled.
- The benchmark for the smart start-up level is the percentage of PID deviation.
- Use the smart start-up function to reduce overshoot when overshoot occurs in the PID feedback at start-up. The smart start-up activates only once at start-up.
- When the smart start-up function is enabled, it starts with the Pr.08-71 frequency and Pr.08-72 acceleration time (Pr.08-72 acceleration time is the time that it accelerates to Pr.08-71). When the PID deviation is smaller than Pr.08-70, it switches to the normal PID control (the smart start-up frequency is filled into the PID integral when switching to PID control to avoid discontinuous frequency).





Default: 0

Settings 0: No switching (refer to Pr.08-01–Pr.08-03)

1: Auto-switch based on the output frequency

2: Auto-switch based on the deviation

7 🔐 - 78 PID2 Parameter Switch Deviation 1

Default: 10.00


Settings 0.00-Pr.08-77%

✓ ☐ PID2 Parameter Switch Deviation 2

Default: 40.00


Settings Pr.08-76-100.00%

- A set of PID parameters cannot meet the requirements of the entire running process in some applications. Use Pr.08-75 to switch to the second set of PID parameters Pr.08-31–08-33. The setting method for Pr.08-31–08-33 is the same as that for Pr.08-01–08-03.
- The two sets of PID parameters switch automatically according to the frequency and deviation. Switch according to the output frequency:
 - When the output frequency is between Pr.01-07 and Pr.01-00, the PID parameter is the linear interpolation value between the two PID parameter groups.



Switch according to the deviation:

- When the deviation absolute value between the set point and feedback is smaller than Pr.08-76 (PID2 Parameter Switch Deviation 1), the first group PID parameters are used.
- When the deviation absolute value between the set point and feedback is larger than Pr.08-77 (PID2 Parameter Switch Deviation 2), the second group PID parameters are used.
- When the deviation absolute value between the set point and feedback is between Pr.08-76 and Pr.08-77, the PID parameter is the linear interpolation value between the two PID parameter groups.



★ ## Allowed Reverse Running Time after Start-up

Default: 0.0

Settings 0.0-6553.5 sec.

- When Pr.08-78 is not set to 0, the allowed reverse running time after start-up is enabled.
- When it is set to 1 second, the PID control is not allowed to change the running direction within 0–1 seconds of starting time (Pr.08-21=0), and is allowed to change after 1 second of starting time (Pr.08-21=1).

09 Communication Parameters

✓ You can set this parameter during operation.

When using the communication interface, the diagram on the right shows the communication port pin definitions. We recommend that you connect the AC motor drive to your PC by using Delta IFD6530 orIFD6500 as a communication converter.



Modbus RS-485 Pin 1, 2, 6: Reserved Pin 3, 7: SGND Pin 4: SG-

Pin 5: SG+ 8-485 Pin 8: +10VS

✓ ☐ ☐ ☐ Communication Address

Default: 1

Settings 1-254

Sets the communication address for the drive if the AC motor drive is controlled through RS-485 serial communication. The communication address for each AC motor drive must be unique.

✓ ☐ ☐ ☐ COM1 Transmission Speed

Default: 9.6

Settings 4.8-115.2 Kbps

- Sets the transmission speed between the computer and the AC motor drive.
- Options are 4.8 Kbps, 9.6 Kbps, 19.2 Kbps, 38.4 Kbps, 57.6 Kbps, or 115.2 Kbps; otherwise, the transmission speed is set to the default 9.6 Kbps.

✓ ## COM1 Transmission Fault Treatment

Default: 3

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop

3: No warning, no fault, and continue operation

- Determines the treatment when an error is detected that the host controller does not continuously transmit data to the AC motor drive during Modbus communication. The detection time is based on the Pr.09-03 setting.
- When a transmission error occurs (for example, the error code CE10 displays), the error remains even if the transmission status returns to normal, and is not cleared automatically. In this case, set a reset command (Reset) to clear the error.

★ ## COM1 Time-out Detection

Default: 0.0

Settings 0.0–100.0 sec.

Sets the communication time-out value.

★ B 9 - B Y COM1 Communication Protocol

Default: 1

Settings 1: 7, N, 2 (ASCII)

2: 7, E, 1 (ASCII)

3: 7, O, 1 (ASCII)

4: 7, E, 2 (ASCII)

5: 7, O, 2 (ASCII)

6: 8, N, 1 (ASCII)

7: 8, N, 2 (ASCII)

8: 8, E, 1 (ASCII)

9: 8, O, 1 (ASCII)

10: 8, E, 2 (ASCII)

11: 8, O, 2 (ASCII)

12: 8, N, 1 (RTU)

13: 8, N, 2 (RTU)

14: 8, E, 1 (RTU)

15: 8, O, 1 (RTU)

16: 8, E, 2 (RTU)

17: 8, O, 2 (RTU)

Control by PC (Computer Link)

When using the RS-485 serial communication interface, you must specify each drive's communication address in Pr.09-00. The computer then implements control using the drives' individual addresses.

Modbus ASCII (American Standard Code for Information Interchange): Each byte of data is the combination of two ASCII characters. For example, one byte of data: 64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex).

1. Code Description


The communication protocol is in hexadecimal, ASCII: "0" ... "9", "A" ... "F", every hexadecimal value represents an ASCII code. The following table shows some examples.


Character	'0'	'1'	'2'	'3'	'4'	'5'	'6'	'7'
ASCII code	30H	31H	32H	33H	34H	35H	36H	37H
Character	'8'	'9'	'A'	'B'	'C'	'D'	'E'	'F'
ASCII code	38H	39H	41H	42H	43H	44H	45H	46H

2. Data Format

10-bit character frame (For ASCII):

(7, N, 2)





11-bits character frame

3. Communication Protocol

3.1 Communication Data Frame

ASCII mode:

STX	Start character = ':'(3AH)	
Address High	Communication address: one 8-bit address consists of 2 ASCII codes	
Address Low		
Function High	Command code:	
Function Low	one 8-bit command consists of 2 ASCII codes	
DATA (n-1)	Contents of data: n x 8-bit data consists of 2n ASCII codes	
DATA 0	n ≤ 16, maximum of 32 ASCII codes (20 sets of data)	
LRC Check High	LRC checksum:	
LRC Check Low	one 8-bit checksum consists of 2 ASCII codes	
END High	End characters:	
END Low	END High = CR (0DH), END Low = LF (0AH)	

RTU mode:

START	Defined by a silent interval of larger than/equal to 10 ms
Address	Communication address: 8-bit binary address
Function	Command code: 8-bit binary command
DATA (n-1)	Contents of data:
	Contents of data:n × 8-bit data, n ≤ 16
DATA 0	11 0 51 0 0 0 0
CRC Check Low	CRC checksum:
CRC Check High	one 16-bit CRC checksum consists of 2 8-bit binary
Cito official riight	characters
END	Defined by a silent interval of larger than/equal to 10 ms

3.2 Communication Address (Address)

00H: Broadcast to all AC motor drives

01H: AC motor drive at address 01

0FH: AC motor drive at address 15

10H: AC motor drive at address 16

:

FEH: AC motor drive at address 254

3.3 Function (Function code) and DATA (Data characters)

(1) 03H: Read data from a register

Example: Reading two continuous data from register address 2102H. AMD address is 01H.

Chapter 12 Descriptions of Parameter Settings | MS300

ASCII mode:

Command Message

STX	· · ·
Addraga	'0'
Address	'1'
Function	'0'
Function	'3'
	'2'
Starting register	'1'
Starting register	'0'
	'2'
	'0'
Number of register	'0'
(count by word)	'0'
	'2'
LRC Check	'D'
LING CHECK	'7'
END	CR
EIND	LF

Response Message

	-
STX	(.,) -
Address	' 0'
Address	'1'
Function	' 0'
Fullction	'3'
Number of register	' 0'
(count by byte)	'4'
	'1'
Content of starting register 2102H	'7 '
	'7 '
	' 0'
	' 0'
Content of register 2102	' 0'
Content of register 2103H	' 0'
	' 0'
LRC Check	'7 '
LRC Check	'1'
END	CR
EIND	LF

RTU mode:

Command Message

Address	01H
Function	03H
Starting data register	21H
Starting data register	02H
Number of register	00H
(count by world)	02H
CRC Check Low	6FH
CRC Check High	F7H

Response Message

Address	01H
Function	03H
Number of register (count by byte)	04H
Content of register	17H
address 2102H	70H
Content of register	00H
address 2103H	00H
CRC Check Low	FEH
CRC Check High	5CH

(2) 06H: Single write, write single data to a register

Example: Writing data 6000 (1770H) to register 0100H. AMD address is 01H.

ASCII mode:

Command Message

Respor	ise i	/lessa	age

STX	· · ·
Address	'0'
Address	'1'
Function	'0'
Function	'6'
	'0'
Torget register	'1'
Target register	'0'
	'0'
	'1'
Pogistor content	'7'
Register content	'7'
	'0'
LRC Check	'7'
LRC Check	'1'
END	CR
END	LF

) SIA	
Address	'0'
Address	'1'
Function	'0'
FullClion	'6 '
	'0'
Target register	'1'
Target register	'0'
	'0'
	'1'
Register content	'7'
Register content	'7'
	'0'
LRC Check	'7'
LRC Check	'1'
END	CR
EIND	LF

RTU mode:

Command Message

	'	5
01H	Address	01H
06H	Function	06H
01H	Target register	01H
00H	Target register	00H
17H	Pogister content	17H
70H	Register content	70H
86H	CRC Check Low	86H
22H	CRC Check High	22H

Response Message

Address 01H Function 06H Target register 01H Register content 17H CRC Check Low 86H CRC Check High 22H

(3) 10H: Write multiple registers (can write at most 20 sets of data simultaneously).

Example: Set the multi-step speed of an AC motor drive (address is 01H):

Pr.04-00 = 50.00 (1388H), Pr.04-01 = 40.00 (0FA0H)

ASCII Mode:

Command Message

STX	4,3		
ADR 1	' 0'		
ADR 0	'1'		
CMD 1	'1'		
CMD 0	' 0'		
	'0'		
Torget register	' 5'		
Target register	' 0'		
	' 0'		
	' 0'		
Number of register	' 0'		
(count by word)	'0'		
, , ,	'2'		
Number of register	' 0'		
(count by Byte)	'4'		
	'1'		
The first data containt	'3'		
The first data content	'8'		
	'8'		
	' 0'		
<u>-</u>	'F'		
The second data content	'A'		
	' 0'		
L DC Charle	'9'		
LRC Check	'A'		
END	CR		
END	LF		

Response Message

STX	': '
ADR 1	'0'
ADR 0	'1'
CMD 1	'1'
CMD 0	'0'
	'0'
Torget register	'5'
Target register	'0'
	'0'
	'0'
Number of register	'0'
(count by word)	'0'
	'2'
LRC Check	'E'
LRC Check	'8'
END	CR
END	LF

RTU mode:

Command Message

ADR	01H
CMD	10H
Torget register	05H
Target register	00H
Number of register	00H
(count by word)	02H
Quantity of data (byte)	04
The first data content	13H
The lifst data content	88H
The second data content	0FH
The second data content	A0H
CRC Check Low	' 9'
CRC Check High	'A'

Response Message

01H
10H
05H
00H
00H
02H
41H
04H

3.4 Checksum

(1) ASCII mode (LRC Check):

LRC (Longitudinal Redundancy Check) is calculated by summing up the values of the bytes from ADR1 to the last data character then calculating the hexadecimal representation of the 2's-complement negation of the sum.

For example, as shown in the above Section 3.3.(1),

01H + 03H + 21H + 02H + 00H + 02H = 29H, the 2's-complement negation of 29H is **D7**H.

(2) RTU mode (CRC Check):

- CRC (Cyclical Redundancy Check) is calculated by the following steps:
- Step 1: Load a 16-bit register (called CRC register) with FFFFH.
- **Step 2:** Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, and put the result in the CRC register.
- **Step 3:** Examine the LSB of CRC register.
- **Step 4:** If the LSB of CRC register is 0, shift the CRC register one bit to the right, fill MSB with zero, then repeat step 3. If the LSB of CRC register is 1, shift the CRC register one bit to the right, fill MSB with zero, Exclusive OR the CRC register with the polynomial value A001H, then repeat step 3.
- **Step 5:** Repeat step 3 and 4 until you perform eight shifts. This processes a complete 8-bit byte.
- **Step 6:** Repeat step 2 through 5 for the next 8-bit byte of the command message. Continue doing this until all bytes are processed. The final contents of the CRC register are the CRC value. When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, that is, the lower order byte is transmitted first.

The following is an example of CRC generation using C language.

The function takes two arguments:

Unsigned char* data ← a pointer to the message buffer

Unsigned char length ← the quantity of bytes in the message buffer

The function returns the CRC value as a type of unsigned integer.

4. Address list

Address list				
Content	Address		Function	
AC motor drive	GGnnH	GG is the parameter group, nn is the parameter number; for		
parameters		example, the address of Pr.04-10 is 040AH.		
Command write only	2000H	bit 1–0	00B: No function	
			01B: Stop	
			10B: Run	
			11B: JOG + RUN	
		bit 3–2	Reserved	
		bit 5–4	00B: No function	
			01B: FWD	
			10B: REV	
			11B: Change direction	
		bit 7–6	00B: 1st accel. / decel.	
			01B: 2 nd accel. / decel.	
			10B: 3 rd accel. / decel.	
			11B: 4th accel. / decel.	
		bit 11–8	000B: Master speed	
			0001B: 1st step speed frequency	
			0010B: 2 nd step speed frequency	
			0011B: 3 rd step speed frequency	
			0100B: 4 th step speed frequency	
			0101B: 5 th step speed frequency	
			0110B: 6 th step speed frequency	
			0111B: 7 th step speed frequency	
			1000B: 8th step speed frequency	
			1001B: 9th step speed frequency	
			1010B: 10 th step speed frequency	
			1011B: 11th step speed frequency	
			1100B: 12 th step speed frequency	
			1101B: 13 th step speed frequency	
			1110B: 14th step speed frequency	
			1111B: 15 th step speed frequency	
		bit 12	1: Enable bit 06–11 function	
		bit 14-13	00B: No function	
			01B: Operated by the digital keypad	
			10B: Operated by Pr.00-21 setting	
			11B: Change the operation source	
		bit 15	Reserved	
	2001H		command (XXX.XX Hz)	
	2002H	bit 0	1: E.F. (External Fault) ON	
		bit 1	1: Reset command	

Chapter 12 Descriptions of Parameter Settings | MS300

Content	Address		Function	
		bit 2	1: B.B. ON	
		bit 4-3	Reserved	
		bit 5	1: Enable fire mode	
		bit 15–6	Reserved	
Status monitor read	2100H	High byte:	Warning code / Low Byte: Error code	
only	2101H	bit 1–0	AC motor drive operation status	
		Dit 1—0	00B: The drive stops	
			01B: The drive is decelerating	
			10B: The drive is in standby status	
		1 '' 0	11B: The drive is operating	
		bit 2	1: JOG command	
		bit 4–3	Operation direction	
			00B: FWD running 01B: From REV running to FWD running	
			10B: From FWD running to REV running	
			11B: REV running	
			1: Master frequency controlled by the	
		bit 8	communication interface	
			1: Master frequency controlled by the analog /	
		bit 9	external terminal signal	
		1:1.40	1: Operation command controlled by the	
		bit 10	communication interface	
		bit 11	1: Parameter locked	
		bit 12	1: Enable to copy parameters from keypad	
		bit 15-13	Reserved	
	2102H	Frequency	command (XXX.XX Hz)	
	2103H	Output fre	quency (XXX.XX Hz)	
			e drive's output current (XX.XX A). When the current	
	2104H		han 655.35, it automatically shifts one decimal place	
			(A). Refer to the high byte of 211F for information on	
	240511	the decima		
	2105H 2106H		oltage (XXX.X V)	
	210011 2107H		Output voltage (XXX.X V) Current step for the multi-step speed operation	
	210711 2108H		Reserved	
	2109H	Counter value		
	210AH	Output power factor angle (XXX.X)		
	210BH		que (XXX.X %)	
	210CH		tor speed (XXXXX rpm)	
	210DH	Reserved	• •	
	210EH	Reserved		
	210FH	Power out	put (X.XXX kW)	
	2116H		tion display (Pr.00-04)	
			Operation Frequency (Pr.01-00) or Maximum	
			ned Value (Pr.00-26)	
	0445		00-26 is 0, this value is equal to Pr.01-00 setting	
	211BH		00-26 is not 0, and the command source is keypad,	
			= Pr.00-24 * Pr.00-26 / Pr.01-00.	
		When Pr.00-26 is not 0, and the command source is 485, this value = Pr.09-10 * Pr.00-26 / Pr.01-00.		
	211FH	High byte: the decimal place of current value (display)		
		Display the drive's output current (XX.XX A). When the current		
	2200H		han 655.35, it automatically shifts one decimal place	
		as (XXX.X A). Refer to the high byte of 211F for information or		
	2201H	the decimal places. Counter value		
	2201H	Actual output frequency (XXXXX Hz)		
	220211	ractual out	put inequently (AAAAA HZ)	

Content	Address	Function
	2203H	DC bus voltage (XXX.X V)
	2204H	Output voltage (XXX.X V)
	2205H	Power factor angle (XXX.X)
	2206H	Display the output power of U, V, W (XXXX.X kW)
		Display the motor speed estimated by the drive or encoder
	2207H	feedback (XXXXX rpm)
	2208H	Display the positive / negative output torque estimated by the
		drive (+0.0: positive torque; -0.0: negative torque) (XXX.X%)
	2209H	Reserved
	220AH	Display the PID feedback value after enabling PID function (XXX.XX%)
	220BH	Display the AVI analog input terminal signal, 0–10 V corresponds to 0.00–100.00% (see Explanation 1 in Pr.00-04)
	220CH	Display the ACI analog input terminal signal, 4–20 mA / 0–10 V corresponds to 0.00–100.00% (2.) (see Explanation 2 in Pr.00-04)
	220DH	Reserved
	220EH	IGBT temperature of the power module (XXX.X °C)
	220FH	Reserved
	2210H	The digital input status (ON / OFF), refer to Pr.02-12 (see Explanation 2 in Pr.00-04)
	224411	The digital output status (ON / OFF), refer to Pr.02-18
	2211H	(see Explanation 3 in Pr.00-04)
	2212H	Current step for the multi-step speed operation
	2213H	The corresponding CPU digital input pin status (d.) (see Explanation 3 in Pr.00-04)
	004411	The corresponding CPU digital output pin status (O.)
	2214H	(see Explanation 4 in Pr.00-04)
	2215H	Reserved
	2216H	Pulse input frequency (XXX.XX Hz)
	2217H	Reserved
	2218H	Reserved
	2219H	Counter value of overload (XXX.XX %)
	221AH	GFF (XXX.XX %)
	221BH	DC bus voltage ripples (XXX.X V)
	221CH	PLC register D1043 data
	221DH	Magnetic field area of the synchronous motor
	221EH	User page displays the value in physical measure
	221FH	Output value of Pr.00-05 (XXX.XX Hz)
		Reserved
	2220H	
	2221H	Reserved
	2222H	Reserved
	2223H	Control mode of the drive 0: speed mode 1: torque mode
	2224H	Carrier frequency of the drive (XX kHZ)
	2225H	Reserved
		Drive status bit 1–0 00b: No direction
	2226H	01b: Forward 10b: Reverse bit 3–2 01b: Drive ready 10b: Error bit 4 0b: Motor drive does not output
		1b: Motor drive outputs bit 5
	2227H	Drive's estimated output torque (positive or negative direction) (XXXX Nt-m)

Chapter 12 Descriptions of Parameter Settings | MS300

Content	Address	Function
	2228H	Reserved
	2229H	KWH display (XXXX.X)
	222AH	Reserved
	222BH	Reserved
	222CH	Reserved
	222DH	Reserved
	222EH	PID target value (XXX.XX %)
	222FH	PID offset (XXX.XX %)
	2230H	PID output frequency (XXX.XX Hz)
	2231H	Reserved
	2232H	Display the auxiliary frequency
	2233H	Display the master frequency
	2234H	Display the frequency after adding and subtracting of the
	223411	master and auxiliary frequencies.

5. Exception response:

Example:

When the drive is using the communication connection, if an error occurs, the drive responds to the error code and sets the highest bit (bit 7) of the command code to 1 (function code AND 80H) then responds to the control system to signal that an error occurred.

If the keypad displays "CE-XX" as a warning message, "XX" is the error code at that time. Refer to the table of error codes for communication error for reference.

ASCII mode:

RTU mode:

STX	· · ·	Address	01H
Address	'0'	Function	86H
Address	'1'	Exception code	02H
Function	'8'	CRC Check Low	C3H
FullClion	'6'	CRC Check High	A1H
Exception code	'0'		
Exception code	'2'		
LRC Check	'7'		
LRC Check	'7'		
END	CR		
END	LF		

The following table describes the exception code.


Exception Code	Description	
1	Function code is not supported or unrecognized.	
2	Address is not supported or unrecognized.	
3	Data is not correct or unrecognized.	
4	Failure to execute this function code	



Default: 2.0

Settings 0.0-200.0 ms

If the host controller does not finish the transmitting/receiving process, you can use this parameter to set the response delay time after the AC motor drive receives communication command as shown in the following picture.



39-18 Communication Main Frequency

Default: 60.00

Default: 0

Settings 0.00-599.00 Hz

When you set Pr.00-20 to 1 (RS-485 communication input), the AC motor drive saves the last Frequency command into Pr.09-10 when there is abnormal power off or momentary power loss. When power is restored, the AC motor drive operates with the frequency in Pr.09-10 if there is no new Frequency command input. When a Frequency command of 485 changes (the Frequency command source must be set as Modbus), this parameter also changes.

×	89-11	Block Transfer 1
×	09-12	Block Transfer 2
×	09-13	Block Transfer 3
×	89-14	Block Transfer 4
×	09-15	Block Transfer 5
×	89-18	Block Transfer 6
×	89-17	Block Transfer 7
×	81 - 80	Block Transfer 8
×	89-19	Block Transfer 9
×	89-28	Block Transfer 10
×	09-21	Block Transfer 11
×	88-88	Block Transfer 12
×	09-23	Block Transfer 13
×	89-24	Block Transfer 14
×	09-25	Block Transfer 15
×	85-88	Block Transfer 16

Settings 0–65535

There is a group of block transfer parameters available in the AC motor drive (Pr.09-11–Pr.09-26). Using communication code 03H, you can store the parameters (Pr.09-11–Pr.09-26) that you want to read.

Default: 1

Settings 0: Decoding method 1

1: Decoding method 2

EtherCAT card only supports decoding method 2 (60xx).

		Decoding Method 1	Decoding Method 2
	Digital Keypad	Digital keypad controls the drive action	regardless of decoding method 1 or 2.
	External Terminal	External terminal controls the drive action	on regardless of decoding method 1 or 2.
Source of	RS-485	Refer to address: 2000h–20FFh	Refer to address: 6000h–60FFh
Operation	CANo	Refer to index: 2020-01h-2020-FFh	Refer to index:2060-01h-2060-FFh
Control	pen	Refer to index. 2020-0 III—2020-FFII	
Control	Communication	Refer to address: 2000h–20FFh	Refer to address: 6000h–60FFh
	Card	Relei to address. 200011–20FF11	
	PLC	PLC command controls the drive action	regardless of decoding method 1 or 2.

★ 33 PLC Command Force to 0

Default: 0

Setting 0-65535

Defines whether the Frequency command or the Speed command must be cleared to zero or not before the PLC starts the next scan.

bit	Description
bit 0	Before PLC scan, set the PLC target frequency = 0
bit 1	Before PLC scan, set the PLC target torque = 0
bit 2	Before PLC scan, set the speed limit of torque mode = 0

PLC Address

Default: 2

Settings 1–254

CANopen Slave Address

Default: 0

Settings 0: Disable

1-127

GG-37 CANopen Speed

Default: 0

Settings 0: 1 Mbps

1: 500 Kbps

2: 250 Kbps

3: 125 Kbps

4: 100 Kbps (Delta only)

5: 50 Kbps

GG-39 CANopen Warning Record

Default: 0

Settings bit 0: CANopen software disconnection 1 (CANopen Guarding Time-out)

bit 1: CANopen software disconnection 2 (CANopen Heartbeat Time-out)

bit 3: CANopen SDO time-out

bit 4: CANopen SDO buffer overflow

bit 5: CANopen hardware disconnection warning (CANopen Bus OFF)

bit 6: CANopen format error warning (Error protocol for CANopen)

CANopen Decoding Method

Default: 1

Settings 0: Use Delta-defined decoding method

1: Use CANopen Standard DS402 protocol

Default: Read only

Settings 0: Node Reset State

1: Com Reset State

2: Boot up State

3: Pre-operation State

4: Operation State

5: Stop State

CANopen Control Status

Default: Read only

Settings 0: Not ready for use state

1: Inhibit start state

2: Ready to switch on state

3: Switched on state

4: Enable operation state

7: Quick stop active state

13: Error reaction activation state

14: Error state

GANopen Reset Index

Default: 65535

Settings bit 0: CANopen reset, the internal address 20XX is 0

bit 1: CANopen reset, the internal address 264X is 0

bit 2: CANopen reset, the internal address 26AX is 0

bit 3: CANopen reset, the internal address 60XX is 0

G9-58 Communication Card Identification

Default: Read only

Settings 0: No communication card

1: DeviceNet Slave

2: PROFIBUS-DP Slave

3: CANopen Slave

4: Modbus-TCP Slave

5: EtherNet/IP Slave

6: EtherCAT

10: Backup Power Supply

## Firmware Version of Communication Card	
89-82 Product Code	
89-83 Error code	

Settings Read only

✓ ☐ Grand Address (for DeviceNet or PROFIBUS)

Default: 1

Default: Read only

Settings DeviceNet: 0-63

PROFIBUS-DP: 1-125

Communication Card Speed Setting (for DeviceNet)

Default: 2

Settings Standard DeviceNet:

0: 125 Kbps

1: 250 Kbps

2: 500 Kbps

3: 1 Mbps (Delta Only)

Non-standard DeviceNet: (Delta only):

0: 10 Kbps

1: 20 Kbps

2: 50 Kbps

3: 100 Kbps

4: 125 Kbps

5: 250 Kbps

6: 500 Kbps

7: 800 Kbps

8: 1 Mbps

v 00 22		
<u> </u>	Additional Settings for Communication Card Speed (for DeviceNet)	
		Default: 0
	Settings 0: Disable	
	In this mode, the baud rate can only be 125 Kbps, 250 Kbp	s, 500 Kbps, or
	1 Mbps in standard DeviceNet speed.	
	1: Enable	
	In this mode, the DeviceNet baud rate can be same as th	at for CANopen
	(0–8).	
Use this	s parameter with Pr.09-71.	
0: The	baud rate can only be set to 0, 1, 2 or 3 as a standard DeviceNet speed.	
1: The	DeviceNet communication rate can be the same as that for CANopen (sett	ing 0–8).
w <u>00-36</u>	Communication Card IP Configuration (for Modbus TCP)	
00 .0	e communication of the configuration (configuration)	Default: 0
	Settings 0: Static IP	
	1: Dynamic IP (DHCP)	
🕮 0: Set t	he IP address manually.	
	ddress is dynamically set by the host controller.	
<u>~ 89- 16</u>	Communication Card IP Address 1 (for Modbus TCP)	
× 88-18	Communication Card IP Address 2 (for Modbus TCP)	
~ 89 - 78	Communication Card IP Address 3 (for Modbus TCP)	
<u> </u>	Communication Card IP Address 4 (for Modbus TCP)	
		Default: 0
	Settings 0–255	
Use Pr.	.09-76–Pr.09-79 with a communication card.	
× 88-88	Communication Card Address Mask 1 (for Modbus TCP)	
~ 03 00 ~ 03 - 8 :		
× <u>88-83</u>	Communication Card Address Mask 4 (for Modbus TCP)	
	0.41	Default: 0
	Settings 0–255	
× 89-84	Communication Card Gateway Address 1 (for Modbus TCP)	
√ 88-85		
√ 09-88		
× 89-83		
<u> </u>	, ,	Default: 0

Settings 0-255

Communication Card Password (Low Word) (for Modbus TCP)

Default: 0

Settings 0–99

Reset Communication Card (for Modbus TCP)

Default: 0

Settings 0: Disable

1: Reset to defaults

Additional Settings for the Communication Card (for Modbus TCP)

Default: 0

Settings bit 0: Enable IP filter

bit 1: Enable Internet parameters (1 bit)

When the IP address is set, this bit is enabled. After updating the parameters for the communication card, this bit changes to disabled.

bit 2: Enable login password (1 bit)

When you enter the login password, this bit is enabled. After updating the communication card parameters, this bit changes to disabled.

Communication Card Status (for Modbus TCP)

Default: 0

Settings bit 0: Enable password

When the communication card is set with a password, this bit is enabled. When the password is cleared, this bit is disabled.


Chapter 12 Descriptions of Parameter Settings | MS300

[This page intentionally left blank]

10 Speed Feedback Control Parameters

✓ You can set this parameter during operation.

In this parameter group, ASR is the abbreviation for Adjust Speed Regulator and PG is the abbreviation for Pulse Generator.



Default: 0

Settings 0: Disabled

5: Pulse input (MI7)

- When you use MI7 single-phase pulse input, you must use it with Pr.00-20=4, Pr.10-00=0 and Pr.10-16=5.
- When you use MI7 single-phase puluse input as speed feedback, you must use it with Pr.10-00=5 and Pr.10-02=5. The drive calculates the MI7 single-phase pulse input speed when the control modes are VF, VFPG, SVC IM/PM FOC sensorless, and IM/PM TQC
- The MS300 does not support the full position control pulse command input function.

- ## Encoder Pulses per Revolution

Default: 600

Settings 1-20000

- This parameter sets the encoder pulses per revolution (PPR). It is a feedback control signal source when using PG. The encoder sets the number of pulses for the motor rotating through one rotation. The A/B phase cycle generates the pulse number.
- This setting is also the encoder resolution. The speed control is more accurate with higher resolution.
- If you set this parameter incorrectly, it may cause motor stall, drive over-current, or a permanent magnetic pole origin detection error for the PM motor in closed-loop control. When using the PM motor, you must perform the magnetic pole origin detection (Pr.05-00 = 13) again if you modify the content of this parameter.

- ## Encoder Input Type Setting

Default: 0

Settings 0: Disable

5: Single-phase input (MI7)



×	10-04	Mechanical	Gear	at Load	Side A1
---	-------	------------	------	---------	---------

Mechanical Gear at Motor Side B1


Mechanical Gear at Load Side A2

Mechanical Gear at Motor Side B2

Default: 100

Settings 1-65535

Use Pr.10-04—Pr.10-07 with the multi-function input terminal setting 48 to switch to Pr.10-04—Pr.10-05 or Pr.10-06—Pr.10-07, as shown in the diagram below.



Default: 115

Settings 0–120% (0: Disable)

Determines the maximum encoder feedback signal allowed before a fault occurs; the maximum operation frequency Pr.01-00 = 100%.

Default: 0.1

Settings 0.0-2.0 sec.

★ ## Encoder Stall Action

Default: 2

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop

When the drive output frequency exceeds the encoder stall level (Pr.10-10), the drive starts to count the time. When the error time exceeds the encoder stall detection time (Pr.10-11), the drive implements the encoder stall action.

Default: 50

Settings 0–50% (0: Disable)

✓ III - III Detection Time of Encoder Slip

Default: 0.5

Settings 0.0-10.0 sec.

★ III - 15 Encoder Stall and Slip Error Action

Default: 2

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop

This parameter acts on the settings for Pr.10-13–Pr.10-15:

When the value of (rotation speed – motor frequency) exceeds the Pr.10-13 setting, and the detection time exceeds Pr.10-14; the drive starts to count the time. If the detection time exceeds Pr.10-14, the encoder feedback signal error occurs.

★ ## Pulse Input Type Setting

Default: 0

Settings 0: Disabled

5: Single-phase input (MI7)

- When Pr.10-16=5, you cannot set Pr.10-02 to 5: Single-phase input (MI7) for closed-loop control.
- The setting steps when using the MI7 single-phase pulse input as the frequency command:
 - 1. Set Pr.00-20=4: Pulse input without direction command
 - 2. Set Pr.10-00=5: Pulse input (MI7)
 - 3. Set Pr.10-01 to motor pulses per revolution (PPR)
 - 4. Set Pr.10-16=5: Single-phase input (MI7)
 - 5. Set Pr.00-04=22 (Pulse input frequency) to verify if the pulse input frequency is correct.

★ III - II Electrical Gear A

🖁 - 👯 Electrical Gear B

Default: 100

Settings 1-65535

Rotation speed = pulse frequency / encoder pulses (Pr.10-01) * electrical gear A / electrical gear B.

PG2 Pulse Input Speed Command Low Pass Filter Time

Default: 0.100

Settings 0.000-65.535 sec.

When you set Pr.00-20 to 4, the system treats the pulse command as a Frequency command. Use this parameter to suppress the speed command jump.

₩ 18 - 24 FOC & TQC Function Control

Default: 0

Settings 0–65535

bit	Description
	ASR controller under torque control.
0	0: use PI as ASR; 1: use P as ASR
1–10	N/A
11	Activates the DC brake when executing the zero torque command.
11	0:ON; 1:OFF
	FOC sensorless mode with crossing zero means the speed goes from negative to positive
12	or positive to negative (forward to reverse direction or reverse to forward direction).
	0: determined by the stator frequency; 1: determined by the speed command
13	N/A
14	N/A
15	Direction control in open-loop torque
15	0: Switch ON direction control; 1: Switch OFF direction control

Only bit = 0 is used for closed-loop; other bits are used for open-loop.

₩-25	FOC Bandwidth for Speed Observer	
		Default: 40.0
	Settings 20.0–100.0 Hz	
Setting	the speed observer to a higher bandwidth could shorten the speed r	esponse time but
creates	greater noise interference during the speed observation.	
85-01	FOC Minimum Stator Frequency	
		Default: 2.0
	Settings 0.0–10.0% fN	
Sets the	e stator frequency lower limit in operation status. This setting ensure	s the stability and
accurac	cy of observer and avoids interferences from voltage, current and motor	parameters. fN is
the moto	or rated frequency.	
10-27	FOC Low Pass Filter Time Constant	
		Default: 50
	Settings 1–1000 ms	
Sets the	e low pass filter time constant of a flux observer at start-up. If you ca	annot activate the
motor d	luring high speed operation, lower the setting for this parameter.	
10-28	FOC Gain for Excitation Current Rise Time	
	С	Default: 100
	Settings 33–100% Tr	
Sets the	e drive's excitation current rise time when it activates in open-loop torque	e mode. When the
drive's a	activation time is too long in torque mode, adjust this parameter to a sho	orter time value. Tr
is the ro	otor time constant.	
10-29	Upper Limit of Frequency Deviation	
	С	efault: 20.00
	Settings 0.00–200.00 Hz	
Limits th	he maximum frequency deviation.	
🚇 If you se	et this parameter too high, an abnormal feedback malfunction occurs.	
If the ap	pplication needs a higher setting for Pr.10-29, note that a higher settin	g results in large
motor s	slip, which causes a PG Error (PGF3, PGF4). In this case, you can	set Pr.10-10 and
Pr.10-13	3 to 0 to disable PGF3 and PGF4 detection, but you must make sure t	he MI7 wiring and
applicat	tion are correct; otherwise, it may lose the instant PG protection. Setting	Pr.10-29 too high
	ommonly done.	_
10-31	I/F Mode, Current Command	
		efault: 40
	Settings 0–150% rated current of the motor	
M C-4- 4-		

Sets the current command for the drive in the low speed area (low speed area: Frequency

command < Pr.10-39). When the motor stalls on heavy duty start-up or forward/reverse with load, increase the parameter value. If the inrush current is too high and causes oc stall, then decrease

N	-	0 - 3 <i>2</i>	PM FOC	Sensorless	Speed Estima	ator Bandw	idth		
								Defa	ault: 5.00
			Settings	0.00-600.00	Hz				
		Sets the	e speed e	estimator band	dwidth. Adjust	the parame	eter to influ	ence the s	tability and the
		accurac	y of the m	otor speed.					
		If there	is low free	quency vibration	on (the wavefo	orm is simila	ar to a sine	wave) durir	ng the process,
		then inc	crease the	bandwidth. If	there is high f	requency vi	bration (the	waveform	shows extreme
		vibratio	n and is lik	e a spur), ther	n decrease the	bandwidth.			
×	1	0-34	PM Sens	sorless Speed	d Estimator Lo	ow-pass Fi	lter Gain		
								Defa	ault: 1.00
			Settings	0.00–655.35					
		Influenc	ces the res	ponse speed o	of the speed es	stimator.			
		If there	is low free	quency vibration	on (the wavefo	orm is simila	ar to a sine	wave) durir	ng the process,
		then in	crease the	e gain. If the	re is high fred	quency vibr	ation (the	waveform s	shows extreme
		vibratio	n and is lik	e a spur), ther	n decrease the	gain.			
×	- ; ;	0-35	AMR (Kp) Gain					
								Def	ault: 1.00
			Settings	0.00-3.00					
×	-	0-36	AMR (Ki)) Gain					
								Def	ault: 0.20
			Settings	0.00-3.00					
×	1	0-39	Frequen	cy Point to S	witch from I/F	Mode to P	M Sensorl	ess Mode	
								Defa	ault: 20.00
			Settings	0.00–599.00	Hz				
		Sets the	e frequency	y for the switcl	h point from lov	w frequency	to high freq	luency.	
					•	•			not estimate the
		accurat	e speed a	nd position of	the rotor. Thu	s, using I/F	mode conti	rol is more	suitable. In the
		medium	า-to-high f	requency are	ea, PM senso	orless can	accurately	estimate 1	the back-EMF,
		stabilize	es and con	trols the moto	r with lower cu	rrent.			
			•			•		•	ency, the motor
			•	•		•		·	ht position and
		•			stall and oc whe	•			•
			•	•	•				mode for a long
			•	•			• •		Pr.10-31 is too
		high, the	e high swit	ch point make	es the drive con	itinue to out	put with the	setting valu	e for Pr.10-31.)

×	1	Frequency Point to Switch from PM Sensorless Mode to I/F Mode
		Default: 20.00
		Settings 0.00-599.00 Hz
		Sets the switch point from high frequency to low frequency.
		Due to the weak back-EMF in the low frequency area, PM sensorless mode cannot estimate the
		accurate speed and position of the rotor. Thus, using I/F mode control is more suitable. In the
		$medium-to-high\ frequency\ area,\ PM\ sensorless\ can\ accurately\ estimate\ the\ back-EMF,\ stabilizes$
		and controls the motor with lower current.
		If the switch point is too low and PM sensorless mode operates at a too low frequency, the motor
		does not generate enough back-EMF to let the speed estimator measure the right position and
		speed of the rotor, and causes stall and oc when running at the switch point frequency.
		If the switch point is too high, the drive easily runs in the frequency area of the $\mbox{\em I/F}$ mode for a long
		time, which generates more current and cannot save energy. (If the current for $Pr.10-31$ is too
		high, the high switch point makes the drive continue to output with the setting value for Pr.10-31.)
×	-	☐ - Ч ☐ Initial Angle Detection Pulse Value
		Default: 1.0
		Settings 0.0–3.0
		The angle detection is fixed to 3: Use the pulse injection method to start. The parameter
		influences the value of the pulse during the angle detection. The larger the pulse, the higher the
		accuracy of rotor's position. A larger pulse might cause oc.
		Increase the parameter when the running direction and the command are opposite during
		start-up. If oc occurs at start-up, then decrease the parameter.
		Refer to Section 12-2 Adjustment & Application for detailed motor adjustment procedure.
×	;	্র - ৭৪ Zero Voltage Time during Start-up
		Default: 0.000
		Settings 0.000–60.000 sec.
		This parameter is valid only when the setting of Pr.07-12 (Speed Tracking during Start-up) = 0.
		When the motor is in static state at start-up, this increases the accuracy when estimating angles.
		In order to put the motor in static state, set the three-phase of the drive output to the motor to 0 $\rm V.$
		The Pr.10-49 setting time is the length of time for three-phase output at 0 V.
		It is possible that even when you apply this parameter, the motor cannot go in to the static state
		because of inertia or some external force. If the motor does not go into a complete static state in
		0.2 seconds, increase this setting value appropriately.
		If $Pr.10-49$ is set too high, the start-up time is longer. If it is too low, then the braking performance
		is weak.

N	-	<pre>[] - 5 Injection F</pre>	requency
			Default: 500
		Settings	0–1200 Hz
		This parameter is a	high frequency injection command in PM SVC control mode, and usually you
		do not need to adjus	st it. But if a motor's rated frequency (for example, 400 Hz) is too close to the
		frequency setting fo	r this parameter (that is, the default of 500 Hz), it affects the accuracy of the
		angle detection. Ref	er to the setting for Pr.01-01 before you adjust this parameter.
		If the setting value	for Pr.00-17 is lower than Pr.10-51*10, then increase the frequency of the
		carrier frequency.	
		Pr.10-51 is valid only	y when Pr.10-53 = 2.
N	H	Injection N	<i>l</i> agnitude
			Default: 15.0 / 30.0 / 37.5
		Settings	115V / 230V series: 100.0 V
		4	460V series: 200.0 V
			575V series: 200.0 V
			Note: The setting range varies depending on the voltage.
		The parameter is the	e magnitude command for the high frequency injection signal in PM SVC
		control mode.	
		Increasing the par	ameter can increase the accuracy of the angle estimation, but the
		electromagnetic nois	se might be louder if the setting value is too high.
		The system uses	this parameter when the motor's parameter is "Auto". This parameter
		influences the angle	estimation accuracy.
		When the ratio of	the salient pole (Lq / Ld) is lower, increase Pr.10-52 to make the angle
		detection accurate.	
		Pr.10-52 is valid only	y when Pr.10-53 = 2.
/	-	O - C 3 Angle Det	action Mathed
~	- 1	<mark>╏-5 ∄</mark> Angle Det	ection Method
		Cattinana	Default: 0
		Settings	0: Disabled
			1: Force attracting the rotor to zero degrees
			2: High frequency injection
			3: Pulse injection
		Set to 2 for IPM; set	to 3 for SPM. If these settings cause problems, then set the parameter to 1.

Chapter 12 Descriptions of Parameter Settings | MS300

[This page intentionally left blank]

11 Advanced Parameters

✓ You can set this parameter during operation.

In this parameter group, ASR stands for Adjust Speed Regulator.

; ; - 🔐 System Control					
		Default: 0			
Settings	bit 0: Auto-tuning for ASR and APR				
	bit 3: Dead time compensation closed				
	bit 7: Save or do not save the frequency				

- ☐ bit 0 = 0: Pr.11-06—Pr.11-11 are valid and Pr.11-03—Pr.11-05 are invalid.
 - bit 7 = 0: Save the frequency before power is OFF. When power is ON again, the saved frequency is displayed.
 - bit 7 = 1: Do not save the frequency before power is OFF. When power is ON again, 0.00 Hz is the displayed frequency.

Per-Unit of System Inertia

Default: 256

Settings 1–65535 (256 = 1 PU)

- To get the system inertia per unit from Pr.11-01, you need to set Pr.11-00 to bit1 = 1 and execute continuous forward / reverse running.
- When Pr.11-01 = 256, it is 1PU. So if you use a 2HP motor, the 2HP motor inertia is 0.00043 kg-cm² according to the table below. If Pr.11-01 = 10000 after tuning, the system inertia is (10000 / 256) x 0.00043 kg-cm².
- Perform the operation test with load based on the inertia after tuning. Run the motor in acceleration, deceleration, and steady speed and observe the values. If values between speed feedback and speed command are close, steady-state error is small and overshoot is less, then this inertia is a better one.
- If the Iq current command from ASR has high-frequency glitch, then decrease the setting. If the response time of sudden loading is too slow, then increase the setting.
- When using torque mode as the control mode, perform the tuning with speed mode first to see if the tuned inertia can work normally. After verifying with speed mode, change the control mode to torque mode.

The following table shows the base value for the induction motor system inertia (Unit: kg-m^2)

Power	Setting	
1 HP	0.00023	
2 HP	0.00043	
3 HP	0.00083	
5 HP	0.00148	
7.5 HP	0.0026	

Power	Setting
10 HP	0.00358
15 HP	0.00743
20 HP	0.00953
25 HP	0.01428
30 HP	0.01765

✓ ::- @ ASR1 / ASR2 Switch Frequency	
	Default: 7.00
Settings 5.00-599.00 Hz	
Sets the low-speed and high-speed ASR switching point in the FOC	area. Provides flexibility to
meet two needs: in the high-speed region of the estimator switch po	oint it has a high response,
and in the low-speed region of the estimator switch point it ha	s a lower response. The
recommended switching point is higher than Pr.10-39.	
A low setting does not cover Pr.10-39. If the setting is too high, high-s	peed range is too narrow.
ASR1 Low-speed Bandwidth	
	Default: Read only
Settings 1–40 Hz	
ASKZ High-speed Balldwidth	Default: Read only
Settings 1–40 Hz	Delault. Nead Offiy
	Default: Read only
Settings 1–40 Hz	
\square After estimating the inertia and setting Pr.11-00 bit 0 = 1 (auto-tuning), you can adjust Pr.11-03,
11-04 and 11-05 separately by speed response. The larger the se	etting value, the faster the
response. Pr.11-02 is the switch frequency between the low-speed/hig	gh-speed bandwidth.
ASR 1 Gain	
7. 00 Mort Foam	Default: 10
Settings 0–40 Hz	Boldan. 10
★ ! ! - ! ? ASR 1 Integral Time	
	Default: 0.100
Settings 0.000–10.000 sec.	
ASR2 Gain	
,	Default: 10
Settings 0–40 Hz	2 0.0.0
★	
	Default: 0.100
Settings 0.000–10.000 sec.	
ASR Gain of Zero Speed	
	Default: 10
Settings 0–40 Hz	· · -
5	




Default: 0.100

Settings 0.000-10.000 sec.

Default: 0

Settings 0–200%


- \square This function enables when Pr.11-00 bit 0 = 1.
- Increase the setting for Pr.11-12 to reduce the command tracking difference and improve the speed response. Use this function for speed tracking applications.
- Set Pr.11-01 correctly to get excellent improvement of the speed response.



Default: 30

Settings 0-200%

- \square This parameter is invalid when Pr.05-24 = 1.
- \square This parameter is valid only when Pr.11-00 bit0 = 1.
- After you estimate and set Pr.11-00 bit0=1 (auto-tuning), use Pr.11-13 to reduce overshoot. However, a shift of the curve may occur earlier. In this case, you can set Pr.11-13=0 first, and then increase the setting value to "a condition with best acceleration and without overshoot" when the acceleration time meets your application but overshoot occurs.
- Increasing Pr.11-13 improves the overshoot of speed tracking, but an excessive value may reduce the transient response.
- Increasing Pr.11-13 enhances the system stiffness in high-speed steady state and reduces the speed transient fluctuation at a sudden loading.
- Ensure that you set the Pr.11-01 system inertia correctly to get excellent improvement of the speed response.




ASR Output Low P	ass Filter Time		
	Default: 0.008		
Settings 0.000-0.3	50 sec.		
Sets the ASR command filter	time.		
Notch Filter Depth			
	Default: 0		
Settings 0–20 db			
Notch Filter Freque	ency		
	Default: 0.00		
Settings 0.00-200.	00 Hz		
Sets the resonance frequency	y of the mechanical system. Adjust it to a smaller value to suppress		
the mechanical system reson	ance.		
A larger value improves resor	nance suppression function.		
The notch filter frequency is the second of the control of the	he mechanical frequency resonance.		
Forward Motor Toro	que Limit		
Forward Regeneral	tive Torque Limit		
Reverse Motor Torque Limit			
Reverse Regenerative Torque Limit			
	Default: 500		
Settings 0-500%			
☐ FOCPG and FOC Sensorless	s mode:		
The motor rated current =	100%. The settings for Pr.11-17–Pr.11-20 compare with the		
Pr.03-00=7, 8, 9, 10. The n	Pr.03-00=7, 8, 9, 10. The minimum value of the comparison result is the torque limit. The		
diagram below illustrates the	torque limit.		
TQCPG and TQC sensorless	TQCPG and TQC sensorless mode:		
The function of Pr.11-17-11-2	The function of Pr.11-17–11-20 is the same as FOC; however, in this case, the torque limit and		

The function of Pr.11-17–11-20 is the same as FOC; however, in this case, the torque limit and the torque command executes the output torque limit at the same time. Therefore, the minimum value between Pr.11-17–11-20 and Pr.06-12 becomes the current output torque limit.

Calculation equation for the motor rated torque:

Motor rated torque: $T(N.M) = \frac{P(W)}{\omega(rad/s)}$;

P (W) value = Pr.05-02;
$$\omega$$
 (rad / s) value = Pr.05-03; $\frac{RPM \times 2\pi}{60}$ = rad / s



All control modes are based on 100% of the motor rated current except:

IM: VF, VFPG, SVC

PM: PMSVC

Default: 90


Settings 0–200%

★ 1 - 2 2 Flux Weakening Curve for Motor 2 Gain Value

Default: 90

Settings 0-200%

- Adjusts the output voltage for the flux weakening curve.
- For the spindle application, use this adjustment method:
 - 1. Run the motor to the highest frequency.
 - Observe the output voltage.
 - 3. Adjust the Pr.11-21 (motor 1) or Pr.11-22 (motor 2) setting to make the output voltage reach the motor rated voltage.
 - 4. The larger the setting value, the greater the output voltage.



★ ! - 2 3 Flux Weakening Area Speed Response

Default: 65

Settings 0–150%

Controls the speed in the flux weakening area. The larger the value, the faster the acceleration/deceleration. In normal condition, you do not need to adjust this parameter.

★ ! ! - 2 ? Maximum Torque Command

Default: 100

Settings 0-500%

- Determines the upper limit of the torque command (motor rated torque is 100%).
- Calculation equation for the motor rated torque:

Motor rated torque: $T(N.M) = \frac{P(W)}{\omega(rad/s)}$;

P (W) value = Pr.05-02; ω (rad / s) value = Pr.05-03; $\frac{RPM \times 2\pi}{60} = rad / s$

Default: 0

Settings 0: Disable

1: Analog signal input

2: RS-485 communication (Pr.11-29)

3: Controlled through external terminals (by Pr.11-30-Pr.11-32)

- Specifies the torque offset source.
- When set to 3, the torque offset sources are Pr.11-30, Pr.11-31 or Pr.11-32 according to the multi-function input terminal settings 31, 32 or 33.

Normally open (N.O.) contact: ON = contact closed, OFF = contact open

Pr.11-32	Pr.11-31	Pr.11-30	Torque Offset
MI = 33 (Low)	MI = 32 (Mid)	MI = 31 (High)	
OFF	OFF	OFF	None
OFF	OFF	ON	Pr.11-30
OFF	ON	OFF	Pr.11-31
OFF	ON	ON	Pr.11-30 + Pr.11-31
ON	OFF	OFF	Pr.11-32

Chapter 12 Descriptions of Parameter Settings | MS300

Pr.11-32	Pr.11-31	Pr.11-30	Torque Offset
MI = 33 (Low)	MI = 32 (Mid)	MI = 31 (High)	
ON	OFF	ON	Pr.11-30 + Pr.11-32
ON	ON	OFF	Pr.11-31 + Pr.11-32
ON	ON	ON	Pr.11-30 + Pr.11-31 + Pr.11-32

★ 11-23 Torque Offset Setting

Default: 0.0

Settings -100.0–100.0 %

- Determines the torque offset command. The motor rated torque is 100%.
- The calculation equation for the motor rated torque:

Motor rated torque: $T(N.M) = \frac{P(W)}{\omega(rad/s)}$;

P (W) value = Pr.05-02; ω (rad / s) value = Pr.05-03; $\frac{RPM \times 2\pi}{60} = rad / s$

✓ II-38 High Torque Offset

Default: 30.0

Settings -100.0-100.0 %

Default: 20.0

Settings -100.0-100.0 %

Default: 10.0

Settings -100.0-100.0 %

- When Pr.11-28 is set to 3, the torque offset sources are Pr.11-30, Pr.11-31 or Pr.11-32 according to the multi-function input terminals settings 31, 32 or 33. The motor rated torque is 100%.
- The calculation equation for the motor rated torque:

Motor rated torque: $T(N.M) = \frac{P(W)}{\omega(rad/s)}$;

P (W) value = Pr.05-02; ω (rad / s) value = Pr.05-03; $\frac{RPM \times 2\pi}{60} = rad / s$

★ ! ! - 3 3 Torque Command Source

Default: 0

Settings 0: Digital keypad

1: RS-485 communication (Pr.11-34)

2: Analog signal input (Pr.03-00)

3: CANopen

5: Communication Card

- When Pr.11-33 is set to 0 or 1, you can set the torque command in Pr.11-34.
- When Pr.11-33 is set to 2, 3 or 5, Pr.11-34 only displays the torque command.

•	
M	- ℥Ҷ Torque Command
	Default: 0.0
	Settings -100.0-100.0%
II II	his parameter sets the torque command. When Pr.11-27 is 250% and Pr.11-34 is 100%, the
ad	ctual torque command = 250 × 100% = 250% of the motor rated torque.
□ TI	he drive saves the settings before power is OFF.
/	- 35 Torque Command Filter Time
	Default: 0.000
	Settings 0.000-1.000 sec.
₩ W	When the setting is too long, the control is stable but the control response is delayed. When the
se	etting is too short, the response is quick but the control may be unstable. Adjust the setting
ad	ccording to your control and response situation.
-	- 36 Speed Limit Selection

Default: 0

Settings 0: Set by Pr.11-37 (Forward Speed Limit) and Pr.11-38 (Reverse Speed Limit)


1: Set by Pr.00-20 (Master Frequency Command (AUTO, REMOTE) Source) and Pr.11-37, Pr.11-38

2: Set by Pr.00-20 (Master Frequency Command (AUTO, REMOTE) Source)

- Speed limit function: when you use the torque control mode, if the torque command is greater than the load, the motor accelerates until the motor speed equals the speed limit. At this time, it switches to speed control mode to stop acceleration.
- Pr.11-36 = 1:
 - When the torque command is positive, the forward speed limit is Pr.00-20 and the reverse speed limit is Pr.11-38. When the torque command is negative, the forward speed limit is Pr.11-37 and the reverse speed limit is Pr.00-20.
 - Example:
 - In an unwinding application, if the torque command direction is different from the motor operating direction, the load drives the motor. In this case, the speed limit must be Pr.11-37 or Pr.11-38. Only in normal applications, that is when the motor drives the load and the torque command is in the same direction as the speed limit, you can set the speed limit according to Pr.00-20.
- In torque control mode, the F page of keypad displays the present speed limit value. For details on the keypad display, refer to the LED Function Description in Section 7-14 Digital Keypad (optional).




Forward/reverse running speed are limited by Pr.11-37 and Pr.11-38




Pr.11-36=2

Forward/reverse running speed are limited by Pr.00-20




Pr.11-36=1

When torque is positive, forward running speed is limited by Pr.00-20; reverse running speed is limited by Pr.11-38



Pr.11-36=1

When torque is negative, forward running speed is limited by Pr.11-37; reverse running speed is limited by Pr.00-20



Forward Speed Limit (Torque Mode)

Default: 10

Settings 0–120%

★ 1 - 38 Reverse Speed Limit (Torque Mode)

Default: 10

Settings 0–120%

Limits the speed for forward and reverse running in torque mode (Pr.01-00 Maximum Operation Frequency = 100%).


PWM Mode Selection

Default: 2

Settings 0: Two-phase modulation mode

2: Space vector modulation mode

- Two-phase modulation mode: effectively reduces the drive power component losses and provides better performance in long wiring applications.
- Space vector modulation mode: effectively reduces the power loss and electromagnetic noise of the motor.



Default: 0000

Settings 0000-FFFFh

bit No.	Function	Description
0	Reserved	
1	4 FMD / DEM estion control	0: FWD / REV cannot be controlled by Pr.02-12 bit 0 & 1.
l	FWD / REV action control	1: FWD / REV can be controlled by Pr.02-12 bit 0 & 1.

13 Industry Application Parameters

✓ You can set this parameter during operation.

🔢 - 🔐 Industry-specific Parameter Application

Default: 00

Settings 00: Disabled

01: User-defined parameter

02: Compressor

03: Fan

04: Pump

05: Conveyor

06: Machine tool

07: Packing

08: Textiles

10: Logistics

11: Tension PID

12: Tension PID + master / auxiliary frequency

Note: after you select the macro, some of the default values adjust automatically according to the application selection.

Setting 02: Compressor

The following table lists the relevant compressor setting application parameters.

Pr.	Parameter Name	Settings
00-11	Speed control mode	0 (IMVF control mode)
00-16	Load selection	0 (Normal load)
00-17	Carrier frequency	Default setting
00-20	Master frequency command source	0 (5-4
00-20	(AUTO, REMOTE)	2 (External analog input)
00-21	Operation command source	1 (External terminals)
00-21	(AUTO, REMOTE)	i (External terminals)
00-22	Stop method	0 (Ramp to stop)
00-23	Motor direction control	1 (Disable reverse)
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1	Default actions
01-01	(Base frequency / Motor's rated frequency)	Default setting
01-02	Output voltage of motor 1	Default setting
01-02	(Base voltage / Motor's rated voltage)	Default Setting
01-03	Mid-point frequency 1 of motor 1	Default setting
01-04	Mid-point voltage 1 of motor 1	Default setting
01-05	Mid-point frequency 2 of motor 1	Default setting
01-06	Mid-point voltage 2 of motor 1	Default setting
01-07	Minimum output frequency of motor 1	Default setting
01-08	Minimum output voltage of motor 1	Default setting

Pr.	Parameter Name	Settings
01-11	Output frequency lower limit	20 (Hz)
01-12	Acceleration time 1	20 (sec.)
01-13	Deceleration time 1	20 (sec.)
03-00	Analog input selection (AVI)	0 (No function)
03-01	Analog input selection (ACI)	1 (Frequency command)
05-01	Full-load current for induction motor 1 (A)	Default setting
05-03	Rated speed for induction motor 1 (rpm)	Default setting
05-04	Number of poles for induction motor 1	Default setting

Setting 03: Fan

The following table lists the relevant fan setting application parameters.

Pr.	Parameter Name	Settings
00-11	Speed control mode	0 (IMVF)
00-16	Load selection	0 (Normal load)
00-17	Carrier frequency	Default setting
00-20	Master frequency command source (AUTO, REMOTE)	2 (External analog input)
00-21	Operation command source (AUTO, REMOTE)	1 (External terminals)
00-22	Stop method	1 (Coast to stop)
00-23	Motor direction control	1 (Disable reverse)
00-30	Master frequency command source (HAND, LOCAL)	0 (Digital keypad)
00-31	Operation command source (HAND, LOCAL)	0 (Digital keypad)
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1 (Base frequency / Motor's rated frequency)	Default setting
01-02	Output voltage of motor 1 (Base voltage / Motor's rated voltage)	Default setting
01-03	Mid-point frequency 1 of motor 1	Default setting
01-04	Mid-point voltage 1 of motor 1	Default setting
01-05	Mid-point frequency 2 of motor 1	Default setting
01-06	Mid-point voltage 2 of motor 1	Default setting
01-07	Minimum output frequency of motor 1	Default setting
01-08	Minimum output voltage of motor 1	Default setting
01-10	Output frequency upper limit	50 (Hz)
01-11	Output frequency lower limit	35 (Hz)
01-12	Acceleration time 1	15 (sec.)
01-13	Deceleration time 1	15 (sec.)

Pr.	Parameter Name	Settings
01-43	V/F curve selection	2 (V/F curve to the power of 2)
02-05	Multi-function input command 5 (MI5)	16 (Rotating speed command from ACI)
02-16	Multi-function output 2 (MO1)	11 (Malfunction indication)
02-17	Multi-function output 3 (MO2)	1 (Indication during RUN)
03-00	Analog input selection (AVI)	1 (Frequency command)
03-01	Analog input selection (ACI)	1 (Frequency command)
03-28	AVI terminal input selection	0 (0–10 V)
03-29	ACI terminal input selection	1 (0–10 V)
03-31	AFM output selection	0 (0–10 V)
03-50	Analog input curve selection	1 (three-point curve of AVI)
07-06	Postart after memortary newer less	2 (Speed tracking by the minimum output
07-00	Restart after momentary power loss	freqeuncy)
07-11	Number of times of restart after fault	5 (times)
07-33	Auto-restart interval of fault	60 (sec.)

Setting 04: Pump

The following table lists the relevant pump setting application parameters.

Pr.	Parameter Name	Settings
00-11	Speed control mode	0 (IMVF)
00-16	Load selection	0 (Normal load)
00-20	Master frequency command source	2 (External analog input)
	(AUTO, REMOTE)	, ,
00-21	Operation command source	1 (External terminals)
	(AUTO, REMOTE)	. (
00-23	Motor direction control	1 (Disable reverse)
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1	Default catting
01-01	(Base frequency / Motor's rated frequency)	Default setting
01-02	Output voltage of motor 1	Default catting
01-02	(Base voltage / Motor's rated voltage)	Default setting
01-03	Mid-point frequency 1 of motor 1	Default setting
01-04	Mid-point voltage 1 of motor 1	Default setting
01-05	Mid-point frequency 2 of motor 1	Default setting
01-06	Mid-point voltage 2 of motor 1	Default setting
01-07	Minimum output frequency of motor 1	Default setting
01-08	Minimum output voltage of motor 1	Default setting
01-10	Output frequency upper limit	50 (Hz)
01-11	Output frequency lower limit	35 (Hz)
01-12	Acceleration time 1	15 (sec.)
01-13	Deceleration time 1	15 (sec.)

Pr.	Parameter Name	Settings
01-43	V/F curve selection	2 (V/F curve to the power of 2)
07-06	Restart after momentary power loss	2 (Speed tracking by the minimum output
		frequency)
07-11	Number of times of restart after fault	5 (times)
07-33	Auto-restart interval of fault	60 (sec.)

Setting 05: Conveyor

The following table lists the relevant conveyor setting application parameters.

Pr.	Parameter Name	Settings
00-11	Speed control mode	0 (IMVF)
00-16	Load selection	0 (Normal load)
00-20	Master frequency command source	0 (5-4
00-20	(AUTO, REMOTE)	2 (External analog input)
00-21	Operation command source	1 (External terminals)
00-21	(AUTO, REMOTE)	1 (External terminals)
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1	Default actting
01-01	(Base frequency / Motor's rated frequency)	Default setting
01-02	Output voltage of motor 1	Default actting
01-02	(Base voltage / Motor's rated voltage)	Default setting
01-03	Mid-point frequency 1 of motor 1	Default setting
01-04	Mid-point voltage 1 of motor 1	Default setting
01-05	Mid-point frequency 2 of motor 1	Default setting
01-06	Mid-point voltage 2 of motor 1	Default setting
01-07	Minimum output frequency of motor 1	Default setting
01-08	Minimum output voltage of motor 1	Default setting
01-12	Acceleration time 1	10 (sec.)
01-13	Deceleration time 1	10 (sec.)

☐ Setting 06: Machine tool

The following table lists the relevant machine tool setting application parameters.

Pr.	Parameter Name	Settings
00-11	Speed control mode	0 (IMVF)
00-17	Carrier frequency	Default setting
00-20	Master frequency command source (AUTO, REMOTE)	2 (External analog input)
00-21	Operation command source (AUTO, REMOTE)	1 (External terminals)
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1 (Base frequency / Motor's rated frequency)	Default setting

Pr.	Parameter Name	Settings
04.00	Output voltage of motor 1	Default catting
01-02	(Base voltage / Motor's rated voltage)	Default setting
01-03	Mid-point frequency 1 of motor 1	0
01-04	Mid-point voltage 1 of motor 1	0
01-05	Mid-point frequency 2 of motor 1	0
01-06	Mid-point voltage 2 of motor 1	0
01-07	Minimum output frequency of motor 1	Default setting
01-08	Minimum output voltage of motor 1	Default setting
01-12	Acceleration time 1	5 (sec.)
01-13	Deceleration time 1	5 (sec.)
01-24	S-curve for acceleration begin time 1	0
01-25	S-curve for acceleration arrival time 2	0
01-26	S-curve for deceleration begin time 1	0
01-27	S-curve for deceleration arrival time 2	0
02-03	Multi-function input command 3 (MI3)	1 (Multi-step speed command 1)
02-04	Multi-function input command 4 (MI4)	2 (Multi-step speed command 2)
02-13	Multi-function output 1 (RY1)	11 (Malfunction indication)
02-16	Multi-function output 2 (MO1)	1 (Indication during RUN)
02-17	Multi-function output 3 (MO2)	2 (Operation speed reached)
03-00	Analog input selection (AVI)	1 (Frequency command)
06-01	Over-voltage stall prevention	0 (Disabled)
06-03	Over-current stall prevention during	0 (Disabled)
00-03	acceleration	0 (Disabled)
06-04	Over-current stall prevention during	0 (Disabled)
00-04	operation	o (Disabled)
06-05	Acceleration / deceleration time selection	0 (By current acceleration / deceleration
00-03	for stall prevention at constant speed	time)
07-01	DC brake current level	20 (%)
07-03	DC brake time at STOP	0.3 (sec.)
07-04	DC brake frequency at STOP	0 (Hz)
07-23	Automatic voltage regulation (AVR) function	1 (Disable AVR)

Setting 07: Packing

The following table lists the relevant packing setting application parameters.

Pr.	Parameter Name	Settings
00-11	Speed control mode	0 (IMVF)
00-20	Master frequency command source (AUTO, REMOTE)	0 (Digital keypad)
00-21	Operation command source (AUTO, REMOTE)	2 (RS-485 communication input)

Pr.	Parameter Name	Settings
02-00	Two-wire / three-wire operation control	1 (two-wire mode 1, power on for operation control (M1: FWD / STOP, M2: REV / STOP))
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1 (Base frequency / Motor's rated frequency)	Default setting
01-02	Output voltage of motor 1 (Base voltage / Motor's rated voltage)	Default setting
01-03	Mid-point frequency 1 of motor 1	Default setting
01-04	Mid-point voltage 1 of motor 1	Default setting
01-05	Mid-point frequency 2 of motor 1	Default setting
01-06	Mid-point voltage 2 of motor 1	Default setting
01-07	Minimum output frequency of motor 1	Default setting
01-08	Minimum output voltage of motor 1	Default setting
01-12	Acceleration time 1	10 (sec.)
01-13	Deceleration time 1	10 (sec.)
01-24	S-curve for acceleration begin time 1	Default setting
01-25	S-curve for acceleration arrival time 2	Default setting
01-26	S-curve for deceleration begin time 1	Default setting
01-27	S-curve for deceleration arrival time 2	Default setting
03-00	Analog input selection (AVI)	1 (Frequency command)
03-28	AVI terminal input selection	Default setting

Setting 08: Textiles

The following table lists the relevant textile setting application parameters.

Pr.	Parameter Name	Settings
00-11	Speed control mode	0 (IMVF)
00-20	Master frequency command source	1 (RS-485 communication input)
00-20	(AUTO, REMOTE)	1 (KS-483 communication input)
00-21	Operation command source	1 (External terminals)
00-21	(AUTO, REMOTE)	1 (External terminals)
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1	Default authoris
01-01	(Base frequency / Motor's rated frequency)	Default setting
01-02	Output voltage of motor 1	Default setting
01-02	(Base voltage / Motor's rated voltage)	
01-03	Mid-point frequency 1 of motor 1	Default setting
01-04	Mid-point voltage 1 of motor 1	Default setting
01-05	Mid-point frequency 2 of motor 1	Default setting
01-06	Mid-point voltage 2 of motor 1	Default setting

Pr.	Parameter Name	Settings
01-07	Minimum output frequency of motor 1	Default setting
01-08	Minimum output voltage of motor 1	Default setting
01-12	Acceleration time 1	10 (sec.)
01-13	Deceleration time 1	10 (sec.)
01-24	S-curve for acceleration begin time 1	0.2 (sec.)
01-25	S-curve for acceleration arrival time 2	0.2 (sec.)
01-26	S-curve for deceleration begin time 1	0.2 (sec.)
01-27	S-curve for deceleration arrival time 2	0.2 (sec.)
06-03	Over-current stall prevention during	180 (%)
00-00	acceleration	100 (70)
06-04	Over-current stall prevention during	180 (%)
00-04	operation	100 (70)
06-07	Over-torque detection level (motor 1)	200 (%)
07-19	Fan cooling control	2 (Fan is ON when the AC motor drive runs;
07-19	Fair cooling control	fan is OFF when the AC motor drive stops)

Setting 10: Logistics

The following table lists the relevant logistics setting application parameters.

Pr.	Parameter Name	Settings
00-20	Master frequency command source (AUTO, REMOTE)	7 (Digital keypad potentiometer knob)
00-21	Operation command source (AUTO, REMOTE)	1 (External terminals)
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1	Default setting
01-01	(Base frequency / Motor's rated frequency)	
01-02	Output voltage of motor 1	400.0
01-02	(Base voltage / Motor's rated voltage)	400.0
01-04	Mid-point voltage 1 of motor 1	20.0
01-06	Mid-point voltage 2 of motor 1	20.0
01-08	Minimum output voltage of motor 1	20.0
01-03	Mid-point frequency 1 of motor 1	1.50
01-07	Minimum output frequency of motor 1	1.50
01-12	Acceleration time 1	3 (sec.)
01-13	Deceleration time 1	3 (sec.)
01-24	S-curve for acceleration begin time 1	0.00
01-25	S-curve for acceleration arrival time 2	0.00
01-26	S-curve for deceleration begin time 1	0.00
01-27	S-curve for deceleration arrival time 2	0.00

Pr.	Parameter Name	Settings
06-03	Over-current stall prevention during acceleration	200
06-04	Over-current stall prevention during	200
06-05	Acceleration / deceleration time selection	2: By the second acceleration / deceleration
00-03	for stall prevention at constant speed	time
07-23	Automatic voltage regulation (AVR) function	1: Disable AVR
07-26	Torque compensation gain	0

☐ Setting 11: Tension PID

The following table lists the relevant tension PID setting application parameters.

Pr.	Parameter Name	Settings
00-20	Master frequency command source (AUTO, REMOTE)	9 (PID controller)
00-21	Operation command source (AUTO, REMOTE)	1 (External terminals)
01-00	Maximum operation frequency	Default setting
01-12	Acceleration time 1	3 (sec.)
01-13	Deceleration time 1	3 (sec.)
03-00	Analog input selection (AVI)	5 (PID feedback signal)
03-50	Analog input curve selection	1: Three-point curve of AVI
03-63	AVI voltage lowest point	0.00
03-65	AVI voltage mid-point	9.99
03-66	AVI proportional mid-point	100%
08-00	Terminal selection of PID feedback	1: Negative PID feedback: by analog input (Pr.03-00, Pr.03-01)
08-01	Proportional gain (P)	10
08-02	Integral time (I)	1
08-20	PID mode selection	1: Parallel connection
08-21	Enable PID to change the operation direction	0: Operation direction cannot be changed
08-65	PID target value source	1: Pr.08-66 setting
08-66	PID target value setting	50%

☐ Setting 12: Tension PID + master / auxiliary frequency

The following table lists the relevant tension PID + master / auxiliary frequency setting application parameters.

Pr.	Parameter Name	Settings	
00-20	Master frequency command source	9 (PID controller)	
	(AUTO, REMOTE)	o (* 12 com ener)	
00-21	Operation command source	1 (External terminals)	
0021	(AUTO, REMOTE)	1 (External terminals)	
01-00	Maximum operation frequency	Default setting	
01-12	Acceleration time 1	3 (sec.)	
01-13	Deceleration time 1	3 (sec.)	
00-35	Auxiliary frequency source	3: Analog input	
03-00	Analog input selection (AVI)	5 (PID feedback signal)	
03-01	Analog input selection (ACI)	12: Auxiliary frequency input	
		0: Negative frequency input is not allowed.	
03-10	Reverse setting when analog signal input is	The digital keypad or external terminal	
03-10	negative frequency	controls the forward and reverse	
		direction.	
03-12	Analog input gain (ACI)	100.0%	
03-29	ACI terminal input selection	1: 0–10 V	
03-50	Analog input curve selection	1: Three-point curve of AVI	
03-63	AVI voltage lowest point	0.00	
03-65	AVI voltage mid-point	9.99	
03-66	AVI proportional mid-point	100%	
08-00	Terminal selection of PID feedback	1: Negative PID feedback: by analog input (Pr.03-00, Pr.03-01)	
08-01	Proportional gain (P)	10	
08-02	Integral time (I)	1	
08-20	PID mode selection	1: Parallel connection	
00.04	Enable PID to change the operation	Or Or another discretion accords to a bound	
08-21	direction	0: Operation direction cannot be changed	
08-65	PID target value source	1: Pr.08-66 setting	
08-66	PID target value setting	50%	
08-67	Master and auxiliary reverse running cutoff	10%	
		1.400/.	

13-01

Application Parameters (User-Defined)

[This page intentionally left blank]

14 Protection Parameters (2)

✓ You can set this parameter during operation.

#4 - 5 ₽ Output Frequency at Malfunction 2	_
14-54 Output Frequency at Malfunction 3	
₹4 - 58 Output Frequency at Malfunction 4	
#4 - 8 ₽ Output Frequency at Malfunction 5	
14 - 55 Output Frequency at Malfunction 6	
	Default: Read only

Default: Read only

Settings 0.00-599.00 Hz

When an error occurs, you can check the output frequency for the malfunction. If the error happens again, this parameter overwrites the previous record.

₹Ч - 5 ↑ DC bus Voltage at Malfunction 2
14 - 55 DC bus Voltage at Malfunction 3
₹Ч - 5 3 DC bus Voltage at Malfunction 4
14 - 5 3 DC bus Voltage at Malfunction 5
14 - 5 7 DC bus Voltage at Malfunction 6

Default: Read only

Settings 0.0–6553.5 V

When an error occurs, you can check the DC bus voltage for the malfunction. If the error happens again, this parameter overwrites the previous record.

∤Ч - 5 ? Output Current at Malfunction 2
↓Ч - 5 5 Output Current at Malfunction 3
↓ ♀
↓ ५ - 万 ⋅ ♥ Output Current at Malfunction 5
14 - 58 Output Current at Malfunction 6

Default: Read only

Settings 0.00–655.35 Amps

When an error occurs, you can check the output current for the malfunction. If the error happens again, this parameter overwrites the previous record.

14-53 IGBT Temperature at Malfunction 2
14-57 IGBT Temperature at Malfunction 3
14 - 5 ↑ IGBT Temperature at Malfunction 4
14 - 55 IGBT Temperature at Malfunction 5
14 - 5 € IGBT Temperature at Malfunction 6

Default: Read only

Settings -3276.7-3276.7 °C

When an error occurs, you can check the IGBT temperature for the malfunction. If the error happens again, this parameter overwrites the previous record.


#4 - ₹₽ Fault Record 7
14 - 7 ↑ Fault Record 8
- 7₽ Fault Record 9
14 - 73 Fault Record 10


Default: 0

Settings


- 0: No fault record
- 1: Over-current during acceleration (ocA)
- 2: Over-current during deceleration (ocd)
- 3: Over-current during steady operation (ocn)
- 4: Ground fault (GFF)
- 6: Over-current at STOP (ocS)
- 7: Over-voltage during acceleration (ovA)
- 8: Over-voltage during deceleration (ovd)
- 9: Over-voltage during constant speed (ovn)
- 10: Over-voltage at stop (ovS)
- 11: Low-voltage during acceleration (LvA)
- 12: Low-voltage during deceleration (Lvd)
- 13: Low-voltage during constant speed (Lvn)
- 14: Low-voltage at stop (LvS)
- 15: Phase loss protection (orP)
- 16: IGBT overheating (oH1)
- 18: IGBT temperature detection failure (tH1o)
- 21: Over load (oL)
- 22: Electronics thermal relay 1 protection (EoL1)
- 23: Electronics thermal relay 2 protection (EoL2)
- 24: Motor PTC overheating (oH3)
- 26: Over-torque 1 (ot1)
- 27: Over-torque 2 (ot2)
- 28: Under current (uC)
- 31: EEPROM read error (cF2)
- 33: U-phase error (cd1)
- 34: V-phase error (cd2)
- 35: W-phase error (cd3)
- 36: cc (current clamp) hardware error (Hd0)
- 37: oc (over-current) hardware error (Hd1)
- 40: Auto-tuning error (AUE)
- 41: PID loss ACI (AFE)
- 43: PG feedback loss (PGF2)
- 44: PG feedback stall (PGF3)
- 45: PG slip error (PGF4)

- 48: ACI loss (ACE)
- 49: External fault (EF)
- 50: Emergency stop (EF1)
- 51: External Base Block (bb)
- 52: Password is locked (Pcod)
- 54: Illegal command (CE1)
- 55: Illegal data address (CE2)
- 56: Illegal data value (CE3)
- 57: Data is written to read-only address (CE4)
- 58: Modbus transmission time-out (CE10)
- 61: Y-connection / Δ-connection switch error (ydc)
- 62: Deceleration energy backup error (dEb)
- 63: Over slip error (oSL)
- 72: STO Loss (STL1)
- 76: STO (STo)
- 77: STO Loss 2 (STL2)
- 78: STO Loss 3 (STL3)
- 79: U-phase over-current before run (Aoc)
- 80: V-phase over-current before run (boc)
- 81: W-phase over-current before run (coc)
- 82: Output phase loss U phase (oPL1)
- 83: Output phase loss V phase (oPL2)
- 84: Output phase loss W phase (oPL3)
- 87: Low frequency overload protection (oL3)
- 89: Rotor position detection error (roPd)
- 101: CANopen guarding error (CGdE)
- 102: CANopen heartbeat error (CHbE)
- 104: CANopen bus off error (CbFE)
- 105: CANopen index error (CidE)
- 106: CANopen station address error (CAdE)
- 107: CANopen memory error (CFrE)
- 111: InrCOM time-out error (ictE)
- 121: Internal communication error (CP20)
- 123: Internal communication error (CP22)
- 124: Internal communication error (CP30)
- 126: Internal communication error (CP32)
- 127: Internal communication error (CP33)
- 128: Over-torque 3 (ot3)
- 129: Over-torque 4 (ot4)
- 134: Internal communication error (EoL3)
- 135: Internal communication error (EoL4)
- 140: Oc hardware error (Hd6)





When you set Pr.14-74 or Pr.14-77 to 2 or 4, an ot3/ot4 warning displays and the drive stops running after over-torque detection. The drive does not run until you manually reset it.



Electronic Thermal Relay Selection 3 (Motor 3)

Electronic Thermal Relay Selection 4 (Motor 4)


Default: 2

Settings 0: Inverter motor (with external forced cooling)

1: Standard motor (motor with the fan on the shaft)


2: Disable


- Prevents self-cooled motor from overheating under low speed. Use an electronic thermal relay to limit the drive's output power.
- Setting the parameter to 0 is suitable for an inverter motor (motor fan using an independent power supply). For this kind of motor, there is no significant correlation between cooling capacity and motor speed. Therefore, the action of electronic thermal relays remains stable in low speed to ensure the load capability of the motor in low speed.
- Setting the parameter to 1 is suitable for standard motor (motor fan is fixed on the rotor shaft). For this kind of motor, the cooling capacity is lower in low speed; therefore, the action of an electronic thermal relay reduces the action time to ensure the life of motor.
- When the power is cycled frequently, if the power is switched OFF, the electronic thermal relay protection is reset; therefore, even setting the parameter to 0 or 1 may not protect the motor well. If there are several motors connected to one drive, install an electronic thermal relay in each motor.



Settings 30.0-600.0 sec.

- Set the parameter to 150% of motor rated current and use with the setting of Pr.14-81 and Pr.14-83 to prevent motor damage due to overheating. When it reaches the setting, the drive displays "EoL3 / EoL4", and the motor coasts to stop.
- Use this parameter to set the action time of the electronic thermal relay. It works based on the I2t characteristic curve of electronic thermal relay, the output frequency and current of the drive, and the operation time to prevent the motor from overheating.





Motor cooling curve with shaft-fixed fan

Motor cooling curve with independent fan


- The action of the electronic thermal relay depends on the settings for Pr.14-80 and Pr.14-82
 - 1. Pr.14-80 or Pr.14-82 is set to 0 (using inverter motor):

When the output current of the drive is higher than 150% of the motor rated current (refer to the motor rated current % corresponded to the motor rated frequency in the motor cooling curve with independent fan), the drive starts to count the time. The electronic thermal relay acts when the accumulated time exceeds Pr.14-81 or Pr.14-83.

2. Pr.14-80 or Pr.14-82 is set to 1 (using standard motor):

When the output current of the drive is higher than 150% of the motor rated current (refer to the motor rated current % corresponded to the motor rated frequency in the motor cooling curve with shaft-fixed fan), the drive starts to count the time. The electronic thermal relay acts when the accumulated time exceeds Pr.14-81 or Pr.14-83.


The actual electronic thermal relay action time adjusts according to the drive output current (shown as the motor loading rate %). The action time is short when the current is high, and the action time is long when the current is low. Refer to the following diagram.



12-2 Adjustment & Application

Standard PM Synchronous AC Motor Adjustment Procedure

Pr.00-11 Speed Control Mode = 2 SVC (Pr.05-33 = 1 or 2)
 PMSVC control diagram



Note: In the diagram, "PM motor" means "permanent magnet synchronous AC motor".

Adjustment procedure

1. Select PM synchronous AC motor control

Pr.05-33 Induction Motor (IM) or Permanent Magnet (PM) Synchronous AC Motor Selection =1 (SPM) or 2 (IPM)

2. Set up motor parameters according to the motor's nameplate

Pr.01-01: Rated frequency Pr.01-02: Rated voltage

Pr.05-34: Rated current

Pr.05-35: Rated Power

Pr.05-36: Rated speed

Pr.05-37: Number of poles for the motor

3. Execute PM synchronous AC motor auto-tuning (static)

Default: 0

Settings 0: No function

1: Dynamic test for induction motor (IM)

2: Static test for induction motor (IM)

5: Rolling auto-tuning for PM synchronous AC motor (IPM / SPM)

12: FOC sensorless inertia estimation

13: High frequency stall test for PM synchronous AC motor

Set Pr.05-00 Motor Parameter Auto-tuning =13 (High frequency stall test for PM synchronous AC motor) and press RUN.

When you finish tuning, the following parameters are available:

Pr.05-39: Stator resistance


Pr.05-40: Permanent magnet synchronous AC motor Ld

Pr.05-41: Permanent magnet synchronous AC motor Iq


Pr.05-43: (V / 1000 rpm), the Ke parameter of PM synchronous AC motor (you can calculate this automatically according to power, current, and speed of the motor).

- 4. Set the speed control mode: Pr.00-10 Control Mode = 0, Pr.00-11 Speed Control Mode = 2 SVC.
- 5. Cycle the power after you finish tuning.
- 6. The ratio of the PMSVC control mode is 1:20.
- 7. When the PMSVC control mode is under 1/20th of the rated speed, the load bearing capacity is 100% of the motor rated torque.
- 8. PMSVC control mode is not applicable to zero speed control.
- 9. The start-up load and the load bearing capacity of the forward/reverse running in PMSVC control mode equal to 100% of the motor rated torque.

10. Adjustment flow chart when starting WITHOUT load:



11. Adjustment flow chart when starting WITH load:



12. Set up the related parameters for speed estimators

I/F Mode, Current Command Default: 40 Settings 0–150% rated current of the motor Sets the current command for the drive in the low speed area (low speed area: Frequency command < Pr.10-39). When the motor stalls on heavy duty start-up or forward/reverse with load, increase the parameter value. If the inrush current is too high and causes oc stall, then decrease the parameter value. PM FOC Sensorless Speed Estimator Bandwidth Default: 5.00 Settings 0.00-600.00 Hz sets the speed estimator bandwidth. Adjust the parameter to influence the stability and the accuracy of the motor speed. If there is low frequency vibration (the waveform is similar to a sine wave) during the process, then increase the bandwidth. If there is high frequency vibration (the waveform shows extreme vibration and is like a spur), then decrease the bandwidth. PM Sensorless Speed Estimator Low-pass Filter Gain Default: 1.00 Settings 0.00-655.35 Influences the response speed of the speed estimator. If there is low frequency vibration (the waveform is similar to a sine wave) during the process, then increase the gain. If there is high frequency vibration (the waveform shows extreme vibration and is like a spur), then decrease the gain. Frequency Point to Switch from I/F Mode to PM Sensorless Mode Default: 20.00 Settings 0.00-599.00 Hz Sets the frequency for the switch point from low frequency to high frequency. Due to the weak back-EMF in the low frequency area, PM sensorless mode cannot estimate the accurate speed and position of the rotor. Thus, using I/F mode control is more suitable. In the medium-to-high frequency area, PM sensorless can accurately estimate the back-EMF, stabilizes and controls the motor with lower current. If the switch point is too low and PM sensorless mode operates at a too low frequency, the motor does not generate enough back-EMF to let the speed estimator measure the right position and speed of the rotor, and causes stall and oc when running at the switch point frequency. If the switch point is too high, the drive easily runs in the frequency area of the I/F mode for a long

time, which generates a larger current and cannot save energy. (If the current for Pr.10-31 is too high, the high switch point makes the drive continue to output with the setting value for Pr.10-31.)

N	11	☐ - Ч Initial Angle Detection Pulse Value
		Default: 1.0
		Settings 0.0–3.0
		The angle detection is fixed to 3: Use the pulse injection method to start. The parameter
		influences the value of the pulse during the angle detection. The larger the pulse, the higher the
		accuracy of rotor's position. A larger pulse might cause oc.
		Increase the parameter when the running direction and the command are opposite during
		start-up. If oc occurs at start-up, then decrease the parameter.
		Refer to Section 12-2 Adjustment & Application for detailed motor adjustment procedure.
×	1	♂ - Ч 分 Zero Voltage Time during Start-up
		Default: 0.000
		Settings 0.000–60.000 sec.
		This parameter is valid only when the setting of Pr.07-12 (Speed Tracking during Start-up) = 0.
		When the motor is in static state at start-up, this increases the accuracy when estimating angles.
		In order to put the motor in static state, set the three-phase of the drive output to the motor to 0 V.
		The Pr.10-49 setting time is the length of time for three-phase output at 0 V.
		It is possible that even when you apply this parameter, the motor cannot go in to the static state
		because of inertia or some external force. If the motor does not go into a complete static state in
		0.2 seconds, increase this setting value appropriately.
		If Pr.10-49 is set too high, the start-up time is longer. If it is too low, then the braking performance
		is weak.
×	1	☐ - 5 / Injection Frequency
		Default: 500
		Settings 0–1200 Hz
		This parameter is a high frequency injection command in PM SVC control mode, and usually you
		do not need to adjust it. But if a motor's rated frequency (for example, 400 Hz) is too close to the
		frequency setting for this parameter (that is, the default of 500 Hz), it affects the accuracy of the
		angle detection. Refer to the setting for Pr.01-01 before you adjust this parameter.
		If the setting value for $Pr.00-17$ is lower than $Pr.10-51*10$, then increase the frequency of the
		carrier frequency.
		Pr.10-51 is valid only when Pr.10-53 = 2.

✓ \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	
	Default: 15.0 / 30.0 / 37.5
Settings 115V / 230V series: 100.0 V	
460V series: 200.0 V	
575V series: 200.0 V	
Note: The setting range varies depending or	า the voltage.
The parameter is the magnitude command for the high frequency control mode.	ency injection signal in PM SVC
Increasing the parameter can increase the accuracy of electromagnetic noise might be louder if the setting value is too	
☐ The system uses this parameter when the motor's param	eter is "Auto". This parameter
influences the angle estimation accuracy.	·
When the ratio of the salient pole (Lq / Ld) is lower, incread detection accurate.	se Pr.10-52 to make the angle
☐ Pr.10-52 is valid only when Pr.10-53 = 2.	
4 10 C3 A 1 D 6 M 11 1	
✓ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	
Cattings O. Disabled	Default: 0
Settings 0: Disabled	
1: Force attracting the rotor to zero degree	es e e e e e e e e e e e e e e e e e e
2: High frequency injection	
3: Pulse injection	
Set to 2 for IPM; set to 3 for SPM. If these settings cause proble	ms, then set the parameter to 1.
13. Speed adjustment parameter	
	Default: 1
Settings IM: 0–10 (when Pr.05-33=0)	
PM Synchronous AC Motor: 0-5000 (when F	Pr.05-33=1 or 2)
With a large motor load, a part of the drive output voltage is	absorbed by the stator winding
resistor; therefore, the air gap magnetic field is insufficient. The	nis causes insufficient voltage at
motor induction and results in excessive output current but insuf	ficient output torque. Auto-torque
compensation can automatically adjust the output voltage accor	ding to the load and keep the air
gap magnetic fields stable to get the optimal operation.	
☐ In the V/F control, the voltage decreases in direct proportion	with decreasing frequency. The
torque decreases at low speed because of a decreasing AC	resistor and an unchanged DC

output current of the drive, motor overheating or trigger the drive's protection function.

get a higher starting torque.

resistor. The auto-torque compensation function increases the output voltage at low frequency to

When the compensation gain is set too high, it may cause motor over-flux and result in a too large

[This page intentionally left blank]

Digital Keypad KPMS-LE01



ID No.	Display on LCD Keypad	Warning Name	Description	
1	68 1	Communication error 1 (CE1)	RS-485 Modbus illegal function code	
		Action and	d Reset	
	Action level	When the function code is not 03, 06, 10 and 63		
	Action time	Immediately act		
War	ning setting parameter	N/A		
	Reset method	-	Pr.09-02=0 and the motor drive keeps running. The drive en receiving the correct function code.	
	Reset condition	Immediately reset		
	Record	N/A		
Cause		Corrective Actions		
	t communication nd from upper unit	Check if the communication	ation command is correct.	
Malfunct	tion caused by interference		ounding of the communication circuit. It is recommended nication circuit from the main circuit, or wire in 90 degree ence performance.	
	Different communication setting from the upper unit Check if the setting for Pr.09-02 is the same as the setting for the upper unit			
Disconnection or bad connection of the cable Check the cable and replace it if necessary.			place it if necessary.	

ID No.	Display on LCD Keypad	Warning Name	Description	
2	583	Communication error 2 (CE2)	RS-485 Modbus illegal data address	
		Action and	l Reset	
	Action level	When the input data address is incorrect		
	Action time	Immediately act		
War	ning setting parameter	N/A		
	Reset method	"Warning" occurs when Pr.09-02=0 and the motor drive keeps running. The drive resets automatically when receiving the correct data address.		
	Reset condition	Immediately reset		
	Record	N/A		
Cause			Corrective Actions	
Incorrect communication command from upper unit		Check if the communication	ation command is correct.	
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
	t communication setting upper unit	Check if the setting for I	Pr.09-02 is the same as the setting for the upper unit.	
Disconnection or bad connection of the cable		Check the cable and re	place it if necessary.	

ID No.	Display on LCD Keypad	Warning Name	Description		
3	683	Communication error 3 (CE3)	RS-485 Modbus illegal data value		
		Action and	l Reset		
	Action level	When the length of com	When the length of communication data is too long		
	Action time	Immediately act			
War	ning setting parameter	N/A			
	Reset method	"Warning" occurs when Pr.09-02=0 and the motor drive keeps running. The drive resets automatically when receiving the correct communication data value.			
	Reset condition	Immediately reset			
	Record	N/A			
Cause		Corrective Actions			
	t communication nd from upper unit	Check if the communication	ation command is correct.		
		Verify the wiring and gro	ounding of the communication circuit. It is recommended		
Malfunct	tion caused by interference	to separate the communication circuit from the main circuit, or wire in 90 degree			
		for effective anti-interference performance.			
	t communication setting upper unit	Check if the setting for I	Pr.09-02 is the same as the setting for the upper unit.		
	Disconnection or bad connection of the cable Check the cable and replace it if necessary.				

ID No.	Display on LCD Keypad	Warning Name	Description	
4	684	Communication error 4 (CE4)	RS-485 Modbus data is written to read-only address	
		Action and	l Reset	
	Action level	When the data is writter	to read-only address	
	Action time	Immediately act		
War	ning setting parameter	N/A		
		· ·	Pr.09-02=0 and the motor drive keeps running. The drive when receiving the correct written address of	
	Reset condition	Immediately reset		
Record		N/A		
Cause			Corrective Actions	
Incorrect communication command from upper unit		Check if the communication	ation command is correct.	
Malfunct	· ·		ounding of the communication circuit. It is recommended nication circuit from the main circuit, or wire in 90 degree ence performance.	
Different communication setting from the upper unit Check if the setting for Pr.09-0			Pr.09-02 is the same as the setting for the upper unit.	
Disconnection or bad connection of the cable Check the cable and replace it if is necessary.			place it if is necessary.	

ID No.	Display on LCD Keypad	Warning Name	Description	
5	0:33	Communication error 10 (CE10)	RS-485 Modbus transmission time-out	
		Action and	Reset	
	Action level	When the communicati communicati	on time exceeds the detection time of Pr.09-03	
	Action time	Pr.09-03		
War	ning setting parameter	N/A		
	Reset method	"Warning" occurs when Pr.09-02=0 and the motor drive keeps running. The drive resets automatically when receiving the next communication packet.		
	Reset condition	Immediately reset		
	Record	N/A		
Cause		Corrective Actions		
The upper unit does not transmit the communication command within Pr.09-03 setting time		Check if the upper unit tra time for Pr.09-03.	ansmits the communication command within the setting	
Malfunct			Inding of the communication circuit. It is recommended cation circuit from the main circuit, or wire in 90 degree nce performance.	
	t communication setting upper unit	Check if the setting for Pr	.09-02 is the same as the setting for the upper unit.	
Disconnof the ca	ection or bad connection able	Check the cable and repl	ace it if necessary.	

ID No.	Display on LCD Keypad	Warning Name	Description	
7	58 /	Save error 1 (SE1)	Keypad COPY error 1: Keypad copy time-out	
		Action and	d Reset	
		"SE1" warning occurs v	when the keypad does not transmit the COPY command	
	Action level	to the drive, and does	not transmit any data to the drive again in 10 ms at the	
		time you copy the parar	meters to the drive.	
	Action time	10 ms		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
Reset condition		Immediately reset		
	Record	N/A		
	Cause		Corrective Actions	
Commu	nication connection error		rror are mostly communication problems between the oard. Potential causes include communication signal	
Keypad error		interference and the un	acceptable communication command to the Slave. curs randomly, or only occurs when copying certain	
Control board error			splays on the upper right corner of the copy page). If you	

ID No	Dianlay on LCD Kaynad	Warning Name	Description	
ID No.	Display on LCD Keypad	Warning Name	Description	
8	S8 <i>2</i>	Save error 2 (SE2)	Keypad COPY error 2: parameter writing error	
		Action and	d Reset	
	Action level	copy parameters to the	when writing the parameters incorrectly at the time you drive. For example, you copy the new firmware version to the drive with old firmware version.	
	Action time	N/A		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	N/A		
	Cause		Corrective Actions	
	v parameters to the new e version.	The Slave compares and the Data ROM. During may occur, or the data occurs. It is suggested to check first.	copied data has been transmitted to the Slave. Index processes the copied data, and then saves the data to the process, the data error (should be attribution error) cannot be saved to EEPROM. At this time, the warning of the status of Data ROM and remove the error causes error, please contact Delta.	
Malfunc	tion caused by interference	,	grounding of the main circuit, control circuit and the ti-interference performance.	

ID No.	Display on LCD Keypad	Warning Name	Description	
9	0 X	IGBT over-heating warning (oH1)	The AC motor drive detects IGBT overheating and exceeds the protection level of oH1 warning. (When Pr.06-15 is higher than the IGBT overheating protection level, the drive shows oH1 error without displaying oH1 warning.)	
		Action and	d Reset	
	Action level	Pr.06-15		
	Action time	"oH1" warning occurs value.	when IGBT temperature is higher than Pr.06-15 setting	
War	ning setting parameter	N/A		
	Reset method	Auto-reset		
	Reset condition	The drive auto-resets when IGBT temperature is lower than oH1 warning level minus (–) 5°C		
	Record	N/A		
Cause			Corrective Actions	
or tempe	erature inside the cabinet gh, or if there is obstruction entilation hole of the control	Change the install resistors, in the sur-	ne ventilation hole of the control cabinet. ed place if there are heating objects, such as brake	
or tempe is too hig in the ve cabinet.	erature inside the cabinet gh, or if there is obstruction entilation hole of the control	 Regularly inspect th Change the install resistors, in the sur Install/ add cooling cabinet. 	ne ventilation hole of the control cabinet. ed place if there are heating objects, such as brake roundings.	
or tempe is too hig in the ve cabinet. Check if the heat	erature inside the cabinet gh, or if there is obstruction entilation hole of the control there is any obstruction on sink or if the fan is running	 Regularly inspect th Change the install resistors, in the sur Install/ add cooling cabinet. 	ne ventilation hole of the control cabinet. ed place if there are heating objects, such as brake roundings. fan or air conditioner to lower the temperature inside the or replace the cooling fan.	
or temperis too high in the verticabinet. Check if the heat Insufficient.	erature inside the cabinet gh, or if there is obstruction entilation hole of the control there is any obstruction on sink or if the fan is running ent ventilation space the drive matches the onded loading	 Regularly inspect the surface of the s	ne ventilation hole of the control cabinet. ed place if there are heating objects, such as brake roundings. fan or air conditioner to lower the temperature inside the or replace the cooling fan. ace of the drive.	

ID No.	Display on LCD Keypad	Warr	ning Name	Description
11	Pīd		edback error (PID)	PID feedback loss (warning for analog feedback signal; works only when PID enables)
			Action and	d Reset
	Action level	When the	e analog input i	s lower than 4 mA (only detects analog input 4–20 mA)
	Action time	Pr.08-08		
War	Warning setting parameter Reset method		and continue o and ramp to sto and coast to sto and operate at	op op
			clears when th	eurs when Pr.08-09=0 or 3. The "Warning" automatically ne feedback signal is larger than 4 mA. when Pr.08-09=1 or 2. You must reset manually.
Reset condition		Immediately reset		
Record				=1 or 2 ("Error"). Pr.08-09=3 ("Warning").

Cause	Corrective Actions
Loose or broken PID feedback	Tighten the terminals again.
wiring	Replace with a new cable.
Feedback device malfunction	Replace with a new feedback device.
Hardware error	If the PID error still occurs after checking all the wiring, return to the factory for
l laidware error	repair.

ID No.	Display on LCD Keypad	Warr	ning Name	Description	
12	Rol		og signal loss (AnL)	Analog input current loss (including all analog 4–20 mA signals)	
		Action and Reset			
	Action level	When the analog input is lower than 4 mA (only detects analog input 4–20 mA)			
	Action time	Immediat	ely act		
Warning setting parameter		Pr.03-19 0: Disable 1: Continue operation at the last frequency (warning, keypad displays ANL)			
		2: Decelerate to 0 Hz (warning, keypad displays ANL)			
		3: Stop immediately and display "ACE"			
	Reset method		Auto "Warning" occurs when Pr.03-19=1 or 2. The "Warning automatically clears when the analog input signal is larger than 4 mA.		
		Manual "Error" occurs when Pr.03-19=3. You must reset manually.			
Reset condition		Immediately reset			
Record Does not record when Pr.03-19=1 or 2		Pr.03-19=1 or 2 ("Warning").			
Cause		Corrective Actions			
Loose or broken ACI wiring		Tighten the terminals again. Replace with a new cable.			
External device error Replace with a new device.		rice.			
Hardwai	re error	If the AnL error still occurs after checking all the wiring, return to the factor repair.			

ID No.	Display on LCD Keypad	Warr	ning Name	Description	
13	υC	Und	er current (uC)	Low current	
			Action an	d Reset	
	Action level	Pr.06-71			
	Action time	Pr.06-72			
Warning setting parameter		Pr.06-73 0: No function 1: Fault and coast to stop 2: Fault and ramp to stop by the 2 nd deceleration time 3: Warn and continue operation			
Reset method		Auto Manual	clears when t	curs when Pr.06-73=3. The "Warning" automatically ne output current is larger than (Pr.06-71+0.1 A). when Pr.06-73=1 and 2. You must reset manually.	
	Reset condition	Immediately reset			
	Record	Does not record when Pr.06-73=3 and uC displays ("Warning").			

Cause	Corrective Actions	
	Exclude the connection issue of the motor and its load.	
Improper setting for the low current protection	Set the proper settings for Pr.06-71, Pr.06-72 and Pr.06-73.	
ILow load	Check the loading status. Make sure the loading matches the motor capacity.	

ID No.	Display on LCD Keypad	Warning Name	Description		
17	oSPd	Over speed warning (oSPd)	Over speed warning		
		Action and Reset			
	Action level	The encoder feedback speed > Pr.10-10			
	Action time	Pr.10-11			
\\/or	ning cotting parameter	Pr.10-12=0			
vvai	ning setting parameter	0: Warn and continue operation			
	Reset method	"Warning" automatically clears when the drive stops			
Reset condition		"Warning" automatically clears when the drive stops			
Record		N/A			
Cause		Corrective Actions			
Improper setting for Pr.10-25 FOC bandwidth for speed observer		Decrease setting value for Pr.10-25.			
Improper bandwidth setting for ASR speed controller		ncrease the bandwidth setting for ASR speed controller.			
Incorrect motor parameter setting		Reset motor parameter and run parameter tuning.			
Malfunction caused by interference		Verify the wiring of the control circuit, and the wiring/grounding of the main circuit to prevent interference.			

ID No.	Display on LCD Keypad	Warning Name	Description		
18	d858	Deviation Warning (dAvE)	Over speed deviation warning		
		Action and Reset			
	Action level	Pr.10-13			
	Action time	Pr.10-14			
War	ning setting parameter	Pr.10-15 Encoder Stall and Slip Error Action =0 0: Warn and continue operation			
	Reset method	"Warning" automatically clears when the drive stops			
	Reset condition	After the drive stops			
Record		N/A			
Cause		Corrective Actions			
Improper parameter setting for the slip error		Reset proper value for Pr.10-13 and Pr.10-14.			
-	er setting for ASR er and acceleration/ ation	Reset ASR parameters. Set proper accel./ decel. time.			
Accel./ [Decel. time is too short	Reset proper accel./ decel. time.			
Motor Io	cked	Remove the causes of motor locked.			
Mechan	ical brake is not released	Check the action timing of the system.			

Incorrect parameter setting of torque limit (Pr.06-12, Pr.11-17–20)	Adjust to proper setting value.
IMalfunction caused by interference	Verify the wiring of the control circuit, and the wiring/grounding of the main circuit to prevent interference.

ID No.	Display on LCD Keypad	Warning Name	Description	
19	PHL	Phase loss (PHL)	Input phase loss warning	
		Action and	d Reset	
	Action level	One of the phases outputs less than Pr.06-47		
	Action time	Pr.06-46		
\\/or	ning setting parameter	Pr.06-45 Output Phase	Loss Detection Action (OPHL) =0	
VVai	Tilling Settling parameter	0: Warn and continue o	peration	
	Reset method	"Warning" automatically	clears when the drive stops	
	Reset condition	After the drive stops		
	Record	N/A		
	Cause	Corrective Actions		
Phase loss of the input power		Verify the wiring of the main circuit.		
Single phase power input on a three-phase model		Use the model with voltage that matches the power.		
The power voltage has changed		If the power of main circuit works well, check if the MC of the main circuit is broken. Cycle the power after verifying the power is normal. If PHL still occurs, return to the factory for repair.		
Loose w	se wiring terminal of input Tighten the terminal screws with the torque listed in the user manual.			
Check if	the input cable of	Make sure the wiring is correct.		
three-ph	ase power is broken	Replace the broken part of the cable.		
Unbalanced three-phase of the input power		Check the status of three-phase power.		

ID No.	Display on LCD Keypad	Warning Name	Description	
20	ot !	Over-torque 1 (ot1)	Over-torque 1 warning	
		Action and Reset		
	Action level	Pr.06-07		
	Action time	Pr.06-08		
War	rning setting parameter	 Pr.06-06 Over-torque Detection Selection (Motor 1) =1 or 3 0: No function 1: Continue operation after over-torque detection during constant speed operation 2: Stop after over-torque detection during constant speed operation 3: Continue operation after over-torque detection during RUN 4: Stop after over-torque detection during RUN 		
	Reset method	When the output current < Pr.06-07, the Ot1 warning automatically clears		
	Reset condition	When the output current < Pr.06-07, the Ot1 warning automatically clears		
	Record	N/A		

Cause	Corrective Actions
Incorrect parameter setting	Configure the settings for Pr.06-07 and Pr.06-08 again.
Mechanical error (e.g. mechanical lock due to over-torque)	Remove the causes of malfunction.
The load is too large	Decrease the loading. Replace with a motor with larger capacity.
Accel./ Decel. time and working cycle is too short	Increase the setting values for Pr.01-12–01-19 (accel./ decel. time)
V/F voltage is too high	Adjust the V/F curve (Motor 1, Pr.01-01–01-08), especially the setting value for the mid-point voltage (if the mid-point voltage is set too small, the load capacity decreases at low-speed).
The motor capacity is too small	Replace with a motor with larger capacity.
Overload during low-speed operation	Decrease the loading during low-speed operation. Increase the motor capacity.
The torque compensation is too large	Adjust the torque compensation value (Pr.07-26 torque compensation gain) until the output current decreases and the motor does not stall.
Improper parameter settings for the speed tracking function (including restart after momentary power loss and restart after fault)	Correct the parameter settings for speed tracking. Start the speed tracking function. Adjust the maximum current for Pr.07-09 speed tracking.

ID No.	Display on LCD Keypad	Warning Name	Description		
21	065	Over-torque (ot2)	Over-torque 2 warning		
		Action and Reset			
	Action level	Pr.06-10			
	Action time	Pr.06-11			
Warning setting parameter		Pr.06-09 Over-torque Detection Selection (Motor 2) =1 or 3 0: No function 1: Continue operation after over-torque detection during constant speed operation			
		2: Stop after over-torque detection during constant speed operation 3: Continue operation after over-torque detection during RUN 4: Stop after over-torque detection during RUN			
	Reset method When the output current < Pr.06-10, the Ot2 warning automatically clears				
	Reset condition	When the output current < Pr.06-10, the Ot2 warning automatically clears			
Record		N/A			
Cause		Corrective Actions			
Incorrect parameter setting		Configure the settings for Pr.06-10 and Pr.06-11			
	ical error (e.g. mechanical to over-torque)	Remove the causes of malfunction.			
The load is too large		Decrease the loading. Replace with a motor with larger capacity.			
	Decel. time and working too short	Increase the setting values for Pr.01-12–01-19 (accel./ decel. time)			
V/F voltage is too high the mid-point voltage		·	Notor 2, Pr.01-35–01-42), especially the setting value for the mid-point voltage is set too small, the load capacity (1).		

The motor capacity is too small	Replace with a motor with larger capacity.
Overload during low-speed operation	Decrease the loading during low-speed operation. Increase the motor capacity.
The torque compensation is too large	Adjust the torque compensation value (Pr.07-71 torque compensation gain) until the output current decreases and the motor does not stall.
Improper parameter settings for the speed tracking function (including restart after momentary power loss and restart after fault)	Correct the parameter settings for speed tracking. Start speed tracking function. Adjust the maximum current for Pr.07-09 speed tracking.

ID No.	Display on LCD Keypad	Warning Name	Description		
12 1101			Motor overheating warning.		
22_1	o×3	Motor over-heating	The AC motor drive detects the temperature inside the		
_	I (0H3) PIC I	motor is too high			
		Action and	Action and Reset		
	Action level	Pr.03-00=6 (PTC), PTC	input level > Pr.06-30 PTC level (default=50%)		
	Action time	Immediately act			
		Error treatment: Pr.06-2	29		
		0: Warn and continue o	peration		
		1: Fault and ramp to sto	рр		
\\/ar	rning setting parameter	2: Fault and coast to sto	ор		
VVai	ming setting parameter	3: No warning			
		When Pr.06-29=0 and	when the temperature is \leq Pr.06-30 level, the oH3		
		warning automatically of	elears.		
		When Pr.06-29=0 ("Wa	rning"), it automatically resets.		
	Reset method	When Pr.06-29=0, oH	3 displays as "Warning". When the temperature is \leq		
	reset method	Pr.06-30 level, the oH3	warning automatically clears.		
	Reset condition	When the temperature	e is \leq Pr.06-30 level, the oH3 warning automatically		
	Treset condition	clears.			
		N/A			
	Record	N/A			
	Cause		Corrective Actions		
Motor lo	Cause	N/A Clear the motor lock sta			
	Cause	Clear the motor lock state Decrease the loading.	atus.		
	Cause	Clear the motor lock sta Decrease the loading. Replace with a motor w	rith larger capacity.		
The load	Cause ocked d is too large	Clear the motor lock sta Decrease the loading. Replace with a motor w Change the installed pla	rith larger capacity. ace if there are heating devices in the surroundings.		
The load	Cause	Clear the motor lock sta Decrease the loading. Replace with a motor w Change the installed pla	rith larger capacity.		
The load	Cause ocked d is too large	Clear the motor lock sta Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan	rith larger capacity. ace if there are heating devices in the surroundings.		
The load	Cause ocked d is too large temperature is too high ooling system error	Clear the motor lock sta Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan	rith larger capacity. ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature.		
The load	Cause ocked d is too large temperature is too high ooling system error	Clear the motor lock start Decrease the loading. Replace with a motor we Change the installed plate Install/ add cooling fand Check the cooling systems.	atus. with larger capacity. ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature. em to make it work normally.		
The load Ambien Motor co	Cause ocked d is too large temperature is too high ooling system error	Clear the motor lock state Decrease the loading. Replace with a motor we Change the installed planstall/ add cooling fand Check the cooling system Replace the fan.	atus. with larger capacity. ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature. em to make it work normally. peration time.		
The load Ambien Motor co	Cause ocked d is too large temperature is too high ooling system error	Clear the motor lock start Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan of Check the cooling syste Replace the fan. Decrease low-speed op	rith larger capacity. ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature. em to make it work normally. peration time. otor for the drive.		
Ambien Motor co Motor fa	Cause ocked d is too large temperature is too high ooling system error	Clear the motor lock start Decrease the loading. Replace with a motor was Change the installed plate Install add cooling fand Check the cooling system Replace the fan. Decrease low-speed op Change to dedicated manufacture in the motor capatillary in the cooling system in the cooling sy	atus. with larger capacity. ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature. em to make it work normally. peration time. otor for the drive. acity.		
Ambien Motor co Motor fa Operate Accel./ [Cause ocked d is too large temperature is too high ooling system error an error	Clear the motor lock start Decrease the loading. Replace with a motor was Change the installed plate Install add cooling fand Check the cooling system Replace the fan. Decrease low-speed op Change to dedicated manufacture in the motor capatillary in the cooling system in the cooling sy	rith larger capacity. ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature. em to make it work normally. peration time. otor for the drive.		
Ambien Motor co Motor fa Operate Accel./ [Cause ocked d is too large temperature is too high ooling system error an error es at low-speed too long Decel. time and working	Clear the motor lock start Decrease the loading. Replace with a motor we Change the installed plate Install add cooling fand to Check the cooling system Replace the fan. Decrease low-speed op Change to dedicated me Increase the motor capallace setting values	atus. with larger capacity. ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature. em to make it work normally. peration time. otor for the drive. acity.		
Ambien Motor co Motor fa Operate Accel./ I cycle is	Cause ocked d is too large temperature is too high ooling system error an error es at low-speed too long Decel. time and working	Clear the motor lock start Decrease the loading. Replace with a motor work Change the installed plate Install add cooling fand Check the cooling system Replace the fan. Decrease low-speed op Change to dedicated motor capa Increase setting values Adjust settings for Pr.0	with larger capacity. ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature. em to make it work normally. peration time. otor for the drive. acity. for Pr.01-12–01-19 (accel./ decel. time).		
Ambien Motor co Motor fa Operate Accel./ I cycle is	Cause ocked d is too large temperature is too high ooling system error an error es at low-speed too long Decel. time and working too short	Clear the motor lock start Decrease the loading. Replace with a motor work Change the installed plate Install add cooling fand Check the cooling system Replace the fan. Decrease low-speed op Change to dedicated motor capa Increase setting values Adjust settings for Pr.0	with larger capacity. ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature. em to make it work normally. peration time. otor for the drive. acity. for Pr.01-12–01-19 (accel./ decel. time). 1-01–08 (V/F curve), especially the setting value for f the mid-point voltage is set too small, the load capacity		
Ambien Motor co Motor fa Operate Accel./ I cycle is	Cause ocked d is too large temperature is too high ooling system error an error es at low-speed too long Decel. time and working too short	Clear the motor lock start Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan of Check the cooling syste Replace the fan. Decrease low-speed op Change to dedicated m Increase the motor cap Increase setting values Adjust settings for Pr.0 the mid-point voltage (indecreases at low-speed	with larger capacity. ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature. em to make it work normally. peration time. otor for the drive. acity. for Pr.01-12–01-19 (accel./ decel. time). 1-01–08 (V/F curve), especially the setting value for f the mid-point voltage is set too small, the load capacity		

Check if the PTC is properly set and wired	Check the connection between PTC thermistor and the heat protection.	
Check if the setting for stall prevention is correct	Set the stall prevention to the proper value.	
Unbalanced three-phase impedance of the motor	Replace the motor.	
Harmonics is too high	Use remedies to reduce harmonics.	

ID No.	Display on LCD Keypad	Warning Name	Description		
		Motor over-heating	Motor overheating warning.		
22_2		(oH3) PT100	The AC motor drive detects the temperature inside the		
		, ,	motor is too high.		
		Action and			
	Action level	` ′	PT100 input level > Pr.06-57 (default=7 V)		
	Action time	Immediately act			
		Error treatment: Pr.06-2			
		0: Warn and continue o			
		1: Fault and ramp to sto	•		
		2: Fault and coast to sto	pp		
Warı	ning setting parameter	3: No warning			
			when the temperature is < Pr.06-56 level, the oH3		
		warning automatically c	lears.		
		If the temperature is b	petween Pr.06-56 and Pr.06-57, the frequency outputs		
		according to the operati	ing frequency setting for Pr.06-58.		
	Reset method	When Pr.06-29=0, oH	3 displays as "Warning". When the temperature is <		
	Neset method	Pr.06-56 level, the oH3	warning automatically clears.		
	Reset condition	When the temperature i	s < Pr.06-56 level, the oH3 warning automatically clears.		
	Record	N/A			
	Cause	Corrective Actions			
Motor lo	cked	Clear the motor lock status.			
The lead	is too large	Decrease loading.			
The load is too large		Replace with a motor w	ith larger capacity.		
Ambion	emperature is too high	Change the installed place if there are heating devices in the surroundings.			
Ambien	emperature is too nign	Install/ add cooling fan or air conditioner to lower the ambient temperature.			
Motor co	oling system error	system error Check the cooling system to make it work normally.			
Motor fai	n error	Replace the fan.			
		Decrease low-speed operation time.			
Operates	s at low-speed too long	Change to dedicated motor for the drive.			
		Increase the motor capacity.			
Accel./ C	ecel. time and working oo short	Increase the setting values for Pr.01-12–01-19 (accel./ decel. time).			
		Adjust the settings for Pr.01-01-08 (V/F curve), especially the setting value			
V/F voltage is too l	ge is too high	for the mid-point voltage (if the mid-point voltage is set too small, the load			
		capacity decreases at low-speed).			
Check if	the motor rated current				
	the motor nameplate	Configure the correct ra	ited current value of the motor again.		
	the PT100 is properly set				
and wire	Check the connection between P1100 thermistor and the heat protection.		etween PT100 thermistor and the heat protection.		
		L			

Check if the setting for stall prevention is correct	Set the stall prevention to the proper value.	
Unbalanced three-phase impedance of the motor	Replace the motor.	
Harmonics is too high	Use remedies to reduce harmonics.	

ID No.	Display on LCD Keypad	Warning Name	Description	
24	o5L	Over slip warning (oSL)	Over slip warning. By using the maximum slip (Pr.10-29) as the base, when the drive outputs at constant speed, and the F>H or F <h 100%="" and="" exceeds="" level="" pr.07-29="Pr.10-29.</td" pr.07-30="" setting="" time,=""></h>	
		Action and	d Reset	
	Action level	When the drive outpu Pr.07-29 level	ts at constant speed, and F>H or F <h exceeds="" td="" the<=""></h>	
	Action time	Pr.07-30		
War	ning setting parameter	Pr.07-31=0 Warning 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning		
Reset method When Pr.07-31=0 and when the drive outputs at constant speed, a F <h automatic<="" exceeds="" level,="" longer="" no="" osl="" pr.07-29="" td="" the="" warning=""><td></td></h>				
	Reset condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
Check if the motor parameter is correct Check the motor parameter.		eter.		
The load	d is too large	Decrease the loading.		
	the settings for Pr.07-29, and Pr.10-29 are properly	Check the parameter settings for oSL protection.		

ID No.	Display on LCD Keypad	Warning Name	Description	
25	ხში	Auto tuning (tUn)	Parameter auto-tuning is processing. When running auto-tuning, the keypad displays "tUn".	
		Action and	d Reset	
	Action level	When running Pr.05-00	motor parameter auto-tuning, the keypad displays "tUn".	
	Action time	N/A		
War	ning setting parameter	N/A		
	Reset method	When auto-tuning is finished and no error occurs, the warning automatically clears.		
	Reset condition	When auto-tuning is finished and no error occurs.		
	Record	N/A		
	Cause	Corrective Actions		
The mot auto-tun	or parameter is running ing	When the auto-tuning is finished, the warning automatically clears.		

ID No.	Display on LCD Keypad	Warning Name	Description	
28	opxi	Output phase loss (oPHL)	Output phase loss of the drive	
		Action and	d Reset	
Action level Pr.06-47				
	Action time	N/A		
		Pr.06-45 0: Warn and continue o	peration	
War	ning setting parameter	1: Fault and ramp to sto	•	
		2: Fault and coast to sto	pp	
		3: No warning		
	Reset method		the oPHL warning automatically clears after the drive	
		stops.		
	Reset condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
	ced three-phase ce of the motor	Replace the motor.		
Check if	the wiring is incorrect	Check the cable. Replace the cable.		
	the motor is a nase motor	Choose a three-phase motor.		
Check if broken	the current sensor is	Check if the control board cable is loose. If yes, reconnect the cable and run the drive to test. If the error still occurs, return to the factory for repair. Check if the three-phase current is balanced with a current clamp meter. If the current is balanced and the oPHL error still shows on the display, return to the factory for repair.		
	capacity of the drive is an the motor	(Choose a drive's canacity matches a motor's		

ID No.	Display on LCD Keypad	Warning Name	Description	
30	583	Copy model error 3 (SE3)	Keypad COPY error 3: copy model error	
		Action and	d Reset	
Action level		"SE3" warning occurs copying parameters.	when different drive identity codes are found during	
	Action time Immediately act when the error is detected			
War	ning setting parameter	N/A		
	Reset method	Reset method Manual reset		
	Reset condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
1 .	copy between different ange drives	It is mainly to prevent parameter copies between different HP/models.		

ID No.	Display on LCD Keypad	Warning Name	Description		
31	o t 3	Over-torque (ot3)	Over-torque 3 warning		
	Action and Reset				
	Action level	Pr.14-75			
	Action time	Pr.14-76			
		Pr.14-74 Over-torque D	etection Selection (Motor 3) =1 or 3		
		0: No function			
		1: Continue operation a	fter over-torque detection during constant speed		
War	ning setting parameter	operation			
		2: Stop after over-torque	e detection during constant speed operation		
		•	fter over-torque detection during RUN		
		4: Stop after over-torque			
	Reset method	·	t < Pr.14-75, the Ot3 warning automatically clears		
	Reset condition	When the output curren	t < Pr.14-75, the Ot3 warning automatically clears		
	Record	N/A			
	Cause		Corrective Actions		
Incorrect	t parameter setting	Configure the settings for Pr.14-75 and Pr.14-76 again.			
	cal error (e.g. mechanical to over-torque)	Remove the causes of malfunction.			
The leas	Lie toe lerge	Decrease the loading.			
The load is too large		Replace with a motor with larger capacity.			
	Decel. time and working soo short	Increase the setting values for Pr.01-12–01-19 (accel./ decel. time)			
		Adjust the V/F curve (M	Notor 3, Pr.01-54–01-61), especially the setting value for		
V/F volta	ige is too high	the mid-point voltage (if the mid-point voltage is set too small, the load capacity			
	decreases at low-speed).		1).		
The mot	or capacity is too small	Replace with a motor w	ith larger capacity.		
Overload	d during low-speed	Decrease the loading during low-speed operation.			
operatio	n	Increase the motor capacity.			
The torq	ue compensation is too	Adjust the torque comp	ensation value (Pr.07-73 torque compensation gain) until		
large		the output current decreases and the motor does not stall.			
Imprope	r parameter settings for	Correct the parameter s	settings for speed tracking		
-	d tracking function	Correct the parameter settings for speed tracking. Start the speed tracking function.			
1	g restart after momentary	Adjust the maximum current for Pr.07-09 speed tracking.			
power loss and restart after fault)					

n		
r 3		
constant speed		
d operation		
RUN		
omatically clears		
omatically clears		
Configure the settings for Pr.14-78 and Pr.14-79 again.		
Remove the causes of malfunction.		
Decrease the loading.		
Replace with a motor with larger capacity.		
Increase the setting values for Pr.01-12–01-19 (accel./ decel. time)		
ally the setting value for		
the mid-point voltage (if the mid-point voltage is set too small, the load capacity decreases at low-speed).		
Decrease the loading during low-speed operation. Increase the motor capacity.		
compensation gain) until		
II		
the output current decreases and the motor does not stall. Correct the parameter settings for speed tracking. Start the speed tracking function. Adjust the maximum current for Pr.07-09 speed tracking.		

ID No.	Display on LCD Keypad	Warning Name	Description	
36	[Gdn	CANopen guarding time-out (CGdn)	CANopen guarding time-out 1	
		Action and	d Reset	
		When CANopen Node	e Guarding detects that one of the slaves does not	
	Action level	respond, the CGdn error displays.		
		The upper unit sets the	factor and time during configuration.	
	Action time	The time that upper unit sets during configuration		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	The upper unit sends a reset package to clear this warning.		

Record	N/A			
Cause	Corrective Actions			
The guarding time is too short, or less detection times	Increase the guarding time (Index 100C) and detection times.			
Malfunction caused by interference	 Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance. Make sure the communication circuit is wired in series. Use CANopen cable or add terminating resistance. 			

ID No.	Display on LCD Keypad	Warning Name	Description
37	:Hbn	CANopen heartbeat error (CHbn)	CANopen heartbeat error
		Action and	d Reset
		When CANopen Heartb	eat detects that one of the slaves does not response, the
	Action level	CHbn error shows.	
	Action level	The upper unit sets the	ne confirming time of producer and consumer during
		configuration.	
	Action time	The upper unit sets the	ne confirming time of producer and consumer during
	Action time	configuration.	
War	ning setting parameter	N/A	
	Reset method	Manual reset	
	Reset condition	The upper unit sends a	reset package to clear this warning.
	Record	When Pr.00-21≠3, CHbn is a "Warning", and the warning is not recorded.	
	Cause	Corrective Actions	
The hea	rtbeat time is too short	Increase heartbeat time	(Index 1016)
		1. Verify the wiring	and grounding of the communication circuit. It is
		recommended to se	eparate the communication circuit from the main circuit,
Malfunct	tion caused by interference	or wire in 90 degree	e for effective anti-interference performance.
		2. Make sure the com	munication circuit is wired in series.
		Use CANopen cable	e or add terminating resistance.
Commulbad con	nication cable is broken or nected	Check or replace the co	ommunication cable.

ID No.	Display on LCD Keypad	Warnir	ng Name	Description
39	[bfn	•	bus off error bFn)	CANopen BUS off error
			Action and	d Reset
		Hardware	When CANo	pen card is not installed, the CbFn warning occurs.
	Action level	Software	warning occ Too much in The master	aster receives wrong communication package, the CbFn urs. terference on BUS receives wrong package when the CAN_H and CAN_L ion cables are short, CbFn warning occurs.
	Action time	Immediately act when the fault is detected		
War	ning setting parameter	N/A		
	Reset method	Manual Reset		
	Reset condition	Cycle the power		

Record	When Pr.00-21≠3, CbFn is a "Warning", and the warning is not recorded.		
Cause	Corrective Actions		
Check if the CANopen card is installed	Make sure the CANopen card is installed.		
Check if the CANopen speed is correct	Reset CANopen speed (Pr.09-37)		
Malfunction caused by interference	 Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance. Make sure the communication circuit is wired in series. Use CANopen cable or add terminating resistance. 		
Communication cable is broken or bad connected	Check or replace the communication cable.		

ID No.	Display on LCD Keypad	Warning Name	Description	
40	Eldn	CANopen index error (Cidn)	CANopen index error	
		Action and	d Reset	
	Action level	CANopen communication	on Index error	
	Action time	Immediately act when the fault is detected		
Warning setting parameter		N/A		
Reset method		Manual Reset		
	Reset condition	The upper unit sends a reset package to clear this warning		
	Record	When Pr.00-21≠3, Cidn is a "Warning", and the warning is not recorded.		
Cause Corrective Actions		Corrective Actions		
Incorrect setting of CANopen index		Reset CANopen index (Pr.00-02=7)		

ID No.	Display on LCD Keypad	Warning Name	Description	
41	[Rdn	CANopen station address error (CAdn)	CANopen station address error (only supports 1–127)	
		Action and	d Reset	
	Action level	CANopen station addre	ss error	
	Action time	Immediately act when the fault is detected		
War	ning setting parameter	N/A		
	Reset method	Manual Reset		
	Reset condition	Pr.00-02=7		
	Record	When Pr.00-21≠3, CAdn is a "Warning", and the warning is not recorded.		
Cause Corrective Actions		Corrective Actions		
Incorrect station a	t setting of CANopen	 Disable CANopen (Reset CANopen (P Reset CANopen state 	,	

ID No.	Display on LCD Keypad	Warning Name	Description	
42	[Frn	CANopen memory error (CFrn)	CANopen memory error	
		Action and	d Reset	
	Action level	When you update the f	irmware version of the control board, the FRAM internal	
	Action level	data does not change, t	hen CFrn warning occurs.	
	Action time	Immediately act when the fault is detected		
War	ning setting parameter	N/A		
Reset method		Manual Reset		
	Reset condition	Pr.00-02=7		
	Record	When Pr.00-21≠3, CFrn is a "Warning", and the warning is not recorded.		
Cause Corrective Actions		Corrective Actions		
		1. Disable CANopen (Pr.09-36=0)	
CANope	en internal memory error	2. Reset CANopen (P	r.00-20=7)	
		3. Reset CANopen sta	ation address (Pr.09-36)	

ID No.	Display on LCD Keypad	Warning Name	Description	
43	ESdn	CANopen SDO time-out (CSdn)	SDO transmission time-out (only shows on master station)	
		Action and	d Reset	
	Action level	When the CANopen ma	ster transmits a SDO command, and the slave response	
	7 totion level	"times-out", CSdn warni	ng occurs.	
	Action time	Immediately act when the	ne fault is detected	
War	ning setting parameter	N/A		
	Reset method	When the master rese	nds a SDO command and receives the response, the	
		warning automatically clears.		
	Reset condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
Slave is	not connected	Connect the slave and	CANopen BUS.	
The syn	chronous cycle is set too	Increase the synchronous time (Index 1006)		
		,	and grounding of the communication circuit. It is eparate the communication circuit from the main circuit,	
Malfunct	tion caused by interference	or wire in 90 degree for effective anti-interference performance.		
		Make sure the communication circuit is wired in series.		
		Use CANopen cable	e or add terminating resistance.	
Disconn	ection or bad connection	Check the status of the	cable, or replace the cable.	
of the co	mmunication cable	Shock the states of the	casio, or replace the casio.	

ID No.	Display on LCD Keypad	Warning Name	Description	
		CANopen SDO		
44	[Sbn	receives register	CANopen SDO receives register overflow	
		overflow (CSbn)		
		Action and	d Reset	
	Action level	The upper unit sends to	o much SDO at one time and causes buffer overflow	
	Action time	Immediately act when the fault is detected		
War	ning setting parameter	N/A		
	Reset method	The upper unit sends a reset package to clear the warning.		
	Reset condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
Too mud	ch SDO from the upper unit	Check if the master se	ends too much SDO command. Make sure the master	
at one ti	me	sends the SDO command according to the command format.		

ID No.	Display on LCD Keypad	Warning Name	Description	
45	[ხხი	CANopen start-up error warning (Cbtn)	CANopen start-up error warning	
		Action and	l Reset	
	Action level	When the amount of se	nt error messages reach 255	
	Action time	N/A		
War	ning setting parameter	Index 6007		
	Reset method	Disable CANopen, and cycle the power after power-off		
	Reset condition	N/A		
Record		N/A		
Cause Corrective Actions		Corrective Actions		
Serious	interference on hardware	Verify if the grounding, t	erminating resistance and bus line are properly installed.	
Incorrec	t setting for	Verify the setting for communication speed.		
commur	nication speed			
The con	nmunication card is not	Make sure the communication card is connected to the drive.		
connect	ed, or the card is loose	iviake sure the commun	ication card is connected to the drive.	

ID No.	Display on LCD Keypad	Warning Name	Description	
46	[Ptn	CANopen format error (CPtn)	CANopen protocol format error	
		Action and	d Reset	
	Action level		t communication data from the upper unit cannot be	
		recognized, and then CPtn warning occurs.		
	Action time	Immediately act when the fault is detected		
War	ning setting parameter	N/A		
	Reset method	The upper unit sends a reset packet to clear the warning		
	Reset condition	N/A		
Record N/A				
Cause			Corrective Actions	
The upp	er unit sends incorrect	Make sure the master	sends the packet based on CANopen DS301 standard	
commun	nication packet	command format.		

ID No.	Display on LCD Keypad	Warning Name	Description	
50	PLod	PLC opposite defect (PLod)	PLC download error warning	
		Action and	Reset	
	Action level		ng, the program source code detects incorrect address ds the range), then the PLod warning occurs.	
	Action time	Immediately act when the fault is detected		
War	ning setting parameter	N/A		
			s correct and download the program again. If the fault ing automatically clears.	
	Reset condition	N/A		
	Record	N/A		
	Cause	Cause Corrective Actions		
	et data number is found ownloading the PLC	Use the correct data nu	mber.	

ID No.	Display on LCD Keypad	Warning Name	Description	
וט ווט.	Display of LCD Reypau	•	Description	
	.	PLC save memory		
51	PLSJ	error	Data error during PLC operation	
		(PLSv)		
		Action and	d Reset	
	Action level	The program detects in	ncorrect written address (e.g. the address exceeds the	
	Action level	range) during PLC operation, then the PLSv warning occurs.		
	Action time	Immediately act when the fault is detected		
Warning setting parameter		N/A		
	Decet weetherd	Check if the program is correct and download the program again. If the fault		
	Reset method	does not exist, the warning automatically clears.		
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
An incor	rect written address is	Males arms the armitters a	dda i dda	
detected	d during PLC operation	Make sure the written address is correct and download the program again.		

ID No.	Display on LCD Keypad	Warning Name	Description	
52	PL	Data defect (PLdA)	Data error during PLC operation	
		Action and	l Reset	
		The program detects in	ncorrect written address when translating the program	
	Action level	source code (e.g. the	address exceeds the range) during PLC downloading,	
		then PLdA warning occi	urs.	
	Action time	Immediately act when the fault is detected		
War	rning setting parameter	N/A		
	Reset method	Check if the program is correct and download the program again. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
During F	PLC operation, the external			
Modbus has written/read incorrect		Check if the upper unit transmits the correct command		
data to i	nternal PLC program			

ID No.	Display on LCD Keypad	Warning Name	Description	
53	PLFn	Function defect (PLFn)	PLC download function code error	
		Action and	d Reset	
	Action level	The program detects incorrect command (unsupported command) during PLC downloading, then PLFn warning occurs.		
	Action time	Immediately act when the fault is detected		
War	ning setting parameter	N/A		
Reset method		Check if the program is correct and download the program again. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A		
Record N/A				
Cause		Corrective Actions		
Unsupported command has used while downloading the program Check if the firmware of the drive is the old version. If yes, please contains		the drive is the old version. If yes, please contact Delta.		

ID No.	Display on LCD Keypad	Warning Name	Description	
54	Plor	PLC buffer overflow (PLor)	PLC register overflow	
		Action and	d Reset	
Action level		When PLC runs the last command and the command exceeds the maximum capacity of the program, then PLor warning occurs.		
	Action time	Immediately act when the	ne fault is detected	
War	rning setting parameter	N/A		
	Reset method	Check if the program is correct and download the program again. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A		
	Record	N/A		
Cause Corrective A		Corrective Actions		
	gram detects internal code error during PLC on	 Disable PLC Reset the PLC program (Pr.00-02=6) Enable PLC Re-download the PLC program 		

ID No.	Display on LCD Keypad	Warning Name	Description	
55	PLFF	Function defect (PLFF)	Function code error during PLC operation	
		Action and	d Reset	
	Action level	The program detects incorrect command (unsupported command) during PLC operation, then PLFF warning occurs.		
	Action time	Immediately act when the fault is detected		
War	ning setting parameter	NA		
	Reset method	Check if the program is correct and download the program again. If the fault does not exist, the warning automatically clears.		
	Reset condition N/A			
Record N/A				

Cause	Corrective Actions
The PLC runs an incorrect	When starting the PLC function and there is no program in the PLC, the PLFF
command during operation	warning occurs. This is a normal warning, please download the program.

ID No.	Display on LCD Keypad	Warning Name	Description	
56	PLSn	Checksum error (PLSn)	PLC checksum error	
		Action and	d Reset	
	Action level	PLC checksum error is detected after the drive is powered on, then PLSn warning occurs.		
	Action time	Immediately act when the	ne fault is detected	
War	ning setting parameter	NA		
	Reset method	Check if the program is correct and download the program again. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
1. Disable PLC The program detects checksum error during PLC operation 1. Disable PLC 2. Reset the PLC program (Pr.00-02=6) 3. Enable PLC 4. Re-download the PLC program		,		

ID No.	Display on LCD Keypad	Warning Name	Description	
57	PLEd	No end command (PLEd)	PLC end command is missing	
		Action and	d Reset	
	Action level	The "End" command is warning occurs.	missing until the last command is executed, the PLEd	
	Action time	Immediately act when the	ne fault is detected	
War	ning setting parameter	NA		
	Reset method	Check if the program is correct and download the program again. If the fault does not exist, the warning automatically clears.		
Reset condition		N/A		
	Record	N/A		
Cause Corrective Actions		Corrective Actions		
	no "END" command PLC operation	 Disable PLC Reset the PLC prog Enable PLC Re-download the P 	· · · · · · · · · · · · · · · · · · ·	

ID No.	Display on LCD Keypad	Warning Name	Description	
58	PLCr	PLC MCR error (PLCr)	PLC MCR command error	
		Action and	l Reset	
	Action level	The MC command is detected during PLC operation, but there is no corresponding MCR command, then the PLCr warning occurs.		
	Action time	Immediately act when the fault is detected		
War	ning setting parameter	NA		
	Reset method	Check if the program is correct and download the program again. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A		
Record N		N/A		
Cause		Corrective Actions		
The MC command is continuously		The MC command cannot be used continuously for 9 times. Check and reset the		
used for	more than 9 times	program, then re-download the program.		

ID No.	Display on LCD Keypad	Warning Name	Description	
59	PLdF	PLC download fail (PLdF)	PLC download failure	
		Action and	l Reset	
	Action level	PLC download failure due to momentary power loss during the downloading. After the power is ON again, the PLdF warning occurs.		
	Action time	Immediately act when the fault is detected		
War	rning setting parameter	NA		
	Reset method	Check if the program is correct and download the program again. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A		
	Record	N/A		
Cause Corrective Actions		Corrective Actions		
	wnload is forced to stop, so en program is incomplete	Check if there is any en	or in the program and re-download the PLC program.	

ID No.	Display on LCD Keypad	Warning Name	Description	
60	PLSF	PLC scan time fail (PLSF)	PLC scan time exceeds the maximum allowable time	
		Action and	d Reset	
	Action level	When the PLC scan tir	ne exceeds the maximum allowable time (400 ms), the	
	Action level	PLSF warning occurs.		
	Action time	Immediately act when the fault is detected		
War	rning setting parameter	NA		
	Reset method	Check if the program is correct and download the program again. If the fault		
	Reset method	does not exist, the warning automatically clears.		
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
The PLC scan time exceeds the maximum allowable time (400 ms)		Check if the source cod	e is correct and re-download the program.	

ID No.	Display on LCD Keypad	Warning Name	Description	
70	8629	ExCom ID fail (ECid)	Duplicate MAC ID error Node address setting error	
		Action and	d Reset	
Action level		Duplicate setting of MAC ID Node address setting error		
	Action time	N/A		
War	ning setting parameter	N/A		
	Reset method	Correct the setting and cycle the power		
	Reset condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
The setting address exceeds the range (0–63)		Check the address setting of the communication card (Pr.09-70)		
The speed setting exceeds the range		Standard: 0–2; non-standard: 0–7		
The address is duplicated with other nodes on the BUS		Reset the address		

ID No.	Display on LCD Keypad	Warning Name	Description	
71	ECLō	ExCom power loss (ECLv)	Low voltage of the communication card	
		Action and	l Reset	
	Action level	The 5V power that the o	drive provides to the communication card is too low	
	Action time	Immediately act		
War	ning setting parameter	N/A		
	Reset method	Cycle the power		
Reset condition		N/A		
Record		N/A		
	Cause		Corrective Actions	
		1. Use the same com	munication card for other MS300 drives to check if the	
The 5V	power that the drive	ECLv warning still occurs. If yes, replace with a new communication card; if		
provides to the communication		not, replace the drive.		
card is too low		2. Use another communication card to test if the ECLv warning still occurs on		
		the same drive. If no	ot, replace the card; if yes, replace the drive.	
The card	d is loose	Make sure the commun	ication card is well inserted.	

ID No.	Display on LCD Keypad	Warning Name	Description	
72	8688	ExCom test mode (ECtt)	The communication card is in the test mode	
Action and Reset			d Reset	
	Action level	The communication card is in the test mode		
	Action time	Immediately act		
War	ning setting parameter	N/A		
	Reset method	Cycle the power and enter the normal mode		
	Reset condition	N/A		
Record		N/A		

Cause	Corrective Actions
Communication command error	Cycle the power

ID No.	Display on LCD Keypad	Warning Name	Description		
73	8888	ExCom Bus off (ECbF)	The communication card detects too many errors in the BUS, then enters the BUS-OFF status and stop communicating.		
		Action and	d Reset		
	Action level	When the drive detects	BUS-off (for DeviceNet)		
	Action time	Immediately act			
War	ning setting parameter	N/A			
	Reset method	Cycle the power			
	Reset condition	N/A			
	Record	N/A			
Cause		Corrective Actions			
Poor co	nnection of the cable	Re-connect the cable			
Bad quality of the cable		Replace the cable			

ID No.	Display on LCD Keypad	Warning Name	Description	
74	86.08	ExCom no power (ECnP)	There is no power supply of the DeviceNet	
		Action and	d Reset	
	Action level	When there is no power	supply of the DeviceNet	
	Action time	Immediately act		
War	rning setting parameter	N/A		
	Reset method	Cycle the power		
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
The drive detects that DeviceNet has no power		Check if the cable and լ	power is normal. If yes, return to the factory for repair.	

ID No.	Display on LCD Keypad	Warning Name	Description	
75	8688	ExCom factory defect (ECFF)	Factory default setting error	
		Action and	d Reset	
	Action level	Factory default setting error		
	Action time	Immediately act		
War	ning setting parameter	N/A		
	Reset method	Cycle the power		
	Reset condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
Factory default setting error		Use DCISoft to reset to the default value.		

ID No.	Display on LCD Keypad	Warning Name	Description	
76	800F	ExCom inner error (ECiF)	Serious internal error	
		Action and	d Reset	
	Action level	Internal memory saving error		
	Action time	Immediately act		
War	ning setting parameter	N/A		
	Reset method	Cycle the power		
Reset condition		N/A		
Record		N/A		
	Cause	Corrective Actions		
		Verify the wiring of the control circuit, and the wiring/grounding of the main circuit		
Noise in	terference	to prevent interference.		
		Cycle the power.		
The me	mory is broken	Reset to the default value and check if the error still exists. If yes, replace the		
The me	HOLY IS DIOKELL	communication card.		

ID No.	Display on LCD Keypad	Warning Name	Description	
		ExCom Parameter		
78	6666	data error	Profibus parameter data error	
		(ECPP)		
		Action and	d Reset	
	Action level	N/A		
	Action time	N/A		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	N/A		
	Cause	Corrective Actions		
Incorrect GSD file		Get the correct GSD file from the software		

ID No.	Display on LCD Keypad	Warning Name	Description	
		ExCom configuration		
79	ECPI	data error	Profibus configuration data error	
		(ECPi)		
		Action and	d Reset	
	Action level	N/A		
	Action time	N/A		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	N/A		
	Cause	Corrective Actions		
Incorrec	t GSD file	Get the correct GSD file from the software		

ID No.	Display on LCD Keypad	Warning Name	Description	
80	8888	Ethernet link fail (ECEF)	The Ethernet cable is not connected	
		Action and	d Reset	
	Action level	Hardware detection		
	Action time	Immediately act		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
The Eth	ernet cable is loose	Re-connect the cable		
Bad qua	lity of the Ethernet cable	Replace the cable		

ID No.	Display on LCD Keypad	Warning Name	Description	
81	6650	Communication time-out (ECto)	Communication time-out for the communication card and the upper unit	
		Action and	d Reset	
	Action level	N/A		
	Action time	N/A		
War	ning setting parameter	N/A		
	Reset method	N/A		
	Reset condition	CMC-EC01: auto-resets when the communication with the upper unit is back to normal		
	Record	N/A		
	Cause		Corrective Actions	
Communication card is not connected with the upper unit		Check if the connection	of the communication cable is correct	
Communication error of the upper unit		Check if the communication	ation of the upper unit is normal	

ID No.	Display on LCD Keypad	Warning Name	Description	
82	8885	Checksum error (ECCS)	Checksum error for the communication card and the drive	
		Action and	d Reset	
	Action level	Software detection		
	Action time	N/A		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	N/A		
Cause		Corrective Actions		
Noise interference		Verify the wiring of the control to prevent interference.	control circuit, and the wiring/grounding of the main circuit	

ID No.	Display on LCD Keypad	Warning Name	Description		
83	8878	Return defect (ECrF)	Communication card returns to the default setting		
		Action and	d Reset		
	Action level	Communication card re	turns to the default setting		
	Action time	N/A			
War	ning setting parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Immediately reset			
	Record	N/A			
Cause		Corrective Actions			
Communication card is returning to default setting		No actions required.			

ID No.	Display on LCD Keypad	Warning Name	Description		
84	86.00	Modbus TCP over (ECo0)	Modbus TCP exceeds the maximum communication value		
		Action and	d Reset		
	Action level	Hardware detection			
	Action time	Immediately act			
War	rning setting parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Immediately reset			
	Record	N/A			
	Cause	Corrective Actions			
The Mas	ster communication value				
exceeds	s the allowable number of	Decrease the Master communication value			
the com	munication cards				
Connec	tion occupied due to not				
disconn	ecting the Modbus TPC	Revise the program of	the upper unit to disconnect the connection while the		
	e upper unit is connected	communication is not used for a long time.			
without	communicating.				
A new M	Modbus TCP connection is				
built who	enever the upper unit is	Revise the program of t	the upper unit to use the same Modhus TCP connection		
connect	ed to the communication	Revise the program of the upper unit to use the same Modbus TCP connection when connecting to the same communication card.			
card, wh	nich causes connection	when connecting to the same communication card.			
occupie	d.				

ID No.	Display on LCD Keypad	Warning Name	Description				
85	EE o 1	EtherNet/IP over (ECo1)	Ethernet/IP value	exceeds	the	maximum	communication
		Action and	d Reset				
	Action level	Hardware detection					
	Action time	Immediately act					
War	rning setting parameter	N/A					
	Reset method	Manual reset					
	Reset condition	Immediately reset					
	Record	N/A					

Cause	Corrective Actions
The Master communication value	
exceeds the allowable number of	Decrease the Master communication value
the communication cards	
Connection occupied due to not	
disconnecting the Modbus TPC	Revise the program of the upper unit to disconnect the connection while the
while the upper unit is connected	communication is not used for a long time.
without communicating.	
A new Modbus TCP connection is	
built whenever the upper unit is	Revise the program of the upper unit to use the same Modbus TCP connection
connected to the communication	when connecting to the same communication card.
card, which causes connection	when connecting to the same communication card.
occupied.	

ID No.	Display on LCD Keypad	Warning Name	Description			
86	8002	IP fail (ECiP)	IP setting error			
		Action and	l Reset			
	Action level	Software detection				
	Action time	Immediately act				
War	ning setting parameter	N/A				
	Reset method	Manual reset				
	Reset condition	Immediately reset				
	Record	N/A				
Cause		Corrective Actions				
IP confli	ct	Reset IP				
DHCP II	configuration error	Contact MIS to check if DHCP Server works normally				

ID No.	Display on LCD Keypad	Warning Name	Description		
87	8 C 3 F	Mail fail (EC3F)	Mail warning: Alarm mail is sent when the condition that the alarm set for the communication card was met.		
		Action and	d Reset		
	Action level	When the condition that	When the condition that the alarm set for the communication card was met		
	Action time	Immediately act			
War	ning setting parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Immediately reset			
	Record	N/A			
Cause		Corrective Actions			
	nication card establishes onditions	No actions required			

ID No.	Display on LCD Keypad	Warning Name			Descrip	tion			
88	8883	ExCom busy (ECbY)	Communication received	card	busy:	too	many	packets	are
		Action and	d Reset						
	Action level	Software detection							
	Action time	N/A							
War	ning setting parameter	N/A							
	Reset method	Manual reset							
	Reset condition	N/A							
	Record	N/A							
	Cause	Corrective Actions							
Too mar	y communication packets								
for the communication card to		Decrease communication packets							
process									

ID No.	Display on LCD Keypad	Warning Name	Description			
89	8888	ExCom card break (ECCb)	Communication card break off warning			
		Action and	d Reset			
	Action level	Communication card break off				
	Action time	N/A				
War	ning setting parameter	N/A				
	Reset method	Auto-resets after the communication card is re-installed				
	Reset condition	Immediately reset				
	Record	N/A				
	Cause	Corrective Actions				
Commu	nication card is loose	Re-install the communication card				

ID No.	Display on LCD Keypad	Warning Name	Description		
90	[PLP	Copy PLC: password error (CPLP)	Copy PLC password error. When KPMS-LE01 is processing PLC copy and the PLC password is incorrect, the CPLP warning occurs.		
		Action and	d Reset		
	Action level	PLC password is incorrect			
Action time		Immediately act			
War	ning setting parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Directly reset			
Record		N/A			
Cause		Corrective Actions			
PLC password is incorrect		Reset and enter the correct PLC password			

ID No.	Display on LCD Keypad	Warning Name	Description			
91	CPLO	Copy PLC: Read mode error (CPL0)	Copy PLC read mode error			
		Action and	l Reset			
	Action level	Incorrect process when copying the PLC read mode				
	Action time	Immediately act				
War	ning setting parameter	N/A				
	Reset method	Manual reset				
	Reset condition	Directly reset				
	Record	N/A				
	Cause	Corrective Actions				
Using incorrect process to copy the PLC read mode again Cycle the power and copy the PLC read mode again			py the PLC read mode again			

ID No.	Display on LCD K	eypad	Warning Name	Description		
92	CPL I		Copy PLC: Write mode (CPL1)	Copy PLC write mode error		
			Action and	l Reset		
	Action level		Incorrect process when	copying the PLC write mode		
	Action time		Immediately act			
War	ning setting parame	eter	N/A			
	Reset method		Manual reset			
	Reset condition		Directly reset			
Record N/A			N/A			
Cause			Corrective Actions			
Using incorrect process to copy the PLC write mode			Cycle the power and copy the PLC write mode again			

ID No.	Display on LCD Keypad	Warning Name	Description		
93	EPLG	Copy PLC: version error (CPLv)	Copy PLC version error. When a non-MS300 built-in PLC is copied to the MS300 drive, the CPLv warning occurs.		
		Action and	d Reset		
	Action level	Software detection			
	Action time	Immediately act			
War	ning setting parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Directly reset			
	Record	N/A			
Cause		Corrective Actions			
A non-M	IS300 PLC program is	Check if the copied PLC program is for MS300.			
copied t	o MS300	Use the correct MS300 PLC program.			

ID No.	Display on LCD Keypad	Warning Name	Description	
94	CPL S	Copy PLC: size error (CPLS)	Copy PLC capacity error	
		Action and	d Reset	
	Action level	Software detection		
Action time		Immediately act		
War	ning setting parameter	N/A		
Reset method		Manual reset		
	Reset condition	Directly reset		
	Record	N/A		
Cause		Corrective Actions		
MS300 exceeds the allowable		Check if the copied PLC program is for MS300 Use the correct capacity for the MS300 PLC program		

ID No.	Display on LCD Keypad	Warning Name	Description		
95	CPLF	Copy PLC: PLC function (CPLF)	KPMS-LE01 Copy PLC function must be executed when PLC is disabled.		
		Action and	l Reset		
	Action level	Software detection			
Action time		Immediately act			
Warning setting parameter		N/A			
	Reset method	Manual reset			
	Reset condition	Directly reset			
	Record	N/A			
Cause		Corrective Actions			
PLC function is enabled when KPMS-LE01 is running PLC copy		Disable the PLC function	n first, and then run the PLC copy function again.		

ID No.	Display on LCD Keypad	Warning Name	Description	
96	(ՔԼ Է	Copy PLC: time-out (CPLt)	Copy PLC time-out	
		Action and	d Reset	
	Action level	Software detection		
	Action time	Immediately act		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Directly reset		
	Record	N/A		
	Cause	Corrective Actions		
KPMS-LE01 is removed while copying the PLC program		The KPMS-LE01 canno	t be removed during the PLC copy process	

ID No.	Display on LCD Keypad	Warning Name	Description	
101	ickn	InrCOM time-out (ictn)	Internal communication time-out	
		Action and	d Reset	
	Action level	When Pr.09-31= (-1) -	(-10) (no -9) and the internal communication between	
	Action level	Master and Slave is abr	normal, the ictn warning occurs.	
	Action time	Immediately act		
War	ning setting parameter	N/A		
	Reset method	Auto-reset		
	Reset condition	The warning automatically clears when the communication is back to normal condition		
Record		N/A		
	Cause	Corrective Actions		
		Verify the wiring and grounding of the communication circuit. It is recommended		
Malfunct	tion caused by interference	to separate the communication circuit from the main circuit, or wire in 90 degree		
		for effective anti-interference performance.		
Different communication setting		Check if the patting for Dr 00 02 is the same as the patting for the upper unit		
from the upper unit		Check if the setting for Pr.09-02 is the same as the setting for the upper unit		
Disconn	ection or bad connection	Check the cable and re	place it if necessary	
of the ca	able	Check the cable and re	piace it il liecessary.	

[This page intentionally left blank]

Digital Keypad KPMS-LE01



*: Refer to setting of Pr.06-17-Pr.06-22 and Pr.14-70-14-73.

	r to setting of Pr.06-17-F			
ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
			Output current exceeds three times of the rated current	
		Over-current during	during acceleration.	
1	oc8	acceleration	When ocA occurs, the drive closes the gate of the	
		(ocA)	output immediately, the motor runs freely, and the	
			display shows an ocA error.	
		Action and	d Reset	
	Action level	300% of the rated curre	ent	
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds a	fter the fault is cleared	
	Record	Yes		
	Cause	Corrective Actions		
		Increase the acceleration time		
		2. Increase the acceleration time of S-curve		
Accelera	ation time is too short	3. Set auto-acceleration	on and auto-deceleration parameter (Pr.01-44)	
		4. Set over-current sta	all prevention function (Pr.06-03)	
		5. Replace the drive with a larger capacity model.		
Short cir	cuit at motor output due to	Check the motor cable	and remove causes of the short circuits, or replace the	
poor ins	ulation wiring	cable before turning on the power.		
Check for	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the		
aging ins	sulation of the motor	insulation is poor.		
		Check if the output current during the whole working process exceeds the AC		
The load	d is too large.	motor drive's rated current. If yes, replace the AC motor drive with a larger		
		capacity model.		
Impulsive change of the load		Reduce the load or increase the capacity of AC motor drive.		
Use special motor or motor with		Check the motor capacity (the rated current on the motor's nameplate should ≤		
larger ca	apacity than the drive	the rated current of the drive)		
Use ON/OFF controller of an		Check the action timing of the contestor and make ourse it is used to accept the contestor and make ourse it is used to accept the contestor and make ourse it is used to accept the contestor and make ourse it is used to accept the contestor and make ourse it is used to accept the contestor and make ourse it is used to accept the contestor and make ourse it is used to accept the contestor and make ourse it is used to accept the contestor and make ourse it is used to accept the contestor and make ourse it is used to accept the contestor and make our accept the contestor		
electromagnetic contactor at the		Check the action timing of the contactor and make sure it is not turned ON/OFF when the drive outputs the voltage.		
output (U/V/W) of the drive		when the arive outputs	the voltage.	

Cause	Corrective Actions		
V/F curve setting error	Adjust the V/F curve setting and frequency/voltage. When the fault occurs, and		
vii curve setting error	the frequency voltage is too high, reduce the voltage.		
Torque compensation is too large	Adjust the torque compensation (refer to Pr.07-26 torque compensation gain)		
Torque compensation is too large	until the output current reduces and the motor does not stall.		
Malfunction caused by interference	Verify the wiring of the control circuit and the wiring/grounding of the main circuit		
ivialidification caused by interference	to prevent interference.		
The motor starts when in free run	Enable the speed tracking during start-up of Pr.07-12.		
Improper parameter settings for	Correct the parameter settings for speed tracking.		
the speed tracking function	Start the speed tracking function.		
(including restart after momentary	Adjust the maximum current for Pr.07-09 speed tracking.		
power loss and restart after fault)	2. Adjust the maximum current for 1 1.07 to open a defailing.		
Incorrect combination of control	Check the settings for Pr.00-11 control mode:		
mode and used motor	1. For IM, Pr.00-11=0, 1, 2, 3, 5		
mode and used motor	2. For PM, Pr.00-11=4, 6, or 7		
The length of motor cable is too	Increase the AC motor drive's capacity.		
long	Install AC reactor(s) on the output side (U/V/W).		
	The ocA occurs due to the short circuit or ground fault at the output side of the		
	drive.		
Hardware failure	Check for possible short circuits between terminals with the electric meter:		
Hardware failure	B1 corresponds to U, V and W; DC- corresponds to U, V and W;		
	corresponds to U, V and W.		
	If short circuit occurs, return to the factory for repair.		
Check if the setting for stall	Set the stell provention to the proper value		
prevention is correct	Set the stall prevention to the proper value.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
2	ocd	Over-current during deceleration (ocd)	Output current exceeds three times of the rated current during deceleration. When ocd occurs, the drive closes the gate of the output immediately, the motor runs freely, and the display shows an ocd error.	
		Action and	d Reset	
	Action level	300% of the rated curre	nt	
	Action time	Immediately act		
Fau	lt treatment parameter	N/A		
Reset method		Manual reset		
	Reset condition	Reset in five seconds after the fault is cleared		
	Record	Yes		
	Cause		Corrective Actions	
Deceleration time too short		 Increase the deceleration time Increase the deceleration time of S-curve Set auto-acceleration and auto-deceleration parameter (Pr.01-44) Set over-current stall prevention function (Pr.06-03) Replace the drive with a larger capacity model 		
Check if the mechanical brake of the motor activates too early		Check the action timing of the mechanical brake		
Short-circuit at motor output due to poor insulation wiring		Check the motor cable and remove causes of the short circuits, or replace the cable before turning on the power.		

Check for possible burnout or	Check the motor insulation value with megger. Replace the motor if the		
aging insulation of the motor	insulation is poor.		
The load is too large	Check if the output current during the whole working process exceeds the AC motor drive's rated current. If yes, replace the AC motor drive with a larger capacity model.		
Impulsive change of the load	Reduce the load or increase the capacity of AC motor drive.		
Use special motor or motor with larger capacity than the drive	Check the motor capacity (the rated current on the motor's nameplate should ≤ the rated current of the drive)		
Use ON/OFF controller of an electromagnetic contactor at the output (U/V/W) of the drive	Check the action timing of the contactor and make sure it is not turned ON/OFF when the drive outputs the voltage.		
V/F curve setting error Adjust the V/F curve settings and frequency/voltage. When the fitted the frequency voltage is too high, reduce the voltage.			
Torque compensation is too large	Adjust the torque compensation (refer to Pr.07-26 torque compensation gain) until the output current reduces and the motor does not stall.		
Malfunction caused by interference	Verify the wiring of the control circuit and the wiring/grounding of the main circuit to prevent interference.		
The length of motor cable is too	Increase the AC motor drive's capacity		
long	Install AC reactor(s) on the output side (U/V/W)		
Hardware error	The ocd occurs due to the short circuit or ground fault at the output side of the drive. Check for possible short circuits between terminals with the electric meter: B1 corresponds to U, V and W; DC- corresponds to U, V and W; © corresponds to U, V and W. If short circuits occurs, return to the factory for repair.		
Check if the setting of stall prevention is correct	Set the stall prevention to the proper value.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
			Output current exceeds three times of the rated current	
		Over-current during	during constant speed.	
3	ocn	steady operation	When ocn occurs, the drive closes the gate of the output	
		(ocn)	immediately, the motor runs freely, and the display	
			shows an ocn error.	
		Action and	d Reset	
Action level		300% of the rated curre	nt	
Action time		Immediately act		
Fault treatment parameter		N/A		
Reset method		Manual reset		
Reset condition		Reset in five seconds a	fter the fault is cleared	
Record		Yes		
	Cause	Corrective Actions		
Short-cir	rcuit at motor output due to	Check the motor cable and remove causes of the short circuits, or replace the		
poor insulation wiring		cable before turning on the power.		
Check fo	or possible shaft lock,	Troubleshoot the motor shaft lock.		
burnout	or aging insulation of the	Check the motor insulation value with megger. Replace the motor if the		
motor		insulation is poor.		
Impulsive change of the load Reduce		Reduce the load or incr	ease the capacity of AC motor drive.	

Use special motor or motor with	Check motor capacity (the rated current on the motor's nameplate should ≤ the		
larger capacity than the drive	rated current of the drive)		
Use ON/OFF controller of an	Check the action timing of the contactor and make cure it is not turned ON/OFF		
electromagnetic contactor at the	Check the action timing of the contactor and make sure it is not turned ON/OFF		
output (U/V/W) of the drive	when the drive outputs the voltage.		
V/F curve setting error	Adjust the V/F curve settings and frequency/voltage. When the fault occurs, and		
V/F curve setting error	the frequency voltage is too high, reduce the voltage.		
Torque compensation is too large.	Adjust the torque compensation (refer to Pr.07-26 torque compensation gain)		
Torque compensation is too large.	until the output current reduces and the motor does not stall.		
Malfunction caused by interference	Verify the wiring of the control circuit and the wiring/grounding of the main circuit		
Manufiction caused by interference	to prevent interference.		
The length of motor cable is too	Increase the AC motor drive's capacity.		
long	Install AC reactor(s) on the output side (U/V/W).		
	The ocn occurs due to the short circuit or ground fault at the output side of the		
	drive.		
Hardware failure	Check for possible short circuit between terminals with the electric meter:		
Hardware failure	B1 corresponds to U, V and W; DC- corresponds to U, V, and W;		
	corresponds to U, V, and W.		
	If short circuits occurs, return to the factory for repair.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
	, , , , , , , , , , , , , , , , , , , ,		When the drive detects grounding short circuit on the	
_		Ground fault	output terminals (U/V/W), the drive closes the gate of	
4	SFF	(GFF)	the output immediately, the motor runs freely, and the	
			display shows a GFF error.	
		Action and	d Reset	
	Action level	N/A		
	Action time	N/A		
Fau	lt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds a	fter the fault is cleared	
	Record	Yes		
Cause		Corrective Actions		
Motor bu	urnout or aging insulation	Check the motor insulation value with megger.		
occurred		Replace the motor if the insulation is poor.		
Short cir	cuit due to broken cable	Troubleshoot the short circuit.		
Onort on	cuit due to broker ouble	Replace the cable.		
l arger s	tray capacitance of the	If the motor cable length exceeds 100 m, decrease the setting value for the		
_	nd terminal	carrier frequency.		
		Take remedies to reduce stray capacitance.		
		Verify the grounding and wiring of the communication circuit. It is recommended		
Malfunc	tion caused by interference	to separate the communication circuit from the main circuit, or wire in 90 degree		
		for effective anti-interference performance.		
 Hardware failure		Cycle the power after checking the status of motor, cable and cable length. If		
		GFF still exists, return to the factory for repair.		
Over-current at constant speed		Refer to the corrective actions for ocn.		
Over-current during acceleration		Refer to the corrective actions for ocA.		
Over-current during deceleration		Refer to the corrective actions for ocd.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
6	oc S	Over-current at stop (ocS)	Over-current or hardware failure in current detection at stop. Cycle the power after ocS occurs. If the hardware failure	
		, ,	occurs, the display shows cd1, cd2 or cd3.	
		Action and	d Reset	
	Action level	300% of the rated curre	ent	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds after the fault is cleared		
	Record	Yes		
	Cause	Corrective Actions		
Malfunction caused by interference		Verify the wiring of the control circuit and the wiring/grounding of the main circuit to prevent interference.		
Hardware failure		Check if other error codes such as cd1–cd3 occur after cycling the power. If yes, return to the factory for repair.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
7	οūЯ	Over-voltage during acceleration (ovA)	DC bus over-voltage during acceleration. When ovA occurs, the drive closes the gate of the output, the motor runs freely, and the display shows an ovA error.	
		Action and Reset		
Action level		230V series: 410 V _{DC} 460V series: 820 V _{DC} 575V series: 1116 V _{DC}		
	Action time	Immediately act when t	ne DC bus voltage is higher than the level	
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
Reset condition		Reset only when the DC bus voltage is lower than 90% of the over-voltage level		
Record		Yes		
Cause			Corrective Actions	
lifting loa	ation is too slow (e.g. hen ad decreases acceleration	The state of the s		
time)		Replace the drive with a larger capacity model.		
	ing for stall prevention smaller than no-load	The setting for the stall	prevention level should be larger than no-load current	
Power voltage is too high		Check if the input voltage is within the rated AC motor drive input voltage range, and check for possible voltage spikes.		
	switch action of phase-in or in the same power	If the phase-in capacitor or active power supply unit acts in the same power system, the input voltage may surge abnormally in a short time. In this case, install an AC reactor.		
Regenerative voltage of motor inertia		Use over-voltage stall prevention function (Pr.06-01) Use auto-acceleration and auto-deceleration setting (Pr.01-44) Use a braking unit or DC bus		

	Check if the over-voltage warning occurs after acceleration stops.		
	When the warning occurs, do the following:		
Acceleration time is too short	Increase the acceleration time		
	Set Pr.06-01 over-voltage stall prevention		
	3. Increase the setting value for Pr.01-25 S-curve acceleration arrival time 2		
	The ground short circuit current charges the capacitor in the main circuit through		
Matar avaluad fault	the power. Check if there is ground fault on the motor cable, wiring box and its		
Motor ground fault	internal terminals.		
	Troubleshoot the ground fault.		
Incorrect wiring of brake resistor or	Charletha wining of the hyples register and hyples writ		
brake unit	Check the wiring of the brake resistor and braking unit.		
Nalfunction council by interference	Verify the wiring of the control circuit and the wiring/grounding of the main circuit		
Malfunction caused by interference	to prevent interference.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
8	oūd	Over-voltage during deceleration (ovd)	DC bus over-voltage during deceleration. When ovd occurs, the drive closes the gate of the output immediately, the motor runs freely, and the display shows an ovd error.	
		Action and Reset		
Action level		230V series: 410 V _{DC} 460V series: 820 V _{DC} 575V series: 1116 V _{DC}		
	Action time	Immediately act when t	he DC bus voltage is higher than the level	
Fau	ılt treatment parameter	N/A	-	
	Reset method	Manual reset		
	Reset condition	Reset only when the D0	C bus voltage is lower than 90% of the over-voltage level	
	Record	Yes		
	Cause	Corrective Actions		
Deceleration time is too short, causing too large regenerative energy of the load		(deceleration time) 2. Connect the brake 3. Reduce the brake f 4. Replace the drive w 5. Use S-curve accele 6. Use over-voltage st 7. Use auto-acceleration	vith a larger capacity model.	
	ing for stall prevention smaller than no-load	The setting for the stall prevention level should be larger than no-load current		
Power v	oltage is too high	Check if the input voltage is within the rated AC motor drive input voltage range, and check for possible voltage spikes.		
	switch action of phase-in or in the same power	If the phase-in capacitor or active power supply unit acts in the same power system, the input voltage may surge abnormally in a short time. In this case, install an AC reactor.		
System		install all AO Todotol.		

Motor ground fault	The ground short circuit current charges the capacitor in the main circuit through the power. Check if there is ground fault on the motor cable, wiring box and its internal terminals.
Incorrect wiring of brake resistor or	Troubleshoot the ground fault.
brake unit	Check the wiring of the brake resistor or braking unit.
IMaltunction caused by interterence	Verify the wiring of the control circuit and the wiring/grounding of the main circuit to prevent interference.

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
9	oūn	Over-voltage during constant speed (ovn)	DC bus over-voltage at constant speed. When ovn occurs, the drive closes the gate of the output immediately, the motor runs freely, and the display shows an ovn error.	
		Action and Reset		
Action level		230V series: 410 V _{DC} 460V series: 820 V _{DC} 575V series: 1116 V _{DC}		
	Action time	Immediately act when the	he DC bus voltage is higher than the level	
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset only when the DO	C bus voltage is lower than 90% of the over-voltage level	
	Record	Yes		
	Cause		Corrective Actions	
Impulsiv	e change of the load	 Connect the brake resistor, braking unit or DC bus to the drive. Reduce the load. Replace the drive with a larger capacity model. Adjust the braking level (Pr.07-01 or bolt position of the brake unit). 		
The setting for stall prevention level is smaller than no-load current		The setting of the stall prevention level should be larger than no-load current		
Regenei inertia	rative voltage of motor	Use over-voltage stall prevention function (Pr.06-01) Use a braking unit or DC bus		
Power v	oltage is too high	Check if the input voltage is within the rated AC motor drive input voltage range, and check for possible voltage spikes.		
	switch action of phase-in r in the same power	· · · · · · · · · · · · · · · · · · ·		
Motor ground fault		The ground short circuit current charges the capacitor in the main circuit through the power. Check if there is ground fault on the motor cable, wiring box and its internal terminals. Troubleshoot the ground fault.		
Incorrec brake ur	t wiring of brake resistor or nit	Check the wiring of the brake resistor or braking unit.		
Malfunction caused by interference		Verify the wiring of the or to prevent interference.	control circuit and the wiring/grounding of the main circuit	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
10	oū5	Over-voltage at stop (ovS)	Over-voltage at stop	
		Action and	d Reset	
		230V series: 410 V _{DC}		
	Action level	460V series: 820 V _{DC}		
		575V series: 1116 V _{DC}		
	Action time	Immediately act when the	ne DC bus voltage is higher than the level	
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset only when the DO	C bus voltage is lower than 90% of the over-voltage level	
	Record	Yes		
	Cause	Corrective Actions		
Power v	oltage is too high	Check if the input voltage is within the rated AC motor drive input voltage range,		
		and check for possible voltage spikes.		
	·	If the phase-in capacitor or active power supply unit activates in the same power		
	r in the same power	system, the input voltage may surge abnormally in a short time. In this case,		
system		install an AC reactor.		
Incorrect brake ur	t wiring of brake resistor or	Check the wiring of the brake resistor or braking unit.		
brake ur	III.	Validada a dinima de da a a da a a da a a dinima/ana a dina de dinima/ana a dina de dina de dinima de da a dinima de da dinima de		
Malfunc	tion caused by interference	Verify the wiring of the control circuit and the wiring/grounding of the main circuit to prevent interference.		
Llandingua failum in valtana		·		
Hardware failure in voltage detection		Check if other error codes such as cd1–cd3 occur after cycling the power. If yes, return to the factory for repair.		
detectio	11	· ·		
		The ground short circuit current charges the capacitor in the main circuit through the power. Check if there is ground fault on the motor cable, wiring box and its		
Motor gi	ound fault	internal terminals.		
		Troubleshoot the ground fault.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
11	LūR	Low-voltage during acceleration (LvA)	DC bus voltage is lower than Pr.06-00 setting value during acceleration	
		Action and	d Reset	
	Action level	Pr.06-00 (Default = dep	ending on the model)	
	Action time	Immediately act when the	he DC bus voltage is lower than Pr.06-00	
Fault treatment parameter		N/A		
Reset method		Manual reset		
	Reset condition	Reset when the DC bus voltage is higher than Pr.06-00 + 30 V		
Record		Yes		
	Cause	Corrective Actions		
Power-c	off	Improve power supply condition.		
Power v	oltage changes	Adjust voltage to the power range of the drive		
Start up	the motor with large	Check the power system.		
capacity		Increase the capacity of power equipment.		
		Reduce the load.		
The load	d is too large	Increase the drive capacity.		
		Increase the acceleration time.		

DC bus	Install DC reactor(s).
lor any DC reactor installed	Connect short circuit plate or DC reactor between terminal +1 and +2. If the error still exists, return to the factory for repair.

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
12	Lūd	Low-voltage during deceleration (Lvd)	DC bus voltage is lower than Pr.06-00 setting value during deceleration	
		Action and	d Reset	
	Action level	Pr.06-00 (Default = dep	ending on the model)	
	Action time	Immediately act when the	he DC bus voltage is lower than Pr.06-00	
Fau	ılt treatment parameter	NA		
	Reset method	Manual reset		
	Reset condition	Reset when the DC bus voltage is higher than Pr.06-00 + 30 V		
	Record	Yes		
Cause		Corrective Actions		
Power-c	off	Improve power supply condition.		
Power v	oltage changes	Adjust voltage to the power range of the drive.		
Start up	the motor with large	Check the power system.		
capacity		Increase the capacity of power equipment.		
Sudden	load	Reduce the load.		
Sudden	IUdu	Increase the drive capacity.		
DC bus	DC bus Install DC reactor(s).			

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
13	Lūn	Low-voltage at constant speed (Lvn)	DC bus voltage is lower than Pr.06-00 setting value at constant speed	
		Action and	d Reset	
	Action level	Pr.06-00 (Default = dep	ending on the model)	
	Action time	Immediately act when the	he DC bus voltage is lower than Pr.06-00	
Fau	ılt treatment parameter	NA		
	Reset method	Manual reset		
	Reset condition	Reset when the DC bus voltage is higher than Pr.06-00 + 30 V		
	Record	Yes		
	Cause	Corrective Actions		
Power-c	off	Improve power supply condition.		
Power v	oltage changes	Adjust voltage to the power range of the drive		
Start up	the motor with large	Check the power system.		
capacity		Increase the capacity of power equipment.		
Sudden load		Reduce the load.		
Sudden	ioau	Increase the drive capacity.		
DC bus	·	Install DC reactor(s).		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
14	LūS	Low-voltage at stop (LvS)	 DC bus voltage is lower than Pr.06-00 setting value at stop Hardware failure in voltage detection 	
		Action and	d Reset	
	Action level	Pr.06-00 (Default = dep	ending on the model)	
	Action time	Immediately act when t	he DC bus voltage is lower than Pr.06-00	
Fau	ılt treatment parameter	N/A		
	Reset method	Manual / Auto: 230V series: Lv level + 30 V_{DC} + 500 ms 460V series: Lv level + 60 V_{DC} + 500 ms 575V series: Lv level + 75 V_{DC} + 500 ms		
	Reset condition	500 ms		
	Record	Yes		
	Cause		Corrective Actions	
Power-c	off	Improve power supply of	condition.	
Incorrec	ct drive models	Check if the power spec	cification matches the drive.	
		Adjust voltage to the power range of the drive.		
Power voltage changes		Cycle the power after checking the power. If LvS error still exists, return to the factory for repair.		
Start up	rt up the motor with large Check the power system.		n.	
capacity	Increase the capacity of power equipment.		f power equipment.	
DC bus		Install DC reactor(s).		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
15	orp	Phase loss protection (orP)	Phase loss of power input	
		Action and	l Reset	
Action level		When DC bus ripple is higher than the protection level, and the output current exceeds 50% of the rated current, the drive starts counting. When the counting value reaches the upper limit, an orP error occurs.		
	Action time	The action time varies v	vith different output current.	
Fau	lt treatment parameter	Pr.06-53		
	Reset method	Manual reset		
	Reset condition	Immediately reset when DC bus is higher than Pr.07-00		
	Record	Yes		
	Cause	Corrective Actions		
Phase lo	oss of input power	Correctly install the wiring of the main circuit power.		
Single phase power input to three-phase model		Choose the model whose power matches the voltage.		
Power voltage changes		If the main circuit power works normally, verify the main circuit. Cycle the power after checking the power, if orP error still exists, return to the factory for repair.		
Loose w	riring terminal of input	Tighten the terminal screws according to the torque described in the user		
power		manual.		
The inpu	ut cable of three-phase Wire correctly.			
power is	cut off	Replace the cut off cable.		
Input po	wer voltage changes too	Verify the setting value for Pr.06-50 Time for Input Phase Loss Detection and		
much		Pr.06-52 Ripple of Input Phase Loss		

Unbalanced three-phase of input	Check the power three-phase status.
power	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions				
16	o#	IGBT overheating (oH1)	IGBT temperature exceeds the protection level.				
	Action and Reset						
		Depending on the model power, refer to Table 1 below.					
Action level		When the setting for Pr.06-15 is higher than the oH1 level, oH1 error occurs					
		instead of oH1 warning. An IGBT overheating error occurs, and the drive stops.					
Fault treatment parameter		N/A					
Reset method		Manual reset					
Reset condition		Reset only when IGBT temperature is lower than oH1 error level minus (-) 10°C					
Record		Yes					
	Cause	Corrective Actions					
Check if the ambient temperature or temperature inside the control cabinet is too high, or if there is obstruction in the ventilation hole of the control cabinet.		 Check ambient temperature. Regularly inspect the ventilation hole of the control cabinet. Change the installed place if there are heating objects, such as brake resistors, in the surroundings. Install/ add cooling fan or air conditioner to lower the temperature inside the cabinet. 					
Check if there is any obstruction on the heat sink or if the fan is running.		Remove the obstruction or replace the cooling fan.					
Insufficient ventilation space In		ncrease ventilation space of the drive.					
Check if the drive matches the corresponding load		 Reduce the load Reduce the carrier wave Replace the drive with a larger capacity model. 					
	e has run 100% or more 0% of the rated output for a e	Replace the drive with a	a larger capacity model.				

Table 1

Valtaria	Model	OH1	Default for Pr.06-15
Voltage	(Note: x = A or E)	(°C)	(°C)
	VFD1A6MS11x□□A□	95	90
Single-phase_115V	VFD2A5MS11x□□A□	95	90
	VFD4A8MS11x□□A□	100	95
	VFD1A6MS21x□□A□	110	105
	VFD2A8MS21x□□A□	100	95
Single-phase_230V	VFD4A8MS21x□□A□	110	105
	VFD7A5MS21x□□A□	105	100
	VFD11AMS21x□□A□	115	110
	VFD1A6MS23x□□A□	100	95
Three-phase_230V	VFD2A8MS23x□□A□	100	95
	VFD4A8MS23x□□A□	105	100

Voltage	Model	OH1	Default for Pr.06-15
Voltage	(Note: x = A or E)	(°C)	(°C)
	VFD7A5MS23x□□A□	105	100
	VFD11AMS23x□□A□	95	90
	VFD17AMS23x□□A□	105	100
Three-phase_230V	VFD25AMS23x□□A□	115	110
	VFD33AMS23x□□A□	115	110
	VFD49AMS23x□□A□	115	110
	VFD65AMS23x□□A□	115	110
	VFD1A5MS43x□□A□	105	100
	VFD2A7MS43x□□A□	115	110
	VFD4A2MS43x□□A□	105	100
	VFD5A5MS43x□□A□	95	90
	VFD7A3MS43x□□A□	100	95
Three phase 4001/	VFD9A0MS43x□□A□	115	110
Three-phase_460V	VFD13AMS43x□□A□	105	100
	VFD17AMS43x□□A□	115	110
	VFD25AMS43x□□A□	115	110
	VFD32AMS43x□□A□	115	110
	VFD38AMS43x□□A□	110	105
	VFD45AMS43x□□A□	115	110

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions		
		IGBT temperature			
18	t X lo	detection failure	IGBT hardware failure in temperature detection		
		(tH1o)			
		Action and	d Reset		
	Action level	NTC broken or wiring fa	illure		
	Action time	When the IGBT temperature is higher than the protection level, and detection			
	Action time	time exceeds 100 ms, the tH1o protection activates.			
Fau	ılt treatment parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Immediately reset			
Record		Yes			
Cause			Corrective Actions		
Hardwa	ro foiluro	Wait for 10 minutes, and then cycle the power. Check if tH1o protection still			
пагома	re failure	exists. If yes, return to the factory for repair.			

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
21	oί	Over load (oL)	The AC motor drive detects excessive drive output current. Overload capacity: Normal duty: Sustains for one minute when the drive outputs 120% of the drive's rated output current. Sustains for three seconds when the drive outputs 150% of the drive's rated output current. Heavy duty: Sustains for one minute when the drive outputs 150% of the drive's rated output current. Sustains for three seconds when the drive outputs 200% of the drive's rated output current.	
		Action and	d Reset	
	Action level	Based on overload curv	ve and derating curve (refer to Section 9-7).	
	Action time	the oL protection activa	r than the protection level and exceeds allowable time, tes.	
Fau		N/A		
		Manual reset		
	Reset condition	Reset in five seconds after the fault is cleared		
	Record	Yes		
	Cause		Corrective Actions	
The load	d is too large	Reduce the load		
	ecel. time or the working e too short	Increase the setting value for Pr.01-12–01-19 (accel./decel. time)		
V/F volta	age is too high	Adjust the settings for Pr.01-01-01-08 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too low, the load capacity decreases at low speed). Refer to the V/F curve selection of Pr.01-43.		
The cap	acity of the drive is too	Replace the drive with a larger capacity model.		
Overload operatio	d during low-speed n	Reduce the load during low-speed operation. Increase the drive capacity. Decrease the carrier frequency of Pr.00-17.		
Torque o	compensation is too large	Adjust the torque compensation (refer to Pr.07-26 Torque Compensation Gain) until the output current reduces and the motor does not stall.		
Check if the setting for stall prevention is correct.		Set the stall prevention to the proper value.		
Output p	phase loss	Check the status of thre	ee-phase motor. oken or the screws are loose.	
Improper parameter settings for the speed tracking function (including restart after momentary) Correct the parameter settings for Correct the parameter settings for the speed tracking function		1. Start the speed trac	settings for speed tracking. cking function. m current for Pr.07-09 speed tracking.	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions		
		Electronics thermal	·		
22	Eol I	relay 1 protection	Electronics thermal relay 1 protection. The drive coasts		
		(EoL1)	to stop once it activates.		
		Action and Reset			
	Action level	Start counting when the	output current > 150% of the motor 1 rated current		
	Action time	Pr.06-14 (If the output current is larger than 105% of the motor 1 rated current			
	Action time	again within 60 sec., the counting time reduces and is less than Pr.06-14)			
Fau	t treatment parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Reset in five seconds a	fter the fault is cleared		
	Record	Yes			
	Cause		Corrective Actions		
	is too large	Reduce the load.			
	ecel. time or the working	Increase the setting val	ues for Pr.01-12–01-19 (accel./decel. time)		
cycle is t	oo short				
		,	Pr.01-01-01-08 (V/F curve), especially the setting value		
V/F volta	ige is too high	for the mid-point voltage (if the mid-point voltage is set too low, the load capacity			
		decreases at low speed).			
		Refer to the V/F curve s	selection of Pr.01-43.		
	d during low-speed				
operation		Decrease low-speed operation time.			
	sing a general motor, even	Replace the drive with a dedicated to VFD model.			
	es below rated current, an	Increase the motor capacity.			
	may still occur during				
	ed operation.				
	sing VFD dedicated	Dr. OC 12-1 alastrania th	samuel velev celestics meetes 4 - standard meetes (meetes		
	Pr.06-13=0 (electronic relay selection motor 1 =		nermal relay selection motor 1 = standard motor (motor		
inverter	•	with fan on the shaft).			
	value of electronic				
thermal		Reset to the correct mo	tor rated current.		
	imum motor frequency is				
set too lo	• •	Reset to the correct mo	tor rated frequency.		
		Set Pr.06-13=2 electron	nic thermal relay selection motor 1= disable, and install		
One driv	e to multiple motors	thermal relay on each n			
Check if	the setting for stall	-			
prevention is correct.		Set the stall prevention	to the proper value.		
Torque	omnonaction is too ler	Adjust the torque comp	ensation (refer to Pr.07-26 torque compensation gain)		
rorque d	ompensation is too large	until the current reduces and the motor does no stall.			
Motor fa	n error	Check the status of the fan, or replace the fan.			
Unbalan	ced three-phase	Replace the motor.			
impedan	ce of the motor	nteplace the motor.			

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions			
	, ,	Electronic thermal	·			
23	Eold	relay 2 protection	Electronic thermal relay 2 protection. The drive coasts			
		(EoL2)	to stop once it activates.			
		Action and Reset				
	Action level	Start counting when the output current > 150% of the motor 2 rated current				
	A ation time	Pr.06-28 (If the output current is larger than 105% of the motor 2 rated current				
	Action time	again within 60 sec., the counting time reduces and is less than Pr.06-28)				
Fau	It treatment parameter	N/A				
	Reset method	Manual reset				
	Reset condition	Reset in five seconds a	fter the fault is cleared			
	Record	Yes				
	Cause		Corrective Actions			
The load	l is too large	Reduce the load				
Accel./D	ecel. time or the working	Increase the setting val	ues for Pr.01-12–01-19 (accel./decel. time)			
cycle are	e too short	increase the setting var	des for F1.01-12-01-19 (accel./decel. time)			
		Adjust the settings for F	Pr.01-35–01-42 (V/F curve), especially the setting value			
V/E volta	nge is too high	for the mid-point voltage	e (if the mid-point voltage is set too low, the load capacity			
V/F VOILE	ige is too nign	decreases at low speed).				
		Refer to the V/F curve selection setting of Pr.01-43.				
Overload	d during low-speed					
operatio	n.	Doorooo low abood on	poration time			
When us	sing general motor, even it	Decrease low-speed operation time.				
operates	below rated current, an	Replace the drive with a dedicated to VFD model.				
overload	may still occur during	Increase the motor capacity.				
low-spee	ed operation.					
When us	sing VFD dedicated					
motors, I	Pr.06-27=0 (electronic	Pr.06-27=1 Electronic thermal relay selection motor 2 = standard motor (motor				
thermal i	relay selection motor 2 = 0	with fan on the shaft).				
inverter ı	motor)					
Incorrect	t value of electronic	Reset to the correct mo	tor rated current			
thermal ı	relay	Veser to the collect IIIO	noi rateu current.			
The max	imum motor frequency is	Reset to the correct mo	tor rated frequency			
set too lo	DW .	Neset to the correct mo	ioi rateu irequericy.			
One driv	e to multiple motors	Set Pr.06-27=2 Electronic thermal relay selection motor 2 = disable, and install				
One unv	e to multiple motors	thermal relay on each motor.				
Check if	the setting for stall	Set the stall prevention	to the proper value			
prevention	on is correct.	Oct the stall prevention	to the proper value.			
Torque	compensation is too large	Adjust the torque comp	ensation (refer to Pr.07-71 torque compensation gain)			
Torque C	ompensation is too large	until the current reduces and the motor does no stall.				
Motor fa	n error	Check the status of the	fan, or replace the fan.			
Unbalan	ced three-phase	Replace the motor.				
impedan	ce of the motor	TOPIAGE THE HIGH.				

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions		
	, , , , , , , , , , , , , , , , , , , ,		Motor overheating (PTC) (Pr.03-00–Pr.03-01=6 PTC),		
24_1	ox3	Motor overheating	when PTC input > Pr.06-30, the fault treatment acts		
_		(oH3) PTC	according to Pr.06-29.		
		Action and Reset			
	Action level	PTC input value > Pr.06-30 setting (Default = 50%)			
	Action time	Immediately act			
		Pr.06-29			
		0: Warn and continue o	peration		
Fau	ılt treatment parameter	1: Fault and ramp to sto	рр		
		2: Fault and coast to sto	рр		
		3: No warning			
	Deart weatherd	When Pr.06-29=0, oH3	is a "Warning". The "Warning" is automatically cleared.		
	Reset method	When Pr.06-29=1 or 2,	oH3 is a "Fault". You must reset manually.		
	Reset condition	Immediately reset			
	Record	When Pr.06-29=1 or 2,	oH3 is a "Fault", and the fault is recorded.		
	Cause		Corrective Actions		
Motor sh	naft lock	Remove the shaft lock.			
The leas	d is too large	Reduce the load.			
THE IOAC	d is too large	Increase the motor capacity.			
∆mhient	t temperature is too high	Change the installed place if there are heating devices in the surroundings.			
Allibielii	t temperature is too nigh	Install/ add cooling fan or air conditioner to lower the ambient temperature.			
Motor co	poling system error	Check the cooling syste	em to make it work normally.		
Motor fa	an error	Replace the fan.			
		Decrease low-speed operation time.			
Operate	at low-speed too long.	Replace the motor with a dedicated to VFD model.			
		Increase the motor capacity.			
Accel./D	ecel. time and working	Increase the setting val	ues for Pr.01-12–01-19 (accel./decel. time)		
cycle are	e too short		,		
		, ,	I-01–01-08 (V/F curve), especially the setting value for		
V/F volta	age is too high		the mid-point voltage is set too low, the load capacity		
		decreases at low speed	l).		
	f the motor rated current				
matches that on the motor		Reset to the correct mo	tor rated current.		
namepla					
Check if the PTC is properly set		Check the connection b	etween PTC thermistor and the heat protection.		
and wire			·		
	the setting for stall	Set the stall prevention	to the proper value.		
•	on is correct.	,			
	nced three-phase	Replace the motor.			
	nce of the motor		. L		
Harmon	ics are too high.	Use remedies to reduce harmonics.			

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
24_2	o X 3	Motor overheating (oH3) PT100	Motor overheating (PT100) (Pr.03-00–Pr.03-01=11 PT100). When PT100 input > Pr.06-57 (default = 7 V), the fault treatment acts according to Pr.06-29.	
		Action and Reset		
	Action level	PT100 input value > Pr.06-57 setting (default = 7 V)		
	Action time	Immediately act		
Fault treatment parameter		Pr.06-29 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning		
	Reset method		he temperature < Pr.06-56, oH3 is automatically cleared. oH3 is a "Fault". You must reset manually.	
	Reset condition	Immediately reset		
	Record	When Pr.06-29=1 or 2,	oH3 is a "Fault", and the fault is recorded.	
	Cause		Corrective Actions	
Motor sh	aft lock	Remove the shaft lock.		
The load	l is too large	Reduce the load. Increase the motor capacity.		
Ambient	temperature is too high		ace If there are heating devices in the surroundings. or air conditioner to lower the ambient temperature.	
Motor co	ooling system error	Check the cooling syste	em to make it work normally.	
Motor fa	n error	Replace the fan.		
Operate	Decrease low-speed operation time. Replace the motor with a dedicated to VFD model. Increase the motor capacity.		a dedicated to VFD model.	
	ecel. time and working e too short	Increase the setting values for Pr.01-12–Pr.01-19 (accel./decel. time)		
V/F volta	age is too high	Adjust settings for Pr.01-01-08 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too low, the load capacity decreases at low speed).		
_	the motor rated current that on the motor tte.	Reset to the correct motor rated current.		
Check if and wire	the PT100 is properly set d.	Check connection of PT100 thermistor.		
	the setting for stall on is correct.	Set the stall prevention to the proper value.		
impedan	ced three-phase ace of the motor	Replace the motor.		
Harmoni	cs are too high	Use remedies to reduce	e harmonics.	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
ID	Display on LCD Reypau	i auit Naine	When the output current exceeds the over-torque	
26 0 1	Over torque 1	detection level (Pr.06-07) and exceeds over-torque		
	o	(ot1)	detection time (Pr.06-08), and when Pr.06-06 or	
		(011)	Pr.06-09 is set to 2 or 4, the ot1 error displays.	
		Action and Reset		
	Action level	Pr.06-07		
	Action time	Pr.06-08		
	Action time	Pr.06-06		
		0: No function		
Fau	ılt treatment parameter		fter over-torque detection during constant speed	
		2: Stop after over-torque	e detection during constant speed operation	
		•	fter over-torque detection during RUN	
		4: Stop after over-torque	e detection during RUN	
	Reset method	Auto When Pr.06-0	6=1 or 3, ot1 is a "Warning". The warning is	
	Reset condition	automatically	cleared when the output current < (Pr.06-07 – 5%)	
	1 COOL CONTRIBUTION	Manual When Pr.06-06=2 or 4, ot1 is a "Fault". You must reset manually.		
	Record	Immediately reset		
	Active level	When Pr.06-06=2 or 4,	ot1 is a "Fault", and the fault is recorded.	
	Cause		Corrective Actions	
Incorrec	t parameter setting	Configure the settings for Pr.06-07 and Pr.06-08 again.		
	ical failure (e.g. que, mechanical lock)	Remove the causes of ı	malfunction.	
The lead	d is too large	Reduce the load.		
THE IOA	u is too large	Replace the motor with a larger capacity model.		
	Decel. time and working e too short	Increase the setting val	ues for Pr.01-12–Pr.01-19 (accel./decel. time)	
		Adjust the V/F curve (M	otor 1, Pr.01-01-01-08), especially the setting value for	
V/F volta	age is too high	the mid-point voltage (if	the mid-point voltage is set too low, the load capacity	
		decreases at low speed).		
The mot	tor capacity is too small	Replace the motor with	a larger capacity model.	
Overloa	d during low-speed	Decrease low-speed op	peration time.	
operatio	n	Increase the motor capacity.		
Torque (compensation is too large	Adjust the torque comp	ensation (refer to Pr.07-26 torque compensation gain)	
Torque	compensation is too large	until the current reduces	s and the motor does no stall.	
	er parameter settings for	Correct the parameter s	settings for speed tracking	
_	acking function (including	Correct the parameter settings for speed tracking. 1. Start the speed tracking function.		
	ifter momentary power loss	· ·	um current for Pr.07-09 speed tracking.	
and restart after fault)		, rajast tilo maximo	and sand the first of speed additing.	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
	, , - ,,		When the output current exceeds the over-torque	
27 062	Over torque 2	detection level (Pr.06-10) and exceeds over-torque		
	000	(ot2)	detection time (Pr.06-11), and when Pr.06-09 is set to 2	
			or 4, the ot2 error displays.	
		Action and		
Action level		Pr.06-10		
	Action time	Pr.06-11		
		Pr.06-09		
		0: No function		
		1: Continue operation a	ofter over-torque detection during constant speed	
Fau	It treatment parameter	operation	,	
	·	2: Stop after over-torqu	e detection during constant speed operation	
			ifter over-torque detection during RUN	
		4: Stop after over-torque		
		When Pr.06-0	9=1 or 3, ot2 is a "Warning". The warning is	
	Reset method	I AUTO I	cleared when the output current < (Pr.06-10 – 5%).	
	Reset condition	Manual When Pr.06-09=2 or 4, ot2 is a "Fault". You must reset manually.		
	Record	Immediately reset	·	
	Active level	When Pr.06-09=2 or 4,	ot2 is a "Fault", and the fault is recorded.	
		Corrective Actions		
	Cause			
Incorrec	Cause t parameter setting	Configure the settings f		
	-		Corrective Actions for Pr.06-10 and Pr.06-11 again.	
Mechani	t parameter setting	Configure the settings f	Corrective Actions for Pr.06-10 and Pr.06-11 again.	
Mechani over-toro	t parameter setting ical failure (e.g. que, mechanical lock)	Remove the causes of Reduce the load.	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction.	
Mechani over-toro	t parameter setting ical failure (e.g.	Remove the causes of Reduce the load.	Corrective Actions for Pr.06-10 and Pr.06-11 again.	
Mechani over-toro The load Accel./D	t parameter setting ical failure (e.g. que, mechanical lock) d is too large.	Remove the causes of Reduce the load. Replace the motor with	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction. a larger capacity model.	
Mechani over-toro The load Accel./D	t parameter setting ical failure (e.g. que, mechanical lock) d is too large.	Remove the causes of Reduce the load. Replace the motor with Increase the setting val	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction. a larger capacity model. ues for Pr.01-12–01-19 (accel./decel. time).	
Mechani over-tord The load Accel./D cycle are	t parameter setting ical failure (e.g. que, mechanical lock) d is too large. ecel. time and working e too short	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the V/F curve (M	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction. a larger capacity model. ues for Pr.01-12–01-19 (accel./decel. time). lotor 2, Pr.01-35–01-42), especially the setting value for	
Mechani over-tord The load Accel./D cycle are	t parameter setting ical failure (e.g. que, mechanical lock) d is too large.	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the V/F curve (M) the mid-point voltage (if	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction. a larger capacity model. ues for Pr.01-12–01-19 (accel./decel. time). dotor 2, Pr.01-35–01-42), especially the setting value for the mid-point voltage is set too low, the load capacity	
Mechani over-tord The load Accel./D cycle are	t parameter setting ical failure (e.g. que, mechanical lock) d is too large. ecel. time and working e too short age is too high	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the V/F curve (M) the mid-point voltage (if decreases at low speed	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction. a larger capacity model. ues for Pr.01-12–01-19 (accel./decel. time). lotor 2, Pr.01-35–01-42), especially the setting value for f the mid-point voltage is set too low, the load capacity st).	
Mechaniover-toro The load Accel./D cycle are V/F volta The mot	t parameter setting ical failure (e.g. que, mechanical lock) d is too large. eccel. time and working e too short age is too high	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the V/F curve (M the mid-point voltage (if decreases at low speed Replace the motor with	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction. a larger capacity model. ues for Pr.01-12–01-19 (accel./decel. time). lotor 2, Pr.01-35–01-42), especially the setting value for f the mid-point voltage is set too low, the load capacity style. a larger capacity model.	
Mechaniover-toro The load Accel./D cycle are V/F volta The mot Overload	t parameter setting ical failure (e.g. que, mechanical lock) d is too large. ecel. time and working e too short age is too high or capacity is too small d during low-speed	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the V/F curve (M the mid-point voltage (if decreases at low speed Replace the motor with Decrease low-speed or	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction. a larger capacity model. ues for Pr.01-12–01-19 (accel./decel. time). dotor 2, Pr.01-35–01-42), especially the setting value for f the mid-point voltage is set too low, the load capacity st). a larger capacity model. peration time.	
Mechaniover-toro The load Accel./D cycle are V/F volta The mot	t parameter setting ical failure (e.g. que, mechanical lock) d is too large. ecel. time and working e too short age is too high or capacity is too small d during low-speed	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the V/F curve (Mother mid-point voltage (if decreases at low speed Replace the motor with Decrease low-speed op Increase the motor cap	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction. a larger capacity model. ues for Pr.01-12–01-19 (accel./decel. time). flotor 2, Pr.01-35–01-42), especially the setting value for f the mid-point voltage is set too low, the load capacity fl). a larger capacity model. beration time. acity.	
Mechaniover-toro The load Accel./D cycle are V/F volta The mot Overload operatio	t parameter setting ical failure (e.g. que, mechanical lock) d is too large. eccel. time and working e too short age is too high or capacity is too small d during low-speed	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the V/F curve (M the mid-point voltage (if decreases at low speed Replace the motor with Decrease low-speed op Increase the motor capa Adjust the torque comp	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction. a larger capacity model. ues for Pr.01-12–01-19 (accel./decel. time). dotor 2, Pr.01-35–01-42), especially the setting value for f the mid-point voltage is set too low, the load capacity d). a larger capacity model. peration time. acity. ensation (refer to Pr.07-71 torque compensation gain)	
Mechaniover-toro The load Accel./D cycle are V/F volta The mot Overload operatio	t parameter setting ical failure (e.g. que, mechanical lock) d is too large. ecel. time and working e too short age is too high or capacity is too small d during low-speed	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the V/F curve (M the mid-point voltage (if decreases at low speed Replace the motor with Decrease low-speed op Increase the motor capa Adjust the torque comp	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction. a larger capacity model. ues for Pr.01-12–01-19 (accel./decel. time). flotor 2, Pr.01-35–01-42), especially the setting value for f the mid-point voltage is set too low, the load capacity fl). a larger capacity model. beration time. acity.	
Mechaniover-toro The load Accel./D cycle are V/F volta The mot Overload operatio Torque of	t parameter setting ical failure (e.g. que, mechanical lock) d is too large. eccl. time and working e too short age is too high or capacity is too small d during low-speed n compensation is too large r parameter settings for	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the V/F curve (M the mid-point voltage (if decreases at low speed Replace the motor with Decrease low-speed op Increase the motor cap Adjust the torque comp until the current reduce	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction. a larger capacity model. ues for Pr.01-12–01-19 (accel./decel. time). dotor 2, Pr.01-35–01-42), especially the setting value for f the mid-point voltage is set too low, the load capacity d). a larger capacity model. peration time. acity. ensation (refer to Pr.07-71 torque compensation gain) s and the motor does no stall.	
Mechaniover-toro The load Accel./D cycle are V/F volta The mot Overload operatio Torque of	t parameter setting ical failure (e.g. que, mechanical lock) d is too large. eccel. time and working e too short age is too high or capacity is too small d during low-speed n	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the V/F curve (Mother mid-point voltage (if decreases at low speed Replace the motor with Decrease low-speed op Increase the motor capacity and it is a compunity to the current reduce. Correct the parameter set is a cause of the computation of the current reduce.	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction. a larger capacity model. ues for Pr.01-12–01-19 (accel./decel. time). flotor 2, Pr.01-35–01-42), especially the setting value for f the mid-point voltage is set too low, the load capacity fi). a larger capacity model. peration time. acity. ensation (refer to Pr.07-71 torque compensation gain) s and the motor does no stall. settings for speed tracking.	
Mechaniover-toro The load Accel./D cycle are V/F volta The mot Overload operatio Torque of Imprope speed tra restart ar	t parameter setting ical failure (e.g. que, mechanical lock) d is too large. eccl. time and working e too short age is too high or capacity is too small d during low-speed n compensation is too large r parameter settings for	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the V/F curve (M the mid-point voltage (if decreases at low speed Replace the motor with Decrease low-speed op Increase the motor cap Adjust the torque comp until the current reduce Correct the parameter s 1. Start the speed tra	Corrective Actions for Pr.06-10 and Pr.06-11 again. malfunction. a larger capacity model. ues for Pr.01-12–01-19 (accel./decel. time). flotor 2, Pr.01-35–01-42), especially the setting value for f the mid-point voltage is set too low, the load capacity fi). a larger capacity model. peration time. acity. ensation (refer to Pr.07-71 torque compensation gain) s and the motor does no stall. settings for speed tracking.	

ID*	Display on LCD Keypad	Fau	ult Name	Fault Descriptions	
28	υĒ	Und	er current (uC)	Low current detection	
			Action and Reset		
	Action level	Pr.06-71			
	Action time	Pr.06-72			
Fault treatment parameter 0: No 1: Fault 2: Fault		1: Fault a	Pr.06-73 D: No function 1: Fault and coast to stop 2: Fault and ramp to stop by the 2 nd deceleration time 3: Warn and continue operation		
	Reset method Reset condition	Auto When Pr.06-73=3, uC is a "Warning". The warning is automatically cleared when the output current > (Pr.06-71+0.1A). Manual When Pr.06-73=1 or 2, uC is a "Fault". You must reset manually.			
	Record	Immediat	tely reset		
	Active level	When Pr.	.06-71=1 or 2,	uC is a "Fault", and the fault is recorded.	
	Cause	Corrective Actions		Corrective Actions	
Motor ca	able disconnection	Troubleshoot the connection between the motor and the load.		ction between the motor and the load.	
Imprope protection	er setting of low-current on	Reset Pr.06-71, Pr.06-72 and Pr.06-73 to proper settings.		2 and Pr.06-73 to proper settings.	
The load	d is too low	Check the load status.			
1110 1040	The load is too low		Check if the motor capacity matches the load.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
31	c F 2	EEPROM read error (cF2)	Internal EEPROM cannot be read	
		Action and	d Reset	
	Action level	Firmware internal detec	tion	
	Action time	cF2 acts immediately w	hen the drive detects the fault	
Fau	ılt treatment parameter	N/A		
Reset method		Manual reset		
	Reset condition	Immediately reset		
Record		Yes		
Cause		Corrective Actions		
		Press "RESET" key or reset the parameter to the default setting, if cF2 still		
Internal	EEPROM cannot be read	exists, return to the factory for repair.		
		Cycle the power, if cF2 error still exists, return to the factory for repair.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
33	cd l	U-phase error (cd1)	U-phase current detection error when power is ON	
		Action and	d Reset	
	Action level	Hardware detection		
	Action time	cd1 acts immediately when the drive detects the fault		
Fau	ılt treatment parameter	N/A		
	Reset method	Power-off		
	Reset condition	N/A		
Record Yes		Yes		
Cause			Corrective Actions	
Hardware failure		Cycle the power. If cd1 still exists, return	to the factory for repair.	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
34 cd2		V-phase error (cd2)	V-phase current detection error when power ON	
		Action and	d Reset	
	Action level	Hardware detection		
	Action time	cd2 acts immediately when the drive detects the fault		
Fau	ılt treatment parameter	N/A		
	Reset method	Power-off		
	Reset condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
Hardware failure		Cycle the power. If cd2 still exists, return to the factory for repair.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
35	c d 3	W-phase error (cd3)	W-phase current detection error when power ON	
		Action and	d Reset	
	Action level	Hardware detection		
	Action time	cd3 acts immediately when the drive detects the fault		
Fau	ılt treatment parameter	N/A		
	Reset method	Power-off		
	Reset condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
lHardware failure		Cycle the power. If cd3 still exists, return to the factory for repair.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions		
36	888	cc hardware error (Hd0)	cc (current clamp) hardware protection error when power is ON		
		Action and	d Reset		
	Action level	Hardware detection			
	Action time	Hd0 acts immediately when the drive detects the fault			
Fau	ılt treatment parameter	N/A			
	Reset method	Power-off			
	Reset condition	N/A			
	Record	Yes			
Cause		Corrective Actions			
Hardware failure		Cycle the power. If Hd0 still exists, return to the factory for repair.			

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
37	88 I	oc hardware error (Hd1)	oc hardware protection error when power is ON	
		Action and	d Reset	
	Action level	Hardware detection		
	Action time	Hd1 acts immediately when the drive detects the fault		
Fau	ılt treatment parameter	N/A		
	Reset method	Power-off		
	Reset condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
Hardware failure		Cycle the power. If Hd1 still exists, return to the factory for repair.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions		
40	888	Auto-tuning error (AUE)	Motor auto-tuning error		
		Action and	d Reset		
	Action level	Hardware detection			
	Action time	Immediately act			
Fau	ılt treatment parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Immediately reset			
	Record	Yes			
	Cause	Corrective Actions			
Press "STOP" key during auto-tuning		Re-execute auto-tuning.			
Incorrect motor capacity (too large or too small) and parameter setting		Check motor capacity and related parameters. Set the correct parameters, that is Pr.01-01–Pr.01-02. Set Pr.01-00 larger than the motor rated frequency.			
Incorrec	t motor wiring	Check the wiring.			
Motor sh	naft lock	Remove the cause of motor shaft lock.			

The electromagnetic contactor is	
ON at output side (U/V/W) of the	Make sure the electromagnetic valve is OFF.
drive	
The lead is too laws	Reduce the load.
The load is too large.	Replace the motor with a larger capacity model.
Accel./Decel. time is too short	Increase the setting values for Pr.01-12–Pr.01-19 (accel./decel. time).

ID*	Display on LCD Keypad	Fau	ult Name	Fault Descriptions	
41	888		loss ACI (AFE)	PID feedback loss (analog feedback signal is only valid when the PID function is enabled)	
			Action and Reset		
	Action level	When the analog input < 4 mA (only detects 4–20 mA analog input)			
	Action time	Pr.08-08			
Fau	lt treatment parameter		and continue o		
l ad	·		1: Fault and ramp to stop 2: Fault and coast to stop 3: Warn and operate at last frequency		
	Reset method		Auto When Pr.08-09=3 or 4, AFE is a "Warning". When the feedback signal is > 4 mA, the "Warning" is automatically cleared. Manual When Pr.08-09=1 or 2, AFE is a "Fault". You must reset manually.		
	Reset condition	Immediately reset			
	Record		When Pr.08-09=1 or 2, AFE is a "Fault", and the fault is recorded; when Pr.08-09=3 or 4, AFE is a "Warning", and the warning is not recorded.		
	Cause		Corrective Actions		
PID feed	dback cable is loose or cut	Tighten the terminal.			
off		Replace the cable with a new one.			
Feedbad	ck device failure	Replace the device with a new one.			
Hardware failure		Check all the wiring. If AFE fault still exists, return to the factory for repair.			

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions		
43	2339	PG feedback loss (PGF2)	Pr.10-00 and Pr.10-02 is not set in the PG control mode. When press "RUN" key, PGF2 fault occurs.		
		Action and	d Reset		
	Action level	Software detection			
	Action time	Immediately act			
Fau	ılt treatment parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Immediately reset			
	Record	Yes			
	Cause		Corrective Actions		
Incorrect setting of encoder parameter		Reset encoder parameters (Pr.10-00 and Pr.10-02)			
Incorrect selection of the control mode		Choose the correct control mode.			

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
44	P6F3	PG feedback stall (PGF3)	Under PG mode, when the motor frequency exceeds the encoder observer stall level (Pr.10-10) and starts to count, the fault time is longer than the detection time of encoder observer stall (Pr.10-11), then PGF3 fault occurs.	
		Action and	d Reset	
	Action level	Pr.10-10		
	Action time	Pr.10-11		
Fault treatment parameter		Pr.10-12 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause	Corrective Actions		
Incorrect setting of encoder parameter		Reset encoder parameter (Pr.10-01)		
Pr. 01-00 is set too small		Set proper value for Pr.01-00.		
Incorrec	t setting for ASR	Reset ASR parameters.		
paramet	ters and accel./decel. time	Set correct accel./decel. time.		
Incorrect setting for PG feedback stall		Reset proper values for Pr.10-10 and Pr. 10-11		

ID*	Display on LCD Kaynad	Го	ult Nieuwe	Foult Descriptions		
"טו	Display on LCD Keypad	Fai	ult Name	Fault Descriptions		
	1			Under PG mode, when the motor frequency exceeds		
45	ዖይዩዣ		slip error	encoder observer slip range (Pr.10-13) and starts to		
	, 0, ,	(PGF4)	count, the fault time is longer than the detection time of		
				encoder observer slip (Pr.10-14), PGF4 fault occurs.		
			Action and	d Reset		
	Action level	Pr.10-13				
	Action time	Pr.10-14				
		Pr.10-15				
Fau	ılt treatment parameter	0: Warn and continue operation				
l ac	iit treatment parameter	1: Fault and ramp to stop				
		2: Fault and coast to stop				
			When Pr.10-15=0, PGF4 is a "Warning". When the deviation between			
	Reset method	Auto	the output free	quency and motor frequency is smaller than the encoder		
	Resermentod		observer slip	range, the warning is automatically cleared.		
		Manual When Pr.10-15=1 or 2, PGF4 is a "Fault". You must reset manually.				
	Reset condition	Immedia	tely reset			
	Record	When Pr.10-15=1 or 2, PGF4 is a "Fault", and the fault is recorded.				
	Cause	Corrective Actions				
Incorrec	Incorrect settings for PG feedback		Decet			
paramet	parameters		Reset correct values for Pr.10-13 and Pr.10-14.			
Incorrec	t settings for ASR	Reset AS	R parameters			
paramet	ters and accel./decel. time	Set correct accel./decel time.				

Incorrect settings of encoder parameters	Reset encoder parameters (Pr.10-01).
Accel./Decel. time is too short	Reset proper accel./decel. time.
Incorrect settings of torque limit parameters (Pr.06-12,Pr.11-17–20)	Reset proper setting values for Pr.06-12 and Pr.11-17–Pr.11-20.
Motor shaft lock	Remove causes of motor shaft lock.
Mechanical brake is not released	Check the action timing of the system.

ID*	Display on LCD Keypad	Fai	ult Name	Fault Descriptions		
48	868		CI loss (ACE)	Analog input loss (including all the 4–20 mA analog signal)		
			Action and	d Reset		
	Action level	When the	e analog input i	is < 4 mA (only detects 4–20 mA analog input)		
	Action time	Immedia	tely act			
		Pr.03-19 0: Disabl	e			
Fau	ılt treatment parameter	Continue operation at the last frequency				
lad	iit ii catinent parameter	(warning, ANL is displayed on the keypad)				
		2: Decelerate to stop (warning, ANL is displayed on the keypad)				
		3: Stop immediately and display ACE				
		When Pr.03-19=1 or 2, ACE is a "Warning". When analog input s				
	Reset method	, (d.0	is > 4 mA, the	s > 4 mA, the warning is automatically cleared.		
		Manual When Pr.03-19=3, ACE is a "Fault". You must reset manually.				
	Reset condition	Immedia	tely reset			
	Record	When Pr	.03-19=3, ACE	is a "Fault", and the fault is recorded.		
	Cause	Corrective Actions				
A CL ach	lo io loggo or out off	Tighten the terminal.				
ACI Cab	ACI cable is loose or cut off		Replace the cable with a new one.			
External	l device failure	Replace the device with a new one.				
Hardware failure Check all the wiring. If ACE still exists, return to the factory for repair.			ACE still exists, return to the factory for repair.			

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
49	8.5	External fault (EF)	External fault. When the drive decelerates based on the setting of Pr.07-20, the EF fault displays on the keypad.	
		Action and	d Reset	
	Action level	MIx=EF and the MI tern	ninal is ON	
	Action time	Immediately act		
Pr.07-20 0: Coast to stop 1: Stop by the 1 st deceleration time 2: Stop by the 2 nd deceleration time 3: Stop by the 3 rd deceleration time 4: Stop by the 4 th deceleration time 5: System deceleration		eration time eration time		
	Reset method	Manual reset		
	Reset condition	Manual reset only after the external fault is cleared (terminal status is recovered)		
	Record	Yes		

Cause	Corrective Actions
External fault	Press RESET key after the fault is cleared.

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
50	8F 1	Emergency stop (EF1)	When the contact of MIx=EF1 is ON, the output stops immediately and displays EF1 on the keypad. The motor is in free running.	
		Action and	d Reset	
	Action level	MIx=EF1 and the MI ter	minal is ON	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Manual reset only after the external fault is cleared (terminal status is recovered)		
Record		Yes		
Cause		Corrective Actions		
When MIx=EF1 activates		Verify if the system is back to normal condition, and then press "RESET" key to go back to the default.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
51	55	External base block (bb)	When the contact of MIx=bb is ON, the output stops immediately and displays bb on the keypad. The motor is in free running.	
		Action and	d Reset	
	Action level	Mlx=bb and the MI term	ninal is ON	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	The display "bb" is automatically cleared after the fault is cleared.		
	Reset condition	N/A		
	Record	No		
	Cause	Corrective Actions		
When MIx=bb activates		Verify if the system is back to normal condition, and then press "RESET" key to go back to the default.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
52	Pcod	Password is locked (Pcod)	Entering the wrong password three consecutive times	
		Action and	d Reset	
	Action level	Entering the wrong password three consecutive times		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Power-off		
Record		Yes		

Cause	Corrective Actions		
	Input the correct password after rebooting the motor drive.		
	2. If you forget the password, do the following steps:		
	Step 1: Input 9999 and press ENTER.		
Incorrect password input through	Step 2: Repeat step 1. Input 9999 and press ENTER.		
Pr.00-07	(You need to finish step 1 and step 2 within 10 seconds. If you don't finish		
	the two steps in 10 seconds, try again.)		
	3. The parameter settings return to the default when the "Input 9999" process		
	is finished.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
54	681	Illegal command (CE1)	Communication command is illegal	
		Action and	l Reset	
	Action level	When the function code	is not 03, 06, 10, or 63.	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		No		
Cause		Corrective Actions		
Incorrect communication command from the upper unit		Check if the communication command is correct.		
Verify the wiring and grounding of the communication circuit. It is recomme Malfunction caused by interference to separate the communication circuit from the main circuit, or wire in 90 d for effective anti-interference performance.		nication circuit from the main circuit, or wire in 90 degree		
	t communication setting upper unit	Check if the setting for Pr.09-02 is the same as the setting for the upper unit.		
Disconnection or bad connection of the cable Check the cable and replace it if necessary.		place it if necessary.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
55	533	Illegal data address (CE2)	Data address is illegal	
		Action and	d Reset	
	Action level	When the data address	is correct.	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	No		
	Cause	Corrective Actions		
Incorrect communication command from the upper unit		Check if the communication command is correct.		
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		

Different communication setting from the upper unit	Check if the setting for Pr.09-02 is the same as the setting for the upper unit.
Disconnection or bad connection of the cable	Check the cable and replace it if necessary.

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
56	833	Illegal data value (CE3)	Data value is illegal	
		Action and	I Reset	
	Action level	When the data length is	too long	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	No		
Cause		Corrective Actions		
Incorrect communication command from the upper unit		Check if the communication command is correct.		
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
	t communication setting Check if the setting for Pr.09-02 is the same as the setting for the upper unit		Pr.09-02 is the same as the setting for the upper unit.	
Disconnection or bad connection of the cable		Check the cable and replace it if necessary.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
		Data is written to		
57	[[[[[[[[[[[[[[[[[[[[[read-only address	Data is written to read-only address	
		(CE4)		
		Action and Reset		
	Action level	When the data is writter	n to read-only address.	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		No		
Cause			Corrective Actions	
Incorrect communication		Chack if the communication command is correct		
command from the upper unit		Check if the communication command is correct.		
		Verify the wiring and grounding of the communication circuit. It is recommended		
Malfunc	tion caused by interference	to separate the communication circuit from the main circuit, or wire in 90 degree		
		for effective anti-interference performance.		
Differen	t communication setting	Chook if the potting for	Dr 00 02 is the same as the setting for the unner unit	
from the	e upper unit	Check if the setting for Pr.09-02 is the same as the setting for the upper unit.		
Disconn	ection or bad connection	Chook the coble and re		
of the ca	able	Check the cable and replace it if necessary.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
58	0:33	Modbus transmission time-out (CE10)	Modbus transmission time-out occurs	
		Action and	d Reset	
Action level		When the communication time exceeds the detection time for Pr.09-03 communication time-out.		
	Action time	Pr.09-03		
Fault treatment parameter		Pr.09-02 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning, no fault, and continue operation		
Reset method		Manual reset		
Reset condition		Immediately reset		
Record		Yes		
	Cause	Corrective Actions		
the com	munication command	Check if the upper unit transmits the communication command within the setting time for Pr.09-03.		
Malfunct	·	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
	communication setting upper unit	Check it the setting for Pr 09-02 is the same as the setting for the upper uni		
Disconno of the ca	ection or bad connection able	Check the cable and replace it if necessary.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions		
	Уdс	Y-connection /			
61		Δ-connection	An error occurs when Y-Λ switches		
01		switch error	An error occurs when 1-4 switches		
		(ydc)			
		Action and	d Reset		
		1. ydc occurs when th	e confirmation signals of Y-connection and Δ -connection		
	Action level	are conducted at th	e same time.		
		2. If any of confirmation signals is not conducted within Pr.05-25, ydc occurs.			
Action time		Pr.05-25			
Fault treatment parameter		N/A			
	Reset method	Manual reset			
		Can be reset only when	the confirmation signal of Y-connection is conducted if it		
	Reset condition	is Y-connection, or when the confirmation signal of Δ -connection is conducted if			
		it is Δ-connection.			
	Record	Yes			
	Cause	Corrective Actions			
The electromagnetic valve		Chook if the electrons	unatia valva warka narmally		
operates	s incorrectly during Y-∆	Check if the electromagnetic valve works normally.			
switch.		If not, replace it.			
Incorrect parameter setting Check if related parameters are all set up and set correctly.					

The wiring of Y-∆ switch function is incorrect	Check the wiring.
IIICOITECI	

ID*	Display on LCD Keypad	Fai	ult Name	Fault Descriptions	
62	d8b	bac	ration energy kup error (dEb)	When Pr.07-13 is not 0, and the power is suddenly off, causing the DC bus voltage lower than the dEb action level, the dEb function acts and the motor ramps to stop. Then dEb displays on the keypad.	
			Action and	d Reset	
	Action level	When Pr	.07-13 is not 0,	and the DC bus voltage is lower than the level of dEb.	
	Action time	Immedia	tely act		
Fau	ılt treatment parameter	N/A			
	Reset method		When Pr.07-13=2 (dEb with auto-acceleration / auto-deceleration, the drive outputs the frequency after the power is restored): dEb is automatically cleared. When Pr.07-13=1 (dEb with auto-acceleration / auto-deceleration, the drive does not output the frequency after the power is restored): The drive stops when dEb acts and the rotation speed becomes 0 Hz, then the drive can be reset manually.		
Reset condition		Auto: The fault is automatically cleared. Hand: When the drive decelerates to 0 Hz.			
	Record	Yes			
	Cause		Corrective Actions		
	Unstable power source or the power is off		Check the power system.		
	any other large load s in the power system	 Replace power system with a larger capacity. Use a different power system from the large load system. 			

ID*	Display on LCD Keypad	Fau	ult Name	Fault Descriptions	
				On the basis of the maximum slip limit set via Pr.10-29,	
				the speed deviation is abnormal. When the motor drive	
		Ove	r slip error	outputs at constant speed, F>H or F <h exceeds="" td="" the<=""></h>	
63	056		(oSL)	level set via Pr.07-29, and it exceeds the time set via	
			,	Pr.07-30, oSL shows. oSL occurs in induction motors	
				only.	
			Action and	d Reset	
	A ation lavel	Pr.07-29			
	Action level		100% of Pr.07-29 = the maximum limit of the slip frequency (Pr.10-29)		
	Action time				
			Pr.07-31		
		0: Warn and continue operation			
Fau	ult treatment parameter	1: Fault and ramp to stop			
		2: Fault and coast to stop			
			3: No warning		
		Pr.07-31=0		a warning.	
		Auto	When the motor drive outputs at constant speed, and F>H or F <h< td=""></h<>		
	Reset method	Auto	does not exceed the level set via Pr.07-29 anymore, oSL warning will		
			be cleared automatically.		
			When Pr.07-31=1 or 2, oSL is an error, and it needs to reset manually.		

Reset condition	Immediately reset	
Record	Pr.07-31=1 or 2, oSL is "Fault", and the fault is recorded.	
Cause	Corrective Actions	
Any of the motor parameters in parameter group 5 may be incorrect	Check the motor parameters	
Overload	Decrease the load	
Any of the setting value of Pr.07-29, 07-30, and 10-29 is improper	Check the setting of oSL protection function related parameters	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
72	SELI	STO Loss 1 (STL1)	STO1–SCM1 internal loop detection error	
		Action and	d Reset	
	Action level	Hardware detection		
	Action time	Immediately act		
Fau	ult treatment parameter	N/A		
	Reset method	Hardware failure, and c	annot reset. Cycle the power.	
	Reset condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
STO1 and SCM1 short circuit lines are not connected		Re-connect the short circuit line		
Hardware failure		After you make sure all the wiring is correct, if STL1 fault still exists after cycling the power, return to the factory for repair.		
Poor connection of the IO card Check if the PIN of the IO card is I Check if the IO card connects to are tightened well.			O card is broken. Onnects to the control board correctly, and if the screws	
	card does not match the of the control board	Contact local agent or Delta		

ID*	Display on LCD Keypad	Fai	ult Name	Fault Descriptions	
76	Sfo		STO (STo)	Safety Torque Off function active	
			Action and	d Reset	
	Action level	Hardware	e detection		
	Action time		Immediately act		
Fau	Fault treatment parameter		N/A		
	Reset method		Auto When Pr.06-44=1 and after STo error is cleared, it automatically resets.		
			Manual When Pr.06-44=0 and after STo error is cleared, reset it manually.		
	Reset condition	Reset on	ly after STo err	or is cleared.	
	Record	Yes			
	Cause	Corrective Actions			
	tch action of STO1/SCM1 D2/SCM2 (OPEN)	Reset the switch (ON) and cycle the power			

Poor connection of the IO card	Check if the PIN of the IO card is broken. Check if the IO card connects to the control board correctly, and if the screws are tightened well.
The IO card does not match the version of the control board	Contact local agent or Delta

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions			
77	SELE	STO Loss 2 (STL2)	STO2–SCM2 internal loop detection error			
		Action and	d Reset			
	Action level	Hardware detection				
	Action time	Immediately act				
Fau	ılt treatment parameter	N/A				
	Reset method	Hardware failure, and cannot reset. Cycle the power.				
	Reset condition	N/A				
	Record	Yes				
Cause		Corrective Actions				
STO2 and SCM2 short circuit lines are not connected		Re-connect the short circuit lines				
Hardware failure		After you make sure all the wiring is correct, if STL2 fault still exists after cycling the power, return to the factory for repair.				
Check if the PIN of the IO card is broken. Poor connection of the IO card Check if the PIN of the IO card is broken. Check if the IO card connects to the control board correctly, and if the so are tightened well.			O card is broken.			
The IO card does not match the version of the control board Contact local agent or Delta			Pelta			

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions		
78	SFL3	STO Loss 3 (STL3)	STO1–SCM1 and STO2–SCM2 internal loop detection error		
		Action and	d Reset		
	Action level	Hardware detection			
	Action time	Immediately act			
Fau	ılt treatment parameter	N/A			
	Reset method	Hardware failure, and cannot reset. Cycle the power.			
	Reset condition	N/A			
Record		Yes			
Cause			Corrective Actions		
STO1 and SCM1, or STO2 and					
SCM2 s	hort circuit lines are not	Re-connect the short circuit lines			
connected					
Hardwa	re failure	After you make sure all the wiring is correct, if STL3 fault still exists after cycling			
l laidware laildle		the power, return to the factory for repair.			
		Check if the PIN of the IO card is broken.			
Poor co	nnection of the IO card	Check if the IO card connects to the control board correctly, and if the screws			
		are tightened well.			

The IO card does not match the	Contact legal agent or Delta
version of the control board	Contact local agent or Delta

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions		
79	Roc	U-phase over-current before run (Aoc)	U-phase short circuit detected when the output wiring detection is performed before the drive runs.		
		Action and Reset			
	Action level	300% of the rated curre	nt		
	Action time	Immediately act			
Fau	ılt treatment parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Reset in five seconds a	fter the fault clears		
	Record	Yes			
	Cause	Corrective Actions			
Incorrec	et wiring for the motor	Check if the motor's internal wiring and the UVW wiring of the drive output terminal are correct.			
Short-ci	rcuit at motor output due to	Check the motor cable and remove causes of the short circuits, or replace the			
poor ins	ulation wiring	cable before turning on the power.			
Check for	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the			
aging in	sulation of the motor	insulation is poor.			
Malfunc	tion caused by interference	Verify the wiring of the control circuit and the wiring/grounding of the main circuit to prevent interference.			
The leng	gth of motor cable is too	Increase the AC motor drive's capacity.			
long Install AC reactor(s) on the output side (U/V/W).			the output side (U/V/W).		
		The Aoc occurs due to the short circuit or ground fault at the output side of the			
		drive. Check for possible short circuits between terminals with the electric meter:			
Hardwa	re failure	B1 corresponds to U, V and W; DC- corresponds to U, V and W;			
		corresponds to U, V and W.			
		If short circuit occurs, return to the factory for repair.			

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
80	вос	V-phase over-current before run (boc)	V-phase short circuit detected when the output wiring detection is performed before the drive runs.	
		Action and	d Reset	
	Action level	300% of the rated curre	nt	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds after the fault clears		
	Record	Yes		
	Cause	Corrective Actions		
Incorrect wiring for the motor Check if the motor's internal wiring and the UVW wiring of the drive outerminal are correct.		ernal wiring and the UVW wiring of the drive output		
Short-cii	rcuit at omotor output due	Check the motor cable and remove causes of the short circuits, or replace the		
to poor i	poor insulation wiring cable before turning on the power.			

Check for possible burnout or	Check the motor insulation value with megger. Replace the motor if the
aging insulation of the motor	insulation is poor.
Malfunction caused by interference	Verify the wiring of the control circuit and the wiring/grounding of the main circuit
Malfunction caused by interference	to prevent interference.
The length of motor cable is too	Increase the AC motor drive's capacity.
long	Install AC reactor(s) on the output side (U/V/W).
	The boc occurs due to the short circuit or ground fault at the output side of the
	drive. Check for possible short circuits between terminals with the electric meter:
Hardware failure	B1 corresponds to U, V and W; DC- corresponds to U, V and W; 😑
	corresponds to U, V and W.
	If short circuit occurs, return to the factory for repair.

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
81	сос	W-phase over-current before run (coc)	W-phase short circuit detected when the output wiring detection is performed before the drive runs.	
		Action and Reset		
	Action level	300% of the rated curre	nt	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds a	fter the fault clears	
	Record	Yes		
	Cause	Corrective Actions		
Incorrec	t wiring for the motor	Check if the motor's internal wiring and the UVW wiring of the drive output terminal are correct.		
Short-ci	rcuit at omotor output due	Check the motor cable and remove causes of the short circuits, or replace the		
to poor i	nsulation wiring	cable before turning on	the power.	
Check for	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the		
aging in	sulation of the motor	insulation is poor.		
Malfunc	tion caused by interference	Verify the wiring of the control circuit and the wiring/grounding of the main circuit to prevent interference.		
The leng	gth of motor cable is too	Increase the AC motor drive's capacity.		
long		Install AC reactor(s) on the output side (U/V/W).		
		The coc occurs due to t	he short circuit or ground fault at the output side of the	
		drive. Check for possible short circuits between terminals with the electric meter:		
Hardwa	re failure	B1 corresponds to U, V and W; DC- corresponds to U, V and W;		
		corresponds to U, V and W.		
		If short circuit occurs, re	eturn to the factory for repair.	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
	0	Output phase loss		
82	oPL I	U phase	U phase output phase loss	
		(oPL1)		
		Action and	d Reset	
	Action level	Pr.06-47		
		Pr.06-46		
	Action time	Pr.06-48: Use the settin	g value of Pr.06-48 first. If DC braking function activates,	
		use that of P	r.06-46.	
		Pr.06-45		
		0: Warn and continue o	peration	
Faul	It treatment parameter	1: Fault and ramp to sto	pp	
		2: Fault and coast to stop		
		3: No warning		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Pr.06-45=1 or 2 is "Faul	t", and the fault is recorded.	
	Cause	Corrective Actions		
Unbalan	ced three-phase	Replace the motor.		
impedan	ce of the motor			
The mot	or is wired incorrectly	Check the cable condition	on.	
THE HIOL		Replace the cable.		
Using a	single-phase motor	Choose a three-phase r	motor	
		Check the flat cable of the control board. Re-do the wiring and test again if the		
The curr	ent sensor is damaged	flat cable is loose. If the fault still exists, return to the factory for repair.		
THE CUIT	ent sensor is damaged	Verify that the three-phase current is balanced with a current clamp meter. If it is		
		balanced and the oPL1 fault still exists, return to the factory for repair.		
The drive capacity is much larger		Make sure the canacity	of the drive and motor match to each other	
than the	motor capacity	Make sure the capacity of the drive and motor match to each other.		

	I			
ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
		Output phase loss		
83	0865	V phase	V phase output phase loss	
		(oPL2)		
		Action and	d Reset	
	Action level	Pr.06-47		
		Pr.06-46		
	Action time	Pr.06-48: Use the setting value of Pr.06-48 first. If DC braking function activates,		
		use that of Pr.06-46.		
		Pr.06-45		
		0: Warn and keep operation		
Fau	ılt treatment parameter	1: Fault and ramp to stop		
		2: Fault and coast to stop		
		3: No warning		
	Reset method Manual reset			
Reset condition Immediately reset				
Record When Pr.06-45=1 or 2, oPL2 is a "Fault", and the fault is recorded.		oPL2 is a "Fault", and the fault is recorded.		

Cause	Corrective Actions	
Unbalanced three-phase impedance of the motor	Replace the motor.	
Check if the wiring is incorrect	Check the cable and replace it if necessary.	
Check if the motor is a single-phase motor	Choose a three-phase motor.	
Check if the current sensor is broken	Check if the control board cable is loose. If yes, reconnect the cable and run the drive to test. If the fault still exists, return to the factory for repair. Check if the three-phase current is balanced with a current clamp meter. If the current is balanced and the oPL2 fault still exists, return to the factory for repair.	
Check if the drive capacity is larger than the motor capacity	Choose the drive that matches the motor capacity	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
		Output phase loss		
84	oPL3	W phase	W phase output phase loss	
		(oPL3)		
		Action and Reset		
	Action level	Pr.06-47		
		Pr.06-46		
	Action time	Pr.06-48: Use the settin	g value of Pr.06-48 first. If DC braking function activates,	
		use that of Pr.	06-46.	
		Pr.06-45		
		0: Warn and continue o	peration	
Fau	ılt treatment parameter	1: Fault and ramp to sto	pp	
		2: Fault and coast to stop		
		3: No warning		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	When Pr.06-45=1 or 2, oPL3 is a "Fault", and the fault is recorded.		
	Cause		Corrective Actions	
Unbalar	nced three-phase	Replace the motor.		
impedar	nce of the motor			
Check if	f the wiring is incorrect	Check the cable and re	place it if necessary.	
Check if	f the motor is a			
single-p	hase motor	Choose a three-phase r	notor.	
		Check if the control boa	rd cable is loose. If yes, reconnect the cable and run the	
Check if	f the current sensor is	drive to test. If the fault still exists, return to the factory for repair.		
broken		Check if the three-phase current is balanced with a current clamp meter. I		
		current is balanced and	the oPL3 fault still exists, return to the factory for repair.	
Check if	f the drive capacity is larger	Change the drive that metabout the metar canacity		
than the	motor capacity	Choose the drive that matches the motor capacity		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
87	07.3	Low frequency overload protection (oL3)	Low frequency and high current protection	
		Action and	l Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		Yes		
	Cause	Corrective Actions		
The drive operates at a frequency below 15 Hz, and output current is too large.		 Lower the carrier free Decrease the voltage the V/F curve. Change Pr.00-11 to 	issipation capacity for the cabinet. equency (Pr.00-17). ge settings that correspond to frequency below 15 Hz in general control mode. with a larger power model.	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
		Rotor position		
89	ropd	detection error	Rotor position detection error protection	
		(roPd)		
		Action and	d Reset	
	Action level	Reset the software		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		Yes		
	Cause	Corrective Actions		
Check if	f the motor cable is	Check or replace the cable.		
abnorma	al or broken			
Motor co	oil error	Replace the motor.		
Hardware failure IG		IGBT broken. Return to the factory for repair.		
Drivo's	current feedback line error	Cycle the power. If roPd still occurs during operation, return to the factory for		
Dilve's (Surrent reedback line effor	repair.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
101	3803	CANopen guarding error (CGdE)	CANopen guarding error	
		Action and	d Reset	
Action level		When CANopen Node Guarding detects that one of the slaves does not respond, the CgdE fault occurs. The upper unit sets the factor and time during configuration.		
	Action time	The time that the upper	unit sets during configuration	
Fau	lt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	The upper unit sends a reset package to clear this fault.		
	Record	Yes		
	Cause		Corrective Actions	
The guarding time is too short, or less detection times		Increase the guarding time (Index 100C) and detection times		
Malfunction caused by interference		 Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance. Make sure the communication circuit is wired in series. Use CANopen cable or add terminating resistance. 		
Commulbad con	nication cable is broken or nected	Check or replace the co	ommunication cable.	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
		CANopen heartbeat		
102	(X8E	error	CANopen heartbeat error	
		(CHbE)		
		Action and	d Reset	
		When CANopen Heartb	eat detects that one of the slaves does not respond, the	
	Action level	ChbE fault occurs.		
	Action level	The upper unit sets the	confirming time of producer and consumer during	
		configuration.		
	Action time	The confirming time that the upper unit sets for producer and consumer during		
	Action time	configuration.		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	The upper unit sends a	reset package to clear this fault	
	Record	Yes		
	Cause	Corrective Actions		
The hea	rtbeat time is too short	Increase heartbeat time (Index 100C)		
		1. Verify the wiring and	d grounding of the communication circuit. It is	
		recommended to separate the communication circuit from the main circuit,		
Malfunct	tion caused by interference	or wire in 90 degree for effective anti-interference performance.		
		2. Make sure the communication circuit is wired in series.		
		Use CANopen cable or add terminating resistance.		
Commu	nication cable is broken or	Check or replace the communication cable.		
bad con	nected	Check of Teplace the Co	iriiriuriicauori cable.	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
104	8443	CANopen bus off error (CbFE)	CANopen bus off error	
		Action and	d Reset	
		Hardware When CANo	pen card is not installed, the CbFE fault occurs.	
	Action level	fault occurs. Software Too much in	aster receives wrong communication package, the CbFE terference on BUS	
			receives wrong package when the CAN_H and CAN_L	
	A ('	l .	ion cables are short, CbFE fault occurs.	
	Action level	Immediately act		
Fau	•	N/A		
		Manual reset		
	Reset condition	Cycle the power		
	Record	Yes		
	Cause		Corrective Actions	
Check if installed	the CANopen card is	Make sure the CANope	n card is installed.	
Check if is correct	the CANopen speed t	Reset CANopen speed	(Pr.09-37)	
Malfunct		 Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance. Make sure the communication circuit is wired in series. Use CANopen cable or add terminating resistance. 		
Commur bad con	nication cable is broken or nected	-		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
טו	Display of LCD Reypau	Fault Name	Fault Descriptions	
105	3653	CANopen index error (CidE)	CANopen index error	
		Action and	d Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fault treatment parameter		N/A		
Reset method		Manual reset		
	Reset condition	The upper unit sends a reset package to clear this fault		
	Record	Yes		
Cause		Corrective Actions		
Incorrect setting of CANopen index		Reset CANopen Index (Pr.00-02=7)		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
106	3883	CANopen station address error (CAdE)	CANopen station address error (only supports 1–127)	
		Action and	d Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset (Pr.00-02=7)		
	Reset condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
Incorrect setting of CANopen station address		 Disable CANopen (Reset CANopen (P Reset CANopen state 	,	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions		
107	CF-8	CANopen index setting exceed limit (CFrE)	CANopen memory error		
		Action and	d Reset		
	Action level	When you update the fi	rmware version of the control board, the FRAM internal		
	Action level	data does not change, then CFrE fault occurs.			
	Action time	Immediately act			
Fault treatment parameter		N/A			
	Reset method	Manual reset			
	Reset condition	Pr.00-02=7			
	Record	Pr.00-21=3, the fault is recorded			
Cause		Corrective Actions			
		1. Disable CANopen (Pr.09-36=0)			
CANope	en internal memory error	2. Reset CANopen (Pr.00-02=7)			
		3. Reset CANopen station address (Pr.09-36)			

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions		
111	[ct8	InrCOM time-out error (ictE)	Internal communication overtime error		
		Action and	d Reset		
	Action level	Pr.09-31=-110 (there	e is no -9), when the internal communication between		
	Action level	Slave and Master is abr	Slave and Master is abnormal, ictE fault occurs.		
	Action time	Immediately act			
Fau	ılt treatment parameter	N/A			
	Reset method	Automatically reset after the internal communication is normal			
	Reset condition	N/A			
	Record	Yes			
Cause			Corrective Actions		
	·	Verify the wiring and gro	ounding of the communication circuit. It is recommended		
Malfunc	tion caused by interference	to separate the communication circuit from the main circuit, or wire in 90 degree			
		for effective anti-interference performance.			

Different communication setting from the upper unit	Check if the setting for Pr.09-02 is the same as the setting for the upper unit.
Disconnection or bad connection of the cable	Check the cable and replace it if necessary.

ID*	Display on LCD Keypad	Fault Name Fault Descriptions		
	\$2.53. Q235 B4000 100 250	Internal communication		
121	6650	error	Internal communication time-out	
		(CP20)		
		Action and	d Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	N/A		
	Reset condition	N/A		
Record		Yes		
	Cause		Corrective Actions	
Internal communication error		Contact your local distributor or Delta.		

ID*	Display on LCD Keypad	Fault Name Fault Descriptions		
100	5593	Internal communication		
123	rec	error (CP22)	Abnormal internal communication	
		(01 22)		
		Action and	d Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	N/A		
	Reset condition	N/A		
Record		Yes		
Cause			Corrective Actions	
Internal communication error		Contact your local distri	butor or Delta.	

ID*	Display on LCD Keypad	Fault Name Fault Descriptions		
		Internal communication		
124	CP30	error	Abnormal internal communication	
		(CP30)		
		Action and	d Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	N/A		
	Reset condition	N/A		
Record		Yes		
	Cause		Corrective Actions	
Internal communication error		Contact your local distri	butor or Delta.	

ID*	Display on LCD Keypad	Fault Name Fault Descriptions			
		Internal communication			
126	(P32	error	Abnormal internal communication		
		(CP32)			
		Action and	d Reset		
	Action level	Software detection			
	Action time	Immediately act			
Fau	ılt treatment parameter	N/A			
	Reset method	N/A			
	Reset condition	N/A			
Record		Yes			
	Cause		Corrective Actions		
Internal communication error		Contact your local distri	butor or Delta.		

ID*	Display on LCD Keypad	Fault Name Fault Descriptions		
		Internal communication		
127	(P33	error	Abnormal internal communication	
		(CP33)		
		Action and	d Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	N/A		
	Reset condition	N/A		
Record		Yes		
	Cause		Corrective Actions	
Internal communication error		Contact your local distri	butor or Delta.	

ID*	Display on LCD Keypad	Fau	ult Name	Fault Descriptions
				When the output current exceeds the over-torque
128	o t 3	Ove	r-torque 3	detection level (Pr.14-75) and exceeds over-torque
120	003		(ot3)	detection time (Pr.14-76), and when Pr.14-74 is set to 2
				or 4, the ot3 error displays.
			Action and	d Reset
	Action level	Pr.14-75		
	Action time	Pr.14-76		
		Pr.14-74		
		0: No function		
		1: Continue operation after over-torque detection during constant speed		
Fau	ılt treatment parameter	operation		
		2: Stop after over-torque detection during constant speed operation		
		3: Continue operation after over-torque detection during RUN		
		4: Stop after over-torque detection during RUN		
		Auto	When Pr.14-7	4=1 or 3, ot3 is a "Warning". The warning is
	Reset method		automatically	cleared when the output current < Pr.14-75.
		Manual When Pr.14-74=2 or 4, ot3 is a "Fault". You must reset manually.		
	Reset condition	Immediately reset		
	Record	Pr.14-74=2 or 4, ot3 is a "Fault", and the fault is recorded.		

Cause	Corrective Actions
Incorrect parameter setting	Reset Pr.14-75 and Pr.14-76
Mechanical failure (e.g. over-torque, mechanical lock)	Remove the causes of malfunction.
The load is too large	Reduce the load. Replace the motor with a larger capacity model.
Accel./ Decel. time and working cycle are too short	Increase the setting for Pr.01-12–Pr.01-19 (accel./ decel. time)
V/F voltage is too high	Adjust the V/F curve (Motor 3, Pr.01-54–01-61), especially the setting value for the mid-point voltage (if the mid-point voltage is set too low, the load capacity decreases at low speed).
The motor capacity is too small	Replace the motor with a larger capacity model.
Overload during low-speed operation	Decrease low-speed operation time. Increase the motor capacity.
Torque compensation is too large	Adjust the torque compensation (refer to Pr.07-73 torque compensation gain) until the current reduces and the motor does not stall.
Improper parameter settings for speed tracking function (including restart after momentary power loss and restart after fault)	Correct the parameter settings for speed tracking. Start the speed tracking function. Adjust the maximum current for Pr.07-09 speed tracking.

ID*	Display on LCD Keypad	Fai	ult Name	Fault Descriptions	
129	o84	Ove	r-torque 4 (ot4)	When the output current exceeds the over-torque detection level (Pr.14-78) and exceeds over-torque detection time (Pr.14-79), and when Pr.14-77 is set to 2 or 4, the ot4 error displays.	
		Action and Reset			
	Action level	Pr.14-78			
	Action time	Pr.14-79			
Fault treatment parameter 2: Stop after over-torque 3: Continue operation a 4: Stop after over-torque When Pr.14-7 automatically		ue operation a tion fter over-torqu ue operation a fter over-torqu When Pr.14-7 automatically When Pr.14-7	ifter over-torque detection during constant speed e detection during constant speed operation ifter over-torque detection during RUN e detection during RUN i7=1 or 3, ot4 is a "Warning". The warning is cleared when the output current < Pr.14-78. i7=2 or 4, ot4 is a "Fault". You must reset manually.		
Reset condition		Immediately reset			
	Record	Pr.14-77=2 or 4, ot4 is a "Fault", and the fault is recorded.			
	Cause			Corrective Actions	
Mechan	et parameter setting ical failure (e.g. que, mechanical lock)	Configure the settings for Pr.14-78 and Pr.14-79 again. Remove the causes of malfunction.			
The load	d is too large	Reduce the load. Replace the motor with a larger capacity model.			
	Decel. time and working e too short	Increase the setting values for Pr.01-12–Pr.01-19 (accel./ decel. time)			

V/F voltage is too high	Adjust the V/F curve (Motor 4, Pr.01-63–01-70), especially the setting value for the mid-point voltage (if the mid-point voltage is set too low, the load capacity decreases at low speed).
The motor capacity is too small	Replace the motor with a larger capacity model.
Overload during low-speed	Decrease low-speed operation time.
operation	Increase the motor capacity.
Horque compensation is too large	Adjust the torque compensation (refer to Pr.07-75 torque compensation gain) until the current reduces and the motor does not stall.
Improper parameter settings for speed tracking function (including restart after momentary power loss and restart after fault)	1. Correct the parameter settings for speed tracking. 2. Start the speed tracking function. 3. Adjust the maximum current for Pr.07-09 speed tracking.

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
134	EoL3	Internal communication error (EoL3)	Electronic thermal relay 3 protection. The drive coasts to stop once it activates.	
		Action and Reset		
	Action level	Start counting when output current > 105% of the motor 3 rated current.		
	Action time	Pr.14-81 (If the output current is larger than 105% of the motor 3 rated current again within 60 sec., the counting time reduces and is less than Pr.14-81)		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds a	fter the fault is cleared	
	Record	Yes		
	Cause		Corrective Actions	
The load	d is too large	Reduce the load.		
Accel. /Decel. time or the working cycle are too short		Increase the setting value for Pr.01-12–01-19 (accel./ decel. time)		
V/F voltage is too high		Adjust the settings for Pr.01-54–01-61 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too low, the load capacity decreases at low speed).		
Overload during low-speed operation. When using a general motor, even it operates below rated current, an overload may still occur during low-speed operation.		Decrease low-speed operation time. Replace the drive with a dedicated to VFD model. Increase the motor capacity.		
Pr.06-13	sing VFD dedicated motor, 3=0 (electronic thermal lection motor 1 = inverter	Pr.14-80 = 1 electronic thermal relay selection motor 1 = standard motor (motor		
	Incorrect value of electronic thermal relay Reset to the correct motor rated current.		tor rated current.	
The max	kimum motor frequency is ow	Reset to the correct motor rated frequency.		
One drive to multiple motors		Set Pr.14-80 electronic thermal relay 3 selection = 2 disable, and install thermal relay on each motor.		

Check if the setting for stall prevention is correct.	Set the stall prevention to the proper value.	
Torque compensation is too large	Adjust the torque compensation (refer to Pr.07-73 torque compensation gain) until the current reduces and the motor does not stall.	
Motor fan error	Check the status of the fan, or replace the fan.	
Unbalanced three-phase impedance of the motor	Replace the motor.	

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
		Internal communication	Floatrania thermal relay 4 protection. The drive exacts	
135	Eoly	error	Electronic thermal relay 4 protection. The drive coasts to stop once it activates.	
		(EoL4)	to stop office it activates.	
		Action and Reset		
	Action level	Start counting when the output current > 105% of the motor 4 rated current.		
	Action time	Pr.14-83 (If the output current is larger than 105% of motor 4 rated current again within 60 sec., the counting time reduces and is less than Pr.14-83)		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds at	fter the fault is cleared	
	Record	Yes		
	Cause		Corrective Actions	
The load	d is too large	Reduce the load.		
Accel. /	Decel. time or the working	Increase the actting value	vo for Dr 04 42 04 40 (coool / door times)	
cycle are	e too short	increase the setting value	ue for Pr.01-12–01-19 (accel./ decel. time)	
		Adjust the settings for Pr.01-62–01-70 (V/F curve), especially the setting value		
V/F volta	age is too high	for the mid-point voltage (if the mid-point voltage is set too low, the load capacity		
		decreases at low speed).		
Overload during low-speed				
operation. When using a general		Decrease low-speed operation time.		
motor, even it operates below		Replace the drive with a dedicated to VFD model.		
rated cu	rrent, an overload may still	Increase the motor capacity.		
occur during low-speed operation.				
When using VFD dedicated motor,				
	•	Pr.14-82 = 1 electronic thermal relay selection motor 1 = standard motor (motor		
	lection motor 1 = inverter	with fan on the shaft).		
motor)				
Incorrect thermal	t value of electronic relay	Reset to the correct motor rated current.		
The maximum motor frequency is set too low		Reset to the correct motor rated frequency.		
One driv	ve to multiple motors	Set Pr.14-82 electronic thermal relay 4 selection = 2 disable, and install thermal		
One drive to maniple motors		relay on each motor.		
Check if the setting for stall		Set the stall prevention to the proper value.		
prevention is correct.				
Torque compensation is too large		Adjust the torque compensation (refer to Pr.07-75 torque compensation gain) until the current reduces and the motor does not stall.		
Motor fan error Check the status of the fan, or replace the fan.		fan, or replace the fan.		
Unbalanced three-phase		Replace the motor.		
impedan	nce of the motor	ποριασε της ποτοι.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions		
140 X & S		oc hardware error (Hd6)	GFF hardware protection error when power is ON.		
		Action and	d Reset		
	Action level	Hardware detection			
Action time		Immediately act when the fault is detected			
Fault treatment parameter		N/A			
Reset method		Power-off			
Reset condition		N/A			
Record		Yes			
Cause		Corrective Actions			
Hardware failure		Cycle the power. If Hd6 still exists, return to the factory for repair.			

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
141	840FF		The ground short circuit detected when the output wiring detection is performed before the drive runs.	
		Action and	l Reset	
	Action letablvel	250% of the rated curre	nt	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
Reset condition		Reset in five seconds after the fault is cleared		
Record		Yes		
Cause		Corrective Actions		
Incorrect wiring for the motor		Check if the motor's internal wiring and the UVW wiring of the drive output terminal are correct.		
Short-circuit at motor output due to		Check the motor cable and remove causes of the short circuits, or replace the		
poor insulation wiring		cable before turning on the power.		
Check for possible burnout or		Check the motor insulation value with megger. Replace the motor if the		
aging in	sulation of the motor	insulation is poor.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
142	8081	Auto-tune error 1 (AuE1)	No feedback current error when the motor parameter automatically detects	
		Action and Reset		
	Action level	Software detection		
Action time		Immediately act		
Fault treatment parameter		N/A		
Reset method		Manual reset		
Reset condition		Immediately reset		
Record		Yes		
Cause		Corrective Actions		
Motor is not wired		Wire the motor correctly		
The electromagnetic contactor is used as an open state on the output side of the drive (U/V/W).		Check if the electromagnetic valve is closed.		

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions		
143	8082	Auto-tune error 2 (AuE2)	Motor phase loss error when the motor parameter automatically detects		
		Action and Reset			
Action level		Software detection			
	Action time	Immediately act			
Fau	ılt treatment parameter	N/A			
Reset method		Manual reset			
Reset condition		Immediately reset			
Record		Yes			
Cause		Corrective Actions			
Incorrect motor wiring		Wire the motor correctly.			
Motor error		Check if the motor works normally.			
The electromagnetic contactor is					
used as an open state on the		Verify that the three-phases of the electromagnetic valve are all closed.			
output side of the drive (U/V/W).					
Motor U	/V/W wire error	Check if the wires are broken.			

ID*	Display on LCD Keypad	Fault Name	Fault Descriptions	
144	8583	Auto-tune error 3 (AuE3)	No load current I ₀ measurement error when the motor parameter automatically detects.	
		Action and	d Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fault treatment parameter		N/A		
Reset method		Manual reset		
Reset condition		Immediately reset		
Record		Yes		
Cause		Corrective Actions		
Incorrect settings for the motor parameter (rated current) Check the settings for I		Check the settings for F	Pr.05-01 / Pr.05-13 / Pr.05-34.	
Motor e	rror	Check if the motor works normally.		

Chapter 14 Fault Codes MS300

[This page intentionally left blank]

15-1	CANopen Overview
15-2	Wiring for CANopen
15-3	CANopen Communication Interface Descriptions
15-4	CANopen Supported Index
15-5	CANopen Fault Codes

15-6 CANopen LED Function

The built-in CANopen function is a kind of remote control. You can control the AC motor drive using the CANopen protocol. CANopen is a CAN-based higher layer protocol that provides standardized communication objects, including real-time data (Process Data Objects, PDO), configuration data (Service Data Objects, SDO), and special functions (Time Stamp, Sync message, and Emergency message). It also has network management data, including Boot-up message, NMT message, and Error Control message. Refer to the CiA website http://www.can-cia.org/ for details.

Delta CANopen supported functions:

- Supports CAN2.0A Protocol
- Supports CANopen DS301 V4.02
- Supports DSP-402 V2.0

Delta CANopen supported services:

- PDO (Process Data Objects): PDO1-PDO4
- SDO (Service Data Objects):

Initiate SDO Download;

Initiate SDO Upload;

Abort SDO;

You can use the SDO message to configure the slave node and access the Object Dictionary in every node.

SOP (Special Object Protocol):

Supports default COB-ID in Predefined Master/Slave Connection Set in DS301 V4.02;

Supports SYNC service;

Supports Emergency service.

NMT (Network Management):

Supports NMT module control;

Supports NMT Error control;

Supports Boot-up.


Delta CANopen does not support this service:

Time Stamp service


15-1 CANopen Overview

CANopen Protocol

CANopen is a CAN-based higher layer protocol, and was designed for motion-oriented machine control networks such as handling systems. Version 4.02 of CANopen (CiA DS301) is standardized as EN50325-4. The CANopen specifications cover the application layer and communication profile (CiA DS301), as well as a framework for programmable devices (CiA DS302), recommendations for cables and connectors (CiA DS303-1) and SI units and prefix representations (CiA DS303-2).



RJ45 Pin Definition




PIN	Signal	Description					
1 CAN_H CAN_H bus line (dominant high)							
2	CAN_L	CAN_L bus line (dominant low)					
3	CAN_GND	Ground / 0 V / V-					
6	CAN_GND	Ground / 0 V / V-					

CANopen Communication Protocol contains the following services:

- NMT (Network Management Object)
- SDO (Service Data Objects)
- PDO (Process Data Objects)
- EMCY (Emergency Object)

NMT (Network Management Object)

The Network Management (NMT) follows a Master/Slave structure for executing NMT service. A network has only one NMT master, and the other nodes are slaves. All CANopen nodes have a present NMT state, and the NMT master can control the state of the slave nodes. The following shows the state diagram of a node:



- (1) After power is applied, start in the auto-initialization state
- (2) Automatically enter the pre-operational state
- (3) (6) Start remote node
- (4) (7) Enter the pre-operational state
- (5) (8) Stop remote node
- (9) (10) (11) Reset node
- (12) (13) (14) Reset communication
- (15) Automatically enter the reset application state
- (16) Automatically enter the reset communication state

Α	١:	NMT	

B: Node Guard

C: SDO

D: Emergency

E: PDO

F: Boot-up

	Initializing	Pre-Operational	Operational	Stopped
PDO			0	
SDO		0	0	
SYNC		0	0	
Time Stamp		0	0	
EMCY		0	0	
Boot-up	0			
NMT		0	0	0

SDO (Service Data Objects)

Use SDO to access the Object Dictionary in every CANopen node using the Client/Server model. One SDO has two COB-IDs (request SDO and response SDO) to upload or download data between two nodes. There is no data limit for SDOs to transfer data, but it must transfer data by segment when the data exceeds four bytes with an end signal in the last segment. However, MS300 series does not support transferring data by segment.

The Object Dictionary (OD) is a group of objects in a CANopen node. Every node has an OD in the system, and OD contains all parameters describing the device and its network behavior. The access path in the OD is the index and sub-index; each object has a unique index in the OD, and has a sub-index if necessary.

					Dat	ta 0				Data 1	Data 2	Data 3	Data 4	Data 5	Data 6	Data 7
Туре		7	6	5	4	3	2	1	0	Index	Index	Index	Data	Data	Data	Data
		cor	nma	and						L	Н	Sub	LL	LH	HL	НН
Domain	Client	0	0	1	-	1	٧	Е	s							
Download	Server	0	1	1	-	-	-	-	-							
Domain	Client	0	1	0	-	-	-	-	-							
Upload	Server	0	1	0	-	1	٧	Е	s							
Abort Domain	Client	1	0	0	-	-	-	-	-							
Transfer	Server	1	0	0	-	-	-	-	-							

N: Bytes not used; E: normal (0) / transferred (1); S: data size

PDO (Process Data Objects)

PDO communication can be described by the producer/consumer model. Each node of the network listens to the messages of the transmission node and distinguishes whether the message has to be processed or not after receiving the message. A PDO can be transmitted from one device to one another device or to many other devices. Every PDO has two PDO services: a TxPDO and an RxPDO. PDOs are transmitted in a non-confirmed mode. All transmission types are listed in the following table

Tura Numahar	PDO									
Type Number	Cyclic	Acyclic	Synchronous	Asynchronous	RTR only					
0		0	0							
1–240	0		0							
241–251	Reserved									
252			0		0					
253				0	0					
254				0						
255				0						

- Type number 1–240 indicates the number of SYNC message between two PDO transmissions.
- Type number 252 indicates the data is updated (but not sent) immediately after receiving SYNC.
- > Type number 253 indicates the data is updated immediately after receiving RTR.
- > Type number 254: Delta CANopen does not support this transmission format.
- > Type number 255 indicates the data is an asynchronous transmission.


All PDO transmission data must be mapped to the index with Object Dictionary.

EMCY (Emergency Object)

When errors occur inside the hardware, an emergency object is triggered. An emergency object is only sent when an error occurs. As long as there is nothing wrong with the hardware, there is no emergency object warning of an error message.

15-2 Wiring for CANopen

Use an external CANopen communication card CMM-COP01 for CANopen wiring to connect the CANopen to the MS300 drive. The link uses an RJ45 cable. You must wire the two farthest ends with 120 Ω terminating resistors as shown in the picture below.



15-3 CANopen Communication Interface Descriptions

15-3-1 CANopen Control Mode Selection

There are two control modes for CANopen: the DS402 standard (Pr.09-40=1) is the default, and the Delta's standard setting (Pr.09-40=0). There are two control modes according to Delta's standard. One is the old control mode (Pr.09-30=0); this control mode can only control the motor drive under the frequency control. The other mode is a new standard (Pr.09-30=1); this new control mode allows the motor drive to be controlled under all kinds of modes. The MS300 currently supports the speed mode. For torque, position and home mode, refer to MH300 series. The following table shows the control mode definitions:

CANonon	Contro	ol Mode				
CANopen Control Mode	Speed					
Control Mode	Index	Description				
DS402 Standard	6042-00	Target rotating speed (RPM)				
Pr.09-40=1						
Delta Standard (Old definition) Pr.09-40=0, Pr.09-30=0	2020-02	Target rotating speed (Hz)				
Delta Standard (New definition)	2060-03	Target rotating speed (Hz)				
Pr.09-40=0, Pr.09-30=1	2060-04	Torque limit (%)				

CANopen	Operatio	n Control
Control Mode	Index	Description
DS402 Standard	6040-00	Operation Command
Pr.09-40=1		
Delta Standard (Old definition) Pr.09-40=0, Pr.09-30=0	2020-01	Operation Command
Delta Standard (New definition)	2060-01	Operation Command
Pr.09-40=0, Pr.09-30=1		

CANopen	Oth	ners
Control Mode	Index	Description
DS402 Standard	605A-00	Quick stop processing mode
Pr.09-40=1	605C-00	Disable operation processing mode
Delta Standard (Old definition) Pr.09-40=0, Pr.09-30=0		
Delta Standard (New definition)		
Pr.09-40=0, Pr.09-30=1		

You can use some indices in either DS402 or Delta's standard. For example:

- 1. Indices that are defined as RO attributes.
- 2. The corresponding index of available parameter groups: (2000–200B-XX)
- 3. Acceleration/Deceleration Index: 604F 6050

15-3-2 DS402 Standard Control Mode

15-3-2-1 Related settings for an AC motor drive (following the DS402 standard)

If you want to use the DS402 standard to control the motor drive, follow these steps:

- 1. Wire the hardware (refer to Section 15-2 Wiring for CANopen).
- 2. Set the operation source: set Pr.00-21 to 3 for CANopen communication card control.
- 3. Set the frequency source: set Pr.00-20 to 6. Choose the source for the Frequency command from the CANopen setting.
- 4. Set DS402 as the control mode: Pr.09-40=1
- 5. Set the CANopen station: set Pr.09-36; the range is between 1–127. When Pr.09-36 = 0, the CANopen slave function is disabled. Note that if an error appears (station address error CAdE or CANopen memory error CFrE) when you finish the station setting, set Pr.00-02 = 7 to reset.
- 6. Set the CANopen baud rate: set Pr.09-37 (CANBUS baud rate: 1 M (0), 500 K (1), 250 K (2), 125 K (3), 100 K (4) or 50 K (5)).
- 7. Set the multiple input functions to Quick Stop. You can also choose to enable or disable; the default setting is disabled. If it is necessary to enable the function, set MI terminal to 53 in one of the following parameters: Pr.02-01–02-07. Note that this function is available in DS402 only.

15-3-2-2 The status of the motor drive (following the DS402 standard)

According to the DS402 definition, the motor drive is divided into 3 blocks and 9 statuses as described below.

3 blocks

- 1. Power Disable: without PWM output
- 2. Power Enable: with PWM output
- 3. Fault: one or more errors have occurred.

9 statuses

- 1. Start: power on
- 2. Not Ready to Switch On: the motor drive is initiating.
- 3. Switch On Disable: occurs when the motor drive finishes initiating.
- 4. Ready to Switch On: warming up before running.
- 5. Switch On: the motor drive has the PWM output, but the reference command is not effective.
- 6. Operation Enable: able to control normally.
- 7. Quick Stop Active: when there is a Quick Stop request, stop running the motor drive.
- 8. Fault Reaction Active: the motor drive detects conditions which might trigger error(s).
- 9. Fault: one or more errors have occurred in the motor drive.


When the motor drive turns on and finishes the initiation, it remains in Ready to Switch On status. To control the operation of the motor drive, change to Operation Enable status. To do this, set the control word's bit0-bit3 and bit7 of the Index 6040H and pair with Index Status Word (Status Word 0X6041). The control steps and index definition are described below.

Index 6040

-								
	15–9	8	7	6–4	3	2	1	0
	Reserved	Halt	Fault Reset	Operation	Enable operation	Quick Stop	Enable Voltage	Switch On

Index 6041

15–14	13–12	11	10	9	8	7	6	5	4	3	2	1	0
Reserved	Operation	Internal limit active	Target reached	Remote	Reserved	Warning	Switch on disabled	Quick stop	Voltage enabled	Fault	Operation enable	Switch on	Ready to switch on



Set command 6040 = 0xE, and then set another command 6040 = 0xF. Then you can switch the motor drive to Operation Enable. The Index 605A determines the direction of the lines from Operation Enable when the control mode changes from Quick Stop Active. When the setting value is 1–3, both direction lines are active, but when the setting value of 605A is not 1–3, once the motor drive is switched to Quick Stop Active, it is not able to switch back to Operation Enable...

Index	Sub	Definition	Default	R/W	Size	Unit	PDO Map	Mode	note
605Ah	0	Quick stop option code	2	RW	S16		No		Disable drive function Slow down on slow down ramp Slow down on quick stop ramp Slow down on slow down ramp and stay in Quick Stop Slow down on quick stop ramp and stay in Quick Stop Slow down on the current limit and stay in Quick stop

When the control block switches from Power Enable to Power Disable, use 605C to define the stop method.

Index	Sub	Definition	Default	R/W	Size	Unit	PDO Map	Mode	note
605Ch	0	Disable operation option code	1	RW	S16		No		0: Disable drive function 1: Slow down with slow down ramp; disable the drive function.

15-3-2-3 Various mode control method (following the DS402 standard)

MS300 supports the speed control mode. The speed control mode is described below.

Speed mode:

- 1. Set MS300 to the speed control mode: set Index6060 to 2.
- 2. Switch to Operation Enable mode: set 6040 = 0xE, and then set 6040 = 0xF.
- 3. Set the target frequency: set target frequency for 6042. Since the operation unit of 6042 is rpm, a conversion is required.

$$n = f \times \frac{120}{p}$$
 n: rotation speed (rpm) (revolutions/minute)

P: number of poles of the motor (Pole)


f: rotation frequency (Hz)

For example:

Set 6042H = 1500 (rpm), if the number of poles for the drive is 4 (Pr.05-04, Pr.05-16, Pr.05-67 or Pr.05-73), then the motor drive's operation frequency is 1500 (120/4) = 50 Hz. The 6042 is defined as a signed operation. The plus or minus sign means to rotate clockwise or counter-clockwise.

- 4. To set acceleration and deceleration: use 604F (Acceleration) and 6050 (Deceleration).
- 5. Trigger an ACK signal: in the speed control mode, control the bit 6–4 of Index 6040. It is defined below.

		Index 6040	Result		
	bit 6	bit 5	bit 4	Result	
Speed mode	1	0	1	Locked at the current frequency.	
(Index 6060 = 2)	1	1 1		Run to reach the target	
				frequency.	
		Other		Decelerating to 0 Hz.	



NOTE 1: Read 6043 to get the current rotation speed (unit: rpm)

NOTE 2: Read bit 10 of 6041 to check if the rotation speed has reached the targeting value (0: Not reached; 1: Reached).

15-3-3 Using the Delta Standard (Old definition, only supports speed mode)


15-3-3-1 Various mode control method (following the Delta old standard)

If you want to use the Delta old standard to control the motor drive, follow these steps:

- 1. Wire the hardware (refer to Section 15-2 Wiring for CANopen).
- 2. Set the operation source: set Pr.00-21 to 3 for CANopen communication card control.
- 3. Set the frequency source: set Pr.00-20 to 6. Choose the source for the Frequency command from the CANopen setting.
- 4. Set Delta Standard (Old definition, only supports speed mode) as the control mode: Pr.09-40 = 0 and Pr.09-30 = 0.
- 5. Set the CANopen station: set Pr.09-36; the range is between 1–127. When Pr.09-36 = 0, the CANopen slave function is disabled. Note that if an error appears (station address error CAdE or CANopen memory error CFrE) when you finish the station setting, set Pr.00-02 = 7 to reset.
- 6. Set the CANopen baud rate: set Pr.09-37 (CANBUS baud rate: 1 M (0), 500 K (1), 250 K (2), 125 K (3), 100 K (4) and 50 K (5))

15-3-3-2 The control method under speed mode

- 1. Set the target frequency: set 2020-02, the unit is Hz, with 2 decimal places. For example, 1000 is 10.00 Hz.
- 2. Operation control: set 2020-01 = 0002H for running, and set 2020-01 = 0001H for stopping.



15-3-4 By Using Delta Standard (New Definition)

15-3-4-1 Related settings for an AC motor drive (following the Delta new standard)


If you want to use the Delta new standard to control the motor drive, follow these steps:

- Wire the hardware (refer to Section 15-2 Wiring for CANopen).
- 2. Set the operation source: set Pr.00-21 to 3 for CANopen communication card control.
- 3. Set the frequency source: set Pr.00-20 to 6. Choose the source for the Frequency command from the CANopen setting.
- 4. Set Delta Standard (New definition) as the control mode: Pr.09-40 = 0 and 09-30 = 1.
- 5. Set the CANopen station: set Pr.09-36; the range is between 1–127. When Pr.09-36=0, the CANopen slave function is disabled. Note that if an error appears (station address error CAdE or CANopen memory error CFrE) when you finish the station setting, set Pr.00-02 = 7 to reset.
- 6. Set the CANopen baud rate: set Pr.09-37 (CANBUS baud rate: 1 M (0), 500 K (1), 250 K (2), 125 K (3), 100 K (4) and 50 K (5))

15-3-4-2 Various mode control method (Delta New Standard)

Speed Mode:

- 1. Set MS300 to speed control mode: set index 6060 = 2.
- Set the target frequency: set 2060-03, unit is Hz, with 2 decimal places. For example, 1000 is 10.00 Hz.
- 3. Operation control: set 2060-01 = 008H for server on, and set 2060-01 = 0081H for running.



15-3-5 Control DI / DO / AI / AO through CANopen

To control the DO and AO of the motor drive through CANopen, follow these steps:

- 1. Define the DO to be controlled by CANopen. For example, set Pr.02-13 = 50 to control RY1.
- 2. Define the AO to be controlled by CANopen. For example, set Pr.03-20 = 20 to control AFM.
- 3. Control the Index mapped by CANopen. To control DO, use control Index 2026-41. To control AO, use control 2026-A1. To set RY1 as ON, set bit 0 of Index 2026-41 = 1, then RY1 outputs 1. To control AFM output = 50.00%, set Index 2026-A1 = 5000, then AFM outputs 50%.

The following table shows the mapping of CANopen DI / DO / AI / AO:

DI:

Terminal	Related Parameters	R/W	Mapping Index						
MI 1	==	RO	2026-01 bit 0						
MI 2	==	RO	2026-01 bit 1						
MI 3	==	RO	2026-01 bit 2						
MI 4	==	RO	2026-01 bit 3						
MI 5	==	RO	2026-01 bit 4						
MI 6	==	RO	2026-01 bit 5						
MI 7	==	RO	2026-01 bit 6						

DO:

Terminal	Related Parameters	R/W	Mapping Index
RY	Pr.02-13 = 50	RW	bit 0 of 2026-41 initial value 0x01
MO1	Pr.02-16 = 50	RW	bit 3 of 2026-41 initial value 0x01
MO2	Pr.02-17 = 50	RW	bit 4 of 2026-41 initial value 0x01

AI:

Terminal	Related Parameters	R/W	Mapping Index
AVI	==	RO	Value of 2026-61
ACI	==	RO	Value of 2026-62

AO:

Terminal	Related Parameters	R/W	Mapping Index
AFM	Pr.03-20 = 20	RW	Value of 2026-A1

15-4 CANopen Supported Index

MS300 Supported Parameter Index:

The parameter index corresponds as shown in this example:

Index sub-Index 2000H + Group member+1

For example:

Pr.10-15 (Encoder Stall and Slip Error Action)

Group member 10(0AH) - 15(0FH)

Index = 2000H + 0AH = 200A Sub-Index = 0FH + 1H = 10H

MS300 Supported Control Index:

Delta Standard Mode (Old Definition)

Index	Sub	Definition	Default	R/W	Size	Note					
	0	Number	3	R	U8						
							00B: Disable				
						bit 1–0	01B: Stop				
						DIL I-U	10B: Disable				
							11B: JOG Enable				
						bit 3–2	Reserved				
							00B:Disable				
						bit 5–4	01B: Direction forward				
						DIL 3-4	10B: Direction reverse				
							11B: Switch direction				
							00B: 1st step accel. /decel.				
						bit 7–6	01B: 2 nd step accel. /decel.				
						ס–7 זומ	10B: 3 rd step accel. /decel.				
							11B: 4 th step accel. /decel.				
							0000B: Master speed				
							0001B: 1 st step speed				
			0	RW	U16		0010B: 2 nd step speed				
	1	Control word					0011B: 3 rd step speed				
	'	Control Word					0100B: 4 th step speed				
2020H							0101B: 5 th step speed				
202011							0110B: 6 th step speed				
						bit 11–8	0111B: 7 th step speed				
							1000B: 8 th step speed				
							1001B: 9 th step speed				
							1010B: 10 th step speed				
							1011B: 11 th step speed				
							1100B: 12 th step speed				
							1101B: 13 th step speed				
							1110B: 14 th step speed				
							1111B: 15 th step speed				
						bit 12	1: Enable the function of bit 6–11				
							00B: No function				
							01B: Operation command by				
						bit 14-13	the digital keypad				
							10B: Operation command by Pr.00-21 setting				
							11B: Switch the operation				
							command source				
						bit 15	Reserved				
						ווווט	i tesei veu				

Index	Sub	Definition	Default	R/W	Size		Note
	2	Freq. command (XXX.XX Hz)	0	RW	U16		
						bit 0	1: E.F. ON
2020H	3	Other trigger	0	RW	U16	bit 1	1: Reset
		Outer algger		1000	0.0	bit2	1: Base Block (B.B) ON
						bit 15–3	Reserved
	0	Number	DH	R	U8		
	1	Error code	0	R	U16		Warning Code
	-						Error Code
	2	AC motor drive status	0	R	U16	bit 1–0	00B: Stop
							01B: Decelerate to stop
							10B: Waiting for operation
							command 11B: In operation
						bit 2	1: JOG command
						bit 4–3	00B: Run forward
						DIL 4-3	01B: Switch from run in reverse
							to run forward
							10B: Switch from run forward
							to run in reverse
							11B: Run in reverse
						bit 7–5	Reserved
							1: Master Frequency command
						bit 8	controlled by communication
							interface
							1: Master Frequency
						bit 9	command controlled by
							analog signal input
						bit 10	1: Operation command controlled by communication
2021H						DIL 10	interface
						bit11	1: Parameter lock
							1: Enable the digital keypad
						bit12	copy parameter function
						bit 15-13	Reserved
	2	Frequency command	0	В	1146		
	3	(XXX.XXHz)	0	R	U16		
	4	Output freq. (XXX.XX Hz)	0	R	U16		
	5	Output current (XX.XA)	0	R	U16		
	6	DC bus voltage (XXX.X V)	0	R	U16		
	7	Output voltage (XXX.X V)	0	R	U16		
	8	The current step run by the	0	R	U16		
		multi-step speed command Reserved	0		U16		
			0	R R	U16		
		Display counter value (c) Display output power factor					
	В	angle (XX.X°)	0	R	U16		
	С	Display output torque (XX.X%)	0	R	U16		
		Display motor speed (rpm)	0	R	U16		
		Reserved					
	F	Reserved					
	10	Power output (X.XXX kWH)	0	R	U16		
	17	Multi-function display	0	R	U16		
		(Pr.00-04)					
	0	Reserved	0	R	U16		
	1	Display the drive's output	0	R	U16		
00001		current					
2022H	2	Counter value	0	R	U16		
	3	Actual output frequency	0	R	U16		
	4	(XXX.XX Hz) DC bus voltage (XXX.X V)	0	R	U16		
	4	DO bus vollage (AAA.A V)	U		010	<u> </u>	

Index	Sub	Definition	Default	R/W	Size	Note
	5	Output voltage (XXX.X V)	0	R	U16	
	6	Power factor angle (XX.X°)	0	R	U16	
	7	Display the output power of U,	0	R	U16	
		V, W in kW				
	8	Display the motor speed estimated by the drive or	0	R	U16	
		encoder feedback in rpm		1.	0.10	
		Display the positive / negative				
	9	output torque estimated by the	0	R	U16	
		drive (+0.0: positive torque;			010	
	Α	-0.0: negative torque) Reserved				
		Display the PID feedback value				
	В	after enabling the PID function	0	R	U16	
		in % (to two decimal places)				
		Display the AVI analog input terminal signal, 0–10 V				
	С	corresponds to 0.00–100.00%	0	R	U16	
		(see Explanation 1 in Pr.00-04)				
		Display the ACI analog input				
	Ь	terminal signal, 4–20 mA / 0–10 V corresponds to	0	R	U16	
		0.00–100.00% (2.) (see	U	11	010	
		Explanation 2 in Pr.00-04)				
	F	IGBT temperature of the power module in °C	0	R	U16	
		The digital input status (ON /				
	11	OFF), refer to Pr.02-12	0	R	U16	
		(see Explanation 2 in Pr.00-04)				
	10	The digital output status (ON / OFF), refer to Pr.02-18	0	R	U16	
200011	12	(see Explanation 3 in Pr.00-04)	U	К	016	
2022H	13	Current step for the multi-step	0	R	U16	
	10	speed operation			010	
	14	The corresponding CPU digital input pin status (d.)	0	R	U16	
		(see Explanation 3 in Pr.00-04)			010	
		The corresponding CPU digital				
	15	output pin status (O.) (see Explanation 4 in	0	R	U16	
		Pr.00-04)				
		Reserved				
		Pulse input frequency (PG2 of	0	R	U16	
		the PG card) Reserved				
		Counter value of overload			1140	
	1A	(0.00–100.00%)	0	R	U16	
		GFF in %	0	R	U16	
	1C	DC bus voltage ripples (Unit: VDC)	0	R	U16	
	1D	PLC register D1043 data	0	R	U16	
	45	Magnetic field area of the	0	R	U16	
	10	synchronous motor	<u> </u>	11	010	
	1F	User page displays the value in physical measure	0	R	U16	
	20	Output value of Pr.00-05	0	R	U16	
		Reserved	-			
		Reserved				
	23	Reserved				
	24	Control mode of the drive 0: speed mode 1: torque mode	0	R	U16	
	25	Carrier frequency of the drive	0	R	U16	
		Reserved	-		J. V	

Index	Sub	Definition	Default	R/W	Size	Note
	27	Motor status				
		Output positive/ negative				
	28	torque of motor drive				
		calculation				
		Torque command				
	2A	kWh display				
2022H	2B	Reserved				
	2C	Reserved				
	2D	Reserved				
	2E	Reserved				
	2F	PID target value				
	30	PID offset				
	31	PID output frequency				

CANopen Remote IO Mapping

Index	Sub	R/W	Definition
	01h	R	Each bit corresponds to different input terminals.
	02h	R	Each bit corresponds to different input terminals.
	03h-40h	R	Reserved
	41h	RW	Each bit corresponds to different output terminals
2026H	42h-60h	R	Reserved
202011	61h	R	AVI (%)
	62h	R	ACI (%)
	63h	R	Reserved
	64h-A0h	R	Reserved
	A1h	RW	AFM1 (%)

Index	bit 0	bit 1	bit 2	bit 3	bit 4	bit 5	bit 6	bit 7	bit8	bit9	bit10	bit11	bit12	bit13	bit14	bit15
2026-01																
DI	MI1	MI2	MI3	MI4	MI5	MI6	MI7									

1: Control broad I/O (Standard)

Delta Standard Mode (New Definition)

Indov	aub	DAM	Sizo	-	Description	ons	Speed Made						
Index	sub	IT / V V	Size	bit	Definition	Priority	Speed Mode						
	00h	R	U8										
				0	Ack	4	0: fcmd = 0 1: fcmd = Fset (Fpid)						
				1	Dir	4	0: FWD run command 1: REV run command						
				2									
		RW	V U16							3	Halt	3	Drive runs until target speed is reached Drive stops by deceleration setting
	01h			4	Hold	4	Drive runs until target speed is reached Frequency stops at current frequency						
2060h				5	JOG	4	0: JOG OFF Pulse 1: JOG RUN						
				6	QStop	2	Quick Stop						
				7	Power	1	0: Power OFF 1: Power ON						
				8	Ext_md2	4	0→1: Absolute position cleared						
	01h	RW	U16	14–9									
	OIII	1700	010	15	RST	4	Pulse 1: Fault code cleared						
	02h	RW			Mode Cmd		0: Speed mode						
	03h	RW					Speed command (unsigned decimal)						
	04h	RW											
	05h	RW	S32										
	06h	RW											

Indov	aub	D/M	Size		Description	ons	Speed Made					
Index	Sub	IT(V V	SIZE	bit	Definition	Priority	Speed Mode					
2060h	07h	RW	U16									
200011	08h	RW	U16									
				0	Arrive		Frequency command reached					
				1	Dir		0: Motor FWD run 1: Motor REV run					
				2	Warn		Warning occurs					
	01h	R	U16	3	Error		Error detected					
	0 111		010	4								
				5	JOG		JOG					
2061h				6	QStop		Quick stop					
200111				7	Power On		Switch ON					
				15–8								
	02h	R										
	03h	R	U16				Actual output frequency					
	04h	R										
	05h	R	S32				Actual position (absolute)					
	06h	R										
	07h R S16 Ac						Actual torque					

DS402 Standard

							PDO		
Index	Sub	Definition	Default	R/W	Size	Unit	Мар	Mode	Note
6007h	0	Abort connection option code	2	RW	S16		Yes		0: No action 2: Disable voltage 3: Quick Stop
603Fh	0	Error code	0	R0	U16		Yes		
6040h	0	Control word	0	RW	U16		Yes		
6041h	0	Status word	0	R0	U16		Yes		
6042h	0	velocity mode target velocity	0	RW	S16	rpm	Yes	vl	
6043h	0	velocity mode velocity demand	0	RO	S16	rpm	Yes	vl	
6044h	0	velocity mode control effort	0	RO	S16	rpm	Yes	vl	
604Fh	0	velocity mode ramp function time	10000	RW	U32	1ms	Yes	vl	The minimum unit is 100 ms. For example, when it is set
6050h	0	velocity mode slow down time	10000	RW	U32	1ms	Yes	vl	to 290 ms, it is regarded as 200 ms. When it is set to 10301 ms, it is regarded as
6051h	0	velocity mode quick stop time	1000	RW	U32	1ms	Yes	vl	10300 ms. In addition, it cannot be set to zero.
605Ah	0	Quick stop option code	2	RW	S16		No		Disable drive function Slow down on slow down ramp Slow down on quick stop ramp Slow down on slow down ramp and stay in QUICK STOP Slow down on quick stop ramp and stay in QUICK STOP
605Ch	0	Disable operation option code	1	RW	S16		No		Disable drive function Slow down with slow down ramp; disable the drive function
6060h	0	Mode of operation	2	RW	S8		Yes		2: Velocity mode
6061h	0	Mode of operation display	2	RO	S8		Yes		Same as above

15-5 CANopen Fault Codes

- Refer to settings for Pr.06-17-Pr.06-22 and Pr.14-70-Pr.14-73
- Refer to Chapter 14 Fault Codes for detailed descriptions.

Setting *	Display	Fault code	Description	CANopen fault register (bit 0-7)	CANopen fault code
1	oc 8	0001H	Over-current during acceleration	1	2213H
2	ocd	0002H	Over-current during deceleration	1	2213H
3	000	0003H	Over-current during steady operation	1	2314H
4	SFF	0004H	Ground fault	1	2240H
6	o c 5	0006H	Over-current at stop	1	2314H
7	οūR	0007H	Over-voltage during acceleration.	2	3210H
8	oūd	ວບໍ່ດີ 0008H Over-voltage during deceleration.		2	3210H
9	oūn	009H	Over-voltage during constant speed.	2	3210H
10	0.5	000AH	Over-voltage at stop.	2	3210H
11	108	000BH	Low-voltage during acceleration	2	3220H
12	Lūd	000CH	Low-voltage during deceleration	2	3220H
13	Lūn	000DH	Low-voltage at constant speed	2	3220H
14	1.55	000EH	Low-voltage at stop	2	3220H
15	orp	000FH	Phase loss protection	2	3130H
16	oX I	0010H	IGBT overheating	3	4310H
18	68 lo	0012H	IGBT temperature detection failure	3	FF00H
21	οĹ	0015H	Over load	1	2310H
22	Eol !	0016H	Electronic thermal relay 1 protection	1	2310H
23	8018	0017H	Electronic thermal relay 2 protection	1	2310H
24	o#3	0018H	Motor overheating	3	FF20H
26	ot !	001AH	Over torque 1	3	8311H
27	065	001BH	Over torque 2	3	8311H
28	υĹ	001CH	Under current	1	8321H
31	c F Z	001FH	EEPROM read error	5	5530H
33	cd l	0021H	U-phase error	1	FF04H
34	cd2	0022H	V-phase error	1	FF05H
35	cd3	0023H	W-phase error	1	FF06H
36	X48	0024H	cc hardware error	5	FF07H

Setting *	Display	Fault code	Description	CANopen fault register (bit 0–7)	CANopen fault code
37	88 I	0025H	oc hardware error	5	FF08H
40	888	0028H	Auto-tuning error	1	FF21H
41	858	0029H	PID loss ACI	7	FF22H
43	PCF2	002BH	PG feedback loss	7	7301H
44	PCF3	002CH	PG feedback stall	7	7301H
45	bllta	002DH	PG slip error	7	7301H
48	8:8	0030H	ACI loss	1	FF25H
49	8.8	0031H	External Fault	5	9000H
50	EF :	0032H	Emergency stop	5	9000H
51	88	0033H	External base block	5	9000H
52	Pcod	0034H	Password is locked	5	FF26H
54	£ 8 1	0036H	Illegal command	4	7500H
55	583	0037H	Illegal data address	4	7500H
56	883	0038H	Illegal data value	4	7500H
57	£ 8 4	0039H	Data is written to read-only address	4	7500H
58	E 8 10	003AH	Modbus transmission time-out	4	7500H
61	Уdс	003DH	Y-connection / Δ-connection switch error	2	3330H
62	d8b	003EH	Deceleration energy backup error	2	FF27H
63	oSL	003FH	Over slip error	7	FF28H
72	SFL !	0048H	STO Loss 1	5	FF30H
76	5f o	004CH	STO	5	FF31H
77	SFL2	004DH	STO Loss 2	5	FF32H
78	SFL3	004EH	STO Loss 3	5	FF33H
79	Roc	0050H	U-phase over-current before run	1	FF2BH
80	ьос	0051H	V-phase over-current before run	1	FF2CH
81	сос	0050H	W-phase over-current before run	1	FF2DH
82	oPL !	0052H	Output phase loss U phase	2	2331H
83	0865	0053H	Output phase loss V phase	2	2332H
84	oPL3	0054H	Output phase loss W phase	2	2333H
87	ol 3	0057H	Low frequency overload protection	0	8A00H
89	ropd	0059H	Rotor position detection error	0	8A00H

Setting *	Display	Fault code	Description	CANopen fault register (bit 0–7)	CANopen fault code
101	3603	0065H	CANopen guarding error	4	8130H
102	[X8E	0066H	CANopen heartbeat error	4	8130H
104	<u> </u>	0068H	CANopen bus off error	4	8140H
105	[[d8	0069H	CANopen index error	4	8100H
106	3683	006AH	CANopen station address error	4	8100H
107	[FrE	006BH	CANopen index setting exceed limit	4	8100H
111	Ict E	006FH	InrCOM time-out error	4	7500H
121	CP20	007AH	Internal communication error	7	FF36H
123	5593	007CH	Internal communication error	7	FF38H
124	(P30	007DH	Internal communication error	7	FF39H
126	[P32	0080H	Internal communication error	7	FF3BH
127	(P33	0081H	Internal communication error	7	FF3CH
128	o & 3	0082H	Over-torque 3	1	2310H
129	064	0083H	Over-torque 4	1	2310H
134	Eol3	0088H	Internal communication error	1	2310H
135	Eoly	0089H	Internal communication error	1	2310H
140	X48	008EH	oc hardware error	1	2240H
141	640FF	0090H	GFF occurs before run	1	2240H
142	8.8:	0091H	Auto-tune error 1	1	FF3DH
143	8082	0092H	Auto-tune error 2	1	FF3EH
144	8083	0093H	Auto-tune error 3	1	FF3FH


15-6 CANopen LED Function

There are two CANopen flash signs: RUN and ERR.

RUN LED:

LED status	Condition	CANopen Status
OFF	Keep lighting off	Initial
Blinking	ON 200 200 ms ms	Pre-operation
Single flash	ON 200 200 1000 ms ms	Stopped
ON	Keep lighting on	Operation

ERR LED:



Chapter 16 PLC Function Applications

16-1	PLC Summary
16-2	Notes Before Using a PLC
16-3	Turn on
16-4	Basic Principles of PLC Ladder Diagrams
16-5	Various PLC Device Functions
16-6	Introduction to the Command Window
16-7	Error Display and Handling
16-8	Explanation of PLC Speed Mode Control
16-9	Count Function Using Pulse Input

16-1 PLC Summary

16-1-1 Introduction

The commands provided by the MS300's built-in PLC functions, including the ladder diagram editing tool WPLSoft, as well as the use of basic commands and application commands, follow the operating methods of Delta's PLC DVP series.

16-1-2 WPLSoft ladder diagram editing tool

WPLSoft is Delta's software program for the DVP and MS300 programmable controllers in Windows operating system environment. In addition to general PLC program design and general Windows editing functions (such as cut, paste, copy, and multiple windows), WPLSoft also provides many features such as Chinese/English annotation editing, registry editing, settings, file reading, saving, and contact graphic monitoring and settings.

Table 16-1 lists the basic requirements for installing the WPLSoft editing software:

Item	System requirements
Operating system	Windows [®] XP / Vista / 7 (32-bit / 64-bit) / 8 / 10 (64-bit)
CPU	At least Pentium 90
Memory	At least 16 MB (we recommend at least 32 MB)
Hard drive	Hard drive capacity: at least 100 MB of free space
Haid drive	One optical drive (to install this software)
Display	Resolution: 640×480, at least 16 colors; it is recommended that the screen
Display	area be set at 800×600 pixels.
Mouse	Ordinary mouse or Windows-compatible pointing device
Printer	Printer with Windows driver software
RS-485 port	Must have at least an RS-485 port to link to the PLC

Table 16-1

16-2 Notes Before Using a PLC

- 1. The MS300 provides two communication serial ports that you can use to download programs to the PLC (see Figure 16-1 below).
- 2. Channel 1 (USB port) communication format is the same as channel 2.
- 3. Channel 2 has a preset communication format of 7, N, 2, 9600; you can change to ASCII in Pr.09-01 (transmission speed) and Pr.09-04 (communication protocol).
- 4. The PLC preset is node 2; you can change the PLC node in Pr.09-35 (PLC address), but this address may not be the same as the drive's address setting in Pr.09-00 (communication address).





Figure 16-1

- 5. The host controller can simultaneously access data from the drive and the internal PLC, using the identifier for the node. For instance, if the drive node is 1 and the internal PLC node is 2, then the host controller command depends on the node address:
 - 01 (node) 03 (read) 0400 (address) 0001 (1 data item), indicating that it must read the data in drive Pr.04-00.
 - 02 (node) 03 (read) 0400 (address) 0001 (1 data item), indicating that it must read the data in internal PLC X0.
- 6. The PLC program is disabled when uploading / downloading programs.
- 7. Note that when using WPR commands to write parameters, you may modify values up to a maximum of 10⁹ times; otherwise, after which a memory write error occurs. The number of modifications depends on whether the parameter value has changed. If you do not change the value, it does not change the number of modifications; however, if the entered value is different from before, the number of modifications increases by one.
- 8. When you set Pr.00-04 to 28, the displayed value is the value of PLC register D1043, as shown in Figure 16-2 below).

Chapter 16 PLC Function Applications | MS300



- In the PLC Run and PLC Stop mode, you cannot set Pr.00-02 to the values 9 or 10, and cannot be reset to the default value.
- 10. You can reset the PLC to the default value when you set Pr.00-02 to 6.
- 11. The corresponding MI function is disabled when the PLC writes to input contact X.
- 12. When the PLC controls the drive operation, the control commands are entirely controlled by the PLC and are not affected by the setting for Pr.00-21.
- 13. When the PLC controls the drive's Frequency commands (FREQ commands), the Frequency commands are entirely controlled by the PLC, and are not affected by the setting for Pr.00-20 or the HAND ON / OFF configuration.
- 14. When the PLC controls the drive operation, if the keypad STOP setting is valid, this triggers a FStP error and causes the drive to stop.

16-3 Turn on

16-3-1 Connect the drive to the PC

Start operating the PLC functions with the following steps:

After pressing the MENU key and choosing 10: PLC on the KPC-CC01 digital keypad (optional), press the ENTER key. And then choose 2: PLC Run and press the ENTER key (see Figure 16-3 below).




Figure 16-3

1. Wiring: Connect the drive's RJ45 communications interface to a PC through the RS-485 cable.





Figure 16-4

2. PLC function usage



Digital keypad (KPMS-LE01)



Select PLC1 to enter PLC mode setting (see Figure 16-6).

PLC 0: Do not implement PLC functions

PLC 1: Initiate PLC Run
PLC 2: Initiate PLC Stop

Figure 16-6

The MS300 automatically switches to PLC mode when the external multi-function input terminals (MI1–MI7) are in PLC Mode selection bit 0 (51) or PLC Mode selection bit1 (52), and the terminal contact is closed or open. In this case, keypad switching is invalid. The corresponding actions are listed in Table 16-2.

PLC r	node	PLC Mode selection	PLC Mode selection	
Using KPC-CC01 (optional)	Using KPMS-LE01	bit1 (52)	bit0 (51)	
Disable	PLC 0	OFF	OFF	
PLC Run	PLC 1	OFF	ON	
PLC Stop	PLC 2	ON	OFF	
Maintain previous state	Maintain previous state	ON	ON	

Table 16-2

Using the MS300 digital keypad to implement the PLC functions

- ☑ When the PLC screen from the keypad is set to PLC0 (or "Disable" on KPC-CC01), the built-in PLC is disabled and you cannot use WPLSoft or ISPSoft to connect to it.
- ☑ When the PLC screen from the keypad is set to PLC1 (or "PLC Run" on KPC-CC01), the built-in PLC is enabled and you can use WPLSoft or ISPSoft to connect to it through Modbus.
- When the PLC screen from the keypad is set to PLC2 (or "PLC Stop" on KPC-CC01), the built-in PLC is enabled and you can use WPLSoft or ISPSoft to connect to it. However, the programs in the built-in PLC do not work.
- ☑ When the built-in PLC is enabled (PLC1 or PLC2), you can switch between PLC Run or PLC Stop through WPLSoft or ISPSoft.
- ☑ The external terminal control method is the same as shown in Table 16-2 above.

NOTE

- When the input / output terminals (MI1–MI7, Relay, and MO) are included in the PLC program, these input / output terminals are used only by the PLC. For example, when the PLC program controls Y0 during PLC operation (PLC1 or PLC2), the corresponding output terminal relay (RA / RB / RC) operates according to the program. At this time, the multifunctional input / output terminal setting has no effect. Because these terminal functions are already being used by the PLC, you can determine the DI / DO / AO in use by the PLC by looking at Pr.02-52, 02-53, and 03-30.
- When the PLC program uses special register D1040, the corresponding AO contact AFM is occupied.

■ Pr.03-30 monitors the action state of the PLC function analog output terminals; bit 0 corresponds to the AFM action state.

16-3-2 I/O device explanation

Input devices:

PLC input relay	X0	X1	X2	X3	X4	X5	X6	X7	X10	X11	X12	X13	X14	X15	X16	X17
Drive input terminal	MI1	MI2	MI3	MI4	MI5	MI6	MI7									

Table 16-3

Output devices:

PLC output relay	Y0	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y10	Y11	Y12	Y13	Y14	Y15	Y16	Y17
Drive output terminal	RY			MO1	MO2											

Table 16-3

RY1 / RY2 / RY3



RY10 / RY11 / RY12



Figure 16-7

16-3-3 Installing WPLSoft

Download and install WPLSoft editing software on Delta's website:

After you install WPLSoft, the WPLSoft program is located in the folder "C: \Program Files\Delta Industrial Automation\WPLSoft x.xx".

16-3-4 Program writing

Step 1. You can run the editing software by double-clicking the WPLSoft icon (see Figure 16-8).






Figure 16-8 Left: WPLSoft icon; right: start screen

Step 2. Then the WPLSoft editing window appears (see Figure 16-9 below). When running the WPLSoft for the first time, before you create a new project file, the menu bar shows only **File**, **View**, **Communications**, **Options**, and **Help** menus.




Figure 16-9

The next time you run WPLSoft, the program opens the last project file you edited. Figure 16-10 describes the main parts of the WPLSoft editing window.




Figure 16-10

Step 3. To open a new project file, on the Toolbar, click the New button (or press Ctrl+N) (see Figure 16-11).




Figure 16-11

Alternatively, on the **File** menu, click **New** (Ctrl+N) (see Figure 16-12).




Figure 16-12

Step 4. This displays the **Select a PLC Model** dialog box where you can enter the **Program Title**, **File Name**, and select the device and communication settings (see Figure 16-13).




Figure 16-13

In the Communication Setting dialog box, define the communication settings and then click OK.




Figure 16-14

When using USB port (MS300 / MH300 series) to connect to the drive, select RS232 for the Connection Setup.

Step 5. After clicking **OK**, you can then begin editing the program. There are two program editing methods: you can edit in the command mode, or edit in the ladder diagram mode (see Figure 16-15).




Figure 16-15

In the ladder diagram mode, you can use the buttons on the function icon row on the toolbar (see Figure 16-16) to edit the programs.




Figure 16-16

Basic Operation

Example: Create the ladder diagram as shown in Figure 16-17.

Figure 16-17

Use the following steps to create the ladder diagram. These steps show you how to use both the mouse and the keyboard (F1–F12) to add functions.

Step 1. Figure 16-18 shows the WPLSoft program after you create a new project file.




Figure 16-18

Step 2. Add an always-open switch. On the toolbar click the always-open switch button or press F1. In the **Input Device Instruction** dialog box, select the device name (such as **M**), device number (such as **10**) and enter comments (such as **auxiliary contact**). Click **OK** when finished. (See Figure 16-19 and Figure 16-20.)




Figure 16-19



Figure 16-20

Step 3. Add an output coil. Click the output coil button or press F7.

In the **Input Device Instruction** dialog box, select the device name (such as **Y**), the device number (such as **0**) and enter comments (such as **output coil**). Click **OK** when finished. (See Figure 16-21 and Figure 16-22.)




Figure 16-21




Figure 16-22

Step 4. On the toolbar, click the Application Command button 🙃 or press F6.

In the **Application Instructions** dialog box, in **Instruction Type** drop-down list, select **All Application Instructions**. In the **Application Instruction** drop-down list, select **END**, or use the keyboard to type "END", and then click **OK**. (See Figure 16-23.)




Figure 16-23

Step 5. Compile the program. On the toolbar, click the Compile button to compile the edited ladder diagram into a command program. After compiling, the number of rungs appear on the left side of the busbar. (See Figure 16-24.)




Figure 16-24

16-3-5 Program download

After you compile your program, click the CODE button . After finish coding, click the Download button. WPLSoft downloads the program to the online PLC in the communication format that you specified for the communication settings.

16-3-6 Program monitoring

After you download the program, confirm that the PLC is in Run mode. On the Communication menu, click Online Mode , and then click **Start Ladder Diagram Control** (see Figure 16-25). This allows you to supervise and operate the ladder diagram while online.




Figure 16-25

16-4 Basic Principles of PLC Ladder Diagrams

16-4-1 Schematic diagram for PLC ladder diagram program scanning

Output results are calculated on the basis of the ladder diagram configuration (internal devices have real-time output before results are sent to an external output point)




Figure 16-26

16-4-2 Introduction to ladder diagrams

Ladder diagrams use a graphic language widely applied in automatic controls. They employ common electrical control circuit symbols. After you use a ladder diagram editor to create a ladder diagram program, the PLC program design is complete. Using a graphic format to control processes is very intuitive and is readily accepted by personnel who are familiar with electrical control circuit technology. Many of the basic symbols and actions in a ladder diagram mimic common electrical devices in conventional automatic control power distribution panels, such as buttons, switches, relays, timers, and counters.

Internal PLC devices: The types and quantities of internal PLC devices vary in different brands of products. Although these internal devices use the same names as the conventional electrical control circuit elements (such as relays, coils, and contacts), a PLC does not actually contain these physical devices, and they instead correspond to basic elements in the PLC's internal memory (bits). For instance, if a bit is 1, this may indicate that a coil is electrified; and if that bit is 0, it indicates that the coil is not electrified. You can use a N.O. contact (Normally Open, or contact A) to directly read the value of the corresponding bit, and use a NC contact (Normally Closed, or contact B) to get the inverse of the bit's value. Multiple relays occupy multiple bits, and eight bits comprise one byte. Two bytes comprise one word, and two words comprise a double word. When multiple relays are processing at the same time (as in addition/subtraction or displacement), it can use a byte, a word, or a double word. Furthermore, a PLC contains two types of internal devices: a timer and a counter. It not only has a coil, but can count time and numerical values. Because of this, when it is necessary to process numerical values, these values are usually in the form of bytes, words, or double words (internally in the PLC).

The various internal devices in a PLC use a certain amount of memory in the PLC's storage area. When you use these devices, the content of the corresponding storage area is read in the form of bits, bytes, or words.

Table 16-5 describes the internal devices in a PLC

Device Type	Description of Function
Input Relay	An input relay constitutes the basic unit of storage in a PLC's internal memory, and corresponds to an external input point. It serves as a terminal connecting with an external input switch and receiving external input signals. It is driven by external input signals, to which it assigns values of 0 or 1. A program design method cannot change the input relay status, and therefore cannot rewrite the corresponding basic units of an input relay. You cannot use WPLSoft to manually perform ON/OFF actions. You can use a relay's contacts (contacts A and B) an unlimited number of times in a program. An input relay with no input signal must be left idle and cannot be used for some other purpose. ☑ Input devices are indicated by X0, X1, X7, X10, X11, and so on. These devices are indicated with the symbol X, and a device's order is indicated with an octal number. Input point numbers are indicated in the main PLC and in expansion devices.
Output Relay	An output relay constitutes the basic unit of storage in a PLC's internal memory, and corresponds to an external output point. It connects with an external load. It can be driven by an input relay contact, a contact on another internal device, or its own contacts. It uses one N.O. contact to connect with external loads or other contacts, and like the input contacts, you can use the output relay's contacts an unlimited number of times in a program. An output relay with no input signal is idle, but can be used by an internal relay if needed. ☑ Output devices are indicated by Y0, Y1, Y7, Y10, Y11, and so on. These devices are indicated with the symbol Y, and a device's order is indicated with an octal number. Output point numbers are indicated in the main PLC and in expansion devices.
Internal Relay	Internal relays have no direct connection with the outside. These relays are auxiliary relays inside a PLC. Their function is the same as that of an auxiliary (central) relay in an electrical control circuit: Each auxiliary relay corresponds to a basic unit of internal storage; they can be driven by input relay contacts, output relay contacts, and the contacts of other internal devices. You can use an internal auxiliary relay's contacts an unlimited number of times in a program. Internal relays have no outputs to the outside, and their status must output through an output point. ☑ Internal relay devices are indicated by: M0, M1–M799, and so on. These devices are indicated with the symbol M, and the device's order is indicated with a decimal number.
Counter	Counters perform counting operations. The setting value for a counter (such as the number of pulses to be counted) must be assigned when a counter is used. A counter contains a coil, contact, and a counting storage device. When the coil goes from OFF → ON, this indicates that the counter receives an input pulse, and adds one to its count. There are 16 bits available in the counter. ☑ Counter device are indicated by: C0, C1–C79, and so on. These devices are indicated by the symbol C, and the device's order is indicated with a decimal number.

Device Type	Description of Function
Timer	Timers perform timing for operations. The timer contains a coil, contact, and a time value register. When the coil is electrified, and the setting value for the timer is reached, the contact is actuated (contact A closes, contact B opens), and the timer's fixed value is given by the setting value. A timer has a regulated clock cycle (timing units: 100 ms). As soon as power to the coil is cut off, the contact is no longer be actuated (contact A opens, contact B closes), and the original timing value returns to zero. ☑ Timer devices are indicated by: T0, T1–T159, and so on. These devices are indicated by the symbol T, and the device's order is indicated with a decimal number.
Data register	Data registers are used exclusively to store data and various parameters. When you use a PLC is to perform various types of sequence control, set time values, and count value controls, the PLC performs data processing and numerical operations and stores the operands, parameters, and results in data registers. Each data register contains 16 bits of binary data (one word). Two data registers with adjacent numbers can process double words. ☑ Data register devices are indicated by: D0, D1− D399, and so on. These devices are indicated by the symbol D, and the device's order is indicated with a decimal number.

Table 16-5

Ladder diagram images and explanations

Ladder diagram structures	Explanation of commands	Command	Using Device
	N.O. switch, contact A	LD	X, Y, M, T, C
	N.C. switch, contact B	LDI	X, Y, M, T, C
	Series N.O.	AND	X, Y, M, T, C
	Series N.C.	ANI	X, Y, M, T, C
	Parallel N.O.	OR	X, Y, M, T, C
	Parallel N.C.	ORI	X, Y, M, T, C
	Rising edge-triggered switch	LDP	X, Y, M, T, C
	Falling edge-triggered switch	LDF	X, Y, M, T, C
	Rising edge-triggered series	ANDP	X, Y, M, T, C
	Falling edge-triggered series	ANDF	X, Y, M, T, C
	Rising edge-triggered parallel	ORP	X, Y, M, T, C

Chapter 16 PLC Function Applications | MS300

Ladder diagram structures	Explanation of commands	Command	Using Device
	Falling edge-triggered parallel	ORF	X, Y, M, T, C
	Block series	ANB	N/A
	Block parallel	ORB	N/A
	Multiple outputs	MPS MRD MPP	N/A
	Coil driven output commands	OUT	Y, M
	Some basic commands, application commands.	Some basic commands, application commands.	
	Inverted logic	INV	N/A

Table 16-6


16-4-3 Overview of PLC ladder diagram editing

The program editing method in WPLSoft begins from the left busbar and proceeds to the right busbar (the right busbar is not visible in WPLSoft). Continue to the next row after completing each row; there are a maximum of 11 contacts on each row. If this is not sufficient, WPLSoft generates a continuous line to indicate the continued connection, so that you can add more devices. A continuous series of numbers is generated automatically and you can use identical input points repeatedly (as shown in the following diagram).

Figure 16-27

The PLC scans a ladder diagram programs from the upper left corner to the lower right corner. The coils and application command computing box are handled in the output, and in the ladder diagram are placed on the farthest right of a rung. Taking the diagram below as an example, we can analyze the procedural sequence of the ladder diagram. The number in the upper right corner gives the sequential order.

Explanation of



Explanation of basic structure of ladder diagrams

LD (**LDI**) **command**: An LD or LDI command appears at the start of a block.




Figure 16-29

LDP and LDF use this command structure, but there are differences in their action state. LDP, LDF only act at the rising or falling edge of a conducting contact (see diagram below).




Figure 16-30

AND (ANI) command: a series configuration in which a single device is connected with one device or a block.



Figure 16-31

ANDP, ANDF use this structure, but their action occurs at the rising and falling edge of a conducting contact.

OR (ORI) command: a single device is connected with one device or a block.




Figure 16-32

ORP, ORF use this structure, but their action occurs at the rising and falling edge a conduction contact.

ANB command: a configuration in which one block is in series with one device or block.




Figure 16-33

ORB command: a configuration in which one block is in parallel with one device or block.




Figure 16-34


In the case of ANB and ORB operations that connect a number of blocks, they should be combined to form a block or network from the top down or from left to right.

MPS, MRD, MPP commands: branching point memory for multiple outputs that enable multiple different outputs. The MPS command begins at a branching point, which refers to the intersection of horizontal and vertical lines. Control relies on the contact status along a single vertical line to determine whether the next contact can give a memory command. While each contact is basically able to give memory commands, in view of convenience and the PLC's capacity restrictions, this can be omitted from some places when editing a ladder diagram. You can use the structure of the ladder diagram to judge what kinds of contact memory commands are used.

MPS is indicated by use of the T symbol. You can use this command consecutively up to eight times. The MRD command is read from branching point memory; because logic states along any one vertical line must be the same, in order to continue analysis of other parts of the ladder diagram, the original contact status must be read. MRD is indicated by the F symbol.

The MPP command is read from the starting state of the uppermost branching point, and it is read from the stack (pop operation); because it is the final command along a vertical line, it indicates that the state of the vertical line can be concluded. MPP is indicated by the ^L symbol.

Although there should basically be no errors when using the foregoing analytical approach, the compiling program may sometimes omit identical state output, as shown in the following diagram.



16-4-4 Common basic program design examples

Start, stop, and protection circuits

Some applications may require a brief close or brief break using a button to start and stop equipment. A protective circuit must therefore be designed to maintain continued operation in these situations. This protective circuit may employ one of the following methods.

Example 1: Priority stop protective circuit

When the start N.O. contact X1=ON, and the stop N.C. contact X2=OFF, Y1=ON. If X2 switches to ON, coil Y1 is no longer electrified, and this is therefore referred to as priority stop.




Figure 16-36

Example 2: Priority start protective circuit

When the start N.O. contact X1=ON, and the stop N.C. contact X2=OFF, Y1=ON, and coil Y1 is electrified and protected. If X2 switches to ON, coil Y1 still protects the contact and continues to be electrified, and this is therefore referred to as priority start.




Figure 16-37

Example 3: Setting (SET) and reset (RST) command protective circuit

The following diagram shows a protective circuit composed of RST and SET commands. A priority stop occurs when you place the RST command after the SET command. Because the PLC executes programs from the top down, at the end of the program, the state of Y1 indicates whether coil Y1 is electrified. When X1 and X2 both actuate, Y1 loses power, and this is therefore referred to as priority stop.

A priority start occurs when you place the SET command after the RST command. When X1 and X2 both actuate, Y1 electrifies, and this is therefore referred to as priority start.

Top priority of stop




Figure 16-38

Top priority of start




Figure 16-39

Commonly used control circuits

Example 4: Conditional control

X1 and X3 respectively start and stop Y1; and X2 and X4 respectively start and stop Y2. All have protective circuits. Because Y1's N.O. contact is in series with Y2's circuit, it becomes an AND condition for the actuation of Y2. The action of Y1 is therefore a condition for the action of Y2, and Y1 must actuate before Y2 can actuate.




Figure 16-40

Example 5: Interlocking control

The diagram below shows an interlocking control circuit. Depending on which of the start contacts X1 or X2 becomes valid first, the corresponding output Y1 or Y2 actuates, and when one actuates, the other does not actuate. Y1 and Y2 cannot actuate at the same time (interlocking effect). Even if both X1 and X2 are valid at the same time, because the ladder diagram program is scanned from the top down, it is impossible for Y1 and Y2 to actuate at same time. This ladder diagram assigns priority only to Y1.




Figure 16-41

Example 6: Sequence control

If the N.C. contact of Y2 in the interlocking control configuration from example 5 is put in series with the Y1 circuit, to create an AND condition for actuation of Y1 (see diagram below), not only is Y1 a condition for the actuation of Y2 in this circuit, but the actuation of Y2 also stops the actuation of Y1. This configuration confirms the actuation order of Y1 and Y2.




Figure 16-42

Example 7: Oscillating circuit

Oscillating circuit with a period of $\Delta T + \Delta T$

The diagram below shows a very simple ladder diagram. When starting to scan the Y1 N.C. contact, because the Y1 coil has lost power, the Y1 N.C. contact is closed. When the Y1 coil is then scanned, it is electrified, and the output is 1. When the Y1 N.C. contact is scanned in the next scanning cycle, because the Y1 coil is electrified, the Y1 N.C. contact is open, the Y1 coil then loses power, and the output is 0. Following repeated scanning, the output of Y1 coil has an oscillating waveform with a period of $\Delta T(ON)+\Delta T(OFF)$.




Figure 16-43

Oscillating circuit with a period of nT+ΔT

The ladder diagram shown below uses timer T0 to control coil Y1's electrified time. After Y1 is electrified, it causes timer T0 to close during the next scanning cycle, which causes the output from Y1 to oscillate as shown in the diagram below. The constant n is the timer's decimal setting value, and T is the clock cycle of the timer.




Figure 16-44

Example 8: Flashing circuit

The following diagram shows an oscillating circuit of a type commonly used to cause an indicator to flash or a buzzer to buzz. It uses two timers to control the ON and OFF time of Y1 coil. Here constants n1 and n2 are the setting values of timers T1 and T2, and T is the clock cycle of the timer.




Figure 16-45

Example 9: Triggering circuit

In the diagram below, a rising edge in input X0 causes coil M0 to generate a single pulse for ΔT (length of one scanning cycle), and coil Y1 is electrified during this scanning cycle. Coil M0 loses power during the next scanning cycle, and N.C. contact M0 and N.C. contact Y1 are both closed. This causes coil Y1 to stay in an electrified state until there is another rising edge in input X0. This again causes the electrification of coil M0 and the start of another scanning cycle, while also causing coil Y1 to lose power, and so on. You can see the sequence of these actions in the diagram below. This type of circuit is commonly used to enable one input to perform two alternating actions. You can see from the time sequence in the diagram below that when input X0 is a square wave signal with a period of T, the output of coil Y1 is a square wave signal with a period of 2T.




Figure 16-46

Example 10: Delay circuit

When input X0 is ON, because the corresponding NC contact is OFF, the timer T10 is in a no power state, and output coil Y1 is electrified. T10 receives power and begins to counter the time only after input X0 is OFF, and output coil Y1 is delayed for 100 seconds (K1000*0.1 sec. =100 sec.) before losing power. You can see the sequence of actions in the diagram below.




Figure 16-47

Example 11: The open/close delay circuit is composed of two timers; output Y4 has a delay no matter input X0 is ON or OFF.




Figure 16-48

Example 12: Extended timing circuit

In the circuit in the ladder diagram on the left, the total delay time from the moment input X0 closes to the time output Y1 is electrified is (n1+n2)*T, where T is the clock cycle. The timers are T11 and T12, and the clock cycle is T.




Figure 16-49

16-5 Various PLC Device Functions

Item	Specifications	Notes
Algorithmic control method	The program is stored internally, alternating back-and-forth scanning method.	The input point renews when the scanning starts, and the output point renews when the scanning ends.
Input / output control method	When the scan starts again after ending (after execution to the END command), the input/output is immediately refreshed.	
Algorithmic processing speed	Basic commands (several µs);	Application command (1 to several tens of µs)
Programming language	Command + ladder diagram	
Program capacity	2000 steps	
Input / output	Digital input (X): 7; digital output (Y): 3	
contacts	Analog input: 2; analog output: 1	

Table 16-7

Туре	Device	Ite	em	Range		Function	
7)	Х	External input		X0–X17, 16 points, octal number	Total 32	Corresponds to external input point	
	Y	External outp	ut relay	Y0–Y17, 16 points, octal number		Corresponds to external output point	
Rel	М	Relay	General Use Special ourpose	M0–M799, 800 points M1000–M1279, 280 points	Total 1080 points	Contact can switch ON/OFF within the program	
Relay bit form	Т	Timer	100 ms timer	T0-T79, 80 points	Total 80 points	Timers referred to by the TMR command; T contact with the same number switches ON when the time is reached.	
	С		16-bit counter, general use	C0–C39, 40 points	Total 40 points	Counter referred to by the CNT command; C contact with the same number switches ON when the count is reached.	
	Т	Current timer value		T0-T79, 80 points		The contact switches ON when the time is reached.	
Regist	С	Current counter value		C0–C39, 16-bit counter 40	points	The counter contact switches ON when the count is reached.	
Register word data	D		Used to maintain power OFF	D0–D9, 10 points	Total	Used as data storage memory area	
data		Data Register	General use	D10-D199, 190 points	420 points		
			Special purpose	D1000–D1219, 220 points	'		
	K	Decimal	Single-byte	Setting Range: K-32,768–			
Constant			Double-byte Single-byte	Setting Range: K-2,147,483,648–K2,147,483,647 Setting Range: H0000–HFFFF		K2,147,483,647	
			Double-byte	Setting Range: H000000000–HFFFFFFFF			
	Serial communication port (program write / read)			RS-485 / USB / keypad port			
			Built-in two analog inputs and one analog output				
High-speed counting			Built-in a (MI7) 32-bit high-speed counter				
Function expansion module Optional Accessories			-				
Comm	Communication Expansion Optional Accessories			CMM-COP02 (CANopen)			
Table 16-8							

Table 16-8

16-5-1 Introduction to device functions

Input/output contact functions

Input contact X has this function: input contact X is connected with an input device, and reads input signals entering the PLC. There are no restrictions on the number of times that the input contact A or B appear in the program. The ON/OFF state of input contact X changes as the input device switches between ON and OFF; you cannot use a peripheral device (WPLSoft) to force contact X ON or OFF.

Output contact Y functions

The output contact Y sends an ON/OFF signal to drive the load connected to output contact Y. There are two types of output contacts: relays and transistors. There are no restrictions on the number of times that contact A or B of an output contact Y appear in a program, but it is recommended that you use the number of output coil Y only once in a program; otherwise the output state when the PLC performs program scanning is determined by the program's final output Y circuit.




Figure 16-50

Numerical value, constant [K] / [H]

Constant	Single-byte	К	Decimal	K-32,768–K32,767
	Double-byte			K-2,147,483,648–K2,147,483,647
	Single-byte	Н	Hexadecimal	H0000-HFFFF
	Double-byte			H0000000—HFFFFFFF

Table 16-9

The PLC uses five types of numerical values to implement calculations based on its control tasks; the following topics explain the use and function of the different numerical values.

Binary Number, BIN

The PLC's numerical operations and memory employ binary numbers. The following table explains terms related to binary numbers.

bit	Bits are the fundamental units of binary values, and have a state of either 1 or 0.
Nibble	Comprised of a series of 4 bits (such as b3–b0); can be used to express a one-nibble decimal number 0–9 or hexadecimal number: 0–F.
Byte	Comprised of a series of two nibbles (i.e. 8 bits, b7–b0); can express a hexadecimal number: 00-FF.
Word	Comprised of a series of two bytes (i.e. 16 bits, b15–b0); can express a hexadecimal number with four nibbles: 0000–FFFF.
Double Word	Comprised of a series of two words (i.e. 32 bits, b31–b0); can express a hexadecimal number with eight nibbles: 00000000–FFFFFFFF

Table 16-10

The following diagram shows the relationship between bits, digits, nibbles, words, and double words in a binary system (see figure below).




Figure 16-51

Octal Number, OCT

The external input and output terminals of a DVP-PLC are numbered using octal numbers.

Example: External input: X0–X7, X10–X17...(Device number table);

External output: Y0–Y7, Y10–Y17...(Device number table)

Decimal Number, DEC

A PLC uses decimal numbers for the following purposes:

- ☑ The setting values of timer T or counter C, such as TMR C0 K50 (K constant).
- ☑ The numbers of devices including M, T, C, or D, such as M10 or T30 (device number).
- ☑ An operand in an application command, such as MOV K123 D0 (K constant).

Binary Coded Decimal, BCD

Uses one nibble or four bits to express the data in a decimal number; a series of 16 bits can therefore express a decimal number with four nibbles. These are used to read the input value of a rotating numerical switch to input or output a numerical value to a seven-segment display drive.

Hexadecimal Number, HEX

A PLC uses hexadecimal numbers as operands in application commands, such as MOV H1A2B D0 (H constant).

Constant K

PLC's usually prefixed decimal numbers with K, such as K100. This indicates that it is a decimal number with a numeric value of 100.

Exceptions: You can combine K with a bit device X, Y, M, or S to produce data in the form of a nibble, byte, word, or double word, such as in the case of K2Y10 or K4M100. Here K1 represents a 4-bit combination, and K2–K4 represent 8-, 12-, and 16-bit combinations.

Constant H

PLC's usually prefixed hexadecimal numbers with H, such as in the case of H100. This indicates a hexadecimal number with a numeric value of 100.

Functions of auxiliary relays

Like an output relay Y, an auxiliary relay M has an output coil and contacts A and B, and you can use the output relay contacts any number of times in a program. You can use an auxiliary relay M to configure the control circuit, but cannot use the auxiliary relay to directly drive an external load. There are two types of auxiliary relays:

Ordinary auxiliary relays: ordinary auxiliary relays all revert to the OFF state when a power outage occurs while the PLC is running, and remains in the OFF state when power is restored.

Special purpose auxiliary relays: each special purpose auxiliary relay has its own specific use. Do not use any undefined special purpose auxiliary relays.

Timer functions

Timers use 100 ms as their timing unit. When the timing method is an upper time limit, and the current timer value = setting value, the timer output coil is energized. Timer setting values use decimal K values; you can also use the data register D as a setting value.

Actual timer setting time = timing units * set value

Counter features

Item	16-bit counter
Туре	General Type
CT Direction:	Up
Setting	0–32,767
Designation of set value	Constant K or data register D
Change in current value	When the count reaches the setting value, it stops counting.
Output contact	When the count reaches the setting value, the contact switches ON and stays ON.
Reset	The current value reverts to 0 when an RST command is executed, and the contact reverts to OFF.
Contact actuation	All are actuated after the end of scanning.

Table 16-11

Counter functions


When a counter's counting pulse input signal switches from OFF to ON, if the counter's current value is equal to the setting value, the output coil switches ON. The setting value can be either a decimal K or a data register D.

16-bit counter:

- ☑ 16-bit counter setting range: K0–K32,767. When K0 and K1 are identical, the output contact is immediately ON during the first count.
- ☐ The current counter value is cleared from an ordinary counter when power to the PLC turns OFF.
- ☑ If you use the MOV command or WPLSoft to transmit a value greater than the setting value to the C0 current value register, when the next X1 switches from OFF to ON, the C0 counter contact changes to ON, and the current value changes to the setting value.

- You can set a counter's setting value directly using a constant K, or indirectly using the value in register D (not including special data registers D1000–D1199 or D2000–D2799).
- ☑ If the setting value is a constant K, the value must be a positive number. If the setting value is from data register D, the value can be either a positive or negative number. If using a data register, and the current value is 32,767, incrementing the count causes the count value to roll over to -32,768 as the count continues to accumulate.

Example



- When X0 = ON and the RST command is executed, the current value of C0 reverts to 0, and the output contact reverts to OFF.
- When X1 switches from OFF to ON, the current value of the counter is incremented by one (add one).
- When the count in C0 reaches the set value K5, the contact C0 switches to ON, and the current value of C0 = setting value = K5.

Afterwards, additional changes in X1 do not affect the count value, and C0 remains at K5.




Figure 16-53

16-5-2 Introduction to special relay functions (special M)

R/W column: RO means read only; RW means read and write.

Special M	Function Descriptions	R/W *
M1000	Monitors N.O. contact (contact A). N.O. while RUN, contact A. This contact is ON while in the RUN state.	RO
M1001	Monitors N.C. contact (contact B). NC while RUN, contact B. This contact is OFF while in the RUN state.	RO
M1002	Initiates a forward pulse (the instant RUN is ON). Initial pulse, contact A. Produces a forward pulse when RUN begins; pulse width = scan cycle.	RO
M1003	Initiates a reverse pulse (the instant RUN is OFF). Initial pulse, contact A. Produces a reverse pulse when RUN ends; pulse width = scan cycle.	RO
M1004		
M1005	Drive malfunction instructions	RO
M1006	Drive has no output	RO
M1007	Drive direction FWD(0) / REV(1)	RO
M1008		
-		
M1010	10	
M1011	10 ms clock pulse, 5 ms ON / 5 ms OFF.	RO
M1012	100 ms clock pulse, 50 ms ON / 50 ms OFF.	RO
M1013	1 sec. clock pulse, 0.5 s ON / 0.5 s OFF	RO
M1014	1 min. clock pulse, 30 s ON / 30 s OFF	RO
M1015	Frequency reached (when used with M1025)	RO
M1016	Parameter read/write error	RO
M1017	Parameter write successful	RO
M1018		
M1019		
M1020	Zero flag	RO
M1021	Borrow flag	RO
M1022	Carry flag	RO
M1023	Divisor is 0	RO
M1024		
M1025	Drive frequency = set frequency (ON) Drive frequency = 0 (OFF)	RW
M1026	Drive operating direction FWD (OFF) / REV (ON)	RW
M1027	Drive Reset	RW
M1028		
M1037		
M1038	MI7 count begins	RW
M1039	Reset MI7 count value	RW
M1040	Hardware power (Servo On)	RW
M1041		
M1042	Quick Stop	RW
M1043		
M1044	Pause (Halt)	RW
M1045		
M1051	Lack fraguency (lack fraguency) lacked at the assument assertion for some	D\^/
M1052	Lock frequency (lock, frequency locked at the current operating frequency)	RW
M1053 — M1055		
M1056	Hardware already has power (Servo On Ready)	RO
M1057		
M1058	On Quick Stopping	RO
141 1000	Table 16 10	

16-5-3 Introduction to special register functions (special D)

Special D	Function Descriptions	R/W *
D1000		
D1001	Device system program version	RO
D1002	Program capacity	RO
D1003	Total program memory content	RO
D1004		
D1009		
D1010	Current scan time (units: 0.1 ms)	RO
D1011	Minimum scan time (units: 0.1 ms)	RO
D1012	Maximum scan time (units: 0.1 ms)	RO
D1013		
D1017		
D1018	Current integral value	RO
D1019	Force setting for PID I integral	RW
D1020	Output frequency (0.00–599.00 Hz)	RO
D1021	Output current (####.#A)	RO
D1022		
	Communication expansion card number	
	0: No expansion card	
D 4000	1: DeviceNet Slave	
D1023	2: Profibus-DP Slave	RO
	3: CANopen Slave 4: Modbus-TCP Slave	
	5: EtherNet/IP Slave	
D1024	J. Eulernette Slave	
-		
D1026		
D1027	PID calculation frequency command (frequency command after PID calculation)	RO
D1028	AVI value (0.00–100.00%)	RO
	ACI value (0.00–100.00%)	RO
D1030		
D1034		
D1035	VR value (0.00–100.00%)	RO
D1036	Servo error bit	RO
D1037	Drive output frequency	RO
D1038	DC bus voltage	RO
D1039	Output voltage	RO
D1040	Analog output value AFM (0.00–100.00%)	RW
D1041		
D1042	Comba war defined (in displayed on march when D 00 04 in the CO 11 in	D) 6 /
D1043	Can be user-defined (is displayed on panel when Pr.00-04 is set to 28; display method is Cxxxx)	RW
D1044		
D1049		
D1050	Actual operation mode 0: Speed	RO
D1051	o. opecu	
D1053		
D1054	MI7 current calculated count value (low word)	RO
D1055	MI7 current calculated count value (high word)	RO
D1056	Rotating speed corresponding to MI7	RO

Chapter 16 PLC Function Applications | MS300

Special D	Function Descriptions	R/W *
D1057	MI7's rotating speed ratio	RW
D1058	MI7 refresh rate (ms) corresponding to rotating speed	RW
D1059	Number of nibbles of rotating speed corresponding to MI7 (0–3)	RW
D1060	Operation mode setting 0: Speed	RW
D1061	485 Modbus communications time-out time (ms)	RW
D1062	Torque command (torque limit in speed mode)	RW
D1063		
D1069	 	
D1100	Target frequency	RO
D1101	Target frequency (must be operating)	RO
D1102	Reference frequency	RO
D1103		
D1106	 	
D1107	π (Pi) low word	RO
D1108	π (Pi) high word	RO
D1109	Random number	RO

Table 16-13

16-5-4 PLC Communication address

Device	Range	Туре	Address (Hex)
X	00–17 (Octal)	bit	0400-040FF
Υ	00–17 (Octal)	bit	0500-050F
Т	00–79	bit/word	0600-064F
M	000–799	bit	0800-0B1F
M	1000–1279	bit	0BE8-0CFF
С	0–39	bit/word	0E00-0E27
D	00–199	word	1000-10C7
D	1000–1219	word	13E8-14C3

Table 16-14

Command codes that can be used

Function Code	Function Descriptions	Function target
H1	Coil status read	Y, M, T, C
H2	Input status read	X, Y, M, T, C
H3	Read single unit of data	T, C, D
H5	Force single coil status change	Y, M, T, C
H6	Write single unit of data	T, C, D
HF	Force multiple coil status change	Y, M, T, C
H10	Write multiple units of data	T, C, D

Table 16-15



When PLC functions have been activated, the MS300 can match the PLC and drive parameters; this method uses different addresses for drives (default station number is 1, PLC sets station number as 2).

16-6 Introduction to the Command Window

16-6-1 Overview of basic commands

Ordinary commands

Command code	Function	OPERAND	Execution speed (μs)
LD	Load contact A	X, Y, M, T, C	0.8
LDI	Load contact B	X, Y, M, T, C	0.8
AND	Connect contact A in series	X, Y, M, T, C	0.8
ANI	Connect contact B in series	X, Y, M, T, C	0.8
OR	Connect contact A in parallel	X, Y, M, T, C	0.8
ORI	Connect contact B in parallel	X, Y, M, T, C	0.8
ANB	Series circuit block	N/A	0.3
ORB	Parallel circuit block	N/A	0.3
MPS	Save to stack	N/A	0.3
MRD	Stack read (pointer does not change)	N/A	0.3
MPP	Read stack	N/A	0.3

Table 16-16

Output command

Command code	Function	OPERAND	Execution speed (µs)
OUT	Drive coil	Y, M	1
SET	Action continues (ON)	Y, M	1
RST	Clear contact or register	Y, M, T, C, D	1.2

Table 16-17

• Timer, counter

Command code	Function	OPERAND	Execution speed (μs)
TMR	16-bit timer	T-K or T-D commands	1.1
CNT	16-bit counter	C-K or C-D (16-bit)	0.5

Table 16-18

Main control command

Command code	Function	OPERAND	Execution speed (μs)	
MC	Common series contact connection	N0-N7	0.4	
MCR	Common series contact release	N0-N7	0.4	

Table 16-19

• Contact rising edge/falling edge detection command

Command code	Function	OPERAND	Execution speed (μs)
LDP	Start of rising edge detection action	X, Y, M, T, C	1.1
LDF	Start of falling edge detection action	X, Y, M, T, C	1.1
ANDP	Rising edge detection series connection	X, Y, M, T, C	1.1
ANDF	Falling edge detection series connection	X, Y, M, T, C	1.1
ORP	Rising edge detection parallel connection	X, Y, M, T, C	1.1
ORF	Falling edge detection parallel connection	X, Y, M, T, C	1.1

Table 16-20

Upper / lower differential output commands

Command code	Function	OPERAND	Execution speed (μs)
PLS	Upper differential output	Y, M	1.2
PLF	Lower differential output	Y, M	1.2

Table 16-21

Stop command

Command code	Function	OPERAND	Execution speed (μs)
END	Program conclusion	N/A	0.2

Table 16-22

Other commands

Command code	Function	OPERAND	Execution speed (μs)	
NOP	No action	N/A	0.2	
INV	Inverse of operation results	N/A	0.2	
Р	Index	Р	0.3	


Table 16-23

16-6-2 Detailed explanation of basic commands

Command	Function								
LD	Load contact A	4							
Onerend	X0-X17	Y0-Y17	M0-M799	T0-159		C0-C79	D0-	D0-D399	
Operand	✓	✓	✓	✓		✓		_	
Use the LD command for contact A starting at the left busbar or contact A starting at a contact circuit block; its function is to save current content and save the acquired contact status in the cumulative register. Ladder diagram: Command code: Description:						acquired			
Example	X0 X						•		
			Y1)	LD	X0	Load Con	itact A	of XU	
				AND	X1	Create connection of X1	a n to c	series ontact A	
				OUT	Y1	Drive Y1	coil		

Command			Fund	ction				
LDI	Load contact I	В						
Onerend	X0-X17	Y0-Y17	M0-M799	T0-159		C0-C79	D0-	-D399
Operand	✓	✓	✓	✓		✓		_
Use the LDI command for contact B starting at the left busbar or contact B starting at a contact circuit block; its function is to save current content and save the acquired contact status in the cumulative register. Ladder diagram: Command code: Description:						acquired		
Example X0		(1 (Ŷ1)	LDI	X0	Load Cor	itact B	of X0
	VI			AND	X1	Create connection of X1	a on to c	series ontact A
				OUT	Y1	Drive Y1	coil	

Command	Function						
AND	Connect conta	act A in series					
Operand	X0-X17	Y0-Y17	M0-M799	T0-159		C0-C79	D0-D399
Operand	✓	✓	✓	✓		✓	_
Use the AND command to create a series connection to contact A; its function is to first read the current status of the designated series contact and the logical operation results before contact in order to perform "AND" operation; saves the results in the cumulative register.							
Example	Ladder diagra	m: (0		Command LDI	code: X1		scription: ntact B of X1
			<u>Y1</u>)	AND	X0	Create a connection of X0	series on to contact A
				OUT	Y1	Drive Y1	coil



Explanation

Use the ANI command to create a series connection to contact B; its function is to first read the current status of the designated series contact and the logical operation results before contact in order to perform "AND" operation; saves the results in the cumulative register.



Ladder diagram: X1 X0 Y1

Command code: Description:

LD X1 Load Contact A of X1


ANI X0 Create a series connection to contact B of X0

OUT Y1 Drive Y1 coil

Command	Function					
OR	Connect conta	Connect contact A in parallel				
Onerend	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	_

Explanation

Use the OR command to establish a parallel connection to contact A; its function is to first read the current status of the designated series contact and the logical operation results before contact in order to perform "OR" operation; saves the results in cumulative register.



Command code: Description:

Create a series

OR

X1

Connection to contact A of X0

OR X1


OUT Y1 Drive Y1 coil

Command	Function					
ORI	Connect conta	act B in paralle				
Onerend	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	_

Explanation

Use the ORI command to establish a parallel connection to contact B; its function is to first read the current status of the designated series contact and the logical operation results before contact in order to perform "OR" operation; saves the results in cumulative register.






Command code: Description:

LD X0 Load Contact A of X0

Create a series
ORI X1 connection to contact B of X1
OUT Y1 Drive Y1 coil

Chapter 16 PLC Function Applications | MS300




Command	Function				
ORB	Parallel circuit block				
Operand	N/A				
Explanation	ORB performs an "OR" operation cumulative register content.	on the previously sav	ed logi	c results and the current	
Fyample	Ladder diagram:	Command	code:	Description:	
Example	X0 X1 Block A	LD	X0	Load Contact A of X0	
	X2 X3 X3	ANI	X1	Establish a parallel connection to contact B of X1	
	Block B	³ LDI	X2	Load Contact B of X2 Establish a parallel	
		AND	X3	connection to contact A of X3	
		ORB		Parallel circuit block	
		OUT	Y1	Drive Y1 coil	


Command	Function
MPS	Save to stack
Operand	N/A
	Saves the current content of the cumulative register to the stack (add one to the stack

Saves the current content of the cumulative register to the stack (add one to the stack pointer).

Command	Function
MRD	Read stack (pointer does not change)
Operand	N/A

Reads the stack content and saves to the cumulative register (the stack pointer does not change).







Command	Function		
CNT	16-bit counter		
Operand	C-K	C0-C79, K0-K32,767	
	C-D	C0-C79, D0-D399	

Explanation

When you execute the CNT command from OFF to ON, switch the designated counter coil from no power to electrified and add one to the counter's count value. When the count reaches the designated value (count value = setting value), the contact has the following action:

N.O. (Normally Open) contact	Open circuit
N.C. (Normally Closed) contact	Closed circuit

After reaching the count value, the contact and count value both remain unchanged even with continued count pulse input. Use the RST command to restart or clear the count.



Command		Function
MC / MCR	Connect	/release a common series contact
Operand	N0-N7	


Explanation

MC is the main control initiation command, and any command between MC and MCR is executed normally. When the MC command is OFF, any command between MC and MCR acts as follows:

Determination of commands	Description
Ordinary timer	The timing value reverts to 0, the coil loses power, and the contact does not operate.
Counter	The coil loses power, and the count value and contact stay in their current state.
Coil driven by OUT command	None receives power.
Elements driven by SET, RST commands	They remain in their current state.
Application commands	None are actuated.


MCR is the main control stop command, and is placed at the end of the main control program. There may not be any contact command prior to the MCR command. The MC-MCR main control program commands support a nested program structure with a maximum of only eight levels; use in the order N0–N7. Refer to the following program example:

Example



Command code:		Description:
LD	X0	Load Contact A of X0
МС	N0	Connection of N0 common series contact
LD OUT :	X1 Y0	Load Contact A of X1 Drive Y0 coil
LD	X2	Load Contact A of X2
MC	N1	Connection of N1 common series contact
LD OUT :	X3 Y1	Load Contact A of X3 Drive Y1 coil
MCR	N1	Release N1 common series contact
MCR : MCR	N1 N0	
:		contact Release N0 common series
MCR	N0	contact Release N0 common series contact
: MCR : LD	N0	contact Release N0 common series contact Load Contact A of X10 Connection of N0 common series


Chapter 16 PLC Function Applications | MS300



Explanation

The LDP command has the same use as LD, but its action is different. Its function is to save the current content while also saving the detected state of the rising edge of the contact to the cumulative register.

Example



code:		Description:
LDP	X0	Start of X0 rising edge detection action
AND	X1	Create a series connection to contact A of X1


OUT Y1 Drive Y1 coil

Command code:

Command	Function					
LDF	Start of falling	Start of falling edge detection action				
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	_

Explanation

The LDF command has the same use as LD, but its action is different. Its function is to save the current content while also saving the detected state of the falling edge of the contact to the cumulative register.



		•
LDF	X0	Start of X0 falling edge detection action
AND	X1	Create a series connection to contact A of X1
OUT	Y1	Drive Y1 coil

Description:

Command	Function					
ANDP	Rising edge d	Rising edge detection series connection				
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	_


Explanation Use the ANDP command for a contact rising edge detection series connection.

Example Ladder diagram:

X0 X1


Y1

Comman	d code:	Description:
LD X0		Load Contact A of X0
		X1 Rising edge detection series connection
OUT	Y1	Drive Y1 coil



Explanation Use the ANDF command for a contact falling edge detection series connection.

Example



Command code:

LD X0 Load Contact A of X0

X1 Falling edge


ANDF X1 detection series

connection

OUT Y1 Drive Y1 coil

Command	Function					
ORP	Rising edge d	Rising edge detection parallel connection				
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	_

Explanation Use the ORP command for a contact rising edge detection parallel connection.



Command code:

Description:


LD X0 Load Contact A of X0

X1 Rising edge
detection parallel connection


OUT Y1 Drive Y1 coil

Command	Function					
ORF	Falling edge d	Falling edge detection parallel connection				
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
	✓	✓	✓	✓	✓	_


Explanation Use the ORF command for a contact falling edge detection parallel connection.





Commar	id code:	Description:
LD	X0	Load Contact A of X0
ORF	X1	X1 Falling edge detection parallel connection
OUT	Y1	Drive Y1 coil



An END command must be added to the end of a ladder diagram program or command program. The PLC scans the program from address 0 to the END command, and then returns to address 0 and begins scanning again.








Explanation

Use pointer P as the target in a subprogram call (command API 01 CALL). Using P does not require starting from zero, but the number cannot be used repeatedly; otherwise, an unpredictable error occurs.

OUT

Y1



Comman	d code:	Description:
LD CALL :	X0 P10	Load Contact A of X0 Call command CALL to P10
P10		Pointer P10
LD	X1	Load Contact A of X1

Drive Y1 coil

16-6-3 Overview of application commands

Classification	API	Comma	nd code	Р	Function	STE	PS
Classification	AFI			command	Function	16 bit	32 bit
	01	CALL	-	✓	Call subprogram	3	-
Circuit control	2	SRET	-	-	End a subprogram	1	-
	06	FEND	-	-	End a main program	1	-
	10	CMP	DCMP	✓	Compare set output	7	13
Send	11	ZCP	DZCP	✓	Range comparison	9	17
comparison	12	MOV	DMOV	✓	Move data	5	9
	15	BMOV	_	✓	Send all	7	
	20	ADD	DADD	✓	BIN addition	7	13
	21	SUB	DSUB	✓	BIN subtraction	7	13
Four logical	22	MUL	DMUL	✓	BIN multiplication	7	13
operations	23	DIV	DDIV	✓	BIN division	7	13
	24	INC	DINC	✓	BIN add one	3	5
	25	DEC	DDEC	✓	BIN subtract one	3	5
Rotational	30	ROR			Right rotation	5	
displacement	31	ROL	DROL	✓	Left rotation	5	
5 . 5	40	ZRST	_	✓	Clear range	5	-
Data Process	49	_	DFLT	✓	Convert BIN whole number to binary floating point number	-	9
Communication	150	MODRW	_	✓	Modbus read/write	7	
	110	_	DECMP	✓	Compare binary floating point numbers	_	13
	111	_	DEZCP	✓	Compare binary floating point number range	_	17
	116	-	DRAD	✓	Convert angle to diameter	_	9
	117	_	DDEG	✓	Convert diameter to angle	_	9
	120	_	DEADD	✓	Add binary floating point numbers	_	13
	121	_	DESUB	✓	Subtract binary floating point numbers	_	13
	122	_	DEMUL	✓	Multiply binary floating point numbers	_	13
	123	123 –		✓	Divide binary floating point numbers	_	13
Floating point	124	_	DEXP	✓	Find exponent of a binary floating point number	_	9
Floating point operation	125	_	DLN	✓	Find natural logarithm of a binary floating point number	_	9
	127	_	DESQR	✓	Find the square root of binary floating point number	_	9
	129	_	DINT	✓	Convert binary floating point number to BIN whole number	_	9
	130	_	DSIN	✓	Find the sine of a binary floating point number	_	9
	131	_	DCOS	✓	Find the cosine of a binary floating point number	_	9
	132	_	– DTAN		Find the tangent of a binary floating point number	_	9
	133	_	DASIN	✓	Find the arcsine of a binary floating point number	_	9
	134	134 – DACOS		✓	Find the arccosine of a binary floating point number	_	9
	135	_	DATAN	✓	Find the arctangent of a binary floating point number	_	9

Chapter 16 PLC Function Applications | MS300

Ol :6: 4:	4 DI	Comma	nd code	Р	F+:	STEPS		
Classification	API	16 bit	32 bit	command	Function	16 bit	32 bit	
	136	_	DSINH	✓	Find the hyperbolic sine of a binary floating point number	_	9	
Floating point operation	137	_	DCOSH	✓	Find the hyperbolic cosine of a binary floating point number	_	9	
	138	_	DTANH	✓	Find the hyperbolic tangent of a binary floating point number	_	9	
	160	TCMP	_	✓	Compare calendar data	11	_	
	161	TZCP	_	✓	Compare calendar data range	9	_	
Calendar	162	TADD	_	✓	Calendar data addition	7	_	
	163	TSUB	_	✓	Calendar data subtraction	7	_	
	166	TRD	_	✓	Calendar data read	3	_	
GRAY code	170	GRY	DGRY	✓	Convert BIN to GRAY code	5	9	
OTATI COUC	171	GBIN	DGBIN	✓	Convert GRAY code to BIN	5	9	
	215	LD&	DLD&	-	Contact form logical operation LD#	5	9	
	216	LDI	DLD	-	Contact form logical operation LD#	5	9	
	217	LD^	DLD^	-	Contact form logical operation LD#	5	9	
	218	AND&	DAND&	-	Contact form logical operation AND#	5	9	
Contact form logical operation	219	ANDI	DANDI	-	Contact form logical operation AND#	5	9	
	220	AND^	DAND^	-	Contact form logical operation AND#	5	9	
	221	OR&	DOR&	-	Contact form logical operation OR#	5	9	
	222	OR	DOR	-	Contact form logical operation OR#	5	9	
	223 OR^		DOR^	-	Contact form logical operation OR#	5	9	
	224	LD=	DLD=	-	Contact form compare LD*	5	9	
	225	LD> DLD>		-	Contact form compare LD*	5	9	
	226	LD<	DLD<	-	Contact form compare LD*	5	9	
	228	LD<>	DLD<>	-	Contact form compare LD*	5	9	
	229	LD<=	DLD<=	-	Contact form compare LD*	5	9	
	230	LD>=	DLD>=	-	Contact form compare LD*	5	9	
	232	AND=	DAND=	-	Contact form compare AND*	5	9	
	233	AND>	DAND>	-	Contact form compare AND*	5	9	
Contact form comparison	234	AND<	DAND<	-	Contact form compare AND*	5	9	
command	236	AND<>	DAND<>	-	Contact form compare AND*	5	9	
	237	AND<=	DAND<=	-	Contact form compare AND*	5	9	
	238	AND>=	DAND>=	-	Contact form compare AND*	5	9	
	240	OR=	DOR=	-	Contact form compare OR*	5	9	
	241	OR>	DOR>	-	Contact form compare OR*	5	9	
	242	OR<	DOR<	-	Contact form compare OR*	5	9	
	244	OR<>	DOR<>	-	Contact form compare OR*	5	9	
	245	OR<=	DOR<=	-	Contact form compare OR*	5	9	
	246	OR>=	DOR>=	-	Contact form compare OR*	5	9	


Chapter 16 PLC Function Applications | MS300

Classification	API	Comma	nd code	Р	Function	STE	
Ciassilication	AFI	16 bit	32 bit	command	Function	16 bit	32 bit
	275	-	FLD=	-	Floating point number contact form compare LD*	-	9
Floating point contact form	276	-	FLD>	-	Floating point number contact form compare LD*	-	9
	277	-	FLD<	-	Floating point number contact form compare LD*	-	9
	278	-	FLD<>	-	Floating point number contact form compare LD*	-	9
	279	-	FLD<=	-	Floating point number contact form compare LD*	-	9
	280	-	FLD>=	-	Floating point number contact form compare LD*	-	9
	281	-	FAND=	-	Floating point number contact form compare AND*	-	9
	282	-	FAND>	-	Floating point number contact form compare AND*	-	9
	283	-	FAND<	-	Floating point number contact form compare AND*	-	9
	284	-	FAND<>	-	Floating point number contact form compare AND*	-	9
Comparison command	285	-	FAND<=	-	Floating point number contact form compare AND*	-	9
	286	-	FAND>=	-	Floating point number contact form compare AND*	-	9
	287	-	FOR=	-	Floating point number contact form compare OR*	-	9
	288	-	FOR>	-	Floating point number contact form compare OR*	-	9
	289 -		FOR<	-	Floating point number contact form compare OR*	-	9
	290	-	FOR<>	-	Floating point number contact form compare OR*	-	9
	291	-	FOR<=	-	Floating point number contact form compare OR*	-	9
	292	-	FOR>=	-	Floating point number contact form compare OR*	-	9
	139	RPR	_	✓	Read servo parameter	5	_
	140	WPR	_	✓	Write servo parameter	5	_
Drive special	141	FPID	_	✓	Drive PID control mode	9	_
command	142	FREQ	_	✓	Drive operation control mode (Frequency command)	7	_
	263	TORQ	_	✓	Set target torque	5	-

Detailed explanation of application commands 16-6-4


API CALL	P	Call a subprogram
bit device X Y M	Word device K H KnX KnY KnM T C	16-bit command (3 STEP) CALL Continuous CALLP Pulse execution type execution type
Notes on operand usage The S operand can MS300 series device		32-bit command
Explanation	S: Call subprogram pointer.	Flag signal: none

- Write the subprogram after the FEND command.
- The subprogram must end after the SRET command.
- Refer to the FEND command explanation and sample content for detailed command functions.




Explanation


- A contact-driven command is not needed. Automatically returns next command after CALL command.
- Indicates end of subprogram. After end of subprogram, SRET returns to main program, and executes next command after the original call subprogram CALL command.
- Refer to the FEND command explanation and sample content for detailed command functions.



- This command indicates the end of the main program. It is the same as the END command when the PLC executes this command.
- The CALL command program must be written after the FEND command, and the SRET command is added to the end of the subprogram.
- When using the FEND command, an END command is also needed. However, the END command must be placed at the end, after the main program and subprogram.

CALL command process





- **S1**: Compare value 1. **S2**: Compare value 2. **D**: Results of comparison.
- Compares the size of the content of operand S1 and S2; stores the results of the comparison in D.
- Size comparison is performed algebraically. All data is compared in the form of numerical binary values. Because this is a 16-bit command, when b15 is 1, this indicates a negative number.

Example

- When the designated device is Y0, it automatically occupies Y0, Y1 and Y2.
- When X10=ON, the CMP command executes, and Y0, Y1 or Y2 is ON. When X10=OFF, the CMP command does not execute, and the state of Y0, Y1 and Y2 remain in the state prior to X10=OFF.
- For ≥, ≤, or ≠ comparison results, use series and parallel connections among Y0–Y2.

```
X10

Y0

If K10>D10

Y0

If K10>D10

Y1

If K10=D10, Y1 = On

Y2

If K10<D10, Y2=On
```

■ To clear results of comparison, use the RST or ZRST command.


```
RST M0

RST M1

RST M2

X10

ZRST M0 M2
```



- **S1**: Lower limit of range comparison. **S2**: Upper limit of range comparison. **S**: Comparative value. **D**: Results of comparison.
- Compares value **S** with the lower limit **S1** and upper limit **S2**, and stores the results of comparison in **D**.
- When lower limit **S1** > upper limit **S2**, the command uses the lower limit **S1** as the upper and lower limit.
- Size comparison is performed algebraically. All data is compared in the form of numerical binary values. Because this is a 16-bit command, when b15 is 1, this indicates a negative number.

Example


- When the designated device is M0, it automatically occupies M0, M1 and M2.
- When X0=ON, the ZCP command executes, and M0, M1 or M2 is ON. When X0=OFF, the ZCP command does not execute, and the state of M0, M1 or M2 remains in the state prior to X0=OFF.
- For ≥, ≤, or ≠ comparison results, use series and parallel connections for M0–M2.

■ To clear results of comparison, use the RST or ZRST command.

```
RST M0 ZRST M0 M2

RST M1

RST M2
```



- S: Data source. D: Destination of data movement.
- Moves the content in S to D. When the command does not execute, the content of D does not change.

Example


- When X0 = OFF, the content of D10 does not change; if X0 = ON, the value K10 is moved to data register D10.
- When X1 = OFF, the content of D10 does not change; if X1 = ON, the current value of T0 is moved to data register D10.

```
X0

MOV K10 D0

X1

MOV T0 D10
```



- **S**: Initiate source device. **D**: Initiate destination device. **n**: Send block length.
- Sends the content of n registers starting from the initial number of the device designated by S to the n registers starting from the initial number of the device designated by n; if the number of points referred to by n exceeds the range used by that device, sends only points within the valid range.

Example 1


When X10=ON, sends the content of registers D0-D3 to the four registers D20-D23.

```
X10
                                                  D<sub>0</sub>
                                                                D20
                  BMOV
                            D0
                                  D20
                                          K4
                                                                D21
                                                  D1
                                                  D2
                                                                D22
                                                  D3
                                                                D23
```

Example 2

When sending from designated bit devices KnX, KnY, and KnM, S and D must have the same number of nibbles, which means n must be identical for source and destination.

```
M1000
                                   M0
                                                Y0
         BMOV
                     K1Y0
               K1M0
                            K3
                                   M1
                                                Y1
                                   M2
                                                Y2
                                   M3
                                                Y3
                                                Y4
                                   M4
                                                Y5
                                   M5
                                                       n=3
                                   M6
                                                Y6
                                   Μ7
                                   M8
                                               Y10
                                   М9
                                               Y11
                                   M10
                                               Y12
                                  M11
```



- Adds **S1** and **S2** using the BIN method and stores result in **D**.
- The highest bit of any data defines the sign: bit=0 indicates (positive) bit=1 indicates (negative); enables the use of algebraic addition operations (for instance: 3+(-9) = -6).
- Flag changes connected with the addition.

16-bit commend:

- 1. When calculation results are 0, the zero flag M1020 is ON.
- 2. When calculation results are less than -32,768, the borrow flag M1021 is ON.
- 3. When calculation results are greater than 32,767, the carry flag M1022 is ON.

32-bit commend:

- 1. When calculation results are 0, the zero flag M1020 is ON.
- 2. When calculation results are less than -2,147,483,648, the borrow flag M1021
- 3. When calculation results are greater than 2,147,483,6477, the carry flag M1022 is ON.


Example


16-bit BIN addition: When X0 = ON, saves the result of the content of addend D0 plus the content of augend D10 in the content of D20.




Remark

Relationship betwen flag actions and negative/positive numbers: Zero flag







- S1: Minuend. S2: Subtrahend. D: Difference.
- Subtracts **S2** from **S1** using the BIN method and stores result in **D**.
- The highest bit of any data defines the sign bit=0 indicates (positive) bit=1 indicates (negative); enables the use of algebraic subtraction operations.
- Flag changes connected with subtraction.

16-bit commend:

- 1. When calculation results are 0, the zero flag M1020 is ON.
- 2. When calculation results are less than -32,768, the borrow flag M1021 is ON.
- 3. When calculation results are greater than 32,767, the carry flag M1022 is ON.


32-bit commend

- 1. When calculation results are 0, the zero flag M1020 is ON.
- 2. When calculation results are less than -2,147,483,648, the borrow flag M1021 is ON
- 3. When calculation results are greater than 2,147,483,6477, the carry flag M1022 is ON.

Example


16-bit BIN subtraction: When X0 = ON, subtracts the content of D10 from the content of D0, and stores the difference in D20.





- S1: Multiplicand. S2: Multiplier. D: Product.
- Multiplies **S1** and **S2** using the BIN method, and stores the product in **D**.

16-bit BIN multiplication operation:




Symbol bit = 0 refers to a positive value. Symbol bit = 1 refers to a negative value.

When **D** is a bit device, K1–K4 can be designated as a hexadecimal number, which occupies two consecutive units.

Example


When 16-bit DO is multiplied by 16-bit D10, the result is a 32-bit product; the upper 16 bits are stored in D21, and the lower 16 bits are stored in D20. The bit at the farthest left indicates the sign of the result.



S1: Dividend. S2: Divisor. D: Quotient and remainder.

Divides **S1** by **S2** and stores the quotient and remainder in **D** using the BIN method. The sign bit for **S1**, **S2**and **D** must be kept in mind when performing a 16-bit operation.

16-bit BIN division:




If **D** is a bit device, K1–K4 can be designated as 16 bits, which occupy two consecutive units and yield the quotient and remainder.

Example

When X0=ON, stores the quotient resulting from division of dividend D0 by divisor D10 in D20, and the remainder in D21. The highest bit indicates the sign of the result.

```
DIV D0 D10 D20
```



- **D**: Destination device.
- If a command is not the pulse execution type, adds 1 to the content of device during each scanning cycle.
- Generally use this command as a pulse execution type command (INCP).
- During 16-bit operation, 32,767 +1 rolls over to -32,768. During 32-bit operation, 2,147,483,647 +1 rolls over to -2,147,483,648.

Example

API

When X0 switches from OFF to ON, it automatically adds 1 to the content of D0.

```
X0 INCP D0
```

2			DEC P) ——	BI	N su	ubtract one
	bit X	devi Y	ice M	K	Н		_	devic KnM	С	D	16-bit command (3 STEP) DEC Continuous DECP Pulse
D Not	es on	opera	and u	* sage:	* none	*	*	*			execution type execution type: 32-bit command (5 STEP)
											DDEC Continuous DDECP Pulse execution type execution type
											Flag signal: none


Explanation

- **D**: Destination device.
- If a command is not the pulse execution type, adds 1 to the content of device D during each scanning cycle.
- Generally use this command as a pulse execution type command (DECP).
- During 16-bit operation, -32,768 -1 rolls over to 32,767. During 32-bit operation, -2,147,483,648 -1 rolls over to 2,147,483,647.

Example

When X0 switches OFF to ON, it automatically subtracts 1 from the content of D0.


```
X0
DECP D0
```




- **D**: Device to be rotated. **n**: Number of bits for one rotation.
- Rotates the device designated by **D** to the right **n** bits.
- Generally use this command as a pulse execution type command (RORP).

Example

When X0 switches OFF to ON, 4 of the 16 bits in D10 specify a right rotation; the content of the bit indicated with * (see diagram below) is sent to the carry flag signal M1022.







- **D**: Device to be rotated. **n**: Number of bits for one rotation.
- Rotates the device designated by **D** to the left **n** bits.
- Generally use this command as a pulse execution type command (ROLP).

Example

When X0 switches OFF to ON, 4 of the 16 bits in D10 specify a left rotation; the content of the bit indicated with * (see diagram below) is sent to the carry flag signal M1022.





- D1: Clear range's initial device. D2: Clear range's final device.
- When the number of operand **D1** > number of operand **D2**, only the operand designated by **D2** is cleared.

Example

- When X0 is ON, clears auxiliary relays M300–M399, changes them to OFF.
- When X1 is ON, 16-bit clears counters C0–C79 (writes 0, and clears and changes contact and coil to OFF).
- When X10 is ON, clears timer T0–T127 (writes 0, and clears and changes contact and coil to OFF).
- When X3 is ON, clears the data in data registers D0–D100 (sets to 0).

```
ZRST
                                 M300
                                              M399
X1
+
                      ZRST
                                   C<sub>0</sub>
                                              C79
X10
┨┞
                      ZRST
                                   T<sub>0</sub>
                                              T127
X3
                      ZRST
                                   D<sub>0</sub>
                                              D100
```

Remark

Devices such as bit device Y, M and word device T, C, D can independently use the clear command (RST).

```
RST M0


RST T0

RST Y0
```

X11

DFLT

D₀




D20

API 110 D ECMP P S1 S2 D								@	D_	С	ompa	are binary floating point numbers
bit device Word device									:16-bit command			
	Χ	Υ	M	K	Н	KnX	KnY	KnM	Т	С	D	
S1				*	*						*	[
S2				*	*						*	32-bit command (13 STEP)
D				*	*						*	DECMP Continuous DECMPP Pulse execution type
Note	Notes on operand usage:											execution type execution type
The operand D occupies three consecutive points. Refer to the												
func	tion s	pecif	icatio	ns tab	le for	each	device	in se	ries fo	or the	scope	Flag signal: none
	evice										•	

- **S**₁: Binary floating point number 1. **S**₂: Binary floating point number 2. **D**: Results of comparison, occupies three consecutive points.
- Compares binary floating point number 1 with binary floating point number 2, and stores the result of comparison (>, =, <) in **D**.
- If the source operand S_1 or S_2 designates a constant K or H, the command converts the constant to a binary floating point number for the purpose of comparison.

Example

- When the designated device is M10, it automatically occupies M10-M12.
- When X0=ON, the DECMP command executes, and one of M10–M12 is ON. When X0=OFF, the DECMP command does not execute, and M10–M12 remains in the X0=OFF state.
- For ≥, ≤, or ≠ comparison results, use series and parallel connections for M10–M12.
- Use the RST or ZRST command to clear the result.



- S₁: Lower limit of binary floating point number in range comparison. S₂: Upper limit for binary floating point number in range comparison. S: Comparison of binary floating point numerical values. D: Results of comparison, occupies three consecutive points.
- Compares binary floating point number **S** with the lower limit value **S**₁ and the upper limit value **S**₂; stores the results of comparison in **D**.
- If the source operand S₁ or S₂ designates a constant K or H, the command converts the constant to a binary floating point number for the purpose of comparison.
- When the lower limit S₁ is greater than the upper limit S₂, the command uses S₁ as the lower and upper limit.

Example

- When the designated device is M0, it automatically occupies M0–M2.
- When X0=ON, the DEZCP command executes, and one of M0–M2 is ON. When X0=OFF, the EZCP command does not execute, and M0–M2 remains in the X0=OFF state.
- Use the RST or ZRST command to clear the result.

```
DEZCP D0 D10 D20 M0

M0


When (D1, D0) > (D21, D20), M0 is On.

M1

When (D1, D0) \leq (D21, D20) \leq (D11, D10), M1 is On.

M2


When (D21, D20) > (D11, D10), M2 is On.
```




- **S**: data source (angle). **D**: result of conversion (diameter).
- Uses the following formula to convert angles to radians.
 Diameter = Angle × (π/180)

Example

When X0=ON, converts the angle of the designated binary floating point number (D1, D0) to radians and stores the result in (D11, D10); the result is a binary floating point number.







- S: data source (radian). D: results of conversion (angle).
- Uses the following formula to convert radians to an angle.

Angle = Radian × $(180/\pi)$

Example

When X0=ON, angle of the designated binary floating point number (D1, D0) in radians is converted to an angle and stored in (D11, D10), with the content consisting of a binary floating point number.






- S₁: addend. S₂: augend. D: sum.
- Adds the content of the register designated by S_2 to the content of the register designated by S_1 , and stores the result in the register designated by D. Addition is performed entirely using binary floating point numbers.
- If the source operand S₁ or S₂ designates a constant K or H, the command converts that constant into a binary floating point number for use in addition.
- In the situation when S₁ and S₂ designate identical register numbers, if a "continuous execution" command is employed, when conditional contact is ON, the register performs addition once during each scan. You generally use Pulse execution type commands (DEADDP) under ordinary circumstances.

Example

When X0=ON, adds a binary floating point number (D1, D0) to a binary floating point number (D3, D2), and stores the results in (D11, D10).

```
DEADD D0 D2 D10
```

■ When X2 =ON, adds a binary floating point number (D11, D10) to K1234 (which is automatically converted to a binary floating point number), and stores the results in (D21, D20).



- **S**₁: minuend. **S**₂: subtrahend. **D**: difference.
- Subtracts the content of the register designated by S₂ from the content of the register designated by S₁, and stores the difference in the register designated by D; subtraction is performed entirely using binary floating point numbers.
- If the source operand S₁ or S₂ designates a constant K or H, the command converts that constant into a binary floating point number for use in subtraction.
- In the situation when S₁ and S₂ designate identical register numbers, if a "continuous execution" command is employed, when conditional contact is ON, the register performs subtraction once during each scan. You generally use pulse execution type commands (DESUBP) under ordinary circumstances.


Example

When X0=ON, subtracts a binary floating point number (D1, D0) from a binary floating point number (D3, D2), and stores the results in (D11, D10).

```
DESUB D0 D2 D10
```

■ When X2 =ON, subtracts the binary floating point number (D1, D0) from K1234 (which is automatically converted to a binary floating point number), and stores the results in (D11, D10).

```
X2
DESUB K1234 D0 D10
```




- S₁: multiplicand. S₂: multiplier. D: product.
- Multiplies the content of the register designated by S₁ by the content of the register designated by S₂, and stores the product in the register designated by D; multiplication is performed entirely using binary floating point numbers.
- If the source operand S₁ or S₂ designates a constant K or H, the command converts that constant into a binary floating point number for use in multiplication.
- In the situation when S₁ and S₂ designate identical register numbers, if you employ a "continuous execution" command, when conditional contact is ON, the register performs multiplication once during each scan. You generally use pulse execution type commands (DEMULP) under ordinary circumstances.

Example

When X1=ON, multiplies the binary floating point number (D1, D0) by the binary floating point number (D11, D10), and stores the product in the register designated by (D21, D20).

```
X1
DEMUL D0 D10 D20
```

■ When X2 =ON, multiplies the binary floating point number (D1, D0) by K1234 (which is automatically converted to a binary floating point number), and stores the results in (D11, D10).




- S₁: dividend. S₂: divisor. D: quotient.
- Divides the content of the register designated by **S**₁ by the content of the register designated by **S**₂ and stores the quotient in the register designated by **D**; division is performed entirely using binary floating point numbers.
- If the source operand S₁ or S₂ designates a constant K or H, the command converts that constant into a binary floating point number for use in division.

Example

When X1=ON, divides the binary floating point number (D1, D0) by the binary floating point number (D11, D10), and stores the quotient in the register designated by (D21, D20).

```
DEDIV D0 D10 D20
```

■ When X2 =ON, divides the binary floating point number (D1, D0) by K1,234 (which is automatically converted to a binary floating point number), and stores the results in (D11, D10).




- **S**: operation source device. **D**: operation results device.
- Taking e =2.71828 as a base, **S** is the exponent in the EXP operation.
- [D+1,D]=EXP[S+1,S]
- Valid regardless of whether the content of **S** has a positive or negative value. The designated register D must have a 32-bit data format. Performs the operation using floating point numbers, and converts **S** to a floating point number.
- Content of operand **D** =e ^S; e=2.71828, **S** is the designated source data.

Example

- When M0 is ON, converts the value of (D1, D0) to a binary floating point number, and stores the result in register (D11, D10).
- When M1 is ON, performs the EXP operation on the exponent of (D11, D10), converts the result to a binary floating point number and stores it in register (D21, D20).

```
M0
DFLT D0 D10
M1
DEXP D10 D20
END
```



- **S**: operation source device. **D**: operation results device.
- Taking e =2.71828 as a base, **S** is the exponent in the EXP operation.
- [D+1, D]=EXP[S+1, S]
- Valid regardless of whether the content of **S** has a positive or negative value. The designated register D must have a 32-bit data format. Performs the operation using floating point numbers and converts **S** to a floating point number.
- Content of operand **D** = e^{S} ; e=2.71828, **S** is the designated source data

Example

- When M0 is ON, converts the value of (D1, D0) to a binary floating point number, and stores the result in register (D11, D10).
- When M1 is ON, performs the EXP operation on the exponent of (D11, D10); converts the result to a binary floating point number stores it in register (D21, D20).


```
M0

DFLT D0 D10

M1

DLN D10 D20

END
```



- **S**: source device for which square root is desired **D**: result of finding square root.
- Finds the square root of the content of the register designated by **S**, stores the result in the register designated by **D**. Square roots are performed entirely using binary floating point numbers.
- If the source operand **S** refers to a constant K or H, the command converts that constant into a binary floating point number for use in the operation.

Example


When X0=ON, finds the square root of the binary floating point number (D1, D0), and stores the result in the register designated by (D11, D10).

```
X0
\rightarrow
DESQR D0 D10

\sqrt{(D1, D0)} \rightarrow (D11, D10)
Binary floating point Binary floating point
```

■ When X2 =ON, finds the square root of K1,234 (which has been automatically converted to a binary floating point number), and stores the results in (D11, D10).

```
DESQR K1234 D10
```




- **S**: the source device to be converted. **D**: results of conversion.
- Converts the content of the register designated by **S** from a binary floating point number format to a BIN whole number, and stores the results in **D**. The BIN whole number floating point number is discarded.
- The action of this command is the opposite of that of command API 49 (FLT).

Example


■ When X0=ON, converts the binary floating point number (D1, D0) into a BIN whole number, and stores the result in (D10); the BIN whole number floating point number is discarded.

```
X0
DINT D0 D10
END
```




- **S**: the designated source value (diameter). **D**: the SIN value result.
- S is the designated source in radians.
- The value in radians (RAD) is equal to (angle × π /180).
- Finds the SIN from the source value designated by **S** and stores the result in **D**.


The following figure displays the relationship between the arc and SIN results:



Example


When X0=ON, finds the SIN value of the designated binary floating point number (D1, D0) in radians (RAD) and stores the result in (D11, D10) as a binary floating point number.





- **S**: the designated source value (diameter). **D**: the COS value result.
- Finds the COS of the source value designated by S and stores it in D.

The following figure displays the relationship between the arc and COS results:




Example

When X0=ON, finds the COS value of the designated binary floating point number (D1, D0) in radians and stores the result in (D11, D10), as a binary floating point number.

```
DCOS D0 D10


S D1 D0 RAD value (x \pi/180) binary floating point

COS value binary floating point
```




- **S**: the designated source value (diameter). **D**: the TAN value result.
- Finds the TAN of the source value designated by **S** and stores it in **D**.


The following figure displays the relationship between the arc and TAN results:



Example


When X0=ON, finds the TAN value of the designated binary floating point number (D1, D0) in radians (RAD) and stores it in (D11, D10), as a binary floating point number.





- **S**: the designated source (binary floating point number). **D**: the ASIN value result.
- ASIN value =sin⁻¹

The figure below shows the relationship between input data and result:




Example

■ When X0=ON, finds the ASIN value of the designated binary floating point number (D1, D0) and stores the result in (D11, D10), as a binary floating point number.

```
DASIN D0 D10


S D1 D0 Binary floating point

ASIN value binary floating point
```



- **S**: the designated source (binary floating point number). **D**: the ACOS value result.
- ACOS value =cos⁻¹


The figure below shows the relationship between input data and result:



Example


■ When X0=ON, finds the ACOS value of the designated binary floating point number (D1, D0) and stores the result in (D11, D10), as a binary floating point number.

```
D D 11 D 10 D 10 D 10 D 10 D 11 D 10 ```




- **S**: the designated source (binary floating point number). **D**: the ATAN value result.
- ATAN value =tan<sup>-1</sup>

The figure below shows the relationship between input data and result:



Example


■ When X0=ON, finds the ATAN value of the designated binary floating point number (D1, D0) and stores the result in (D11, D10), as a binary floating point number.




- **S**: the designated source (binary floating point number). **D**: the SINH value result.
- SINH value =(e<sup>s</sup>-e<sup>-s</sup>)/2

Example

When X0=ON, finds the SINH value of the designated binary floating point number (D1, D0) and stores the result in (D11, D10), as a binary floating point number.






**S**: the designated source (binary floating point number). **D**: the COSH value result.


COSH value =(e<sup>s</sup>+e<sup>-s</sup>)/2

Example

When X0=ON, finds the COSH value of the designated binary floating point number (D1, D0) and stores the result in (D11, D10), as a binary floating point number.



#### Chapter 16 PLC Function Applications | MS300




Explanation

**S**: the designated source (binary floating point number). **D**: the TANH value result.

■ TANH value =(e<sup>s</sup>-e<sup>-s</sup>)/(e<sup>s</sup>+e<sup>-s</sup>)

Example

When X0=ON, finds the TANH value of the designated binary floating point number (D1, D0) and stores the result in (D11, D10), as a binary floating point number.



ΛDI

| 15 | MODRW P S1 S2 S3 S n Modbus data read/write     |   |   |   |   |     |     |     |   |   |   |                                                            |  |
|----|-------------------------------------------------|---|---|---|---|-----|-----|-----|---|---|---|------------------------------------------------------------|--|
|    | bit device Word device :16-bit command (5 STEP) |   |   |   |   |     |     |     |   |   |   |                                                            |  |
|    | Х                                               | Υ | М | K | Н | KnX | KnY | KnM | Т | С | D | MODRW Continuous MODRW Pulse execution type execution type |  |
| S1 |                                                 |   |   | * | * |     |     |     |   |   | * | execution type P execution type                            |  |
| S2 |                                                 |   |   | * | * |     |     |     |   |   | * |                                                            |  |
| S3 |                                                 |   |   | * | * |     |     |     |   |   | * | 32-bit command                                             |  |
| S  |                                                 |   |   |   |   |     |     |     |   |   | * | : : : :                                                    |  |
| n  |                                                 |   |   | * | * |     |     |     |   |   | * | <u></u>                                                    |  |
|    | Flag signal: M1077 M1078 M1079                  |   |   |   |   |     |     |     |   |   |   |                                                            |  |

Explanation

- S₁: online device address. S₂: communication function code. S₃: address of data to read/write. S: register for data to be read/written is stored. n: length of data to be read/written.
- Before using this command, define COM1 to be controlled by the PLC and then set the corresponding communication speed and format (Pr.09-01 and Pr.09-04).
   S<sub>2</sub>: communication function code. Currently supported function codes are describes as follows; other function codes are not supported.

| Function | Description          |
|----------|----------------------|
| H 02     | Input read           |
| H 03     | Read word            |
| H 06     | Write single word    |
| H 0F     | Write multiple coils |
| H 10     | Write single word    |

- After executing this command, M1077, M1078 and M1079 immediately changes to 0.
- For example, assume that MS300 controls another drive and PLC when the drive has a station number of 10 and the PLC has a station number of 20. Refer to the following table for the examples.

#### The drive that controls the salve


| THE GI | lve that controls the salve                                                                                                   |               | 1405           | ND14/          |                |        |  |  |  |
|--------|-------------------------------------------------------------------------------------------------------------------------------|---------------|----------------|----------------|----------------|--------|--|--|--|
|        |                                                                                                                               | MODRW command |                |                |                |        |  |  |  |
| Serial | Example                                                                                                                       | $S_1$         | S <sub>2</sub> | S <sub>3</sub> | S <sub>4</sub> | n      |  |  |  |
| No.    | ·                                                                                                                             | Node<br>ID    | Function code  | Address        | Register       | Length |  |  |  |
| 1      | Reads 4 sets of data comprising the drive slave device parameters Pr.01-00 to Pr.01-03, and saves the read data in D0 to D3.  | K10           | Н3             | H100           | D0             | K4     |  |  |  |
| 2      | Reads 3 sets of data comprising the drive slave device addresses H2100 to H2102, and saves the read data in D5 to D7.         | K10           | Н3             | H2100          | D5             | K3     |  |  |  |
| 3      | Writes 3 sets of data comprising the drive slave device parameters Pr.05-00 to Pr.05-03, and writes the values as D10 to D12. | K10           | H10            | H500           | D10            | K3     |  |  |  |
| 4      | Writes 2 sets of data comprising the drive slave device addresses H2000 to H2001, and writes the values as D15 to D16.        | K10           | H10            | H2000          | D15            | K2     |  |  |  |


## Chapter 16 PLC Function Applications | MS300

PLC controlling slave device

| PLC 0  | ontrolling slave device                                        |                | MOD               | D\\\           |                |         |
|--------|----------------------------------------------------------------|----------------|-------------------|----------------|----------------|---------|
| Carial | Evenne                                                         | 0              |                   | RW com         |                | -       |
| Serial | Example                                                        | S <sub>1</sub> | S <sub>2</sub>    | S <sub>3</sub> | S <sub>4</sub> | n       |
| No.    |                                                                | Node<br>ID     | Functio<br>n code | Addres<br>s    |                | Length: |
|        | Reads 4 sets of data comprising the                            | טו             | 11 code           | 5              | r              |         |
| 1      | PLC slave device's X0 to X3 state, and                         | K20            | H2                | H400           | D0             | K4      |
| '      | saves the read data in bits 0 to 3 of D0.                      | K20            | 112               | 11400          | D0             | 114     |
|        | Reads 4 sets of data comprising the                            |                |                   |                |                |         |
| 2      | PLC slave device's Y0 to Y3 state, and                         | K20            | H2                | H500           | D1             | K4      |
| _      | saves the read data in bits 0 to 3 of D1.                      | 1120           | 112               | 11000          |                | IXT     |
|        | Reads 4 sets of data comprising the                            |                |                   |                |                |         |
| 3      | PLC slave device's M0 to M3 state, and                         | K20            | H2                | H800           | D2             | K4      |
|        | saves the read data in bits 0 to 3 of D2.                      |                |                   |                |                |         |
|        | Reads 4 sets of data comprising the                            |                |                   |                |                |         |
| 4      | PLC slave device's T0 to T3 state, and                         | K20            | H2                | H600           | D3             | K4      |
|        | saves the read data in bits 0 to 3 of D3.                      |                |                   |                |                |         |
|        | Reads 4 sets of data comprising the                            |                |                   |                |                |         |
| 5      | PLC slave device's C0 to C3 state, and                         | K20            | H2                | HE00           | D4             | K4      |
|        | saves the read data in bits 0 to 3 of D4.                      |                |                   |                |                |         |
|        | Reads 4 sets of data comprising the                            |                |                   |                |                |         |
| 6      | PLC slave device's T0 to T3 count                              | K20            | НЗ                | H600           | D10            | K4      |
|        | value, and saves the read data in D10                          | . 120          | 1.0               | 11000          | 2.0            |         |
|        | to D13.                                                        |                |                   |                |                |         |
|        | Reads 4 sets of data comprising the                            |                |                   |                |                |         |
| 7      | PLC slave device's C0 to C3 count                              | K20            | Н3                | HE00           | D20            | K4      |
|        | value, and saves the read data in D20 to D23.                  |                |                   |                |                |         |
|        | Reads 4 sets of data comprising the                            |                |                   |                |                |         |
|        | PLC slave device's D0 to D3 count                              |                |                   |                |                |         |
| 8      | value, and saves the read data in D30                          | K20            | Н3                | H1000          | D30            | K4      |
|        | to D33.                                                        |                |                   |                |                |         |
|        | Writes 4 sets of the PLC slave device's                        |                |                   |                |                |         |
| 9      | Y0 to Y3 state, and writes the values as                       | K20            | HF                | H500           | D1             | K4      |
|        | bits 0 to 3 of D1.                                             |                |                   |                |                |         |
|        | Writes 4 sets of the PLC slave device's                        |                |                   |                |                |         |
| 10     | M0 to M3 state, and writes the values                          | K20            | HF                | H800           | D2             | K4      |
|        | as bits 0 to 3 of D2.                                          |                |                   |                |                |         |
|        | Writes 4 sets of the PLC slave device's                        |                |                   |                |                |         |
| 11     | T0 to T3 state, and writes the values as                       | K20            | HF                | H600           | D3             | K4      |
|        | bits 0 to 3 of D3                                              |                |                   |                |                |         |
| 10     | Writes 4 sets of the PLC slave device's                        | 1/20           | ue.               | LIEOO          | D4             | 12.4    |
| 12     | C0 to C3 state, and writes the values                          | K20            | HF                | HE00           | D4             | K4      |
|        | as bits 0 to 3 of D4.  Writes 4 sets of the PLC slave device's |                |                   |                |                |         |
| 13     | T0 to T3 count value, and writes the                           | K20            | H10               | H600           | D10            | K4      |
| 13     | values in D10 to D13.                                          | 1120           | 1110              | 11000          | 510            | 114     |
|        | Writes 4 sets of the PLC slave device's                        |                |                   |                |                |         |
| 14     | C0 to C3 count value, and writes the                           | K20            | H10               | HE00           | D20            | K4      |
|        | values in D20 to D23.                                          |                |                   |                |                |         |
|        | Writes 4 sets of the PLC slave device's                        |                |                   |                |                |         |
| 15     | D0 to D3 count value, and writes the                           | K20            | H10               | H1000          | D30            | K4      |
|        | values in D30 to D33.                                          |                |                   |                |                |         |

- When starting the PLC program for the first time, M0 is triggered to ON and executes one MODRW command.
- After receiving the slave device's response, if the command is correct, it executes one ROL command, which triggers M1 to ON.
- After receiving the slave device's response and after a delay of 10 PLC scanning cycles, M50 =1 is triggered, and it executes one MODRW command.
- After receiving the slave device's response again, if the command is correct, it executes one ROL command, which triggers M2 to ON (M2 can be defined as a repeat of M). Then, K4M0 changes to K1 again, and only M0 remains 1. This enables the transmission to proceed in a continuous cycle. If you need to add a sending command, just add the desired command in the frame with a dotted line, and change repeat M to Mn+1.






- S: source device. D: device storing GRAY code.
- Converts the BIN value of the device designated by **S** to a GRAY code, and stores the result in the device designated by **D**.
- The valid range for **S** is as shown below; if you exceed this range, it is an error, and the command does not execute.


16-bit command: 0-32,767

32-bit command: 0-2,147,483,647

Example

■ When X0=ON, converts the constant K6513 to a GRAY code and stores it in D0.





- **S**: source device storing GRAY code. **D**: device storing BIN value after conversion.
- Converts the GRAY code corresponding to the value of the device designated by S that is converted into a BIN value, and stores it in the device designated by D.
- This command converts the value of the absolute position encoder connected with the PLC's input (this encoder usually has an output value in the form of GRAY code) into a BIN value, and stores it in the designated register.
- The valid range of **S** is as shown below; if you exceed this range, it is an error, and the command does not execute.


16-bit command: 0-32,767

32-bit command: 0-2,147,483,647

Example

When X20=ON, converts the GRAY code of the absolute position encoder connected with input points X0–X17 to a BIN value and stores it in D10.

#### Chapter 16 PLC Function Applications | MS300



Explanation

- S₁: data source device 1. S₂: data source device 2.
- This command compares the contents of  $S_1$  and  $S_2$ . When the result of comparison is not 0, this command activates; when the result of comparison is 0, this command does not activate.
- You can use the LD# command directly to connect with the busbar


| API No. | 16-bit   | 32-bit       | Co             | ndi    | tions fo       | r            | Conditions for |   |                |    |  |
|---------|----------|--------------|----------------|--------|----------------|--------------|----------------|---|----------------|----|--|
| APTINO. | commands | commands     | ;              | vation |                | inactivation |                |   |                |    |  |
| 215     | LD&      | <b>D</b> LD& | S <sub>1</sub> | &      | S <sub>2</sub> | <b>≠</b> 0   | S <sub>1</sub> | & | S <sub>2</sub> | =0 |  |
| 216     | LD       | <b>D</b> LD  | S <sub>1</sub> |        | S <sub>2</sub> | ≠0           | S <sub>1</sub> |   | S <sub>2</sub> | =0 |  |
| 217     | LD^      | <b>D</b> LD^ | S <sub>1</sub> | ٨      | S <sub>2</sub> | <b>≠</b> 0   | S <sub>1</sub> | ٨ | S <sub>2</sub> | =0 |  |

- &: logical AND operation.
- |: logical OR operation.
- ^: logical XOR operation.

- When you compare the contents of C0 and C10 with the logical AND operation, and the result is not equal to 0, then Y10=ON.
- When you compare the content of D200 and D300 with the logical OR operation, and the result is not equal to 0, and X1=ON, then Y11=ON and remains in that state.

```
LD & C0 C10 Y10

LD | D200 D300 | SET Y11
```



- S₁: data source device 1. S₂: data source device 2.
- This command compares the contents of S₁ and S₂. When the result of comparison is not 0, this command activates; when the result of comparison is 0, this command does not activate.
- The AND# command is an operation command in series with the contact.


| API No. | 16-bit   | 32-bit        | Co             | ondi | tions fo       | or         | Conditions for |   |                |    |  |  |
|---------|----------|---------------|----------------|------|----------------|------------|----------------|---|----------------|----|--|--|
| AFTINO. | commands | commands      |                | acti | vation         |            | inactivation   |   |                |    |  |  |
| 218     | AND&     | <b>D</b> AND& | S <sub>1</sub> | &    | S <sub>2</sub> | ≠0         | S <sub>1</sub> | & | S <sub>2</sub> | =0 |  |  |
| 219     | AND      | <b>D</b> AND  | S <sub>1</sub> | _    | S <sub>2</sub> | <b>≠</b> 0 | S <sub>1</sub> |   | S <sub>2</sub> | =0 |  |  |
| 220     | AND^     | <b>D</b> AND^ | S <sub>1</sub> | ^    | S <sub>2</sub> | <b>≠</b> 0 | S <sub>1</sub> | ٨ | S <sub>2</sub> | =0 |  |  |


&: logical AND operation.

|: logical OR operation.

^: logical XOR operation.

- When X0=ON and you compare the contents of C0 and C10 with the logical AND operation, and the result is not equal to 0, then Y10=ON.
- When X1=OFF and you compare the contents D10 and D0 with the logical OR operation, and the result is not equal to 0, then Y11=ON and remains in that state.
- When X2 =ON and you compare the contents of the 32-bit register D200 (D201) and the 32-bit register D100 (D101) with the logical XOR operation, and the result is not equal to 0 or M3=ON, then M50=ON.





- S<sub>1</sub>: data source device 1. S<sub>2</sub>: data source device 2.
- This command compares the contents of S₁ and S₂. When the result of comparison is not 0, this command activates; when the result of comparison is 0, this command does not activate.


| API No. | 16-bit   | 32-bit       | Co             | ondi | tions fo       | r          | Conditions for |   |                |    |
|---------|----------|--------------|----------------|------|----------------|------------|----------------|---|----------------|----|
| APTINO. | commands | commands     |                | acti | vation         |            | inactivation   |   |                |    |
| 221     | OR&      | DOR&         | S <sub>1</sub> | &    | S <sub>2</sub> | ≠0         | S <sub>1</sub> | & | S <sub>2</sub> | =0 |
| 222     | OR       | <b>D</b> OR  | S <sub>1</sub> | _    | S <sub>2</sub> | <b>≠</b> 0 | S <sub>1</sub> |   | S <sub>2</sub> | =0 |
| 223     | OR^      | <b>D</b> OR^ | S <sub>1</sub> | ^    | S <sub>2</sub> | <b>≠</b> 0 | S <sub>1</sub> | ٨ | S <sub>2</sub> | =0 |


&: logical AND operation.

: logical OR operation.

^: logical XOR operation.

- Compare the contents of C0 and C10 with the logical AND operation, and the result is not equal to 0, then Y0=ON.
- Compare the contents of the 32-bit register D10 (D11) and the 32-bit register D20 (D21) with the logical OR operation, and the result is not equal to 0, or you compare the contents of the 32-bit counter C235 and the 32-bit register D200 (D201) with the logical XOR operation, and the result is not equal to 0, then M60=ON.







- S₁: data source device 1. S₂: data source device 2.
- This command compares the contents of  $S_1$  and  $S_2$ . Taking API 224 (LD=) as an example, this command activates when the result of comparison is "equal," and does not activate when the result is "unequal."
- You can use the LD\* directly to connect with the busbar

| API No. | 16-bit commands | 32-bit commands | Conditions for activation | Conditions for inactivation     |
|---------|-----------------|-----------------|---------------------------|---------------------------------|
| 224     | LD =            | <b>D</b> LD =   | $S_1 = S_2$               | S <sub>1</sub> ≠ S <sub>2</sub> |
| 225     | LD >            | <b>D</b> LD >   | $S_1 > S_2$               | $S_1 \leq S_2$                  |
| 226     | LD <            | <b>D</b> LD <   | $S_1 < S_2$               | $S_1 \ge S_2$                   |
| 228     | LD <>           | <b>D</b> LD <>  | $S_1 \neq S_2$            | $S_1 = S_2$                     |
| 229     | LD < =          | <b>D</b> LD < = | $S_1 \leq S_2$            | S <sub>1</sub> > S <sub>2</sub> |
| 230     | LD > =          | <b>D</b> LD > = | $S_1 \geq S_2$            | S <sub>1</sub> < S <sub>2</sub> |

- When the content of C10 is equal to K200, then Y10=ON.
- When the content of D200 is greater than K-30, and X1=ON, then Y11=ON and remains in that state.
- When C20 < K678493 or MI = ON, then MI50 = ON.







- **S**<sub>1</sub>: data source device 1. **S**<sub>2</sub>: data source device 2.
- This command compares the contents of  $S_1$  and  $S_2$ . Taking API 232 (AND=) as an example, when the result of comparison is "equal", this command activates; when the result of comparison is "unequal", this command does not activate.
- The AND\* command is a comparison command in series with a contact.

| API No. | 16-bit commands | 32-bit commands  | Conditions for activation                     | Conditions for inactivation        |
|---------|-----------------|------------------|-----------------------------------------------|------------------------------------|
| 232     | AND =           | <b>D</b> AND =   | <b>S</b> <sub>1</sub> = <b>S</b> <sub>2</sub> | S <sub>1</sub> ≠ S <sub>2</sub>    |
| 233     | AND >           | <b>D</b> AND >   | $S_1 > S_2$                                   | $S_1 \leq S_2$                     |
| 234     | AND <           | <b>D</b> AND <   | $S_1 < S_2$                                   | $S_1 \ge S_2$                      |
| 236     | AND <>          | <b>D</b> AND <>  | $S_1 \neq S_2$                                | $S_1 = S_2$                        |
| 237     | AND < =         | <b>D</b> AND < = | $S_1 \leq S_2$                                | $S_1 > S_2$                        |
| 238     | AND > =         | <b>D</b> AND > = | $S_1 \ge S_2$                                 | S <sub>1 &lt;</sub> S <sub>2</sub> |

- When X0=ON and the current value of C10 is also equal to K200, then Y10=ON.
- When X1=OFF and the content of register D0 is not equal to K-10, then Y11=ON and remains in that state.
- When X2=ON and the content of the 32-bit register D0 (D11) is less than 678,493, or M3=ON, then M50=ON.





- S₁: data source device 1. S₂: data source device 2.
- This command compares the contents of **S**<sub>1</sub> and **S**<sub>2</sub>. Taking API 240 (OR=) as an example, when the result of comparison is "equal", this command activates; when the result of comparison is "unequal", this command does not activate.
- The OR\* command is a comparison command in parallel with a contact.

| API No. | 16-bit commands | 32-bit commands | Conditions for activation                     | Conditions for inactivation                   |
|---------|-----------------|-----------------|-----------------------------------------------|-----------------------------------------------|
| 240     | OR =            | <b>D</b> OR =   | $S_1 = S_2$                                   | $S_1 \neq S_2$                                |
| 241     | OR >            | DOR >           | S <sub>1</sub> > S <sub>2</sub>               | $S_1 \leq S_2$                                |
| 242     | OR <            | DOR <           | S <sub>1</sub> < S <sub>2</sub>               | $S_1 \ge S_2$                                 |
| 244     | OR < >          | <b>D</b> OR <>  | S <sub>1</sub> ≠ S <sub>2</sub>               | $S_1 = S_2$                                   |
| 245     | OR < =          | <b>D</b> OR < = | $S_1 \leq S_2$                                | $S_1 > S_2$                                   |
| 246     | OR > =          | <b>D</b> OR > = | <b>S</b> <sub>1</sub> ≥ <b>S</b> <sub>2</sub> | <b>S</b> <sub>1</sub> < <b>S</b> <sub>2</sub> |

- When X1=ON, or the current value of C10 is less than / equal to 200, then Y0=ON.
- When X2=ON and M30=ON, or the content of the 32-bit register D100 (D101) is more than / equal to 100000, then M60=ON.

```
X1

OR>= K200 C10

X2 M30

H DOR>= D100 K100000
```

| 275<br>28              | j_                                                                   | F    | LD)   | *      |             |                          | <b>S</b> 1) | <b>S</b> 2      |                | FI | oatin | g point number contact form compare LD* |
|------------------------|----------------------------------------------------------------------|------|-------|--------|-------------|--------------------------|-------------|-----------------|----------------|----|-------|-----------------------------------------|
| bit device Word device |                                                                      |      |       |        |             |                          | Vord        | :16-bit command |                |    |       |                                         |
|                        | Х                                                                    | Υ    | М     | K      | Н           | KnX                      | KnY         | KnM             | Т              | С  | D     |                                         |
| S1                     |                                                                      |      |       |        |             |                          |             |                 | *              | *  | *     | <br>                                    |
| S2                     |                                                                      |      |       |        |             |                          |             |                 | *              | *  | *     | :32-bit command (9 STEP)                |
|                        | es on                                                                | oper | and u | sage:  | <b>*</b> ,: | (; : , =, >, <, <>, ≤, ≥ |             |                 |                |    |       | FLD% Continuous – –                     |
|                        | Refer to the function specifications table for each device in series |      |       |        |             |                          |             |                 | execution type |    |       |                                         |
|                        |                                                                      |      |       | ice us |             |                          |             |                 |                |    |       | Flag signal: none                       |

- S<sub>1</sub>: data source device 1. S<sub>2</sub>: data source device 2.
- This command compares the contents of  $S_1$  and  $S_2$ . Taking "FLD=" as an example, if the result of comparison is "equal", this command activates; but it does not activate when the result is "unequal".
- The FLD\* command can directly input floating point numbers (for instance: F1.2) to the S₁, S₂ operands, or store floating point numbers in register D for use in operations.
- You can use this command while directly to connect with the busbar

| API No. | 32-bit commands | Conditions for activation                     | Conditions for inactivation     |
|---------|-----------------|-----------------------------------------------|---------------------------------|
| 275     | FLD =           | $S_1 = S_2$                                   | S <sub>1</sub> ≠ S <sub>2</sub> |
| 276     | FLD >           | S <sub>1</sub> > S <sub>2</sub>               | $S_1 \leq S_2$                  |
| 277     | FLD <           | S <sub>1</sub> < S <sub>2</sub>               | $S_1 \ge S_2$                   |
| 278     | FLD <>          | <b>S</b> <sub>1</sub> ≠ <b>S</b> <sub>2</sub> | $S_1 = S_2$                     |
| 279     | FLD < =         | $S_1 \leq S_2$                                | S <sub>1</sub> > S <sub>2</sub> |
| 280     | FLD > =         | $S_1 \ge S_2$                                 | S <sub>1</sub> < S <sub>2</sub> |

Example

When the floating point number in register D200 (D201) is less than or equal to F1.2, and X1 is activated, then contact Y21 activates and remains in that state.

```
FLD<= D200 F1.2 | X1 | SET | Y21
```

| 281<br>280 | _                                                                                                                                          | FÆ  | AND | * |   |         | <u>S1</u> ) | <b>S2</b> ) |        | FI                | oatin | g point number contact form compare AND*     |
|------------|--------------------------------------------------------------------------------------------------------------------------------------------|-----|-----|---|---|---------|-------------|-------------|--------|-------------------|-------|----------------------------------------------|
|            | bit                                                                                                                                        | dev | ice |   |   | ٧       | Vord        | devic       | е      |                   |       | :16-bit command ::                           |
|            | Х                                                                                                                                          | Υ   | М   | K | Н | KnX     | KnY         | KnM         | Т      | С                 | D     | <u>                                     </u> |
| S1         |                                                                                                                                            |     |     |   |   |         |             |             | *      | *                 | *     | \                                            |
| S2         |                                                                                                                                            |     |     |   |   |         |             |             | *      | *                 | *     | 32-bit command (9 STEP)                      |
|            |                                                                                                                                            |     |     | _ |   |         |             |             |        |                   |       | FAND Continuous                              |
|            | Notes on operand usage: ※, : , =, >, <, <>, ≤, ≥ Refer to the function specifications table for each device for the scope of device usage. |     |     |   |   | or each | n devi      | ce in :     | series | Flag signal: none |       |                                              |

- S₁: data source device 1. S₂: data source device 2.
- This command compares the contents of S₁ and S₂. Taking "FAND=" as an example, if the result of comparison is "equal", this command activates; but it does not activate when the result is "unequal".
- The FAND\* command can directly input floating point numbers (for instance: F1.2) to the S₁ and S₂ operands, or store the floating point numbers in register D for use in operations.
- You can use this command directly to connect with the busbar.

| API No. | 32-bit commands | Conditions for activation       | Conditions for inactivation     |
|---------|-----------------|---------------------------------|---------------------------------|
| 281     | FAND =          | $S_1 = S_2$                     | S <sub>1</sub> ≠ S <sub>2</sub> |
| 282     | FAND >          | $S_1 > S_2$                     | $S_1 \leq S_2$                  |
| 283     | FAND <          | S <sub>1</sub> < S <sub>2</sub> | $S_1 \ge S_2$                   |
| 284     | FAND <>         | S <sub>1</sub> ≠ S <sub>2</sub> | $S_1 = S_2$                     |
| 285     | FAND <=         | $S_1 \leq S_2$                  | S <sub>1</sub> > S <sub>2</sub> |
| 286     | FAND > =        | $S_1 \ge S_2$                   | S <sub>1</sub> < S <sub>2</sub> |

Example

When X1=OFF, and the floating point number in register D100 (D101) is not equal to F1.2, then Y21=ON and remains in that state.

```
X1 FAND<> F1.2 D0 SET Y21
```

| 287<br>292 | _     | F      | OR)    | * |         | (                  | <u>S1</u> ) | (S2)            |        | FI    | oatin  | g point number contact form compare OR* |
|------------|-------|--------|--------|---|---------|--------------------|-------------|-----------------|--------|-------|--------|-----------------------------------------|
|            | bit   | dev    | ice    |   |         | ٧                  | Vord        | devic           | e      |       |        | 16-bit command                          |
|            | Х     | Υ      | М      | K | Н       | KnX                | KnY         | KnM             | Т      | С     | D      | ]: - : - : - : - :                      |
| S1         |       |        |        |   |         |                    |             |                 | *      | *     | *      |                                         |
| S2         |       |        |        |   |         |                    |             |                 | *      | *     | *      | 32-bit command (9 STEP)                 |
| Ref        | er to | the fu | ınctio |   | cificat | , =, >,<br>ions ta |             | ≤, ≥<br>or each | n devi | ce in | series | FOR Continuous                          |

- S<sub>1</sub>: data source device 1. S<sub>2</sub>: data source device 2.
- This command compares the contents of S₁ and S₂. Taking "FOR=" as an example, if the result of comparison is "equal", this command activates; but it does not activate when the result is "unequal".
- The FOR\* command can directly input floating point numbers (for instance: F1.2) to the S₁, S₂ operands, or store floating point numbers in register D for use in operations.
- You can use this command directly to connect with the busbar.

| API No. | 32-bit commands | Conditions for activation       | Conditions for inactivation     |
|---------|-----------------|---------------------------------|---------------------------------|
| 287     | FOR =           | $S_1 = S_2$                     | S <sub>1</sub> ≠ S <sub>2</sub> |
| 288     | FOR >           | $S_1 > S_2$                     | $S_1 \leq S_2$                  |
| 289     | FOR <           | S <sub>1</sub> < S <sub>2</sub> | $S_1 \ge S_2$                   |
| 290     | FOR <>          | S <sub>1</sub> ≠ S <sub>2</sub> | $S_1 = S_2$                     |
| 291     | FOR <=          | $S_1 \leq S_2$                  | S <sub>1</sub> > S <sub>2</sub> |
| 292     | FOR > =         | $S_1 \ge S_2$                   | S <sub>1</sub> < S <sub>2</sub> |

Example

When X2 and M30 are both equal to ON, or the floating point number in register D100 (D101) is greater than or equal to F1.234, then M60=ON.

## 16-6-5 Detailed explanation of drive special application commands

| AP 13 |       |      |       |       |      |     | <u>S1</u> ) ( | <u>S2</u> |   | Re | Read servo parameter |                                    |  |  |
|-------|-------|------|-------|-------|------|-----|---------------|-----------|---|----|----------------------|------------------------------------|--|--|
|       | bit   | dev  | ice   |       |      | ٧   | Vord          | devic     | e |    |                      | 16-bit command (5 STEP)            |  |  |
|       | Х     | Υ    | М     | K     | Н    | KnX | KnY           | KnM       | Т | С  | D                    | RPR Continuous RPRP Pulse          |  |  |
| S1    |       |      |       | *     | *    |     |               |           |   |    | *                    | execution type RPRP execution type |  |  |
| S2    |       |      |       |       |      |     |               |           |   |    | *                    | ,,                                 |  |  |
| Note  | es on | oper | and u | sage: | none |     |               |           |   |    |                      | 32-bit command_                    |  |  |
|       | , ,   |      |       |       |      |     |               |           |   |    |                      | <u> </u>                           |  |  |
|       |       |      |       |       |      |     |               |           |   |    |                      | Flag signal: none                  |  |  |

Explanation

**S**<sub>1</sub>: Parameter address of data to be read. **S**<sub>2</sub>: Register where data that is read is stored.

| API 140 WPR P S1 S2 Write servo parameter |                                                |         |   |   |   | servo parameter |       |       |               |   |   |                                       |
|-------------------------------------------|------------------------------------------------|---------|---|---|---|-----------------|-------|-------|---------------|---|---|---------------------------------------|
|                                           | bi                                             | t devic | e |   |   | W               | ord o | devic | е             |   |   | 16-bit command (5 STEP)               |
|                                           | Χ                                              | Y       | M | K | Н | KnX             | KnY   | KnM   | Т             | С | D | WPR Continuous WPRP Pulse             |
| S1                                        |                                                |         |   | * | * |                 |       |       |               |   | * | execution type: WPRP execution type   |
| S2                                        |                                                |         |   | * | * |                 |       |       |               |   | * | :32-bit command                       |
| Notes                                     | Notes on operand usage: none                   |         |   |   |   |                 |       |       | : - : - : - : |   |   |                                       |
|                                           | Flag signal: M1016 parameter read/write error, |         |   |   |   |                 |       |       |               |   |   |                                       |
|                                           |                                                |         |   |   |   |                 |       |       |               |   |   | M1017 parameter written successfully. |

Explanation

- **S**<sub>1</sub>: Data to write to specified page. **S**<sub>2</sub>: Parameter address of data to be written.
- When the data in the MS300 drive's parameter H01.00 is read and written to D0, data from H01.01 is read and written to D1.
- When M0=ON, the content of D10 is written to the MS300 drive Pr.04.00 (first speed of multiple speed levels).
- When M1017=ON, the parameter has been written successfully.
- The MS300's WPR command does not support writing to the 20XX address, but the RPR command supports reading of 21XX, 22XX, 61XX.

Recommendation: Be cautious when using the WPR command. When writing parameters, most parameters are recorded when they are written, and these parameters may only be revised 106 times: a memory write error may occur if parameters are written more than (MS)10<sup>6</sup> or (MH)10<sup>9</sup> times.

> The following commonly-used parameters have special treatment, so there are no limits for the number of times that they can be written.

Pr.00-10: Control method

Pr.00-11: Speed mode selection

Pr.00-27: User-defined value

Pr.01-12: Acceleration time 1

Pr.01-13: Deceleration time 1

Pr.01-14: Acceleration time 2

Pr.01-15: Deceleration time 2

Pr.01-16: Acceleration time 3

Pr.01-17: Deceleration time 3

Pr.01-18: Acceleration time 4

Pr.01-19: Deceleration time 4

Pr.02-12: Select MI Conversion Time mode

Pr.02-18: Select MO Conversion Time mode

Pr.04-50-Pr.04-69: PLC register parameter 0-19

Pr.08-04: Upper limit of integral control


Pr.08-05: PID output upper limit

Pr.10-17: Electronic gear A

Pr.10-18: Electronic gear B

Pr.11-34: Torque command


The number of times a parameter is written is based on whether the written value is modified. For instance, writing the same value 100 times at the same time counts as writing only once. When writing a PLC program, if you are not sure the usage of the WPR command, it is recommended that you use the WPRP command.



- S<sub>1</sub>: PID reference target value input terminal selection. S<sub>2</sub>: PID function proportional gain P. S<sub>3</sub>: PID function integral time I. S<sub>4</sub>: PID function differential time D.
- The FPID command can directly control the drive's PID feedback control Pr.08-00 Terminal Selection of PID Feedback, Pr.08-01 Proportional Gain (P), Pr.08-02 Integral Time (I), and Pr.08-03 Differential Time (D).

- When M0=ON, the set PID reference target value input terminal selection is 0 (no PID function), the PID function proportional gain P is 0, the PID function integral time I is 1 (units: 0.01 sec.), and the PID function differential time D is 1 (units: 0.01 sec.).
- When M1=ON, the set PID reference target value input terminal selection is 0 (no PID function), the PID function proportional gain P is 1 (units: 0.01), the PID function integral time I is 0, and the PID function differential time D is 0.
- When M2=ON, the set PID reference target value input terminal selection is 1 (target frequency input is controlled through the digital keypad), the PID function proportional gain P is 1 (units: 0.01), the PID function integral time I is 0, and the PID function differential time D is 0.
- D1027: Frequency command after PID operation.

```
M0
 FPID
 H0
 H0
 H1
 H1
 M1
 FPID
 H0
 H₀
 ┨┠
 H1
 H₀
 M2
 FPID
 H1
 H1
 H0
 H₀
M1000
 D1027
 ┨┠
 MOV
 D1
 END
```



- S<sub>1</sub>: Frequency command. S<sub>2</sub>: Acceleration time. S<sub>3</sub>: Deceleration time
- **S**<sub>2</sub>,S3: In the acceleration and deceleration time settings, the number of decimal places is determined by the definition in Pr.01-45.

#### Example

Pr.01-45=0).

When Pr.01-45=0: units of 0.01 sec.

A setting of  $S_2$ =50 (acceleration time) in the ladder diagram below implies 0.5 sec., and the  $S_3$  (deceleration time) setting of 60 implies 0.6 sec..

■ The FREQ command can control drive Frequency commands, and acceleration and deceleration time. It also uses special register control actions, such as:

M1025: Control drive RUN(ON)/STOP(OFF) (RUN requires Servo On (M1040 ON) to be effective)

M1026: Control drive operating direction FWD(OFF)/REV(ON)

M1040: Control Servo On/Servo Off.


M1042: Trigger Quick Stop (ON)/does not trigger Quick Stop (OFF).

M1044: Pause (ON)/release pause (OFF)

M1052: Lock frequency (ON)/release lock frequency (OFF)

Example

- M1025: Drive RUN (ON)/STOP (OFF), M1026: drive operating direction FWD(OFF)/REV(ON). M1015: frequency reached.
- When M10=ON, sets the drive frequency command K300 (3.00 Hz) with an acceleration and deceleration time of 0.
  When M11=ON, sets the drive frequency command K3000 (30.00 Hz), with an acceleration time of 50 (0.5 sec.) and deceleration time of 60 (0.6 sec.) (when
- When M11=OFF, the drive frequency command changes to 30 Hz.



■ Pr.09-33 are defined on the basis of whether reference commands have been cleared before the PLC operation

- bit 0: Prior to PLC scanning procedures, acts on whether the target frequency has been cleared to 0. This is written to the FREQ command when the PLC is ON.
- bit 1: Prior to PLC scanning procedures, acts on whether the target torque has been cleared to 0. This is written to the TORQ command when the PLC is ON.
- bit 2: Prior to PLC scanning procedures, acts on whether speed limits in the torque mode have been cleared to 0. This is written to the TORQ command when the PLC is ON.

Example: When using r to write a program,

```
FREQ K2000 K1000 K1000 END
```

If we force M0 to 1, the frequency command is 20.00 Hz; but when M0 is set to 0, there is a different situation.

- Case 1: When the Pr.09-33 bit 0 is 0, and M0 is set as 0, then the frequency command remains at 20.00 Hz.
- Case 2: When the Pr.09-33 bit 0 is 1, and M0 is set as 0, then the frequency command changes to 0.00 Hz

This is because when the Pr.09-33 bit 0 is 1 prior to PLC scanning procedures, the frequency first reverts to 0.

When the Pr.09-33 bit 0 is 0, the frequency does not revert to 0.

## 16-7 Error Display and Handling

| Code | ID | Description                                                                                                                                                                  | Recommended error resolution                                                                                                                                                  |
|------|----|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PLod | 50 | The addresses in program exceed the range during PLC downloading. For example, T only supports T0–T159, however, if you use T160, PLod warning shows during PLC downloading. | Check whether the program has an error, correct it and download the program again.                                                                                            |
| PLSv | 51 | The program detects incorrect written address during PLC operation, then PLSv warning occurs.                                                                                | Check if the program is correct and download the program again.                                                                                                               |
| PLdA | 52 | The program detects incorrect read/written address from Modbus during PLC operation, then PLdA warning occurs.                                                               | Check if the command that the host controller transmits is correct.                                                                                                           |
| PLFn | 53 | When unsupported commands are found during PLC downloading, then PLFn warning shows.                                                                                         | Check if the firmware of the drive is the old version. If yes, please contact Delta.                                                                                          |
| PLor | 54 | When internal program code errors are detected during PLC operation, then PLor warning shows.                                                                                | <ol> <li>Disable PLC function</li> <li>Clear PLC program (set Pr.00-02 = 6)</li> <li>Enable PLC function</li> <li>Download PLC program again</li> </ol>                       |
| PLFF | 55 | When the corresponding command that PLC executes is unreasonable during PLC operation, then PLFF warning shows.                                                              | When PLC function is enabled and there is no program in the internal PLC program, then PLFF warning shows. This is a normal situation. You can download the program directly. |
| PLSn | 56 | operation.                                                                                                                                                                   | <ol> <li>Disable PLC function</li> <li>Clear PLC program (set Pr.00-02 = 6)</li> <li>Enable PLC function</li> <li>Download PLC program again</li> </ol>                       |
| PLEd | 57 | No END command during PLC operation.                                                                                                                                         | <ol> <li>Disable PLC function</li> <li>Clear PLC program (set Pr.00-02 = 6)</li> <li>Enable PLC function</li> <li>Download PLC program again</li> </ol>                       |
| PLCr | 58 | MC command has been used continuously more than nine times.                                                                                                                  | Cannot continuously use MC command more than nine times. Check whether the program has an error and download the program again.                                               |
| PLdF | 59 | Forced to stop during PLC downloading and causes incomplete writing.                                                                                                         | Check whether the program has an error and download again.                                                                                                                    |
| PLSF | 60 | PLC scan time excessively long                                                                                                                                               | Check whether the program code has a writing error and download again.                                                                                                        |

<sup>\*</sup>ID: Warning code

## 16-8 Explanation of PLC Speed Mode Control

The following tables describe the control mode and setting. These are the register tables for speed mode.

## Control special M

| Special<br>M | Function Description                                                       | Attributes |
|--------------|----------------------------------------------------------------------------|------------|
| M1025        | Drive frequency = set frequency (ON) / drive frequency = 0 (OFF)           | RW         |
| M1026        | Drive operating direction FWD (OFF) / REV (ON)                             | RW         |
| M1040        | Hardware power (Servo On)                                                  | RW         |
| M1042        | Quick Stop                                                                 | RW         |
| M1044        | Pause (Halt)                                                               | RW         |
| M1052        | Lock frequency (lock, frequency locked at the current operating frequency) | RW         |

#### Status special M

| Special<br>M | Function Description                        | Attributes |
|--------------|---------------------------------------------|------------|
| M1015        | Frequency reached (when used with M1025)    | RO         |
| M1056        | Hardware already has power (Servo On Ready) | RO         |
| M1058        | On Quick Stopping                           | RO         |

## Control special D

| Special<br>D | Function Description           | Attributes |
|--------------|--------------------------------|------------|
| D1060        | Mode setting (speed mode is 0) | RW         |

#### Status special D

| Special<br>D | Function Description                    | Attributes |
|--------------|-----------------------------------------|------------|
| D1037        | Drive output frequency (0.00–599.00 Hz) | RO         |
| D1050        | Actual operation mode (speed mode is 0) | RO         |

## Speed mode control commands:

**FREQ(P)** S1 S2 S3


Target speed The first acceleration time setting The first deceleration time setting

Example of speed mode control:

Before using speed control, if you use the FOC (magnetic field orientation) control method, you must first complete the setting of the electro-mechanical parameters.

- 1. Setting D1060 = 0 shifts the drive to speed mode (default).
- 2. Use the FREQ command to control frequency, acceleration time, and deceleration time.
- 3. Setting M1040 = 1, the drive is now excited, but the frequency is 0.
- 4. Setting M1025 = 1, the drive Frequency command now jumps to the frequency designated by FREQ, and acceleration and deceleration is controlled on the basis of the acceleration time and deceleration time specified by FREQ.
- 5. Use M1052 to lock the current operation frequency.


- 6. Use M1044 to temporarily pause the operation, and the deceleration method uses the deceleration settings.
- 7. Use M1042 to perform Quick Stop, and deceleration is as fast as possible without causing an error. There may still be a jump error if the load is too large.
- 8. Control user rights: M1040 (Servo ON) > M1042 (Quick Stop) > M1044 (Halt) > M1052 (LOCK)



## 16-9 Count Function Using Pulse Input

## 16-9-1 High-speed count function

The MS300's MI7 supports one-way pulse counting with a maximum speed of 33 k. The starting method is very simple, and only requires setting M1038 to begin counting. The 32-bit count value is stored in D1054 and D1055 in non-numerical form. M1039 resets the count value to 0.



When the PLC program defines MI7 for use as a high-speed counter, that is, when M1038 or M1039 is written in PLC procedures, other functions of MI7 are disabled.

## 16-9-2 Frequency calculation function

Apart from high-speed counting, the MS300's MI7 can also convert a received pulse to a frequency. The following figure shows that there is no conflict between frequency conversion and count calculations, which the MS300 can perform simultaneously.

PLC speed calculation formula

D1057 Speed

D1058 Interval between calculations

D1059 Decimal places

Assume that there are five input pulses each second, (see figure below) we set D1058 = 1000 ms = 1.0 second as the calculation interval. This enables five pulses to be sent to the drive each second.



Assume that each five pulses correspond to 1 Hz, we set D1057 = 5.

Setting D1059 = 2 displays numbers to two decimal places, which is also 1.00 Hz. The numerical value displayed at D1056 is 100. For simplicity, the D1059 conversion formula can be expressed in the following formula:

D1058= 
$$\frac{\text{Pulses per second}}{\text{D1057}} \times \frac{1000}{\text{D1057}} \times 10^{\text{D1059}}$$

## Chapter 16 PLC Function Applications | MS300

[This page intentionally left blank]

# Chapter 17 Safe Torque Off Function

| 17-1 | Basic | <b>Function</b> | Descri | ption |
|------|-------|-----------------|--------|-------|
|------|-------|-----------------|--------|-------|

- 17-2 Safe Torque Off Terminal Function Description
- 17-3 Wiring Diagram
- 17-4 Failure Rate of the Drive Safety Function
- 17-5 Reset the Parameter Settings
- 17-6 Timing Diagram Description
- 17-7 Error Code and Troubleshooting Instructions
- 17-8 Test and Fault Confirmation

## 17-1 Basic Function Description

The MS300 series provides a Safe Torque Off (STO) function. The MS300 series uses dual-channel S1 and S2 signal inputs to turn off IGBT switching, further preventing the generation of motor torque in order to achieve a safe stop. Refer to Figure 17-1 for the Safe Torque Off function circuit diagram.

The MS300 Safe Torque Off function meets the following international standards:

ISO 13849-1: 2015 Category 3 PL d

IEC 61508 SIL2

EN 62061 SIL CL 2

EN 60204-1 Category 0




Figure 17-1: The circuit diagram for the Safe Torque Off function

## 17-2 Safe Torque Off Terminal Function Description

Table 17-1 describes the STO (Safe Torque Off) related terminal functions.

| Terminals | Terminal Function                                                                                      | Descriptions                                                                                                                                                                                           |
|-----------|--------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| +24 V     | When the STO function is not used, you can disable the STO function by shorting S1 and S2 with + 24 V. | Output voltage range: +24 V ± 10% Output voltage capacity: 100 mA                                                                                                                                      |
| S1        | Signal input for STO function channel 1                                                                | S1-DCM / S2-DCM  Rated input voltage: +24 V <sub>DC</sub> ± 10%;  maximum input voltage: +30 V <sub>DC</sub> ± 10%                                                                                     |
| S2        | Signal input for STO function channel 2                                                                | Rated input current: 6.67 mA ± 10%  STO activation mode  Input voltage level: 0 V <sub>DC</sub> < S1–DCM and S2–DCM < 5 V <sub>DC</sub>                                                                |
| DCM       | Reference ground for S1 and S2 signal                                                                  | STO response time: ≤ 20 ms (time required for S1 / S2 to operate until the drive stops outputting)  STO cut-off mode  Input voltage level: 11 V <sub>DC</sub> < S1–DCM and S2–DCM < 30 V <sub>DC</sub> |

Table 17-1: STO terminal function description

Table 17-2 describes the action logic and keypad display after the S1 / S2 signal input.

| Signal                        | Status             |                                  |                                  |                                 |
|-------------------------------|--------------------|----------------------------------|----------------------------------|---------------------------------|
| S1-DCM                        | ON                 | ON                               | OFF                              | OFF                             |
| S2-DCM                        | ON                 | OFF                              | ON                               | OFF                             |
| Drive output                  | Ready to output    | STL2 mode<br>(Torque output off) | STL1 mode<br>(Torque output off) | STO mode<br>(Torque output off) |
| Error displayed on the keypad | No error displayed | STL2                             | STL1                             | STO                             |

Table 17-2: Action logic and keypad display description

- STO means channel 1 and 2 operate simultaneously and enter Safe Torque Off.
- STL1 means channel 1 operates.
- STL2 means channel 2 operates.
- STL3 means there is an error detected in the internal loop of the channel 1 or channel 2.
- S1-DCM / S2-DCM ON: means S1-DCM / S2-DCM inputs a power supply > 11 V<sub>DC</sub>.
- □ S1–DCM / S2–DCM OFF: means S1–DCM / S2–DCM inputs a power supply < 5 V<sub>DC</sub>.

## 17-3 Wiring Diagram

- 17-3-1. Figure 17-2 shows the internal circuit diagram of the safe control loop.
- 17-3-2. The terminals of the safe control loop + 24V-S1-S2 are short-circuited together with the jumper wire at the factory, as shown in Figure 17-2.
- 17-3-3. The safe control loop wiring diagram is as follows:
  - 1. Remove the jumper wire from +24V-S1-S2.
  - 2. The wiring is shown in Figure 17-3 below. Normally, you must close the ESTOP contact switch, so the drive can output without displaying an error.
  - 3. In STO mode, the switch ESTOP is turned on. The drive stops outputting and the keypad displays STO.




Figure 17-2




Figure 17-3

NOTE

<sup>\*1</sup> is factory jumper wire shorting +24V-S1-S2. To use the Safety function, remove this jumper wire. To disable the Safety function, short-circuit +24V-S1-S2 with a jumper wire.

## 17-4 Failure Rate of the Drive Safety Function


Refer to Table 17-3 for the relevant safe loop parameters.

| Item                                             | Definition                                   | Standard   | Performance             |
|--------------------------------------------------|----------------------------------------------|------------|-------------------------|
| SFF                                              | Safe failure fraction                        | IEC61508   | S1-DCM = 88.35%         |
| SFF                                              | Sale failule fraction                        |            | S2-DCM = 88.2%          |
| HFT                                              | Hardware fault tolerance                     | IEC61508   | 1                       |
| (Type A subsystem)                               | riardware fault tolerance                    | IEC01308   |                         |
| 011                                              |                                              | IEC61508   | SIL 2                   |
| SIL                                              | Safety integrity level                       | IEC62061   | SILCL 2                 |
| PFH                                              | Average frequency of dangerous failure [h-1] | IEC61508   | 1.36 x 10 <sup>-9</sup> |
| Probability of dangerous failure on demand       |                                              | IEC61508   | 5.99 x 10 <sup>-6</sup> |
| PTI                                              | PTI Proof test interval                      |            | 1 year                  |
| Category                                         | Category                                     | ISO13849-1 | Category 3              |
| PL Performance level                             |                                              | ISO13849-1 | d                       |
| MTTF <sub>d</sub> Mean time to dangerous failure |                                              | ISO13849-1 | High                    |
| DC Diagnostic coverage                           |                                              | ISO13849-1 | Low                     |

Table 17-3: Relevant safe loop parameters

## 17-5 Reset the Parameter Settings

Use Pr.06-44 to specify the reset method when an STO alarm occurs.



- Pr.06-44=0: STO Alarm Latch. After you clear the cause of the STO Alarm, use a Reset command to clear the STO Alarm..
- Pr.06-44=1: STO Alarm no Latch. After you clear the cause of the STO Alarm, the STO Alarm clears automatically.
- All of STL1–STL3 errors are "Alarm Latch" mode (in STL1–STL3 mode, the Pr.06-44 function is not available).

## 17-6 Timing Diagram Description

The following timing diagrams show the status of relevant signals under different conditions.

## 17-6-1 Normal operation status

As shown in Figure 17-4, when S1–DCM and S2–DCM is ON (STO function is not required), the drive executes Operating or Output Stop according to RUN command.




Figure 17-4

## 17-6-2-1 STO, Pr.06-44=0, Pr.02-35=0

## (external operation control selection after reset / reboot, 0=disable)

As shown in Figure 17-5, when both S1–DCM and S2–DCM are OFF during operation (STO function is required), the drive stops outputting when it enters safe mode regardless of whether the RUN command is in ON or OFF status.




Figure 17-5

## 17-6-2-2 STO, Pr.06-44=0, Pr.02-35=1

# (external operation control selection after reset / reboot, 1= drive runs if the RUN command remains after reset or reboot)

As shown in Figure 17-6, the action is the same as in Figure 17-5; however, because Pr.02-35=1, if the RUN command remains after reset, the drive immediately executes the RUN command again.




Figure 17-6

## 17-6-3 STO, Pr.06-44=1

As shown in Figure 17-7, when both of S1–DCM and S2–DCM are OFF during operation (STO function is required), the drive stops outputting. When the S1 / S2 status is restored (ON), the STO alarm clears automatically. The drive outputs when the RUN command is executed again.




Figure 17-7

#### 17-6-4 STL1, Pr.06-44=0 or 1

As shown in Figure 17-8, when S1–DCM is OFF during operation (STO function is required) and S2–DCM is ON (STO function is not required), the drive stops outputting and the keypad shows the STL1 error. However, you cannot reset the STL1 error even if the S1 status is restored (ON) regardless of the parameter setting. You must cycle the power to reset and to restore the drive to the normal standby state.




Figure 17-8

#### 17-6-5 STL2, Pr.06-44=0 or 1

As shown in Figure 17-9, when S1–DCM is ON during operation (STO function is not required) and S2–DCM is OFF (STO function is required), the drive stops outputting and the keypad shows the STL2 error. However, you cannot reset the STL2 error even if the S2 status is restored (ON) regardless of the parameter setting. You must cycle the power to reset and to restore the drive to the normal standby state.




Figure 17-9

## 17-7 Error Code and Troubleshooting Instructions

## 17-7-1 Error Code Description

Refer to Pr.06-17–Pr.06-22 for the fault record; the relevant STO error codes are 72/76/77/78.

The definition is described in Table 17-4 below.

| ## Fault Record 1 |
|-------------------|
| ## Fault Record 2 |
| ## Fault Record 3 |
| ## Fault Record 4 |
| ## Fault Record 5 |
| ## Fault Record 6 |

## Settings

72: STO Loss 1 (STL1)

76: STO (STo)

77: STO Loss 2 (STL2)

78: STO Loss 3 (STL3)

| Error code   | Name            | Description                                           |  |
|--------------|-----------------|-------------------------------------------------------|--|
| 72<br>(STL1) | STO Loss 1      | STO1–SCM1 internal loop detection error               |  |
| 76<br>(STO)  | Safe Torque Off | Safe Torque Off function active                       |  |
| 77<br>(STL2) | STO Loss 2      | STO2–SCM2 internal loop detection error               |  |
| 78<br>(STL3) | STO Loss 3      | STO1–SCM1 and STO2–SCM2 internal loop detection error |  |

Table 17-4: Error code description

## 17-7-2 Troubleshooting Instructions

Refer to the following instructions for troubleshooting in Table 17-5 when STO / STL1 / STL2 / STL3 appear on the keypad (refer to Chapter 14 Fault Codes for details).

|        | KPMS-LE01      |                                                                                   |
|--------|----------------|-----------------------------------------------------------------------------------|
| ID No. | Keypad Display | Descriptions                                                                      |
|        |                | STO1–SCM1 internal loop detection error                                           |
|        |                | Cause and Corrective Actions                                                      |
|        |                | ■ STO1 and SCM1 short circuit lines are not connected                             |
|        |                | → Re-connect the short circuit line.                                              |
|        |                | ■ Hardware failure                                                                |
|        |                | → After you make sure all the wiring is correct, if STL1 fault still exists after |
| 72     | SFLI           | cycling the power, return to the factory for repair.                              |
|        | 2001 (1995)    | ■ Poor connection of the IO card                                                  |
|        |                | → Check if the PIN of the IO card is broken.                                      |
|        |                | → Check if the IO card connects to the control board correctly, and if the        |
|        |                | screws are tightened well.                                                        |
|        |                | ■ The IO card does not match the version of the control board                     |
|        |                | → Contact local agent or Delta.                                                   |
|        |                | Safe Torque Off function active                                                   |
|        |                | Cause and Corrective Actions                                                      |
|        |                | ■ The switch action of STO1/SCM1 and STO2/SCM2 (OPEN)                             |
|        |                | → Reset the switch (ON) and cycle the power.                                      |
| 76     | Sfo            | ■ Poor connection of the IO card                                                  |
| 10     | 510            | → Check if the PIN of the IO card is broken.                                      |
|        |                | → Check if the IO card connects to the control board correctly, and if the        |
|        |                | screws are tightened well.                                                        |
|        |                | ■ The IO card does not match the version of the control board.                    |
|        |                | → Contact local agent or Delta.                                                   |
|        |                | STO2–SCM2 internal loop detection error.                                          |
|        |                | Cause and Corrective Actions                                                      |
|        |                | ■ STO2 and SCM2 short circuit lines are not connected                             |
|        |                | → Re-connect the short circuit line.                                              |
|        |                | ■ Hardware failure                                                                |
|        | 6613           | → After you make sure all the wiring is correct, if STL2 fault still exists after |
| 77     | SFL2           | cycling the power, return to the factory for repair.                              |
|        |                | ■ Poor connection of the IO card                                                  |
|        |                | → Check if the PIN of the IO card is broken.                                      |
|        |                | → Check if the IO card connects to the control board correctly, and if the        |
|        |                | screws are tightened well.                                                        |
|        |                | The IO card does not match the version of the control board                       |
|        |                | Contact local agent or Delta.                                                     |
|        | SFL3           | STO1–SCM1 and STO2–SCM2 internal loop detection error.                            |
|        |                | Cause and Corrective Actions                                                      |
| 78     |                | ■ STO1 and SCM1, or STO2 and SCM2 short circuit lines are not connected           |
|        |                | Re-connect the short circuit line.                                                |
|        |                | Hardware failure                                                                  |
|        |                | → After you make sure all the wiring is correct, if STL3 fault still exists after |
|        |                | cycling the power, return to the factory for repair.                              |
| 1      |                | Poor connection of the IO card                                                    |
|        |                | → Check if the PIN of the IO card is broken.                                      |
|        |                | Check if the IO card connects to the control board correctly, and if the          |
|        |                | screws are tightened well.                                                        |
|        |                | The IO card does not match the version of the control board                       |
|        |                | → Contact local agent or Delta.                                                   |

Table 17-5 KPMS-LE01 Instrucstions for Troubleshooting

## 17-8 Test and Fault Confirmation

After wiring the STO circuit in accordance with Section 17-3 Wiring Diagram, follow the steps below to verify that the STO and related detection functions work normally.

- When the drive is powered on, make sure that the S1-DCM and S2-DCM voltage falls between 11-30 V<sub>DC</sub>. At this time, the drive should enter Standby mode and wait for RUN command. There is no error displayed on the keypad.
- 2. Press RUN on the keypad and use the emergency button or other method to make the S1–DCM and S2–DCM voltage fall between 0–5 V<sub>DC</sub>. At the same time, after the output frequency is reached, the drive should enter Torque Stop mode STO and stop outputting voltage. The keypad displays the STO error, and the response time of the S1 and S2 signals to cause the drive to stop outputting voltage should be ≤ 20 ms. Then restore the S1–DCM and S2–DCM voltage to 11–30 V<sub>DC</sub>, and press RESET button on the keypad to clear the STO error. The drive should enter Standby mode and wait for RUN command.
- 3. Press RUN on the keypad and use the emergency button or other method to make the S1–DCM voltage fall between 0–5  $V_{DC}$ , and the S2–DCM voltage remain between 11–30  $V_{DC}$  after the output frequency is reached. At this time, the drive should enter Torque Stop mode STL1 and stop outputting voltage. The keypad displays the STL1 error, and the response time of S1 signals to cause the drive to stop outputting voltage should be  $\leq$  20 ms. Then restore the S1–DCM voltage to 11–30  $V_{DC}$ . However, pressing RESET button on the keypad cannot clear the STL1 error. You must cycle the power to the drive. Make sure that the S1–DCM and S2–DCM voltage falls between 11–30  $V_{DC}$  and then cycle the power to the drive, then the STL1 error is cleared. The drive should enter Standby mode and wait for RUN command.
- 4. Press RUN on the keypad and use the emergency button or other method to make the S2–DCM voltage fall between 0–5  $V_{DC}$ , and the S1–DCM voltage remain between 11–30  $V_{DC}$  after the output frequency is reached. At this time, the drive should enter Torque Stop mode STL2 and stop outputting voltage. The keypad displays the STL2 error, and the response time of the S2 signals to cause the drive to stop outputting voltage should be  $\leq$  20 ms. Then restore the S2–DCM voltage to 11–30  $V_{DC}$ . However, pressing RESET button on the keypad cannot clear the STL2 error. You must cycle the power to the drive. Make sure that the S1–DCM and S2–DCM voltage falls between 11–30  $V_{DC}$  and then cycle the power to the drive, then the STL2 error is cleared. The drive should enter Standby mode and wait for RUN command.
- 5. If you can conduct these four steps normally in sequence with no other error, then the Safe Torque Off function loop is normal, as shown in Table 17-6 below. However, if a situation that differs from these four steps, or if STL3 occurs, then the Safe Torque Off function loop does not work normally. Refer to Section 17-7 Error Code and Troubleshooting Instructions for details.

#### Chapter 17 Safe Torque Off Function | MS300

| Signal                        | Status             |                          |                          |                      |
|-------------------------------|--------------------|--------------------------|--------------------------|----------------------|
| S1-DCM                        | ON                 | ON                       | OFF                      | OFF                  |
| S2-DCM                        | ON                 | OFF                      | ON                       | OFF                  |
| Duite control                 | Ready to output    | STL2 mode                | STL1 mode                | STO mode             |
| Drive output                  |                    | (Torque output off)      | (Torque output off)      | (Torque output off)  |
| Error displayed on the keypad | No error displayed | STL2                     | STL1                     | STO                  |
| Response time                 | N/A                | ≤ 20 ms                  |                          |                      |
| RESET mechanism               | N/A                | Cycle power to the drive | Cycle power to the drive | Press RESET directly |

Table 17-6: Action logic and keypad display description

- STO means channel 1 and 2 operate simultaneously and enter Safe Torque Off.
- STL1 means channel 1 operates.
- STL2 means channel 2 operates.
- STL3 means there is an error detected in the internal loop of the channel 1 or channel 2.
- S1-DCM / S2-DCM ON: means S1-DCM / S2-DCM inputs a power supply > 11 V<sub>DC</sub>.
- S1–DCM / S2–DCM OFF: means S1–DCM / S2–DCM inputs a power supply < 5 V<sub>DC</sub>.

## Appendix A. Revision History

| New and Updated information                                               |                        |  |  |
|---------------------------------------------------------------------------|------------------------|--|--|
| Description                                                               | Related part           |  |  |
| Add the content of MS300 3kW models to this manual.                       | Chapter 2, 3, 5, 7, 9, |  |  |
| Add the content of MS500 5kW models to this manual.                       | 11, and 12             |  |  |
| Update ambient temperature derating for each installation method          | Chpater 3              |  |  |
| Update contact input terminals – SINK/SOURCE diagram                      | Chpater 6              |  |  |
| Update section 7-6 EMC Filter and 7-11 Keypad Panel Mounting.             | Ob autou 7             |  |  |
| Change section 7-9 title Conduit Box to NEMA 1 / UL Type 1 Kit            | Chapter 7              |  |  |
| Update section 9-7 Derating for Ambient Temperature, Altitude and Carrier | Oharatan O             |  |  |
| Frequency.                                                                | Chpater 9              |  |  |
| Add parameters.                                                           |                        |  |  |
| Parameter group 00: 00-47                                                 |                        |  |  |
| Update desciptions of the following parameters.                           |                        |  |  |
| Parameter group 00: 00-00, 00-01, 00-10                                   |                        |  |  |
| Parameter group 02: 02-09, 02-10                                          | Chapter 11,            |  |  |
| Parameter group 03: 03-29                                                 | Section 12-1           |  |  |
| Parameter group 06: 06-01, 06-17-06-22, 06-30, 06-80                      |                        |  |  |
| Parameter group 07: 07-03                                                 |                        |  |  |
| Parameter group 08: 08-06, 08-18                                          |                        |  |  |
| Parameter group 09: 09-30                                                 |                        |  |  |